

DESCRIPTION:	12M Zone 1 Lubrication and Service	FREQUENCY:	12 Months
LOCATION:	ST41 Goodna Sewerage Treatment Plant	STANDARD JOB No.:	LTS327

Tools & Equipment
Spare Parts/Materials List
Castrol SP220 Oil
Castrol Hyspin AWH46
Castrol EPL2 Grease
Reference
Maintenance Group
Grit Classifier and Conveyor
Grit Pump
Wash Presses
PTA Penstocks
Air Treatment Facility
Procedural Steps:
*Before isolating any equipment where possible observe in running condition. Check for correct operation.
Grit Classifier and Conveyor
Check classifier for noise, leaks, vibration.
Check conveyor for noise, leaks, vibration.
Check classifier drive gearbox for oil leaks.
Check conveyor drive gearbox for oil leaks.
Check valve actuator and airlines for leaks and defects.
Isolate Classifier and Grit Conveyor
Open the inspection hatch on the sedimentation tank.
Check baffle plate in the sedimentation tank for entanglement and coarse substances.
Ensure that the discharge pipe and overflow edge are free from obstruction.

Doc Id:FOR722Active Date:01/07/2017Revision: 3OwnerMatthew DellawayPrinted:Page 1 of 3

Note: Printed copies of this document should be verified for currency against the published electronic copy.



DESCRIPTION:	12M Zone 1 Lubrication and Service	FREQUENCY:	12 Months
LOCATION:	ST41 Goodna Sewerage Treatment Plant	STANDARD JOB No.:	LTS327

Drain sedimentation chamber.	
Check stirring unit for deformations and blockages.	
Clear blockages if any.	
Orain classifier drive gearbox oil and refill with SP220.	
Check classifier drive gearbox breather and clear any obstructions.	
Grease classifier drive gearbox stuffing box with AP3 grease.	
Check classifier structure for loose bolts, defects.	
Check access platform for loose bolts, defects.	
Check pipe work and valving for leaks and defects.	
Orain conveyor drive gearbox oil and refill with SP220.	
Check conveyor drive gearbox breather and clear any obstructions.	
Check conveyor structure for loose bolts, defects.	
Clean feed water rotameter.	
Bring Classifier and Grit Conveyor back online.	
Grit Pump	
Check pump for noise, leaks, vibration.	
Check pump bearing housing for oil leaks.	
Drain pump bearing housing and refill with Castrol Hyspin AWH46.	
Check condition of couplings and rubbers	
Check pipe work and valving for leaks, defects.	
Check pumps assembly for loose bolts, defects.	
Clean flushing water rotameter.	
Grease suction, delivery and bypass valve spindles via grease nipp	les with EPL2.
Grease grit chamber valves adjacent to grit pump area via grease n	nipples with EPL2.
Wash Press 1	
Check wash press for noise, leaks, vibration.	
Check wash press drive gearbox for oil leaks.	
Orain wash press drive gearbox oil and refill with SP220.	
Check conveyor bearing auto greasing canister.	
Check wash press structure for loose bolts, defects.	
Check the conveyor cleaning brush, liner and screw for wear.	da Is m als
<ul> <li>Isolate wash press and drain feeder box. Open top cover to</li> <li>Open cover on discharge end to view conveyor screw and I</li> </ul>	
<ul> <li>Check screw diameter and liner thickness.</li> </ul>	iii içi.

Doc Id:FOR722Active Date:01/07/2017Revision: 3OwnerMatthew DellawayPrinted:Page 2 of 3

Note: Printed copies of this document should be verified for currency against the published electronic copy.



DESCRIPTION:	12M Zone 1 Lubrication and Service	FREQUENCY:	12 Months
LOCATION:	ST41 Goodna Sewerage Treatment Plant	STANDARD JOB No.:	LTS327

neck w	ash press for noise, leaks, vibration.
	ash press drive gearbox for oil leaks.
	sh press drive gearbox oil and refill with SP220.
heck co	onveyor bearing auto greasing canister.
heck w	ash press structure for loose bolts, defects.
	e conveyor cleaning brush, liner and screw for wear.
	solate wash press and drain feeder box. Open top cover to view brush.
	Open cover on discharge end to view conveyor screw and liner.
• (	Check screw diameter and liner thickness.
Vash Pr	ress Area
Grease F	PTA drain valves located near Wash Presses via grease nipple with EPL2.
TA Per	nstocks
lean dr	ive shafts and regrease with EPL2 Grease.
nspect f	or wear on drive nuts.
nspect s	eals and other components for wear and damage.
Check bo	olt tension.
	tment Facility (ATF)
	duction fans for noise, vibration.
	I drainage lines for leaks, defects.
	ecirculation Pumps for noise, leaks, vibration.
heck R	ecirculation Pumps pipe work for leaks, defects.
Check po	ump mounting skid for defects and tightness of fasteners.
Check N	utrient pump and pipe work for leaks, defects.

Doc Id:FOR722Active Date:01/07/2017Revision: 3OwnerMatthew DellawayPrinted:Page 3 of 3

Note: Printed copies of this document should be verified for currency against the published electronic copy.