



BRISBANE CITY COUNCIL BRISBANE WATER

Australia Trade Coast Sewer Project

SP298

Lytton Rd No. 4 Pump Station

Operation & Maintenance Manual

Contract No. BW30137-02/03

Volume No. 2

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

<u>Volume</u>	<u>Section</u>	<u>Description</u>	<u>Pages</u>
1	1	Table of Contents	7
		Electronic copy of complete Operation & Maintenance Manual on CD.	
		Hyperlink Files\Title Page Volume 1.doc Hyperlink Files\Title Page Volume 2.doc Hyperlink Files\Title Page Volume 2.1.doc Hyperlink Files\Title Page Volume 3.doc Hyperlink Files\Binder Labels.doc Hyperlink Files\Title Page Volume 4.doc Hyperlink Files\Title Page Volume 5.doc Volume/Title Pages & Binder Labels	
		Hyperlink Files\Revisions Page.xls Revisions	1
	1.1	Introduction and System Overview Lytton Road No.4 P/S SP298	
		Hyperlink Files\OMM SP298 Introduction Description Design and Process RevA.doc Subsection 1	6
		Description of System and Overview Locality Keyplan Subsection 1.1	
		Design and Process Subsection 1.2	
		Pumping System Operation Subsection 1.3	
		Inlet Valve Pit at SP298 No.4 Interconnected Rising Mains Subsection 1.4	
		Interconnected Rising Mains Manual Operated Valves Subsection 1.5	
		Flow Diverted from SP298 No.4 to Gibson Island WWTP Subsection 1.6	
		Pump Station SP298 No.4 Layout Subsection 1.7	
	1.2	Pump Station Equipment Operation	
		Functional Specification SP298 Lytton Rd 4 described in this document are in addition to the standard functionality detailed in SPSV3 57pages. 1.1 General Process Description 2.1 Standard Equipment 2.2 Non Standard Equipment 2.2.3 Actuated Valves 3.1 Normal Operation Figure 3: SP298 Station Level Set Points 3.4 Non Standard Control 3.6 Non Standard IDTS Picture	18
		Hyperlink Files\SPSV3.doc Standard Functional Specification SPSV3	57
2	2	Proprietary Equipment Manuals/Maintenance and Service	
	2.1	Weir Services: Hydrostal Pumps	
		Hyperlink Files\Hydrostal Pump I & O manual Lytton Rd - rev A.doc Including the following	52
		Description of Equipment	
		Operation and Maintenance	
		Maintenance and Service	
		Impeller Clearance Adjustment for Wear	
		Recommended Spare Parts	

Issue Date: 11 OCT 05

Page 1 of 7

Rev: A

G:\CNPMS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

<u>Volume</u>	<u>Section</u>	<u>Description</u>	<u>Pages</u>
		<u>Appropriate Records</u> Pump Declaration of Conformity/ Pump Volute Casing Water Pressure Test/Pump Workshop Test Records Q/H & NPSH etc/	
		<u>Hyperlink Files\wd8159_2 Layout1 (1).pdf</u> Pump General Arrangement Drg	
	2.2	SE Power Equipment: Generator Set	
		<u>Hyperlink Files\Section 1 - Instructions for Use.doc</u> SE Power Equipment: Generator Operation & Maintenance Manuals	4
		<u>Hyperlink Files\Section 2 - John Deere Operation Manual.pdf</u> Diesel Engine Generator Operator's Manual	86
		<u>Hyperlink Files\Section 3 - Stamford Installation, Service & Maintenance Man.pdf</u> AC Generator Installation, Service & Maintenance Manual	44
		<u>Hyperlink Files\Section 4 - Part 1 PLC GE Fanuc.pdf</u> GE Fanuc Automation Series 90TM-30 PLCs	2
		<u>Hyperlink Files\Section 4 - Part 2 PLC GE Fanuc.pdf</u> GE Fanuc Automation Programmable Control Products Series 90TM-30 PLC Installation and Hardware Manual	67
		<u>Hyperlink Files\Section 4 - Part 3 GE Fanuc.pdf</u> GE Fanuc Automation Programmable Control Products Series 90TM-30 Programmable Control Troubleshooting Guide	18
		<u>Hyperlink Files\Section 5 - Functional Description.doc</u> Local Control Panel Functional Description	14
		<u>Hyperlink Files\SE Power Equipment Generator Drg.pdf</u> Diesel Engine/Generator Drg	6
		<u>Hyperlink Files\SE Power Works Test ITP Generator.pdf</u> SE Power Works Test ITP Generator	19
		<u>Hyperlink Files\BW Factory Test Report Generator.doc</u> BW Factory Test Report Generator	12
		Stanby Generator Software (ON DISK)	
	2.3	Cathodic Protection	
		<u>Hyperlink Files\Cathodic Protection System Manual SP298.pdf</u> Cathodic Protection Installation Performed Testing & Maintenance.	15
2.1	2.4	Common Logic: Main Switchboard & Associated Equipment	
		<u>Hyperlink Files\JH42MC01 Lytton Rd.pdf</u> Main Switchboard Manual. Including the following.	12

Issue Date: 11 OCT 05

Page 2 of 7

Rev: A

G:\CNPMS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian
Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

<u>Volume</u>	<u>Section</u>	<u>Description</u>	<u>Pages</u>
		Section 1.0 General Description of Operation	
		Section 2.0 General Description of System (Componenets)	
		Hyperlink Files\Common Logic.pdf Section 3.0 As Construction Drawings. Including Door Key Allocation	13
		Hyperlink Files\Drg Transmittal Common Logic.pdf Section 3.1 Drawing Transmittal	3
		Hyperlink Files\Parts List Common Logic.pdf Section 4.0 Part List	3
		Hyperlink Files\Tech Data Sheets Common Logic.pdf Section 5.0 Technical Manuals and Data Sheets	1
		Hyperlink Files\TDS1804S277.pdf Section 5.0 TDS-DinLine Surge Suppressor. Installation Instructions	32
		Hyperlink Files\TDF10A240V.pdf Section 5.0 Transient Discriminating Filter Model Number TDF-10A-240V. Installation Instructions	2
		Hyperlink Files\DAR275V.pdf Section 5.0 DinLine Alarm Relay (DAR) Model Number DAR275v. Installation Instructions.	2
		Hyperlink Files\3000-000-06.pdf Section 5.0 Rotork Circuit Diagram N0-REV 3000-000-06	1
		Hyperlink Files\Rotork Electric E170E2.pdf Section 5.0 Rotork IQ Range Installation and Maintenance Instructions	86
		Hyperlink Files\RWS300 (IQ IQT Remote Control 24Vdc).pdf Section 5.0 Rotork Standard IQ/IQT Remote Control Circuitry (24V DC)	1
		Hyperlink Files\multitrode_mtr_international-datasheet.pdf Section 5.0 Liquid Level Control Relay	2
		Hyperlink Files\Switchboard Electrical Accessories\AustSol\CA10 switches.pdf Section 5.0	56
		Hyperlink Files\Switchboard Electrical Accessories\CROMPTON\analogue244.pdf Section 5.0	21
		Hyperlink Files\Switchboard Electrical Accessories\CROMPTON\din250 trip relay.pdf Section 5.0	8
		Hyperlink Files\Switchboard Electrical Accessories\Mann Ind\MannIndQS_FTXDMV.pdf Section 5.0	2
		Hyperlink Files\Switchboard Electrical Accessories\Phoenix Contact\3004032[1].pdf Section 5.0	7
		Hyperlink Files\Switchboard Electrical Accessories\Phoenix Contact\3004100[1].pdf Section 5.0	7
		Hyperlink Files\Switchboard Electrical Accessories\Phoenix	2

Issue Date: 11 OCT 05

Page 3 of 7

Rev: A

G:\CNPMSS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

Volume	Section	Description	Pages
		Contact\uk5n_en.pdf Section 5.0	
		Hyperlink Files\Vegabar27525-EN.pdf Section 5.0 Vegabar 64 Pressure Transmitter 4—20 mA/HART. Operating Instructions	72
		Hyperlink Files\Vegadis20591-EN.pdf Section 5.0 Adjustment Module for Pressure Transmitter. Operating Instructions	16
		Hyperlink Files\Vegawell27630-EN.pdf Section 5.0 Vegawell 72 is a suspension pressure transmitter for level and gauge measurement. Operating Instructions	48
		Hyperlink Files\MagMaster flowmeter.pdf Section 5.0 Instruction Manual	24
		Section 5.1 Contents Sheet	
		Hyperlink Files\mg10p222.pdf Section 6.0 Danfoss VFD Instruction Manual Modbus RTU	33
		Hyperlink Files\SP298 VFD Settings Pump No 1 and No. 2 As Built rev 1.pdf Section 6.1 VFD Settings and Parameters	3
		Hyperlink Files\doc_C 1 MG80A802.pdf Section 6.2 Danfoss VFD Operating Instructions VLT 8000 AQUA	197
		Hyperlink Files\Lytton Rd ITP.pdf Hyperlink Files\Lytton Rd FAT.pdf Section 7.0 ITP Procedure, Test Sheets & Factory Acceptance Test	5 11
		Hyperlink Files\BW Factory Acceptance Test Document Switchboard.pdf BW Factory Acceptance Test Document Switchboard	4
3	3	Drawings & Drawing Register	
		Electronic copy of the following drawings on CD. Table of Contents	
	3.1	Hyperlink Files\Drawing Register.xls	7
		Hyperlink Files\486 5 7-TR201 001.pdf Locality Keyplan Drawing	1
		Hyperlink Files\Location Map SP298.doc Street Location Map	1
		As Constructed Drawings Rising Mains	
	3.2	Hyperlink Files\Pages from Rising Main Lindum Rd to Lytton Rd.pdf Sewer Rising Main from Connection to Kiawanah Road P/S SP49 Rising Main at Lindum Road to Lytton Road No 4 Pump Station.	10
	3.3	Hyperlink Files\Pages from Rising Main Prichard St to Lytton Rd.pdf Sewer Rising Main Prichard Street Pumping Station to Lytton Road No.4	13

Issue Date: 11 OCT 05

Page 4 of 7

Rev: A

G:\CNPMSS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian
Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

Volume	Section	Description	Pages
		Pumping Station	
	3.4	Hyperlink Files\Rising Main Drg Lytton Rd to Serpentine Rd.pdf Sewer Rising Main Lytton Road Pump Station (SP298) to Serpentine Road Pump Station (SP300)	16
		As Constructed Drawings Pump Station SP298 Mechanical/Electrical/Switchboard/Generator/Pit Covers	
	3.5	Hyperlink Files\lytton rd.pdf As-constructed drawings Lytton Rd Pump Station SP298. Mechanical/Electrical/Switchboard/Generator/Pit Covers	89
		Weir Services: Pump General Arrangement Drawing	
	3.6	Hyperlink Files\wd8159_2 Layout1 (1).pdf	1
4	4	Traning/System Testing/Pre-Commissioning/Installation Method Statement/QA Records	
		BW Site Based Traning Hyperlink Files\BW Site Based Training.pdf	4
	4.1	BW: System Integration Testing	
		Hyperlink Files\SP298 SP300 System Integration Testing Procedure Rev 1.doc (BW) System Integration Testing Procedure SP 298 Lytton Rd Pump Station & SP 300 Serpentine Rd Pump Station. Including the following	7
		Hyperlink Files\BW ITP 001 Rev0.pdf (BW) ITP: 001 Rev.0 EQUIPMENT: Sewer RM Pritchard St PS to Lytton Rd PS. Sewer RM from connection to Kiawanah Rd PS SP49 RM at Lindum Rd to Lytton Rd PS.	1
		Hyperlink Files\BW ITP 002 Rev0.pdf (BW) ITP: 002 Rev.0 (Separable Portion 2 SP298 Lytton Rd Pump Station) EQUIPMENT: Pumping Station Site System Commissioning	1
		Hyperlink Files\BW ITP 003 Rev0.pdf (BW) ITP: 003 Rev.0 (Separable Portion 2 SP300 Serpentine Rd Pump Station) EQUIPMENT: Pumping Station Site System Commissioning	1
		Hyperlink Files\Check List 1.pdf (BW) Inspection Check List No1 Lytton Rd	1

Issue Date: 11 OCT 05

Page 5 of 7

Rev: A

G:\CNPMS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

<u>Volume</u>	<u>Section</u>	<u>Description</u>	<u>Pages</u>
		Hyperlink Files\Check List 2.pdf (BW) Inspection Check List No 2 Serpentine Rd	1
		Hyperlink Files\SP300 Serpentine Road Functional Spec 1-10.doc	24
		Hyperlink Files\SP300 FS Document Signoff Approval.pdf	1
		Hyperlink Files\SP300 Functional Specification Rev 3.doc Parsons Brinckerhoff Date of Issue: 4 November 2004	26
		Hyperlink Files\SP298 Lytton Road 4 Functional Spec 1-10.doc	18
		Hyperlink Files\SP298 FS Document Signoff Approval.pdf (BW) 1-05. doc	1
		Hyperlink Files\SP298 Functional Specification Rev 4.pdf Parsons Brinckerhoff Date of Issue: 5 November 2004	24
		Hyperlink Files\Trends SP298 13-06-2005 (2-6-24 hours).pdf Lytton Rd P/S SP298 No.4 Pump Trends (2/6/24hours)	3
		Hyperlink Files\Trends SP300 - Concrete Main - 06-10-2005 (2-6-24 hours).pdf Serpentine Rd P/S SP300 Pumping into the DN1840 Concrete Rising Main. Eagle Farm at Maximum Flow. Pump Trends (2/6/24hours)	3
		Hyperlink Files\Trends Steel Main SP300 11-06-2005 (2-6-24 hours).pdf Serpentine Rd P/S SP300 Pumping into the DN1370 Steel Rising Main. Pump Trends (2/6/24hours)	3
		Hyperlink Files\BW Site Acceptance Test Document Switchboard.pdf BW Site Acceptance Test Document Switchboard	3
		Hyperlink Files\BW IDTS Point Commissioning Sheet Switchboard.pdf BW IDTS Point Commissioning Sheet Switchboard	5
		Hyperlink Files\BW Site Inspection Report Switchboard.pdf BW Site Inspection Report Switchboard	6
4.2	Leighton/Parsons Brinckerhoff: Pre-Commissioning Report		
		Hyperlink Files\Letter Electrical Installation in accordance with AS3000.pdf Letter from REDILEC (who was working under Leighton direction) to certify that the electrical works is in accordance with AS3000.	1
		Hyperlink Files\RPT020Bvb - Precommissioning Lytton Rd PS.pdf Pre-commissioning Report Lytton Road Pump Station SP298. Including the following.	34
		Introduction	
		Appendix A: Pre-commissioning plan	
		Appendix B: Temporary pre-commissioning pipework arrangement	
		Appendix C: Manufacturers test data	
		Appendix D: Pre-Commissioning test data	

Issue Date: 11 OCT 05

Page 6 of 7

Rev: A

G:\CNPMS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road P/S SP298 Australia Trade Coast Sewer Project

BW30137-02/03

<u>Volume</u>	<u>Section</u>	<u>Description</u>	<u>Pages</u>
		Appendix E: Pump data comparison graphs	
		Conclusion	
	4.3	Leighton: Work Method Statement	
		Hyperlink Files\Q1112-CS-701 CMS SP1 Rising Main.pdf Leighton Construction Method Statement: Rising mains from Pritchard St P/S to Lytton Rd P/S and Lytton Rd P/S to Lindum Rd pipeline.	9
		Hyperlink Files\Q1112-CS-703 CMS of SP2 Rising Main.pdf Leighton Construction Method Statement: Rising mains from Lytton Rd P/S to Serpentine Rd P/S.	8
		Hyperlink Files\Q1112-CS-704 CMS of Lytton Road pump station.doc Leighton Construction Method Statement: Lytton Rd P/S	9
	4.4	Leighton: Installation QA Records	
		Hyperlink Files\QA Records.zip Open Lytton QA Register (xls) first for Abbreviated Description	
5	5	Leighton/Parsons Brinckerhoff: Design Report	
		Hyperlink Files\SP298 design report.zip Revised Developed Design Report Separable Portion No.2 Lytton Road Pump Station SP298. Including the following	213
		Introduction	
		Design Summary	
		Drawings	
		Input Design Data	
		Developed Design	
		Environmental Management	
		Permits and Approvals	
		List of Appendices A to I	

Issue Date: 11 OCT 05

Page 7 of 7

Rev: A

G:\CNPMS\Asset Creation Program\STTG -Australia TradeCoast Sewer\2004-2005\COMMISS\Reg McGIRR\Australian Trade Coast Sewer Project\OMM SP298\Table of Contents SP298.doc

2	2	Proprietary Equipment Manuals/Maintenance and Service	
	2.1	Weir Services: Hydrostal Pumps	
		Hyperlink Files\Hydrostal Pump I & O manual Lytton Rd - rev A.doc	52
		Including the following	
		Description of Equipment	
		Operation and Maintenance	
		Maintenance and Service	
		Impeller Clearance Adjustment for Wear	
		Recommended Spare Parts	
		Appropriate Records	
		Pump Declaration of Conformity/ Pump Volute Casing Water Pressure Test/Pump Workshop Test Records Q/H & NPSH etc/	
		Hyperlink Files\wd8159 2 Layout1 (1).pdf	
		Pump General Arrangement Drg	
	2.2	SE Power Equipment: Generator Set	
		Hyperlink Files\Section 1 - Instructions for Use.doc	4
		SE Power Equipment: Generator Operation & Maintenance Manuals	
		Hyperlink Files\Section 2 - John Deere Operation Manual.pdf	86
		Diesel Engine Generator Operator's Manual	
		Hyperlink Files\Section 3 - Stamford Installation, Service & Maintenance Man.pdf	44
		AC Generator Installation, Service & Maintenance Manual	
		Hyperlink Files\Section 4 - Part 1 PLC GE Fanuc.pdf	2
		GE Fanuc Automation Series 90TM-30 PLCs	
		Hyperlink Files\Section 4 - Part 2 PLC GE Fanuc.pdf	67
		GE Fanuc Automation Programmable Control Products Series 90TM-30 PLC Installation and Hardware Manual	
		Hyperlink Files\Section 4 - Part 3 GE Fanuc.pdf	18
		GE Fanuc Automation Programmable Control Products Series 90TM-30 Programmable Control Troubleshooting Guide	
		Hyperlink Files\Section 5 - Functional Description.doc	14
		Local Control Panel Functional Description	
		Hyperlink Files\SE Power Equipment Generator Drg.pdf	6
		Diesel Engine/Generator Drg	
		Hyperlink Files\SE Power Works Test ITP Generator.pdf	19
		SE Power Works Test ITP Generator	
		Hyperlink Files\BW Factory Test Report Generator.doc	12
		BW Factory Test Report Generator	
		Stanby Generator Software (ON DISK)	
	2.3	Cathodic Protection	
		Hyperlink Files\Cathodic Protection System Manual SP298.pdf	15
		Cathodic Protection Installation Performed Testing & Maintenance.	

2.1

PASTEL
MANILLA
DIVIDERS
5 TAB A4



Ref. No. 37000
Made in China
Distributed by ACCO Australia



9 312311 370002



Installation and Operating Instructions

BRISBANE CITY COUNCIL

Brisbane Water

Lytton Road

Raw Sewage

Hidrostal Pump
H08K-M02R+HE5T4-X5EK+NDB6-13

Job No.: 208888
Serial No.: H3084, H3103
Fabrication No.: 138075, 138076

Prepared by:

WEIR SERVICES
15 Gindurra Road
SOMERSBY NSW 2250
Australia

Phone: (02) 4349 2999
Fax: (02) 4349 2900



Revisions:

Issue No.	Date of Issue	Changed By	Details of Change	Approved By
A	19 August 2005	-	Original Issue	

Contents:

Section	Title	Page
1.	Introduction and Background Information	5
1.1.	Introduction.....	5
1.2.	Description of Equipment.....	5
1.2.1.	Equipment Information:.....	5
1.3.	Supplier Contacts:.....	6
2.	Installation and Commissioning	7
2.1.	Handling, Unpacking and Storage.....	7
2.1.1.	Delivery	7
2.1.2.	Reception of Pump Unit	7
2.1.3.	Storage	7
2.2.	Installation Process	7
2.2.1.	Installation	7
2.2.2.	Installation of Pump Guide System	8
2.2.3.	Lowering the Pump Into Sump.....	8
2.2.4.	Mounting.....	9
2.2.5.	Piping.....	9
2.2.6.	Direction of Rotation	10
2.2.7.	Level Switches	14
2.2.8.	Level Control	14
2.2.9.	Required Submergence.....	14
3.	Appropriate Records.....	15
4.	Operation and Maintenance.....	30
4.1.	Start-up	30
4.1.1.	Starting of Pump	30
4.1.2.	General Operating Conditions	30
4.1.3.	Operating Troubles	31
4.2.	Maintenance and Service.....	32
4.2.1.	General.....	32
4.2.2.	Pump Cooling	32
4.2.3.	Impeller Clearance Adjustment for Wear.....	33
4.3.	Field Tests.....	34
4.3.1.	Visual Checks	34

4.3.2.	Motor Housing Test	35
4.3.3.	Oil Check	35
4.3.4.	Oil Change for Internal Cooled Motors	37
4.3.5.	Greasing Instructions	37
4.3.6.	Motor Cables	38
4.3.7.	Re-connection of Cable	38
4.3.8.	Test for Leaks	38
4.4.	Assembly Disassembly	39
4.4.1.	Replacement of Mechanical Seal.....	39
4.4.2.	Assembly of Back Cover	40
4.4.3.	Assembly of Pump Side Mechanical Seal	40
4.4.4.	Leak Test for Pump Side Mechanical Seal.....	41
4.4.5.	Disassembly of Hydraulic Parts.....	41
4.4.6.	Removal of Impeller	42
4.4.7.	Removal of Impeller Flange	42
4.4.8.	Removal of Liner	42
4.4.9.	Assembly of Impeller Flange.....	43
4.4.10.	Assembly of Impeller	43
4.4.11.	Assembly of Liner	43
4.4.12.	Final Assembly	44
4.5.	Recommended Spare Parts	45
4.6.	Section Arrangement	45
4.6.1.	Pump	45
4.6.2.	Motor	47

1. Introduction and Background Information

The Operation and Maintenance details enclosed cover Hidrostral screw centrifugal pumps supplied for Brisbane City Council's, Australian Trade Coast project.

Weir Services Australia's scope of supply includes the supply and testing of dry well submersible sewage pumps and their associated mounting pedestals.

1.1. Introduction

Each pump unit is equipped with a nameplate attached to the motor, containing all motor and pump data. It is essential to give the complete data for any inquiry about parts or service.

The Hidrostral warranty is void unless the following requirements are met:

- a) Temperature protection circuit is wired so as to positively disconnect power to the motor when excessive winding temperature is sensed.
- b) Proper extra-quick-trip overload protectors must be used on all three phases of each motor (section 2.2.8.).
- c) Optional conductivity probe circuit is wired to a special relay for use with these motors. See section 2.2.8. for wiring instructions and a list of approved relays.
- d) Any repairs must be made exactly as per instructions in this manual, and using only genuine Hidrostral replacement parts furnished through the Hidrostral distribution organisation. Use of any other parts will void the Hidrostral warranty.

Prior to shipment, each pump has been tested by the factory for proper mechanical and electrical operation as well as absolute water-tightness of the motor. Disassembly of the pump by other than official Hidrostral service centers may cause loss of any remaining warranty.

1.2. Description of Equipment

Project:	Brisbane Water ATC
Equipment:	Hidrostral Pump
Manufacturer:	Hidrostral
Local Representative:	Weir Services Australia Pty Ltd
Pump Model No.:	H08K-M02R+HEVT4-XMEK+NDB6-13
Serial No.'s:	H3083, H3103
Fabrication No's:	138075, 138076

1.2.1. Equipment Information:

Flow:	160 l/s
Head:	25.6 m
Speed:	1460 rpm
Rotation:	counter clockwise viewed from suction end

1.3. Supplier Contacts:

Pump Supply Contact: Weir Services Australia,
15 Gindurra rd, Somersby, NSW 2250
Ph: (02) 43492999 fax: (02) 43492900
e-mail: wsa@weir.com.au

Spare Parts Contact: 'as above'

Service Contact: 'as above'

2. Installation and Commissioning

2.1. Handling, Unpacking and Storage

2.1.1. Delivery

Weir Services Australia (WSA) will not assume responsibility for damage to the pump that has been caused due to not following instructions in this manual, nor for consequential damages of any kind.

2.1.2. Reception of Pump Unit

Inspect the shipment for shortages or damage. Report any discrepancies to the carrier, note them on the shipping documents and sign them with date together with the carrier.

2.1.3. Storage

If the unit is not to be installed immediately, note:

- Store in a dry and clean place without extreme changes in temperature (storage room temperature -10° to +40°C (14° to 104°F)).
- Rotate the shaft by turning the impeller once every two weeks to ensure positive coating on the lubricated surfaces and to prevent sticking of surfaces due to rust or oxidation.
- Do not store in a location where the pump would be subject to vibrations, otherwise brinelling of the bearings could occur.

2.2. Installation Process

2.2.1. Installation

The pump should be placed as near to the liquid source as possible, and as low as possible, to provide the maximum possible suction head, avoiding elbows and excessive pipe lengths wherever possible. Provide adequate ventilation of pump room.

Warning:

If the pump can be exposed to temperatures at or below the freezing point of the media, the pump should be drained when not in use (formation of ice within the pump can cause cracking and other damage to the construction).

All building and technical construction work must be finished before the pump will be installed. Make sure that length of cable supplied is sufficient for local conditions.

Attention: very important: For installation and servicing it is recommended to install a block and tackle or chain hoist over the pump sump (or at least make sure that it could be installed later on). The lifting capacity of the crane has to support at least double the weight of the pump. There should be a water supply of about 4 bar (70 psi) pressure to wash down the pump when removed from the sump.

During the installation of the pump make sure that the free ends of the cables **NEVER CONTACT WATER**.

2.2.2. Installation of Pump Guide System

- a) Fasten the upper guiderail bracket. Be sure to leave enough space for sliding shoe.
- b) Sump floor where the discharge stand is to be placed must be even and level. Fasten the discharge stand to the sump floor with cast-in place or expansion-type bolts and nuts so that the guide rail pins or recesses on the discharge stand are vertically in line with (i.e. directly below) the guide rail pins on the bracket.
- c) The guide rails should be made from galvanized standard (or stainless steel) pipe. Cut pipe to the correct length. Put lower pipe ends in discharge stand guiderail pins or recesses. Unbolt upper guide rail bracket. Insert pins into upper pipe ends and re-bolt it. Check to see that the guide rails are exactly vertical and parallel.
- d) The discharge pipe must be connected without stress or misalignment to the discharge stand. If a check valve is installed close to the pump, air must be vented from the pump casing or discharge piping (before the check valve) during first startup to ensure priming (Section 2.2.6,)

Preparatory Checks

Before lowering the pump into the sump check to see that:

- The lifting chain or steel lifting cable is correctly fastened to the lifting eyes.
- The cable entry assemblies on motor have not been damaged or loosened and that the cables are firmly gripped by the cable entry assemblies.
- The cables have not been damaged during transportation or installation. Look especially for nicks and cuts on insulation; any damage penetrating through the outer layer of the cable will require replacement of them.
- The cables are long enough and that they can follow the pump unhindered.
- The cable ends have never come in contact with water.
- The rubber seal on the pump discharge is correctly seated in its groove, and is not damaged.
- The rubber seal is thoroughly greased.
- The direction of rotation is correct (Section 2.2.6, Fig. 3).

2.2.3. Lowering the Pump Into Sump

- Clear the sump bottom carefully of all building debris and other solid particles.
- Lubricate the rubber seal with grease.
- Lift and move the pump to a position directly over the guides until the sliding shoe fits correctly. Lower the pump steadily down to seat against the discharge stand. The sealing of mating faces is accomplished by the rubber seal that is incorporated in the sliding shoe attached to the pump discharge flange. This is pressed to the discharge stand (after the pump is in position) by the pump's own weight.

- When the chain is slack, unfasten it from the lifting device and fasten it to its retaining hook, so that there is as little slack as possible.

Warning:

The chain and cable must be fastened reliably to their retaining hooks. If they come loose they may be drawn into the pump suction with severe destructive consequences.

2.2.4. Mounting

- General: The pump is to be mounted in a vertical position.
- Fastenings: The pump can be stood using a special suction elbow on its suction flange or using a bracket bolted to the volute casing.

2.2.5. Piping

The suction and discharge piping should be independently supported near the pump and be installed in such a manner so as not to impose stresses and strains on the pump casing.

Suction Piping

To obtain maximum available suction head, the suction line should be as direct and as short as possible, avoiding elbows. If elbows must be used, a long radius type is preferred. It is important to avoid any sagging in a suction line in which air may accumulate and cause loss of prime. For the same reason, it is important to have the suction line airtight when suction lift exists.

The suction pipe must be such that no air pockets can form, and must slope upward to the pump intake.

The losses of the suction side should be kept to a minimum, the pipework should never be less than the suction diameter of the pump and preferably be one pipe size larger. When larger diameter pipework is required the transition should be made close to the pump using flat-topped tapers (Fig. 1). Concentric tapers should never be used, as air pockets could result (Fig. 2).




fig 1




fig 2

Unusual suction conditions such as high liquid temperature, altitude above sea level and high specific gravity or viscous liquids should be compensated for, by proper engineering of a sufficiently sized suction pipe.

Warning:

The pump should not operate on a suction lift when pumping liquids with entrained air or gas. Non-return valves should not be used in the suction line. Gate valves should preferably

be installed with the spindle horizontal to prevent trapping air or gas. Suction valves must be fully open during operation.

Discharge Piping

Use as few fittings as possible and when elevating to any height, go vertically upward from the pump, then horizontal to the point of discharge. When using non return valves in the discharge line it is important the maximum permitted velocity specified by the manufacturer is not exceeded. For single-flap valves operating on dirty liquids a typical maximum velocity is 3.5 m/second.

If these values are exceeded shock waves can result when the valve closes, which may cause the face of mechanical seals to open and allow material to become trapped between the faces resulting in premature seal failure and contamination/loss of the seal oil.

Warning:

Does the pump work with closed or blocked up suction or discharge piping, there is a danger of overheating in the volute casing. It is possible to dry out the medium occluding gas bubbles. They could cause damages on person or machine if they will be eliminated inexpert.

Connection of Piping

This should only be undertaken after the grout (if used) has thorough set and holding down bolts have been tightened. The pipework should be connected to the pump flanges with gaskets in place and the bolts properly tightened. Make sure the pipe flanges are parallel and in line.

Warning:

For all pumps in cast iron, great care must be used in connecting these flanges. Tighten evenly and adjust to a snug fit. Under no circumstances should the casing be subjected to piping strains. Such strains could result in structural failure leading to operator injury.

2.2.6. Direction of Rotation

Before installing the pump into the sump, the electrical controls and pump power cable junction boxes must be placed above any expected water level. They should also be adequately sealed and/or vented to avoid internal condensation. Check the direction of rotation. This must be counter-clockwise viewed from suction end. Check impeller rotation by suspending pump from the lifting eyes, resting inclined on the floor, and start up for one second. The starting jerk should be counter-clockwise viewed from driving side (Fig. 3). This procedure must be repeated for each speed, if units are multi-speed pumps.

Caution:

If rotation is not correct on multi-speed or multi-pump installations, only change the pump cable leads of the pump or speed with wrong rotation at its starter in the control panel. **DO NOT** change the primary power leads coming into the control panel: This would change the rotation of all pumps or speeds.




fig 3

Electrical Connection

The motor winding leads will be factory-connected according specifications (see nameplate).

Make sure that the power supply to the control panel is the same as on the pump nameplates (tolerance $\pm 5\%$). From 5 % to 10 % lower voltage, there may be a slight diminishing of hydraulic performance and a slight increase in amperage, but no harm to the motor. For voltages lower than 10 % of rating, severe performance drop and excessive draw (motor overheating and considerable operating problems) can be expected. The motor ratings shown on the nameplate are for ambient temperature (liquid and air) of up to 40° C. For higher temperatures, contact factory.

All electrical connections are made according to electrical diagram.

Operator Safety

Prior to any work on the pump, the power supply must be disconnected either by means of a locked isolator or by removing the fuses from the panel. It is not safe enough to switch off the control switch. A wiring mistake or a control system malfunction could put the motor back into operation.

Minimum Requirements

The control panel must contain the following components:

- a) Isolation switch, preferably lockable.
- b) Slow trip fuses or circuit breakers in each incoming phase.
- c) Lightning protection. Lightning arrestor on each incoming phase, if there is any possibility of lightning damage.
- d) Motor starter. Full-voltage magnetic-contact starter has to be sized according to local electrical code requirements based on motor power rating.
- e) Extra quick trip overload protectors. They must be selected according to the amperage indicated on the nameplate. They must trip within 6 seconds on locked rotor condition (approximately 6 times full load amps) in order to adequately protect the motor windings; consult "trip curve" of overload protectors to ensure they meet this requirement.

Caution:

Warranty on immersible pump motor is void unless proper extra quick trip overload protectors are used on all motor phases. Claims for warranty repair of motors must include documentation that proper overload protectors have been installed.



2.2.7. Level Switches

- It is recommended to use an intrinsically safe circuit for the level controls, for explosion-proof installations.
- For the on and off levels, use control systems that are appropriate for the pumped liquid.
- Use a floating-ball type switch for the high-level alarm, even when there is another type used for the pump control (this has proven to be the most fail-safe type).
- The floating ball for the alarm should be placed at a reasonable distance above the highest pump start level to avoid false alarms.

2.2.8. Level Control

"ON" and "OFF" levels must be set in such a way as to provide sufficient sump capacity between "ON" and "OFF" so that the pump cannot be switched on more than 10 times per hour. Higher starting frequency may damage the motor control devices in the panel and will cause excessive power consumption. The following formula will calculate the required minimum sump capacity:

$$V = \frac{0.9 \times Q_p}{Z}$$

V = sump capacity or volume, between on and off levels (in cubic meters)
Q_p = pump flow for one pump (in litres/second)
Z = number of starts per hour (Z = 10, maximum)

2.2.9. Required Submergence


Hidrostal immersible pumps can work continuously submerged or in a dry environment. The motors do not require submergence in liquid for cooling.

In the case of wet pit pumps the "OFF" level can therefore be set below the pump casing.

However, care should be taken to provide sufficient submergence to avoid vortexing or pulling of air into the pump suction.

Priming of the pump will require the "ON" level to be at least as high as the tip of the impeller.

3. Appropriate Records

	DECLARATION OF CONFORMITY	16
We,  AG		
CH-8213 Neunkirch/SH, Gigerling 27 Tel. 0041 52 687 06 87, Fax. 0041 52 681 20 84		
declare under our sole responsibility that the product/s:		
ORDER NR.:	04 05 353 / 030	
YOUR NUMBER:	P.O. 70 891	
TYP:	H08K - M02R + HEVT4 - XMEK + NDB6 - 13	
FAB. NR.:	138 075 / 138 076	
CUSTOMER CODE: BPAU		
to which this declaration relates is in conformity with the following standard(s) or other normative documents:		
VDMA 24287, DIN 24295, DIN 31000 EN 292-1+2, EN 60204-1, EN 60034-1, -5, -7, EN 23741		
following the provisions of Directive:		
98/37/EG, 73/23/EEC, 89/336/EEC, 93/31/EEC (+ 94/9/EG for Ex-proof)		
		
Neunkirch, 01.06.2004	U. Eckmann, Q - Manager	
File: FORM_KON	Drawn by / Bearb. Dat. Vis.: 04.02.00 ue/ml Approved by / Gepr. Dat. Vis.: 04.02.00 ue	No. 98-QM 5862E/c



ZENTRIFUGALPUMPEN

HIDROSTAL AG
CH-8213 Neunkirch

Telefon: ..041 (0)52 / 687 06 87
Telefax: ..041 (0)52 / 681 20 84

Order No. 04.05.353

Neunkirch-SH

CERTIFICATE

Subj.: Pump-Type: **H08K-M02R + HEVT4-XMEK**
Serial-Number: **138075+138076**
Date of Test: **27.10.2004**

WE HEREWITH CONFIRM TO HAVE WATER-PRESSURE TESTED
THE VOLUTE CASING OF THE ABOVE MENTIONED PUMP WITH
A PRESSURE OF 6 BARS DURING 15 MINUTES.

THE VOLUTE CASING WAS FOUND IN GOOD CONDITION.

NEUNKIRCH, 27.10.2004



PRU VM Npsh98

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road / Q1112-SA-005



Verification of guarantee


according ISO 2548 class = C

Client: **Weir Engineering Pty Ltd**
Pump type: **H08K-M02R + HEVT4-XMEK**


Date : **13.09.2004**
Order No. : **04.05.353**
Fab-No. : **138075**

Guarantee points:
at 50 Hz.

Volume rate of flow Q: **200 l/s = Qg**
Pump total head H: **22.5 m = Hg**
NPSH : **3 m**



NPSH-Test at 50 Hz. and 200.17 l/s



Verification of the guarantee:

ΔH : **+ 0.61 m**
 ΔQ : **+ 4.97 l/s**
overall eta: **73.4 %**

NPSH at 200.17 l/s
2.88 m

Tolerances factors:

XQ: **0.07**
XH: **0.04**
 η : **95.5 %**
NPSH: **-3 % of H or η :**

NPSH 2.88 m is lower than 3.00 m

$$\left(\frac{Q_g \times X_Q}{\Delta Q} \right)^2 + \left(\frac{H_g \times X_H}{\Delta H} \right)^2 \geq 1 = 10.09$$



VM-Npsh /3 Q-Management B.V./v.Ah Rev. 0 /21.06.98



Verification of guarantee


according ISO 2548 class = C

Client: **Weir Engineering Pty Ltd**
Pump type: **H08K-M02R + HEVT4-XMEK**


Date : **13.09.2004**
Order No. : **04.05.353**
Fab-No. : **138075**

Guarantee points:
at 50 Hz.

Volume rate of flow Q: **100 l/s = Q_g**
Pump total head H: **36 m = H_g**
NPSH : **4.1 m**



NPSH-Test at 50 Hz. and 100.09 l/s



Verification of the guarantee:

NPSH at 100.09 l/s
1.91 m

Tolerances factors:

XQ: **0.07**
XH: **0.04**

NPSH: **-3 % of H or η:**

NPSH 1.91 m is lower than 4.10 m




VM-Npsh /3 | Q-Management | B.V./v.Ah | Rev. 0 /21.06.98

I & O manual Lytton Rd - rev A.doc

19 August 2005

20 of 49

		NPSH - Pump test record for venturi meterrun measurements with Motor According to ISO standard 5167										Date: 13.09.2004 Signature: H.P.M.					
		Motor data Motor-Typ : HEVT4-XMEK P nominal : 60.0 kW Speed : 1471 R.P.M. P1 max. : 71.0 kW Voltage : 400 V Cycles : 50 Hz Current max.: 117.0 A η Motor : 100 %					Constant for test bed Z1 : 0.760 m Z2 : 0.710 m D2 Delivery pipe : 0.200 m D1 Suction pipe : 0.300 m Venturi specifications, size : 300 Throat diameter d : 0.177 m. Diameter ratio β : 0.571 d/D Coefficient of discharge C : 1.002 Atmosph. pressure. : 9.827 m										
Order-No. : 04.05.353 Client : Weir Engineering Pty Ltd Your Order : P.O.70891 Fab-No. : 138075 Pump type : H08K-M02R + HEVT4-XMEK Impeller : Prod. Impeller Clearance : 0.4 mm.		Measured values at 50 Hz										Calculated a test speed					
U	I	W.Temp.	density	Va.pres.	Venturi	H1-inlet		H2-outlet		P1	ZZ	Q	H	P1	η	NPSH	
Volt	A	C°	kg/dm³	m	mb.	x factor	m	x factor	m	kW	m	l/s	m	kW	%	m	
						10.2		10.2							Overall		
393	97.6	20	0.9982	0.2380	73	0.015	0.15	3.360	34.27	56.5	0	100.1	36.3	56.5	63.1	8.8	
393	97.6	20	0.9982	0.2380	73	0.015	0.15	3.360	34.27	56.5	0	100.1	36.3	56.5	63.1	8.8	
396	97.7	20	0.9982	0.2380	73	0.150	1.53	3.210	32.74	57.0	0	100.1	36.2	57.0	62.2	7.4	
396	99	20	0.9982	0.2380	73	0.294	3.00	3.100	31.62	57.7	0	100.1	36.5	57.7	62.1	5.9	
396	101	20	0.9982	0.2380	73	0.416	4.24	3.010	30.70	59.5	0	100.1	36.8	59.5	60.7	4.7	
396	104.3	20	0.9982	0.2380	73	0.517	5.27	2.980	30.40	61.7	0	100.1	37.6	61.7	59.7	3.7	
396	110.7	20	0.9982	0.2380	73	0.764	7.79	2.590	26.42	66.0	0	100.1	36.1	66.0	58.7	1.2	
396	96.1	20	0.9982	0.2380	73	0.779	7.95	1.420	14.48	55.9	0	100.1	24.3	55.9	42.7	0.0	
VM-Npsh /1		Q-Management		B.V. / v.Ah		Rev. 0 / 25 6.98.						PRU-VM-Npsh98					
Because of the system losses, a booster pump was used on the discharge pipe, giving a negative pressure reading on the NPSH-test.																	

 BRISBANE CITY COUNCIL
 Brisbane Water
 Lytton Road / Q1112-SA-005




Verification of information


according ISO 2548 class = C

Client: **Weir Engineering Pty Ltd**
Pump type: **H08K-M02R + HEVT4-XMEK**


Date : **13.09.2004**
Order No. : **04.05.353**
Fab-No. : **138075**

Information points:
at 50 Hz.

Volume rate of flow Q: **300 l/s = Qg**
Pump total head H: **10 m = Hg**
NPSH : **5.2 m**



NPSH-Test at 50 Hz. and 300.03 l/s



Verification of the information:

NPSH at 300.03 l/s
4.47 m

Tolerances factors:

XQ: **0.07**
XH: **0.04**

NPSH: **-3 % of H or η:**

NPSH 4.47 m is lower than 5.20 m



VM-Npsh /3 Q-Management B.V./v.Ah Rev. 0 /21.06.98


I & O manual Lytton Rd - rev A.doc

19 August 2005

22 of 49

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road / Q1112-SA-005

WEIR

		NPSH - Pump test record for venturi meterrun measurements										Date: 13.09.2004																																																																																																																																																																																																											
		with Motor										Signature: H.P.M.																																																																																																																																																																																																											
		According to ISO standard 5167																																																																																																																																																																																																																					
Order-No. : 04.05.353 Client : Weir Engineering Pty Ltd Your Order : P.O.70891 Fab-No. : 138075 Pump type : H08K-M02R + HEVT4-XMEK Impeller : Prod. Impeller Clearance : 0.4 mm.						Motor data				Constant for test bed																																																																																																																																																																																																													
						Motor-Typ : HEVT4-XMEK P nominal : 60.0 kW Speed : 1471 R.P.M. P1 max. : 71.0 kW Voltage : 400 V Cycles : 50 Hz Current max.: 117.0 A η Motor : 100 %				Z1 : 0.760 m Z2 : 0.710 m D2 Delivery pipe : 0.200 m D1 Suction pipe : 0.300 m Venturi specifications, size : 300 Throat diameter d : 0.177 m. Diameter ratio B : 0.571 d/D Coefficient of discharge C : 1.002 Atmosph. pressure. : 9.827 m																																																																																																																																																																																																													
<table border="1"> <thead> <tr> <th colspan="11">Measured values at 50 Hz</th> <th colspan="4">Calculated a test speed</th> </tr> <tr> <th>U</th> <th>I</th> <th>W.Temp.</th> <th>density</th> <th>Va.pres.</th> <th>Venturi</th> <th colspan="2">H1-inlet</th> <th colspan="2">H2-outlet</th> <th>P1</th> <th>ZZ</th> <th>Q</th> <th>H</th> <th>P1</th> <th>η</th> <th>NPSH</th> </tr> <tr> <th>Volt</th> <th>A</th> <th>C°</th> <th>kg/dm³</th> <th>m</th> <th>mb.</th> <th>x factor</th> <th>m</th> <th>x factor</th> <th>m</th> <th>kW</th> <th>m</th> <th>l/s</th> <th>m</th> <th>kW</th> <th>%</th> <th>m</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>10.2</td> <td></td> <td>10.2</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>Overall</td> <td></td> </tr> <tr> <td>396</td> <td>88.7</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.140</td> <td>1.43</td> <td>0.390</td> <td>3.98</td> <td>51.1</td> <td>0</td> <td>300.0</td> <td>10.6</td> <td>51.1</td> <td>61.1</td> <td>8.3</td> </tr> <tr> <td>396</td> <td>88.7</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.140</td> <td>1.43</td> <td>0.390</td> <td>3.98</td> <td>51.1</td> <td>0</td> <td>300.0</td> <td>10.6</td> <td>51.1</td> <td>61.1</td> <td>8.3</td> </tr> <tr> <td>396</td> <td>89</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.219</td> <td>2.23</td> <td>0.280</td> <td>2.86</td> <td>50.1</td> <td>0</td> <td>300.0</td> <td>10.3</td> <td>50.1</td> <td>60.4</td> <td>7.5</td> </tr> <tr> <td>392</td> <td>88.3</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.303</td> <td>3.09</td> <td>0.210</td> <td>2.14</td> <td>51.1</td> <td>0</td> <td>300.0</td> <td>10.4</td> <td>51.1</td> <td>60.1</td> <td>6.7</td> </tr> <tr> <td>392</td> <td>88.3</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.405</td> <td>4.13</td> <td>0.090</td> <td>0.92</td> <td>51.1</td> <td>0</td> <td>300.0</td> <td>10.2</td> <td>51.1</td> <td>59.0</td> <td>5.6</td> </tr> <tr> <td>392</td> <td>89.6</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.520</td> <td>5.30</td> <td>-0.070</td> <td>-0.71</td> <td>51.4</td> <td>0</td> <td>300.0</td> <td>9.8</td> <td>51.4</td> <td>56.0</td> <td>4.5</td> </tr> <tr> <td>392</td> <td>89.6</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.539</td> <td>5.50</td> <td>-0.280</td> <td>-2.86</td> <td>51.6</td> <td>0</td> <td>300.0</td> <td>7.8</td> <td>51.6</td> <td>44.7</td> <td>4.3</td> </tr> <tr> <td>392</td> <td>83.9</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.541</td> <td>5.52</td> <td>-0.440</td> <td>-4.49</td> <td>47.1</td> <td>0</td> <td>300.0</td> <td>6.2</td> <td>47.1</td> <td>38.9</td> <td>4.2</td> </tr> </tbody> </table>														Measured values at 50 Hz											Calculated a test speed				U	I	W.Temp.	density	Va.pres.	Venturi	H1-inlet		H2-outlet		P1	ZZ	Q	H	P1	η	NPSH	Volt	A	C°	kg/dm³	m	mb.	x factor	m	x factor	m	kW	m	l/s	m	kW	%	m							10.2		10.2							Overall		396	88.7	20	0.9982	0.2380	656	0.140	1.43	0.390	3.98	51.1	0	300.0	10.6	51.1	61.1	8.3	396	88.7	20	0.9982	0.2380	656	0.140	1.43	0.390	3.98	51.1	0	300.0	10.6	51.1	61.1	8.3	396	89	20	0.9982	0.2380	656	0.219	2.23	0.280	2.86	50.1	0	300.0	10.3	50.1	60.4	7.5	392	88.3	20	0.9982	0.2380	656	0.303	3.09	0.210	2.14	51.1	0	300.0	10.4	51.1	60.1	6.7	392	88.3	20	0.9982	0.2380	656	0.405	4.13	0.090	0.92	51.1	0	300.0	10.2	51.1	59.0	5.6	392	89.6	20	0.9982	0.2380	656	0.520	5.30	-0.070	-0.71	51.4	0	300.0	9.8	51.4	56.0	4.5	392	89.6	20	0.9982	0.2380	656	0.539	5.50	-0.280	-2.86	51.6	0	300.0	7.8	51.6	44.7	4.3	392	83.9	20	0.9982	0.2380	656	0.541	5.52	-0.440	-4.49	47.1	0	300.0	6.2	47.1	38.9	4.2
Measured values at 50 Hz											Calculated a test speed																																																																																																																																																																																																												
U	I	W.Temp.	density	Va.pres.	Venturi	H1-inlet		H2-outlet		P1	ZZ	Q	H	P1	η	NPSH																																																																																																																																																																																																							
Volt	A	C°	kg/dm³	m	mb.	x factor	m	x factor	m	kW	m	l/s	m	kW	%	m																																																																																																																																																																																																							
						10.2		10.2							Overall																																																																																																																																																																																																								
396	88.7	20	0.9982	0.2380	656	0.140	1.43	0.390	3.98	51.1	0	300.0	10.6	51.1	61.1	8.3																																																																																																																																																																																																							
396	88.7	20	0.9982	0.2380	656	0.140	1.43	0.390	3.98	51.1	0	300.0	10.6	51.1	61.1	8.3																																																																																																																																																																																																							
396	89	20	0.9982	0.2380	656	0.219	2.23	0.280	2.86	50.1	0	300.0	10.3	50.1	60.4	7.5																																																																																																																																																																																																							
392	88.3	20	0.9982	0.2380	656	0.303	3.09	0.210	2.14	51.1	0	300.0	10.4	51.1	60.1	6.7																																																																																																																																																																																																							
392	88.3	20	0.9982	0.2380	656	0.405	4.13	0.090	0.92	51.1	0	300.0	10.2	51.1	59.0	5.6																																																																																																																																																																																																							
392	89.6	20	0.9982	0.2380	656	0.520	5.30	-0.070	-0.71	51.4	0	300.0	9.8	51.4	56.0	4.5																																																																																																																																																																																																							
392	89.6	20	0.9982	0.2380	656	0.539	5.50	-0.280	-2.86	51.6	0	300.0	7.8	51.6	44.7	4.3																																																																																																																																																																																																							
392	83.9	20	0.9982	0.2380	656	0.541	5.52	-0.440	-4.49	47.1	0	300.0	6.2	47.1	38.9	4.2																																																																																																																																																																																																							
VM-Npsh /1		Q-Management		B.V. / v.Ah		Rev. 0 / 25 6.98.						PRU-VM-Npsh 98																																																																																																																																																																																																											
Because of the system losses, a booster pump was used on the discharge pipe, giving a negative pressure reading on the NPSH-test.																																																																																																																																																																																																																							





Verification of guarantee


according ISO 2548 class = C

Client: **Weir Engineering Pty Ltd**
Pump type: **H08K-M02R + HEVT4-XMEK**


Date : **16.09.2004**
Order No. : **04.05.353**
Fab-No. : **138076**

Guarantee points:
at 50 Hz.

Volume rate of flow Q: **200 l/s = Qg**
Pump total head H: **22.5 m = Hg**
NPSH : **3 m**



NPSH-Test at 50 Hz. and 200.17 l/s



Verification of the guarantee:

ΔH : **+ 0.06 m** NPSH at 200.17 l/s
 ΔQ : **+ 0.53 l/s** **2.59 m**
overall eta: **72.3 %**

Tolerances factors:

XQ: **0.07**
XH: **0.04**
 η : **95.5 %**
NPSH: **-3 % of H or η :**

NPSH 2.59 m is lower than 3.00 m

$$\left(\frac{Q_g \times X_Q}{\Delta Q} \right)^2 + \left(\frac{H_g \times X_H}{\Delta H} \right)^2 \geq 1 = 904.09$$



VM-Npsh /3 Q-Management B.V./v.Ah Rev. 0 /21.06.98

I & O manual Lytton Rd - rev A.doc

19 August 2005

25 of 49

BRISBANE CITY COUNCIL
Brisbane Water
Lytton Road / Q1112-SA-005

		NPSH - Pump test record for venturi meterrun measurements with Motor According to ISO standard 5167										Date: 16.09.2004 Signature: H.P.M.					
		Motor data Motor-Typ : HEVT4-XMEK P nominal : 60.0 kW Speed : 1471 R.P.M. P1 max. : 71.0 kW Voltage : 400 V Cycles : 50 Hz Current max.: 117.0 A η Motor : 100 %					Constant for test bed Z1 : 0.760 m Z2 : 0.710 m D2 Delivery pipe : 0.200 m D1 Suction pipe : 0.300 m Venturi specifications, size : 300 Throat diameter d : 0.177 m. Diameter ratio β : 0.571 d/D Coefficient of discharge C : 1.002 Atmosph. pressure. : 9.888 m										
Order-No. : 04.05.353 Client : Weir Engineering Pty Ltd Your Order : P.O.70891 Fab-No. : 138076 Pump type : H08K-M02R + HEVT4-XMEK Impeller : Prod. Impeller Clearance : 0.4 mm.																	
Measured values at 50 Hz														Calculated a test speed			
U	I	W.Temp.	density	Va.pres.	Venturi	H1-inlet		H2-outlet		P1	ZZ	Q	H	P1	η	NPSH	
Volt	A	C°	kg/dm³	m	mb.	x factor	m	x factor	m	kW	m	l/s	m	kW	%	m	
						10.2		10.2							Overall		
397	96	20	0.9982	0.2380	73	0.052	0.53	3.330	33.97	56.6	0	100.1	36.4	56.6	63.1	8.5	
397	96	20	0.9982	0.2380	73	0.052	0.53	3.330	33.97	56.6	0	100.1	36.4	56.6	63.1	8.5	
397	97	20	0.9982	0.2380	73	0.165	1.68	3.170	32.33	57.0	0	100.1	35.9	57.0	61.8	7.3	
397	98	20	0.9982	0.2380	73	0.331	3.38	3.080	31.42	58.3	0	100.1	36.7	58.3	61.7	5.6	
397	101	20	0.9982	0.2380	73	0.434	4.43	3.000	30.60	60.0	0	100.1	36.9	60.0	60.4	4.6	
397	102	20	0.9982	0.2380	73	0.591	6.03	2.850	29.07	60.8	0	100.1	37.0	60.8	59.7	3.0	
397	112	20	0.9982	0.2380	73	0.761	7.76	2.500	25.50	66.9	0	100.1	35.1	66.9	51.8	1.2	
397	97	20	0.9982	0.2380	73	0.784	8.00	1.300	13.26	56.5	0	100.1	23.1	56.5	40.2	1.0	
VM-Npsh /1		Q-Management		B.V. / v.Ah		Rev. 0 / 25 6.98.								PRU-VM-Npsh98			
Because of the system losses, a booster pump was used on the discharge pipe, giving a negative pressure reading on the NPSH-test.																	




Verification of information

according ISO 2548 class = C


Client:	Weir Engineering Pty Ltd	Date :	16.09.2004
Pump type:	H08K-M02R + HEVT4-XMEK	Order No. :	04.05.353
		Fab-No. :	138076

Information points: at 50 Hz.

Volume rate of flow Q:	100 l/s = Q_g
Pump total head H:	36 m = H_g
NPSH :	4.1 m



NPSH-Test at 50 Hz. and 100.09 l/s



Verification of the information:

NPSH at 100.09 l/s
1.90 m

Tolerances factors:

XQ: **0.07**
XH: **0.04**

NPSH: **-3 % of H or η :**

NPSH 1.90 m is lower than 4.10 m



VM-Npsh /3	Q-Management	B.V./v.Ah	Rev. 0 /21.06.98
------------	--------------	-----------	------------------



Verification of information


according ISO 2548 class = C

Client: **Weir Engineering Pty Ltd**
Pump type: **H08K-M02R + HEVT4-XMEK**


Date : **16.09.2004**
Order No. : **04.05.353**
Fab-No. : **138076**

Information points:
at 50 Hz.

Volume rate of flow Q: **300 l/s = Q_g**
Pump total head H: **10 m = H_g**
NPSH : **5.2 m**



NPSH-Test at 50 Hz. and 300.03l/s



Verification of the information:

NPSH at 300.03 l/s
4.47 m

Tolerances factors:


XQ: **0.07**
XH: **0.04**

NPSH: **-3 % of H or η :**

NPSH 4.47 m is lower than 5.20 m




VM-Npsh /3 Q-Management B.V./v.Ah Rev. 0 /21.06.98

		NPSH - Pump test record for venturi meterrun measurements										Date: 16.09.2004																																																																																																																																																																																																																		
with Motor		According to ISO standard 5167										Signature: H.P.M.																																																																																																																																																																																																																		
Order-No. : 04.05.353 Client : Weir Engineering Pty Ltd Your Order : P.O.70891 Fab-No. : 138076 Pump type : H08K-M02R + HEVT4-XMEK Impeller : Prod. Impeller Clearance : 0.4 mm.						Motor data				Constant for test bed																																																																																																																																																																																																																				
						Motor-Typ : HEVT4-XMEK P nominal : 60.0 kW Speed : 1471 R.P.M. P1 max. : 71.0 kW Voltage : 400 V Cycles : 50 Hz Current max.: 117.0 A η Motor : 100 %				Z1 : 0.760 m Z2 : 0.710 m D2 Delivery pipe : 0.200 m D1 Suction pipe : 0.300 m Venturi specifications, size : 300 Throat diameter d : 0.177 m. Diameter ratio β : 0.571 d/D Coefficient of discharge C : 1.002 Atmosph. pressure. : 9.888 m																																																																																																																																																																																																																				
<table border="1"> <thead> <tr> <th colspan="10">Measured values at 50 Hz</th> <th colspan="8">Calculated a test speed</th> </tr> <tr> <th>U</th> <th>I</th> <th>W.Temp.</th> <th>density</th> <th>Va.pres.</th> <th>Venturi</th> <th colspan="2">H1-inlet</th> <th colspan="2">H2-outlet</th> <th>P1</th> <th>ZZ</th> <th>Q</th> <th>H</th> <th>P1</th> <th>η</th> <th>NPSH</th> </tr> <tr> <th>Volt</th> <th>A</th> <th>C°</th> <th>kg/dm³</th> <th>m</th> <th>mb.</th> <th>x factor</th> <th>m</th> <th>x factor</th> <th>m</th> <th>kW</th> <th>m</th> <th>l/s</th> <th>m</th> <th>kW</th> <th>%</th> <th>m</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>10.2</td> <td></td> <td>10.2</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>Overall</td> <td></td> </tr> <tr> <td>396</td> <td>88</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.142</td> <td>1.45</td> <td>0.390</td> <td>3.98</td> <td>51.1</td> <td>0</td> <td>300.0</td> <td>10.6</td> <td>51.1</td> <td>61.2</td> <td>8.4</td> </tr> <tr> <td>396</td> <td>88</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.142</td> <td>1.45</td> <td>0.340</td> <td>3.47</td> <td>51.0</td> <td>0</td> <td>300.0</td> <td>10.1</td> <td>51.0</td> <td>58.3</td> <td>8.4</td> </tr> <tr> <td>396</td> <td>87</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.210</td> <td>2.14</td> <td>0.250</td> <td>2.55</td> <td>50.6</td> <td>0</td> <td>300.0</td> <td>9.9</td> <td>50.6</td> <td>57.5</td> <td>7.7</td> </tr> <tr> <td>396</td> <td>89</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.321</td> <td>3.27</td> <td>0.140</td> <td>1.43</td> <td>51.8</td> <td>0</td> <td>300.0</td> <td>9.9</td> <td>51.8</td> <td>56.2</td> <td>6.6</td> </tr> <tr> <td>396</td> <td>90</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.413</td> <td>4.21</td> <td>0.070</td> <td>0.71</td> <td>52.1</td> <td>0</td> <td>300.0</td> <td>10.1</td> <td>52.1</td> <td>57.2</td> <td>5.6</td> </tr> <tr> <td>396</td> <td>90</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.523</td> <td>5.33</td> <td>-0.080</td> <td>-0.82</td> <td>52.1</td> <td>0</td> <td>300.0</td> <td>9.7</td> <td>52.1</td> <td>54.9</td> <td>4.5</td> </tr> <tr> <td>396</td> <td>90</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.531</td> <td>5.42</td> <td>-0.200</td> <td>-2.04</td> <td>52.0</td> <td>0</td> <td>300.0</td> <td>8.6</td> <td>52.0</td> <td>48.5</td> <td>4.4</td> </tr> <tr> <td>396</td> <td>81</td> <td>20</td> <td>0.9982</td> <td>0.2380</td> <td>656</td> <td>0.536</td> <td>5.47</td> <td>-0.530</td> <td>-5.41</td> <td>46.8</td> <td>0</td> <td>300.0</td> <td>5.3</td> <td>46.8</td> <td>33.1</td> <td>4.4</td> </tr> </tbody> </table>																		Measured values at 50 Hz										Calculated a test speed								U	I	W.Temp.	density	Va.pres.	Venturi	H1-inlet		H2-outlet		P1	ZZ	Q	H	P1	η	NPSH	Volt	A	C°	kg/dm³	m	mb.	x factor	m	x factor	m	kW	m	l/s	m	kW	%	m							10.2		10.2							Overall		396	88	20	0.9982	0.2380	656	0.142	1.45	0.390	3.98	51.1	0	300.0	10.6	51.1	61.2	8.4	396	88	20	0.9982	0.2380	656	0.142	1.45	0.340	3.47	51.0	0	300.0	10.1	51.0	58.3	8.4	396	87	20	0.9982	0.2380	656	0.210	2.14	0.250	2.55	50.6	0	300.0	9.9	50.6	57.5	7.7	396	89	20	0.9982	0.2380	656	0.321	3.27	0.140	1.43	51.8	0	300.0	9.9	51.8	56.2	6.6	396	90	20	0.9982	0.2380	656	0.413	4.21	0.070	0.71	52.1	0	300.0	10.1	52.1	57.2	5.6	396	90	20	0.9982	0.2380	656	0.523	5.33	-0.080	-0.82	52.1	0	300.0	9.7	52.1	54.9	4.5	396	90	20	0.9982	0.2380	656	0.531	5.42	-0.200	-2.04	52.0	0	300.0	8.6	52.0	48.5	4.4	396	81	20	0.9982	0.2380	656	0.536	5.47	-0.530	-5.41	46.8	0	300.0	5.3	46.8	33.1	4.4
Measured values at 50 Hz										Calculated a test speed																																																																																																																																																																																																																				
U	I	W.Temp.	density	Va.pres.	Venturi	H1-inlet		H2-outlet		P1	ZZ	Q	H	P1	η	NPSH																																																																																																																																																																																																														
Volt	A	C°	kg/dm³	m	mb.	x factor	m	x factor	m	kW	m	l/s	m	kW	%	m																																																																																																																																																																																																														
						10.2		10.2							Overall																																																																																																																																																																																																															
396	88	20	0.9982	0.2380	656	0.142	1.45	0.390	3.98	51.1	0	300.0	10.6	51.1	61.2	8.4																																																																																																																																																																																																														
396	88	20	0.9982	0.2380	656	0.142	1.45	0.340	3.47	51.0	0	300.0	10.1	51.0	58.3	8.4																																																																																																																																																																																																														
396	87	20	0.9982	0.2380	656	0.210	2.14	0.250	2.55	50.6	0	300.0	9.9	50.6	57.5	7.7																																																																																																																																																																																																														
396	89	20	0.9982	0.2380	656	0.321	3.27	0.140	1.43	51.8	0	300.0	9.9	51.8	56.2	6.6																																																																																																																																																																																																														
396	90	20	0.9982	0.2380	656	0.413	4.21	0.070	0.71	52.1	0	300.0	10.1	52.1	57.2	5.6																																																																																																																																																																																																														
396	90	20	0.9982	0.2380	656	0.523	5.33	-0.080	-0.82	52.1	0	300.0	9.7	52.1	54.9	4.5																																																																																																																																																																																																														
396	90	20	0.9982	0.2380	656	0.531	5.42	-0.200	-2.04	52.0	0	300.0	8.6	52.0	48.5	4.4																																																																																																																																																																																																														
396	81	20	0.9982	0.2380	656	0.536	5.47	-0.530	-5.41	46.8	0	300.0	5.3	46.8	33.1	4.4																																																																																																																																																																																																														
VM-Npsh /1 Q-Management				B.V. / v.Ah				Rev. 0 / 25 6.98.				PRU-VM-Npsh98																																																																																																																																																																																																																		
Because of the system losses, a booster pump was used on the discharge pipe, giving a negative pressure reading on the NPSH-test.																																																																																																																																																																																																																														



INSPECTION & TEST PLAN						PAGE: 1 of 3								
CUSTOMER/PROJECT: Leighton Contractors - SP298 EQUIPMENT: Submersible Sewage Pumpsets					ORDER REF: Q1112-SA-005 WSA CONTRACT REF: 208888		DATE: 30/08/04 ITP: 510 Rev: 3							
ITEM NO. 1 DRAWING NO: Various S/C: Hidrostal AG COMPONENTS: SP298 Lytton Road Pump Station = 2 off H08K-M02R+HE5T4-XSEK+NDB6-12 MATERIAL: Various					KEY TO INSPECTION ACTIVITIES H - Hold point W - Witness S - Surveillance R - Review N - Notification DR - Document Req'd.									
NO	PROCESS DESCRIPTION/ACTIVITY		PROCEDURE	ACCEPTANCE STANDARD	CERTIFYING OR VERIFYING DOCUMENT	INSPECTIONS								
						WSA KEY	SGN	Supplier KEY	SGN	Customer KEY	SGN	Contractor KEY	SGN	
1	Contracts Review	W	AC-P-05	ISO 9001:2000	AC-F011 v 2.2									
2	Order Placement for Hidrostal Pumps	W	AF-P-01	ISO 9001:2000	PO No. 70891									
3	Production of Units	C	Hidrostal QA Protocol No 03-TU6555a	ISO 9001:2000	98 QM 5862E/c									
4	Hydrotest	C		150% max op. Press Hold 30mins	Hydrotest Certificate	R		DR			R			
5	Performance Testing to ISO 2548 Class C at the following duty points;	C	ISO 2548 Class C	ISO 2548 Class C	Test Certificates	H		DR			R			
	G.P. = 200 l/s @ 22.5m, NPSH R = 5.2m							DR						
	T.P. = 300 l/s @ 10m, NPSH R = 3.0m							DR						
	T.P. = 100 l/s @ 36m, NPSH R = 4.1m							DR						
6	Approval of Hidrostal Test Results	C	ISO 2548 Class C	ISO 2548 Class C		R		DR			R			
7	Dispatch by Seafreight	C	Freight Forwarder		Consignment Documents			DR						

ORIGINAL ISSUE PREPARED BY: MR APPROVED BY: RP		KEY TO LOCATION ACTIVITIES W - WSA S - Supplier C - Sub Contractor E - Site		 WEIR SERVICES AUSTRALIA PTY LTD 15 Gindarra Rd Somersby NSW 2250	
--	--	---	--	--	--

Form IIS Rev 1

4. Operation and Maintenance

4.1. Start-up

The pump is ready to start when the following has been completed:

- a) All construction debris has been removed from suction well.
- b) Base plate or suction elbow is bolted to the foundation.
- c) All rotating parts are found to turn freely by hand.
- d) Motor has been checked for correct rotation, which is counter-clockwise viewed from suction end (section 2.2.6).
- e) Suction and discharge gate valves are completely open.
- f) All level controls are correctly set. The off-level is sufficiently high to prevent air entrance to the pump section.
- g) Never run a pump dry, as the liquid in the pump serves as lubricant for close running surfaces. Damage may be caused to the pump if operated dry for extended period of time.

Note:

If installed with suction lift, the pump may be primed by using an ejector or vacuum pump. Vertically installed Hidrostal solids handling pumps will prime themselves if impeller tip is submerged in the pumping liquid, and an automatic air vent is connected to the pump casing or discharge pipe work (between pump and non-return valve).

4.1.1. Starting of Pump

Never start pump against closed valves (except non-return valves). Start the pump using manual operation. Measure the amperage drawn on each phase leg. Record and verify these readings with the nameplate ratings. If amperage is more than 5 % higher, stop pump and check probable causes according to "Operating Troubles" chart (Section 4.1.3.).

Once preliminary checks are complete, place the pump into automatic operation. Cycle the system through several wetwell pumpdowns to observe that level controls are properly set and functioning correctly. Observe that the alarm system and change over switch (if included in control panel) are working properly.

Log date and hours meter reading, and set pump for automatic operation. Perform maintenance according to Section 4.2.

4.1.2. General Operating Conditions

The pump should not be allowed to operate continuous-duty outside of performance curve: high discharge pressure with low flow or low discharge pressure with high flow. Bearing life is shortened and abrasive wear is accelerated in these operating conditions.

4.1.3. Operating Troubles

<div>POSSIBLE REASON</div> <div>TROUBLE</div>	No Flow	Flow not sufficient	Head not sufficient	Reduction of flow or head after start up	Vibration	Motor overload	Noise	Motor does not start
1. Pump not fully filled with water, not vented	X							
2. RPM too slow	X		X					
3. RPM too high					X	X	X	
4. Air entrance into suction line	X	X		X	X		X	
5. Discharge line clogges / valve closed	X				X	X		
6. Air or gas in pumped liquid	X	X	X	X	X		X	
7. TDH too high (higher than calculated)	X	X			X			
8. Suction head too high				X	X		X	
9. Insufficient suction head on hot liquids		X			X		X	
10. Insufficient submergence of suction	X	X	X	X	X		X	
11. Sludge concentration higher than assumed		X	X			X		
12. Specific weight of medium higher than assumed						X		
13. Impeller or suction line clogged	X	X			X			
14. Wrong direction of rotation	X	X	X					
15. Impeller clearance too high		X	X					
16. Damaged impeller		X	X		X			
17. Thermal overload tripped, control switch off								X
18. Motor damage					X	X	X	X
19. Low voltage		X	X			X		X
20. Attachment loose					X		X	
21. Coolent loss						X		
22. Bearing worn out					X			
23. Impeller out of balance					X			
24. Impeller dragging against suction cover					X	X	X	
25. Thick sludge and tight impeller clearance						X		
26. Air or gas on impeller backside	X		X					

4.2. Maintenance and Service

4.2.1. General

Before doing any work on the pump unit, switch off main isolator switch and remove fuses from panel. The following checks (Section 4.3.) can be done in the field. When a repair is indicated, send the pump unit to Weir Service Australia.

Caution:

When disconnecting the power cable at the control panel, take care that the cable ends **CANNOT** come in contact with water. Replace the plastic cable-end shipped with the pump (if this is no longer available, wrap the cable ends inside a plastic bag, and seal with tape) for water-tightness during handling and shipping.

4.2.2. Pump Cooling

Hidrostal immersible motors can be operated on continuous duty either submerged in the liquid or totally outside of the liquid (as in dry-pit installation).

Opening "R"

Opening "MOT"

Opening "F"




fig 5.

Internal Cooling

This type transfers motor heat from the stator into a cooling oil which is circulated through a cooling jacket surrounding the stator housing. The oil then transfers this heat to the pumped media

through the motor seal chamber (pump backplate), which acts as a heat-exchanger. The oil is circulated by an impeller on the motor shaft.

4.2.3. Impeller Clearance Adjustment for Wear

The impeller gap should be checked and readjusted whenever a significant decrease in pump performance is noticed, or at least once every year (until experience indicates how often this will be required).

- Excessive clearance can cause a drop in performance.
- Less clearance than the minimum listed can overload the motor and/or cause vibration due to a too great friction.
- When pumping thick sludges or high consistency material, it may be necessary to double the clearances in Fig 7.
- Regulable pumps are adjusted by means of a movable liner (421); its position is regulated by three external regulator nuts (422) found on the suction casing (416) or volute casing (400).
- Loosen and back off hex nuts (413) on end of each regulator nut (422). Now slowly and evenly screw in each large threaded regulator nut just until pump shaft cannot be turned (this will eliminate all clearance between the impeller and the liner). Be sure to take the same number of turns on each threaded regulator nut; this keeps the liner concentric to the impeller.

Note: If impeller tip is binding, see section 4.4.12.

Now back off the threaded regulator nut a bit. Holding each threaded regulator nut from turning, tighten the three hex nuts (413) (this pulls liner (421) away from impeller (401) the required clearance, and also locks the regulator nut in place).

With a feeler gauge, check the actual clearance between impeller and liner (reaching in through the suction of the pump). If the clearance "C" is significantly different to the table (Fig. 7), it is possible that the wear is excessive or not uniform: disassembly and inspection is recommended.




fig 6.




Fig 7.

4.3. Field Tests

4.3.1. Visual Checks

- Check pump and motor for possible mechanical damage. Pay attention to the cable.
- If pump volume or pressure are not acceptable, check impeller clearance (see manual for hydraulic).
- Check overload relay, fuses and time relays (if any) for correct setting.
- Check correct function of level control.
- Check insulation resistance of motor windings and cables with a high-voltage ohm-meter ("megger").

This initial test should be made from the point where the cables attach to the motor starter. Check from each winding lead to the other two winding leads and to the ground lead.

Insulation Chart		
Condition of Motor and Cables	OHM Value	Megohm value
A new motor	2 000 000 (or more)	2
A used motor which can be re-installed in well	1 000 000 (or more)	1
Motor In Pit. Ohm readings are for cable plus motor. A motor in the pit in reasonable good condition	500 000 – 1 000 000	0.5 – 1.0
A motor which may have been damaged by lightning or with damaged leads. Do not pull the pump for this reason	20 000 – 500 000	0.02 – 0.5
A motor which has wet or damaged cable or windings. The pump should be pulled soon and repairs made to the cable or the motor dried and replaced. The motor will not fail for the reason, but it will probably not operate for long.	10 000 – 20 000	0.01 – 0.02
A motor which has failed or with completely destroyed cable	Less than 10 000	0 – 0.01

insulation. The pump must be pulled and repaired or the motor replaced.		
---	--	--

- The motor will probably not operate for long.
- The motor will not run in this condition

Caution:

Do NOT "Megger test" control leads when thermistors are fitted: Voltages over 2,5 V will cause thermistors to fail, and may destroy the winding. Any reading less than 1.0 Megohm could indicate failure of cable or winding insulation. If failure is indicated, remove pump with cable and proceed to Section 4.3.6. for further tests.

4.3.2. Motor Housing Test

This test consists of a check on the condition of the motor side mechanical seal and/or motor housing "O"- rings. Stand pump vertically on its suction flange. Remove screw plug "MOT" (Fig. 7) with copper washer (536) so that any liquid can run out. Do the following repairs according to what comes out of the motor housings:

WATER

MIXTURE WATER/OIL = General overhaul with change of bearings and seals

OIL = Change motor side mechanical seal (Pos. 516)

NO LIQUID (DRY) = Stator housing is OK. No defect.

Caution:

This screw plug must be completely watertight. Sealing surfaces must be clean and smooth before assembly. Heat new copper ring to dull red and immediately quench in water to soften copper ring for best seal. All copper rings supplied by Hidrostal are softened.

4.3.3. Oil Check

This is a check on the condition of the pump side mechanical seal. For pump units supplied with a moisture probe, total failure of the pump side seal will be indicated by activation of the resistance relay. A failure can be detected by the following oil check, even without this circuit.

Oil checking must be done after the first 1'000 hours of operation and once a year thereafter.

Immediately before checking, run the pump for a few minutes to distribute any impurities throughout the oil. Raise the pump out of the sump and clean it with a water hose.

Oil Level Check

Stand pump with shaft vertical and remove screw plug "R". Oil level must be at the level of opening "R" (Fig. 8).

If coolant is far below this level, the pump side mechanical seal may have leaked and may require replacement (section 4.4.1.). If oil level is only a small amount below this level, proceed with following test. Top-up with new oil and recheck in 200 to 500 hours.




Fig 8.

Oil quality check

Lay pump down horizontally with opening "OIL" (536a) upwards. Remove screw plug "OIL". Insert a tube or rubber hose, place a finger over top of tube and remove it with a small sample. Repeat until a sufficient quantity has been collected for observation. Evaluation will show one of three conditions:

- If oil is clear there are no problems with the pump side seal. Top up with oil and close opening "OIL" with screw plug and a new softened copper seal ring.
- If there is just a little water in the oil but the oil is clear, repair of the pump is not necessary. Remove oil and separate water from oil (Section 4.3.4.).

Pour back the clean oil into the mechanical seal housing and close opening with screw plug "OIL" and softened copper seal ring (536). However, check oil quality again after 500 hours of operation.

With a new mechanical seal (515) it is possible that during the run-in period a small amount of water could enter into the oil chamber. Thus, if at the first check after start-up a small quantity of water is detected, it can be neglected. Oil with a small amount of water will be milky in appearance, but will still be of very low viscosity, that is, it will still run much more freely than motor oil, almost as thin as kerosene.

- If too much water has entered the oil, the viscosity will be much higher, then oil will be as thick as motor oil or even thicker. In this case, or when sludge or sewage smell are detected in the oil, the pump side mechanical seal (515) must be repaired or replaced.

For oil removal as indicated in (b) above or for prior to a major repair refer to Section 4.3.4.

Replace oil with new oil only if strongly contaminated, otherwise separate water from oil and re-use oil. Required oil must be extremely low viscosity. Factory uses the following oil:

Specific Gravity at 20 °C	0.812 g/ml
Viscosity at 20 °C	6.750 mm ² /s (cst)
Viscosity at 40 °C	3.520 mm ² /s (cst)
Solidification point	-38.000 °C
Flash point	132.000 °C
Burning point	142.000 °C
Evaporation point	251.000 kJ/kg
Solubility in water	none

Other recommended oils:

Shell Pella A or S5585, Gulf mineral seal oil 896 or others with equal specification as above: The specified low viscosity is very important for proper cooling.

4.3.4. Oil Change for Internal Cooled Motors

Remove screw plugs "OIL" and "R" (Fig. 9) and drain oil chamber casing and cooling jacket completely by turning the pump around slowly, until openings "OIL" and "R" are upside down (Fig. 9). When oil has completely drained, re-install screw plug "OIL" with softened copper seal ring. Place pump vertically.




Fig 9.

Refill with separated oil or new oil of correct specification. The pump is full when the oil is flush with opening "R" (536) and the motor is in vertical position. Re-install screw plug "R", with softened copper seal ring.

4.3.5. Greasing Instructions

Hidrostal motors use bearings which are grease lubricated. For re-lubrication, grease is hand packed into the bearings when the motor is disassembled during a major overhaul. Sufficient grease is provided initially and at each overhaul to allow for the number of operating hours between overhauls ("Overhaul Chart", Section 4.3.8.). The overhaul should be done by an authorized Hidrostal service center.

Caution:

The overhaul of Ex-proof-motors must be done in the factory or in an authorized Hidrostal service center, otherwise the Ex-certification will be invalidated. No other lubrication service is required between overhauls for these motors. For regreasing we recommend:

STABURAGS NBU 8 EP by Kluber-Lubrication.

This grease is of a mineral oil base containing a barium complex as thickener.

Typical characteristics:

Colour	beige	mPas
Apparent dynamic visc. (approx)	6000	⁰ C
Operating temperature range	-30..150	⁰ C
Max. temperature (short time)	170	
Consistency class (NLGI)	2	
Penetration DIN ISO 2137 (0.1 mm)	280	
Dropping point DIN ISO 2176	>220	⁰ C
Corrosion protection DIN 51802	0	
RPM-parameter (n x d m)	5 x 10 ⁵	

4.3.6. Motor Cables

Whenever opening motor housing, it is imperative that all O-rings have to be replaced with new items supplied from Hidrostat. O-rings glued-up from bulk stock are totally unsatisfactory for this critical application; the glued joint will inevitably leak water into the motor after a short time.

If tests conducted through the cables in the field (Section 2.6.3.1) showed insufficient insulation resistance, and if humidity relay has not tripped (continuity exists between lead 1 and 2), it can be assumed that the insulation failure is in the cable rather than in the stator. Remove fasteners (509) and carefully lift off cable cover.

Cut the leads between cable and winding and now make a separate "megger" test on cable and winding. If windings are at fault, send the entire motor to the nearest authorized Hidrostat service station. If cable is at fault, a new cable set can be installed.

4.3.7. Re-connection of Cable

Place O-ring (525) into position around the seal face on cover (500). Cables should be re-connected to the winding leads, using new insulated splices. Take care that this insulation is rated for 110° C.

4.3.8. Test for Leaks

Before putting the pump back into operation after opening of the motor (as when changing cables), a test for leaks should be carried out as follows:

Connect source of dry air (from air compressor or bicycle hand pump) to opening left by removal of plug "MOT" (Fig. 7). Air pressure should be a maximum of 0.5 bar (7 psi). Motor should then be totally submerged in a test tank.

Caution:

Do not immerse loose end of cables. If any continuously escaping bubbles are detected, motor cover is not water-tight. The preceding procedure for cable installation should be repeated to eliminate leaks.

Caution:

The overhaul of Ex-motors must be done in factory or in a authorized Hidrostral service center, otherwise the Ex-certification will be invalidated.

Motor Type	Motor side seal	Pump side seal	Seal oil lit.	Hrs before regreasing
HE5T4	3"	3"	44	35'000

4.4. Assembly Disassembly

4.4.1. Replacement of Mechanical Seal

Pump Side Mechanical Seal

Stainless-steel-shroud seal - type "X"

Remove all three small setscrews from outer body of rotating part. Remove snap ring (546). Oil the shaft for ease of disassembly. Now the seal rotating part can be pulled off the shaft by hand.




Fig 10.

Remove static part of the mechanical seal as follows:

Unfasten nuts (534) and carefully remove back cover or mechanical seal plate (507) from oil chamber casing. Make sure that the static part of the seal (515) does not hit the shaft so that the ring can't be damaged. Now the static part of the seal can be carefully pushed out of the chamber from the back side. Some Hidrostral seals can be repolished or repaired (Consult WSA). When sending a seal for inspection or repair, it is important to thoroughly protect the seal faces to prevent damage during transportation.




Fig 11.

Maintenance of Motor Side Mechanical Seal

It is **IMPORTANT** to note that removal of this seal should not be attempted in the field. If leakage of this seal has been detected from the motor housing test as described in Section 4.3.2, the entire motor should be sent to WSA center for a complete inspection.

4.4.2. Assembly of Back Cover

Cleanliness is of utmost importance for this assembly work! All parts must be washed in solvent before assembly. All machined mating surfaces must be clean and free from burrs. All grooves and seatings for "O"-rings and other static seals must be inspected for nicks or scratches. All threads must be clean especially those in holes for studs. All "O"-rings **MUST** be replaced with new ones and they should be lubricated with light oil prior to assembly.

Warning:

Never use "O"-rings glued from "O"-ring stock. Our experience is that this glue joint will inevitably leak.

Place a new "O"-ring (527) on the oil chamber casing (504). Carefully assemble back cover or mechanical seal plate (507) to the oil chamber casing and fasten with fastening set (534).

4.4.3. Assembly of Pump Side Mechanical Seal


Stationary seat (all types)

Lubricate the rubber circumference of the static mechanical seal part and carefully press all the way into its seat in the back cover or mechanical seal plate (507). The ring must fit tightly in place. Protect the seal face during this operation. Examine gap between shaft and inner diameter of seal face; when face is correctly installed, gap will be uniform all the way around.

Warning:

The seal face is very brittle, and can easily snap unless pressure is uniform during installation. We suggest pushing in with special tool (Fig. 12).

Make sure that the shaft is free of burrs and has no sharp edges, so that the rubber part or the mechanical seal cannot be damaged. File groove edges if necessary.



R	S	T	U	V	W	X	BOLT SIZE
92 +/-1	77 +1/-0	100 +/-1	29	110	170	5	M27

Fig 12.

Stainless-steel-shroud seal - type "X"

Lubricate inner rubber O-rings of seal and put a small amount of oil onto shaft. Install entire seal over shaft, and press gently down shaft until rotating face touches stationary face. Now install snap ring over shaft, and push until it snaps into its groove.

If necessary use the special tool (Fig. 12). Then reinstall the three small setscrews into the seal rotating part, and tighten firmly.

4.4.4. Leak Test for Pump Side Mechanical Seal

Remove screw plug "OIL" (536) and drain the oil from the motor. Connect dry compressed air source such as bicycle tyre pump to the opening. Use a pressure reducing valve and relief valve set to 0.5 bar (7 psi).

Warning:

- Make sure that the pressure never exceeds 1 bar. This could displace the seal.
- Immerse the motor into a test tank full of water and watch for continuously escaping bubbles. This would indicate leakage past the seal or associated "O"-ring.
- Do not immerse end of cable!
- Correct failure if leakage has been found. After finishing tightness test remove pressure connection hose and fill with oil according to Section 4.3.4.

4.4.5. Disassembly of Hydraulic Parts

Casing-suction cover assembly should be placed with the suction flange flat on the floor or workbench, and the drive unit-impeller assembly removed or lowered into place from above by a suitable hoist. Remove nuts (419) around the flange. Lift the rotating assembly including impeller from the pump casing. Areas to be examined for wear will be the impeller surface (especially the edges) and the conical machined surface in the liner or suction cover. Uniform wear on any of these surfaces can be compensated by reshimming or adjusting according to Section 4.2.3. However, excessive or uneven wear will require replacement of the worn parts.

4.4.6. Removal of Impeller

Hold the impeller (401) from turning by hand, or by a strap wrench, or by locking pliers clamped to the impeller. Inset a hexagonal key wrench into the impeller bolt (415) and with a hammer, tap the wrench counterclockwise to loosen the bolt.

Factory Fitted Impeller Bolts		
Size	Hexagon SW	Torque Nm
M27	19	380

4.4.7. Removal of Impeller Flange

If existing, disengage tabs on locking washer (167) and remove impeller nut (166) with coupling end of shaft secured from rotation. Remove impeller flange (165) by either levering with two screw drivers between impeller flange and back cover (507) or seal plate (511) or tapping with a rubber mallet at 90° intervals. Or, it may be required to use a gear puller. Remove Woodruff key (112).

Hydraulic size	Cone size	Impeller nut size	wrench size	Thread size "M"
E	28	-	-	M12
E	38	M28	41 mm	M12




Fig 13.

4.4.8. Removal of Liner

This pump has an externally-adjustable liner (421), held in place by the volute casing (400) or the suction casing (416) which is bolted to the volute casing (400) by studs and nuts (417). This construction can be recognized by the presence of three large regulator nuts (422). If the conical surface is worn, the liner need be replaced. It can be removed while the volute casing or suction casing remain attached to the piping. Alternately, the suction casing may be removed by removing nuts (417).

Removing of liner: completely remove nuts (413). To force the liner out, push the three studs through the holes in the large regulator nuts (422), or the large regulator nuts can be turned all the way into the casing.

Do not yet disassemble the regulator studs (412)! They are loctited in place, and must be heated with a torch to break the loctite bond after removing of the liner.

The wear ring (408) should only be removed from suction casing or volute casing if badly damaged. Therefore heat the mating surfaces with a torch to destroy the special adhesive between these two parts. Then press out suction ring with a hydraulic press (Fig. 14).




Fig 14.

4.4.9. Assembly of Impeller Flange

If existing, put in Woodruff key (112), coat the shaft taper with an anti-rust paste, put on the impeller flange (165), the locking washer (167) and the nut (166). The nut must be tightened to 120 Nm (90 ft-lbs) by using torque wrench. Bend over locking washer tab.

4.4.10. Assembly of Impeller

If impeller (401) with impeller flange (165) is used, mount it so that the pin (410) on back of impeller will fit in the corresponding hole on flange. Before fitting a new impeller or a new impeller bolt, length "L" of impeller bolt should be checked as follows:

By measuring of the impeller and the impeller bolt, it must be secured that:

- a) thread reach "L" is $1.25 \times$ thread diameter, e.g. M16:

$$16 \times 1.25 = 20 \text{ mm.}$$

- b) end of thread "G1" on impeller bolt is sufficient (re-cut the thread).
- c) end of thread "G2" in the shaft is sufficient (shorten impeller bolt, see point 1.).

Attention:

Oil shaft taper slightly with a shred. NEVER use thick oil, grease or anti-size compound! Install impeller directly onto shaft. Coat the impeller bolt thread with grease or anti-size compound. Tighten screw with torque according table 3.3.2.

Note:

If torque wrench not available, torque can be approximated with an extension pipe and weight.

4.4.11. Assembly of Liner

Glue three regulation screws (412) into liner (421). Thoroughly grease O-ring (430) and install into groove in suction casing (416). This groove is nearly hidden by the wear ring in some pump models.

If wear ring (408) was removed, glue it firmly back into place. Tap wear ring into suction casing with a lead hammer, until wear ring is flush with flange surface.

Grease the external threaded portion of large regulator nuts (422), and install these into the suction casing (416), hex-side toward the outside, direction to the suction flange. Screw these into the suction casing until they are flush with the inside.

Now grease O-ring (431) and install it into groove of wear ring (408, if there is no wear ring, this O-ring is not used).

Now place liner into suction casing or volute casing, engaging the three stud bolts into the holes through the three regulator nuts.

Note:

The three stud bolts are not spaced evenly around the liner, so there is only one orientation of the liner where the bolts will correctly fit through the regulator nuts.

Install suction casing into down-side of the volute casing with fastening set (417).

Caution:

Since up-side and down-side of the volute casing are machined identically in some models, it is potentially possible to assemble the volute casing in a wrong way. Form of the volute casing.

4.4.12. Final Assembly

When ONLY a new impeller is fitted, the following clearance check must be done: install drive unit-impeller assembly into volute casing. If the tip of the impeller touches the wear ring (408) or the lip in the liner (or suction cover) or if there is less than 1 mm clearance between the tip and the lip (the spiral edge of the impeller is firmly seated against the conical taper inside the liner or suction cover), then the impeller tip must be ground off, parallel to the suction flange, until 1 to 2 mm clearance is obtained (Fig. 15).




fig 15.

If (411) is a spacer ring in lieu of shims place it over the spigot of the drive unit. Grease O-ring (209) and place into groove on spigot of the drive unit. Now install drive unit-impeller assembly into volute casing. Install and tighten nuts (419). See Section 3.2 for correct setting of regulator nuts, or for placement of shims (411) for final adjustment of impeller clearance.

4.5. Recommended Spare Parts

Description	Part No.	Qty	Pos
Impeller flange	2SF-H75	1	165
Impeller nut	2FM-56	1	166
Impeller bolt	4B1-27/14&	1	415
Suction casing	4H1-H08KM	1	416
Liner	4K2-H08KM	1	421
Ball bearing	8LW-6314Z	1	513
Mechanical seal	8DM-X3.0/C	1	515
Mechanical seal	8DM-G3.0	1	516
Angular contact ball bearing	8LW-7217BGUO	1	121
Angular contact ball bearing	8LW-7317BG	2	121
Oil seal	8DS-080/100BA	1	555

4.6. Section Arrangement

4.6.1. Pump




Fig 16

Description	Part No.	Qty	Pos
Woodruff key	2FK-75	1	112
Impeller flange	2SF-H75	1	165
Impeller nut	2FM-56	1	166
Impeller locking washer	2FF-56	1	167
Volute casing	4G1-H08K/C	1	400
Impeller	411-H08KM	1	401
Inspection cover	451-INSP.A	1	405
O-Ring	8DO-7/430	1	406
Wear ring	4R2-H08K	1	408
O-Ring	8DO-5/115	1	409
Shaft sleeve pin stainless	8FZ-12R30	1	410
Set of shims	8UR-16	8	411
Regulating screw	4S1-16B130	3	413
Spring washer	8FF-16R	3	413
Hexagon nut	8FM-16R	3	413
Impeller bolt	4B1-27/14&	1	415
Suction casing	4H1-H08KM	1	416
Fastening Set	8BB-16/090C	8	417
Fastening Set	8BB-16/045B	8	419
Fastening Set	8BB-12/035B	2	420
Liner	4K2-H08KM	1	421
Distance bush	4BD-16/18	3	422
Regulating nut	4V1-16A062/B	3	422
Hexagon socket pipe plug	8FO-1/2	1	423
Hexagon socket pipe plug	8FO-1/2	1	424
O-Ring	8DO-7/270	1	430
O-Ring	8DO-5/450	1	442

4.6.2. Motor





Fig 17

Description	Part No.	Qty	Pos
Stator lamination	5ES-5MT4	1	0
Oel chamber casing	5GO-5H3.0ES	1	0
Spacer ring for disassembly	5SA-5M/H	1	0
Moisture probe internal	8EF-INTERN/EXL	1	0
Protecting cap	8EH-06	2	0
Spacer ring	8RS-085/3.5	1	104
Angular contact ball bearing	8LW-7217BGUO	1	121
Angular contact ball bearing	8LW-7317BG	2	121
Lock nut for shaft	8LM-KM17	1	126
Locking washer	8LF-MB17	1	127
O-Ring	8DO-7/430	1	209
Socket set screw	8FG-16R20K	8	231
Motor cover	5DM-5	1	501
Stator lamination	8ES-5T4MTE1	1	502
Stator lamination	8ES-5T4MTG1	1	502
Shaft motor	8ER-5HHMT4	1	503
Oel chamber casing	5GO-5H3.0E/B	1	504
Bearing cap	5DL-5HN	1	505
Back cover	5GD-H5/3.0	1	507
Ball bearing	8LW-6314Z	1	513
Mechanical seal	8DM-X3.0/C	1	515
Mechanical seal	8DM-G3.0	1	516
Spring washer	8FF-06R	4	520
Hexagonal bolt	8FS-06R012	4	520
O-Ring	8DO-5/330	1	524
O-Ring	8DO-5/160	1	525
Ring rolled	5RD-5	1	526
O-Ring	8DO-7/393	1	526
O-Ring	8DO-5/350	1	527
O-Ring	8DO-7/388	1	529
O-Ring	8DO-5/290	1	530
Fastening Set	8BB-16R035F	8	532
Fastening Set	8BB-10/030A	4	533
Fastening Set	8BB-12R040F	8	534
Copper-Sealing ring	8FD-1/4CU	2	536
Copper-Sealing ring	8FD-3/4CU	1	536
Copper-Sealing ring	8FD-3/8CU	1	536

Description	Part No.	Qty	Pos
Halfmoon for Ex-proof	8FH-1/4	1	536
Hexagon head screw plug	8FV-1/4R	2	536
Hexagon head screw plug	8FV-3/4R	1	536
Hexagon head screw plug	8FV-3/8R	1	536
Spring washer	8FF-06	4	537
Socket head cap screw	8FI-06/016	4	537
Fastening Set	8BB-16R040F	8	538
Flat washer	8FU-17R30X4.0	8	538
Snap ring (Seeger)	8RF-A077	1	545
Snap ring (Seeger)	8RF-A075R	1	546
Snap ring (Seeger)	8RF-A075R	1	546
Socket set screw	8FG-08/12K	1	550
Plug, R 1"	8FO-1	1	552
Oil seal	8DS-080/100BA	1	555
Stator housing	5GM-5MT	1	557
Stator housing	5GM-5MTR1E	1	557
Cooling jacket	5KG-5MT	1	558
Spring ring	5RF-5	1	559
Impeller for circ. of cool. liquid	5KI-5/3.0	1	560
Guidance sheet	5KB-5/B	1	561
Spring washer	8FF-08	4	569
Socket head cap screw	8FI-08/016	4	569
O-Ring	8DO-5/100	1	570
Float switch	5ES-03	1	572
Copper-Sealing ring	8FD-1/8CU	1	572
Plate for float switch	5BF-4	1	577
Copper-Sealing ring	8FD-1/4CU	1	577
Hexagon head screw plug	8FV-1/4R	1	577
Moisture probe internal	8EF-INTERN/EXL	1	578
Grease retaining disc 2-parts	5SS-5H	1	583
Oil tubes	5KR-5	60	598
Steel strip black	8BK-1210	1	598
Fixing seal	8BV-BK	1	598
Snap ring (Seeger)	8RF-A021	16	598



2.2



OPERATION and MAINTENANCE MANUALS

For

LEIGHTON CONTRACTORS AUSTRALIA TRADE COAST PROJECT SEWAGE PUMP STATION SP298 Lytton Road

Manuals Prepared by:

S E Power Equipment
47 Proprietary Street
Tingalpa, Qld 4173
Phone No. 07 3890 1744

Copyright © 2002 All Rights Reserved

REVISION A: February 2005

**OPERATION and MAINTENANCE MANUALS****Status**

Revision	Date	Initials	Comments
A	07-02-05	JP	Issued for approval

Prepared by: Jim Pringle

Date: ____/____/____

Reviewed
Project Manager: _____

Date: ____/____/____



OPERATION and MAINTENANCE MANUALS

Equipment List

SP198	LYTTON ROAD
SEPE NUMBER	412002
ENGINE	JOHN DEERE 6068T
SERIAL NUMBER	752250
ALTERNATOR	STAMFORD UCI 274H
SERIAL NUMBER	X04H320265/1

TABLE OF CONTENTS

Section 1. Instructions for use

Section 2. John Deere Operation Manual

Section 3. Stamford Installation, Service & Maintenance Manual (UCI 274)

Section 4. PLC – GE Fanuc

Section 5. Functional Description

Section 6. Drawings

Section 7. Test Reports




OPERATION and MAINTENANCE MANUALS

INSTRUCTIONS FOR USE

1. Units placed on site using "Hook Truck" (Cleanaway Type) over cable pit.
2. Cable pit to be under switchboard section of unit (rear).
3. Attach hold down / anti-theft chains to location points at rear of unit (beside switchboard).
4. Check engine lube oil level.
5. Check engine coolant level.
6. Check the battery is connected and the electrolyte level is correct.
7. Connect cables to plugs via colour-coded sequence.
8. Connect power inlet socket (240V).
9. Connect communication socket.
10. Connect pump station control socket.
11. Check fuel level (mechanical gauge beside fill point).
12. Refer to section 6, Functional Description for start/run and connection procedure.
13. Remember **SAFETY** is important **ALWAYS** wear your Personal Protection Equipment (PPE)

**POWER Units for
Gensets (Saran)
2.9L/4039/4.5/6.8L
(128/008/158/258)**

**OPERATOR'S
MANUAL**



John Deere Usine de Saran
OMCD16564 (03JAN00)



Introduction

THIS MANUAL COVERS the following engines for generator sets:

ENGINE FAMILY	ENGINE MODEL
300-SERIES	CD3029DF128
	CD4039DF008
	CD4039TF008
POWERTECH®	CD4045DF158
	CD4045HF158
	CD4045TF158
	CD4045TF258
	CD6068HF158
	CD6068TF158
	CD6068TF258

READ THIS MANUAL carefully to learn how to operate and service your engine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your engine and should remain with the engine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in metric. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

WRITE ENGINE SERIAL NUMBERS and option codes in the spaces indicated in the Record Keeping Section. Accurately record all the numbers. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the engine or machine.

RIGHT-HAND AND LEFT-HAND sides are determined by standing at the drive or flywheel end (rear) of the engine and facing toward the front of the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

Information relative to emissions regulations

Depending on final destination, this engine can meet the emissions regulations according to the US Environmental Protection Agency (EPA), California Air Resources Board (CARB) and for Europe, the Directive 97/68/EC relating the measures against the emissions of gaseous and particulates pollutants from internal combustion engines. In this case an emission label is stuck on the engine.

Emission regulations prohibit tampering with the emission-related components listed below which would render that component inoperative or to make any adjustment on the engine beyond published specifications. It is also illegal to install a part or component where the principal effect of that component is to bypass, defeat, or render inoperative any engine component or device which would affect the engine conformance to the emissions regulations. To summarize, it is illegal to do anything except return the engine to its original published specifications.

List of emission-related components:

- Fuel injection pump
- Intake manifold
- Turbocharger
- Charge air cooling system
- Piston

CALIFORNIA PROPOSITION 65 WARNING
Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

Contents

	Page		Page
Identification Views		Diesel Engine Coolant	10-4
Identification views	01-1	Operating in Warm Temperature Climates	10-5
Maintenance Records		Operating the Engine	
Using maintenance records	02-1	Break-in period	15-1
100 Hours of operation	02-1	Starting the engine	15-1
500 Hours of operation	02-2	Cold weather operation	15-1
1000 Hours of operation	02-2	Using a booster battery or charger	15-3
1500 Hours of operation	02-3	Engine operation	15-4
2000 Hours of operation	02-3	Standby power units	15-4
2500 Hours of operation	02-4	Stopping the engine	15-5
3000 Hours of operation	02-4		
3500 Hours of operation	02-5	Maintenance	
4000 Hours of operation	02-5	Observe service intervals	20-1
4500 Hours of operation	02-6	Use correct fuels, lubricants and coolant	20-1
5000 Hours of operation	02-6	Maintenance interval chart	20-2
5500 Hours of operation	02-7		
6000 Hours of operation	02-7	Maintenance/Daily or every 10 hours	
6500 Hours of operation	02-8	Daily prestarting checks	25-1
7000 Hours of operation	02-8		
7500 Hours of operation	02-9	Maintenance/500 hours	
8000 Hours of operation	02-9	Changing engine oil and filter	30-1
8500 Hours of operation	02-10	Replacing fuel filter element	30-3
9000 Hours of operation	02-10	Checking belt (300-SERIES ENGINES)	30-4
9500 Hours of operation	02-11	Checking belt (POWERTech ENGINES with manual tensioner)	30-5
10000 Hours of operation	02-11		
Record Keeping		Maintenance/1000 hours/1 year	
POWERTech® medallion	03-1	Cleaning crankcase vent tube	35-1
Engine serial number plate	03-1	Checking air intake system	35-1
Record engine serial number	03-2	Checking automatic belt tensioner (POWERTech ENGINES)	35-2
Engine option codes	03-3	Check and adjust engine valve clearance (300-SERIES ENGINES)	35-3
Record fuel injection pump model number	03-5		
Safety	05-1	Maintenance/2000 hours/2 years	
		Check and adjust engine valve clearance (POWERTech ENGINE)	40-1
Fuels, Lubricants and Coolant		Checking engine speed	40-3
Diesel Fuel	10-1	Adjust speed droop governor	40-3
Handling and Storing Diesel Fuel	10-1		
Engine Break-In Oil	10-2		
Diesel Engine Oil	10-3		
Lubricant Storage	10-3		
Mixing of Lubricants	10-4		

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.


COPYRIGHT © 1999
DEERE & COMPANY
European Office Mannheim
All rights reserved
A John Deere ILLUSTRATION® Manual

Contents

	Page
Checking crankshaft vibration damper (6-CYLINDER ENGINE ONLY)	40-4
 Maintenance/2500 hours/3 years	
Drain and flush cooling system	45-1
 Maintenance/As required	
Additional service information	50-1
Do not modify fuel system	50-1
Clean or replace air filter (one-piece)	50-2
Clean or replace air filter element	50-3
Replacing fan and alternator belt (POWERTech ENGINES)	50-4
Checking fuel filter	50-5
Bleeding the fuel system	50-6
 Troubleshooting	
Engine troubleshooting	55-1
Electrical troubleshooting	55-6
 Storage	
Engine storage guidelines	60-1
Use AR41785 engine storage kit	60-1
Preparing engine for long term storage	60-2
Removing engine from long term storage	60-3
 Specifications	
General engine specifications	65-1
Unified Inch Bolt and Cap Screw Torque Values	65-4
Metric Bolt and Cap Screw Torque Values	65-5

Identification Views

IDENTIFICATION VIEWS



4045HF158

CD30744 -JUN-23AUG89


Continued on next page

DPSG.CD03523.3 -19-05JUL99-1/2

01-1

112699
PN=5

Identification Views



CD30745 -UN-23AUG99

DPSG,CD03523.3 -19-05JUL99-2/2

01-2

112699
PN=6

Maintenance Records

USING MAINTENANCE RECORDS

To obtain the best performance, economy and service life from your engine, ensure service is carried out according to this present manual and recorded in the following pages. It is recommended that your engine Distributor or your Dealer carry out this service work and stamp the appropriate case.

Keeping an accurate account of all service performed on your engine will give more value to the machine when you resell it.

John Deere oils and coolants have been formulated to give maximum protection and performance to your engine. We recommend only genuine John Deere service products and replacement parts.

To protect your rights under the warranty ensure all scheduled services are carried out and recorded. If your engine is covered by extended warranty, it is important to maintain this record for the duration of the warranty.

DPSG.CD03523.6 -19-05JUL99-1/1

100 HOURS OF OPERATION

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Hose connections, check

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG.CD03523.7 -19-05JUL99-1/1

*Maintenance Records***500 HOURS OF OPERATION**

- ☐ Engine oil, replace
☐ Engine oil filter, replace
☐ Fuel filter, replace
☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
☐ Valve clearance, adjust (300-Series)

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,8 -19-05JUL99-1/1

1000 HOURS OF OPERATION

- ☐ Engine oil, replace
☐ Engine oil filter, replace
☐ Fuel filter, replace
☐ Check belt and tensioning system
☐ Crankcase vent tube, clean
- ☐ Air intake system, check

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,9 -19-05JUL99-1/1

02-2112599
PN=8

Maintenance Records

1500 HOURS OF OPERATION

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Fuel filter, replace
- ☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
- ☐ Valve clearance, adjust (300-Series)

Number of hours:

Comments:

Dealer or distributor stamp

Date:

b done by:

DPSG.CD03523.10 -19-05JUL99-1/1

2000 HOURS OF OPERATION

- | | |
|--|--|
| <ul style="list-style-type: none"> <input type="checkbox"/> Engine oil, replace <input type="checkbox"/> Engine oil filter, replace <input type="checkbox"/> Fuel filter, replace <input type="checkbox"/> Check belt and tensioning system <input type="checkbox"/> Crankcase vent tube, clean | <ul style="list-style-type: none"> <input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is not used) <input type="checkbox"/> Valve clearance, adjust (POWERTech) <input type="checkbox"/> Air intake system, check <input type="checkbox"/> Vibration damper, check |
|--|--|

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG.CD03523.59 -19-16AUG99-1/1

02-3

112699
PN=9

*Maintenance Records***2500 HOURS OF OPERATION**

- | | |
|---|---|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
<input type="checkbox"/> Valve clearance, adjust (300-Series) | <input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is used) |
|---|---|

Number of hours: Date: Job done by:	Comments:	Dealer or distributor stamp
---	-----------	-----------------------------

DPSG,CD03523,60 -19-16AUG99-1/1

3000 HOURS OF OPERATION

- | | |
|--|---|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Check belt and tensioning system
<input type="checkbox"/> Crankcase vent tube, clean | <input type="checkbox"/> Air intake system, check |
|--|---|

Number of hours: Date: Job done by:	Comments:	Dealer or distributor stamp
---	-----------	-----------------------------

DPSG,CD03523,61 -19-16AUG99-1/1

02-4112699
PN=10

*Maintenance Records***3500 HOURS OF OPERATION**

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Fuel filter, replace
- ☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
- ☐ Valve clearance, adjust (300-Series)

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523.62 -19-16AUG99-1/1

4000 HOURS OF OPERATION

- | | |
|---|---|
| <input type="checkbox"/> Engine oil, replace | <input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is not used) |
| <input type="checkbox"/> Engine oil filter, replace | <input type="checkbox"/> Valve clearance, adjust (POWERTech) |
| <input type="checkbox"/> Fuel filter, replace | <input type="checkbox"/> Air intake system, check |
| <input type="checkbox"/> Check belt and tensioning system | <input type="checkbox"/> Vibration damper, check |
| <input type="checkbox"/> Crankcase vent tube, clean | |

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523.63 -19-16AUG99-1/1

02-5112599
PN=11

Maintenance Records**4500 HOURS OF OPERATION**

- | | |
|---|---|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
<input type="checkbox"/> Valve clearance, adjust (300-Series) | <input type="checkbox"/> Vibration damper, replace (6 cyl.) |
|---|---|

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,64 -19-16AUG99-1/1

5000 HOURS OF OPERATION

- | | |
|--|---|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Check belt and tensioning system
<input type="checkbox"/> Crankcase vent tube, clean | <input type="checkbox"/> Injection nozzles, replace
<input type="checkbox"/> Air intake system, check
<input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is used) |
|--|---|

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,65 -19-16AUG99-1/1

02-6112699
PN=12

Maintenance Records

5500 HOURS OF OPERATION

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Fuel filter, replace
- ☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
- ☐ Valve clearance, adjust (300-Series)

Number of hours: Date: Job done by:	Comments:	Dealer or distributor stamp
---	-----------	-----------------------------

DPSG,CD03523.66 -19-16AUG99-1/1

6000 HOURS OF OPERATION

- | | |
|--|--|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Check belt and tensioning system
<input type="checkbox"/> Crankcase vent tube, clean | <input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is not used)
<input type="checkbox"/> Valve clearance, adjust (POWERTech)
<input type="checkbox"/> Air intake system, check
<input type="checkbox"/> Vibration damper, check |
|--|--|

Number of hours: Date: Job done by:	Comments:	Dealer or distributor stamp
---	-----------	-----------------------------

DPSG,CD03523.67 -19-16AUG99-1/1

02-7

112699
PN=13

Maintenance Records

6500 HOURS OF OPERATION

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Fuel filter, replace
- ☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
- ☐ Valve clearance, adjust (300-Series)

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,68 -19-16AUG99-1/1

7000 HOURS OF OPERATION

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Fuel filter, replace
- ☐ Check belt and tensioning system
- ☐ Crankcase vent tube, clean
- ☐ Air intake system, check

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,69 -19-16AUG99-1/1

02-8

112699
PN=14

Maintenance Records

7500 HOURS OF OPERATION

- | | |
|---|---|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
<input type="checkbox"/> Valve clearance, adjust (300-Series) | <input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is used) |
|---|---|

Number of hours: Date: Job done by:	Comments:	Dealer or distributor stamp
---	-----------	-----------------------------

DPSG,CD03523,70 -19-16AUG99-1/1

8000 HOURS OF OPERATION

- | | |
|--|--|
| <input type="checkbox"/> Engine oil, replace
<input type="checkbox"/> Engine oil filter, replace
<input type="checkbox"/> Fuel filter, replace
<input type="checkbox"/> Check belt and tensioning system
<input type="checkbox"/> Crankcase vent tube, clean | <input type="checkbox"/> Cooling system, drain and flush (if COOL-GARD is not used)
<input type="checkbox"/> Valve clearance, adjust (POWERTech)
<input type="checkbox"/> Air intake system, check
<input type="checkbox"/> Vibration damper, check |
|--|--|

Number of hours: Date: Job done by:	Comments:	Dealer or distributor stamp
---	-----------	-----------------------------

DPSG,CD03523,71 -19-16AUG99-1/1

02-9

112699
PN=15

Maintenance Records

8500 HOURS OF OPERATION

☐ Engine oil, replace

☐ Engine oil filter, replace

☐ Fuel filter, replace

☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)

☐ Valve clearance, adjust (300-Series)

Number of hours:

Date:

Job done by:

Comments:

Dealer or distributor stamp

DPSG.CD03523.72 -19-16AUG99-1/1

9000 HOURS OF OPERATION

☐ Engine oil, replace Air intake system, check

☐ Engine oil filter, replace Vibration damper, replace (6 cyl.)

☐ Fuel filter, replace

☐ Check belt and tensioning system

☐ Crankcase vent tube, clean

Number of hours:

Date:

Job done by:

Comments:

Dealer or distributor stamp

DPSG.CD03523.73 -19-16AUG99-1/1

Maintenance Records

9500 HOURS OF OPERATION

- ☐ Engine oil, replace
- ☐ Engine oil filter, replace
- ☐ Fuel filter, replace
- ☐ Belt, check tension and wear (300-Series and POWERTech with manual tensioner)
- ☐ Valve clearance, adjust (300-Series)

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,74 -19-16AUG99-1/1

10000 HOURS OF OPERATION

- | | |
|---|---|
| <ul style="list-style-type: none"> <input type="checkbox"/> Engine oil, replace <input type="checkbox"/> Engine oil filter, replace <input type="checkbox"/> Fuel filter, replace <input type="checkbox"/> Check belt and tensioning system <input type="checkbox"/> Crankcase vent tube, clean <input type="checkbox"/> Air intake system, check | <ul style="list-style-type: none"> <input type="checkbox"/> Cooling system, drain and flush <input type="checkbox"/> Valve clearance, adjust (POWERTech) <input type="checkbox"/> Thermostat, replace <input type="checkbox"/> Vibration damper, check <input type="checkbox"/> Injection nozzles, replace |
|---|---|

Number of hours:

Comments:

Dealer or distributor stamp

Date:

Job done by:

DPSG,CD03523,75 -19-16AUG99-1/1


02-11

112698
PN=17

Record Keeping

POWERTECH® MEDALLION

A medallion is located on the rocker arm cover which identifies each engine as a John Deere POWERTECH® engine.




RG8041 -UN-15JAN99

POWERTECH is a trademark of Deere & Company


DPSG,CD03523,11 -19-05JUL99-1/1

ENGINE SERIAL NUMBER PLATE



RG8007 -UN-15JAN99

POWERTEch engine



CD30746 -UN-24SEP99

300-Series engine

Each engine has a 13-digit John Deere serial number. The first two digits identify the factory that produced the engine:

“CD” indicates the engines was built in Saran, France.

Your engine's serial number plate (A) is located on the right-hand side of cylinder block behind the fuel filter for POWERTEch engines and near the fuel supply pump on 300-Series engines.

DPSG,CD03523,12 -19-05JUL99-1/1

Record Keeping

RECORD ENGINE SERIAL NUMBER


Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information.


Engine Serial Number (B)

Engine Model Number (C)

Coefficient of Absorption Value (D)



300-Series engine plate




POWERTech engine plate

DPSG.CD03523,13 -19-05JUL99-1/1

Record Keeping

ENGINE OPTION CODES



CD30748A -JN-26AUG99

Engine option code label

In addition to the serial number plate, OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

An additional sticker may be also delivered (in a plastic bag attached to the engine or inserted in the machine documentation). It is recommended to stick this option code list sticker either:

- On this page of your Operator's manual below this section.
- or
- On the "Engine Owner's Warranty" booklet under the title OPTION CODES (Engine manufacturing configuration).

NOTE: The Machine Manufacturer may have already stuck it at a specific accessible place (inside the enclosure or close to a maintenance area).

The engine option code label includes an engine base code (A). This base code must also be recorded along with the option codes. At times it will be necessary to furnish this base code to differentiate two identical option codes for the same engine model.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

NOTE: These option codes are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX. The list on the next page shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following page.

NOTE: Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.

If option code label is lost or destroyed, consult your servicing dealer or engine distributor selling the engine for a replacement.

Continued on next page

OPSG,CD03523,14 -19-05JUL99-1/2

03-3

112699
PN=20

Record Keeping

Option Codes	Description	Option Codes	Description
Engine Base Code: _____			
11 _____	Rocker Arm Cover	45 _____	Balancer Shaft
12 _____	Oil Filler Neck	46 _____	Cylinder Block With Liners and Camshaft
13 _____	Crankshaft Pulley	47 _____	Crankshaft and Bearings
14 _____	Flywheel Housing	48 _____	Connecting Rods and Pistons
15 _____	Flywheel	49 _____	Valve Actuating Mechanisms
16 _____	Fuel Injection Pump	50 _____	Oil Pump
17 _____	Air inlet	51 _____	Cylinder Head With Valves
18 _____	Air cleaner	52 _____	Auxiliary Gear Drive
19 _____	Oil pan	54 _____	Oil heater
20 _____	Coolant pump	55 _____	Shipping stand
21 _____	Thermostat Cover	56 _____	Paint Option
22 _____	Thermostat	57 _____	Coolant Inlet
23 _____	Fan Drive	59 _____	Oil Cooler
24 _____	Fan Belt	60 _____	Add-on Auxiliary Drive Pulley
25 _____	Fan	62 _____	Alternator Mounting
26 _____	Engine Coolant Heater	64 _____	Exhaust Elbow
7 _____	Radiator	65 _____	Turbocharger
3 _____	Exhaust Manifold	66 _____	Temperature Switch
29 _____	Ventilator System	67 _____	Electronic Tachometer Sensor
30 _____	Starting Motor	68 _____	Damper
31 _____	Alternator	69 _____	Engine Serial Number Plate
32 _____	Instrument Panel	74 _____	Air Conditioning System Compressor Mounting
35 _____	Fuel Filter	75 _____	Air Restriction Indicator
36 _____	Front Plate	76 _____	Oil Pressure Switch
37 _____	Fuel Transfer Pump	86 _____	Fan Pulley
39 _____	Thermostat Housing	87 _____	Automatic Belt Tensioner
40 _____	Oil Dipstick	88 _____	Oil Filter
41 _____	Belt Driven Front Auxiliary Drive	91 _____	Special Equipment (Factory Installed)
43 _____	Starting Aid	97 _____	Special Equipment (Field Installed)
44 _____	Timing Gear Cover with Gears	98 _____	Shipping

DPSG.CD03523.14 -19-05JUL99-22


*Record Keeping***RECORD FUEL INJECTION PUMP MODEL NUMBER**

Record the fuel injection pump model and serial information found on the serial number plate (A).

Model No. _____ RPM _____

Manufacturer's No. _____

Serial No. _____



DPSG,CD03523,15 -19-07JUL99-1/1

Safety

RECOGNIZE SAFETY INFORMATION

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



TS1389 -UN-07DEC88

DX,ALERT -19-29SEP98-1/1

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



TS187 -19-30SEP88

DX,SIGNAL -19-03MAR93-1/1

Safety

ENGINE LIFTING PROCEDURE

CAUTION: The only recommended method for lifting the engine is with JDG23 Engine Lifting Sling (A) and safety approved lifting straps (B) that come with engine. Use extreme caution when lifting and NEVER permit any part of the body to be positioned under an engine being lifted or suspended.


Lift engine with longitudinal loading on lifting sling and lifting straps only. Angular loading greatly reduces lifting capacity of sling and straps.

NOTE: If engine does not have lifting straps, universal straps can be procured through service parts under part numbers JD-244-1 and JD-244-2.

1. If not equipped, install lifting straps and torque to 200 N•m (145 lb-ft).
2. Attach JDG23 Engine Lifting Sling (A) to engine lifting straps (B) and overhead hoist.

IMPORTANT: Lifting straps are designed to lift the engine and accessories such as radiator, air filter and other small components. If larger components, such as power take-off, transmission, generator air compressor... etc, are attached to engine, the lifting straps provided with engine or through parts channel are not intended for this purpose. Technician is responsible for providing adequate lifting devices under these situations. See machine manuals for additional information on removing engine from machine.

3. Carefully move engine to desired location.



DPSG,CD03523,95 -19-06OCT99-1/1

05-2

112699
PN=24

Safety


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



TS201 -UN-23AUG88


DX,READ -19-03MAR93-1/1

PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.



TS177 -UN-11JAN89

DX,BYPAS1 -19-29SEP98-1/1

Safety

HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



TS202 -UN-23AUG88


DX,FIRE1 -19-03MAR93-1/1

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1

HANDLE STARTING FLUID SAFELY

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.



TS1356 -UN-18MAR92

DX,FIRE3 -19-16APR92-1/1

05-4

112699
PN=26

Safety


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



TS207 -UN-23AUG88

DX,NOISE -19-03MAR93-1/1

Safety

HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure the PTO driveline is stopped before making adjustments or performing any type service on the engine or PTO-driven equipment.



TS1644 -UN-22AUG95

CD,PTO -19-12SEP95-1/1

Safety

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.




TS218 -UN-23AUG88

DX,SERV -19-17FEB99-1/1

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



TS220 -UN-23AUG88

DX,AIR -19-17FEB99-1/1

Safety


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




X8811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



TS953 -UN-15MAY90

DX,TORCH -19-03MAR93-1/1

Safety

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.




TS220 -UN-23AUG88

DX,PAINT -19-03MAR93-1/1

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS251 -UN-23AUG88

DX,RCAP -19-04JUN90-1/1

Safety


AVOID HARMFUL ASBESTOS DUST

Avoid breathing dust that may be generated when handling components containing asbestos fibers. Inhaled asbestos fibers may cause lung cancer.

Components in products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates, and some gaskets. The asbestos used in these components is usually found in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding material containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If not available, apply a mist of oil or water on the material containing asbestos.

Keep bystanders away from the area.



TS220 -UN-23AUG88

DX,DUST -19-15MAR91-1/1

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



TS1133 -UN-26NOV90

DX,DRAIN -19-03MAR93-1/1

05-10

112699
PN=32

Fuels, Lubricants and Coolant

DIESEL FUEL

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended.

In all cases, the fuel shall meet the following properties:

Cetane number of 40 minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20°C (-4°F) or elevations above 1000 m (5,000 ft).

Cold Filter Plugging Point (CFPP) below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

Fuel lubricity should pass a minimum of 3100 gram load level as measured by the BOCLE scuffing test.

Sulfur content:

- Sulfur content should not exceed 0.5%. Sulfur content less than 0.05% is preferred.
- If diesel fuel with sulfur content greater than 0.5% sulfur content is used, reduce the service interval for engine oil and filter by 50%.
- DO NOT use diesel fuel with sulfur content greater than 1.0%.

Bio-diesel fuels may be used ONLY if the fuel properties meet DIN 51606 or equivalent specification.

DO NOT mix used engine oil or any other type of lubricant with diesel fuel.

DX,FUEL1 -19-17FEB99-1/1

HANDLING AND STORING DIESEL FUEL



CAUTION: Handle fuel carefully. Do not fill the fuel tank when engine is running.

DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent condensation and freezing during cold weather.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented cap.

When fuel is stored for an extended period or if there is a slow turnover of fuel, add a fuel conditioner to stabilize the fuel and prevent water condensation. Contact your fuel supplier for recommendations.

DX,FUEL4 -19-18MAR96-1/1

*Fuels, Lubricants and Coolant***ENGINE BREAK-IN OIL**

New engines are filled at the factory with John Deere ENGINE BREAK-IN OIL. During the break-in period, add John Deere ENGINE BREAK-IN OIL as needed to maintain the specified oil level.

Change the oil and filter after the first 100 hours of operation of a new or rebuilt engine.

After engine overhaul, fill the engine with John Deere ENGINE BREAK-IN OIL.

If John Deere ENGINE BREAK-IN OIL is not available, use a diesel engine oil meeting one of the following during the first 100 hours of operation:

- API Service Classification CE

- ACEA Specification E1

After the break-in period, use John Deere PLUS-50® or other diesel engine oil as recommended in this manual.

IMPORTANT: Do not use PLUS-50 oil or engine oils meeting API CG4, API CF4, ACEA E3, or ACEA E2 performance levels during the first 100 hours of operation of a new or rebuilt engine. These oils will not allow the engine to break-in properly.

PLUS-50 is a registered trademark of Deere & Company.

DX.ENOIL4 -19-10OCT97-1/1

Fuels, Lubricants and Coolant

DIESEL ENGINE OIL

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred:

- John Deere PLUS-50®

The following oil is also recommended:


- John Deere TORQ-GARD SUPREME TORQ-GARD SUPREME®

Other oils may be used if they meet one or more of the following:

- API Service Classification CG-4
API Service Classification CF-4
- ACEA Specification E3
- ACEA Specification E2

Multi-viscosity diesel engine oils are preferred.

If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval by 50%.



PLUS-50 is a registered trademark of Deere & Company.
TORQ-GARD SUPREME is a trademark of Deere & Company

CD,ENOIL -19-10OCT97-1/1

LUBRICANT STORAGE

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1

*Fuels, Lubricants and Coolant***MIXING OF LUBRICANTS**

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Consult your John Deere dealer to obtain specific information and recommendations.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

DX,LUBMIX -19-18MAR96-1/1

DIESEL ENGINE COOLANT

The engine cooling system is filled to provide year-round protection against corrosion and cylinder liner pitting, and winter freeze protection to -37°C (-34°F).

John Deere COOL-GARD is preferred for service.

If John Deere COOL-GARD is not available, use a low silicate ethylene glycol base coolant concentrate in a 50% mixture of concentrate with quality water.

The coolant concentrate shall be of a quality that provides cavitation protection to cast iron and aluminum parts in the cooling system. John Deere COOL-GARD meets this requirement.

A 50% mixture of ethylene glycol engine coolant in water provides freeze protection to -37°C (-34°F). If protection at lower temperatures is required, consult your John Deere dealer for recommendations.

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized

water is recommended for mixing with ethylene glycol base engine coolant concentrate.

IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.

COOLANT DRAIN INTERVALS

Drain the factory fill engine coolant, flush the cooling system, and refill with new coolant after the first 3 years or 3000 hours of operation. Subsequent drain intervals are determined by the coolant used for service. At each interval, drain the coolant, flush the cooling system, and refill with new coolant.

When John Deere COOL-GARD is used, the coolant drain interval is 3 years or 3000 hours of operation.

If COOL-GARD is not used, the drain interval is reduced to 2 years or 2000 hours of operation.

DX,COOL8 -19-12FEB99-1/1

*Fuels, Lubricants and Coolant***OPERATING IN WARM TEMPERATURE CLIMATES**

John Deere engines are designed to operate using glycol base engine coolants.

Always use a recommended glycol base engine coolant, even when operating in geographical areas where freeze protection is not required.

IMPORTANT: Water may be used as coolant *in emergency situations only.*

Foaming, hot surface aluminum and iron corrosion, scaling, and cavitation will occur when water is used as the coolant, even when coolant conditioners are added.

Drain cooling system and refill with recommended glycol base engine coolant as soon as possible.

DX.COOL6 -19-18MAR96-1/1

Operating the Engine

BREAK-IN PERIOD

Within first 100 hours of operation

During the first 100 hours of operation, avoid overloading, excessive idling and no-load operation.

See ENGINE BREAK-IN OIL for eventual addition of oil.

NOTE: During the break-in period a higher-than-usual oil consumption should be considered as normal.

After first 100 hours of operation

After the first 100 hours, drain the crankcase and

change the oil filter (see CHANGING ENGINE OIL AND FILTER). Fill crankcase with seasonal viscosity grade oil (see DIESEL ENGINE OIL).

Check tension of alternator belt.

Check connections of air intake hoses.

Check for proper tightening of cap screws all around the engine.

DPSG.CD03523.17 -19-09JUL99-1/1

STARTING THE ENGINE



CAUTION: Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.

NOTE: If temperature is below 0°C (32°F), it may be necessary to use cold weather starting aids (See COLD WEATHER OPERATION).

1. Perform all prestarting checks outlined in Maintenance/Daily Section.

2. Open the fuel supply shut-off valve, if equipped.

3. Activate the starter motor switch to crank the engine and release it as soon as engine starts.

NOTE: Do not operate the starter motor more than 20 seconds at a time.

DPSG.CD03523.18 -19-09JUL99-1/1

COLD WEATHER OPERATION

Depending on equipment, various cold weather starting aids are available to assist in starting the engine at temperatures below 0°C (32°F).

Continued on next page

DPSG.CD03523.19 -19-09JUL99-1/4


Operating the Engine

Air intake heater

Air intake heater is either a grid-type (A) for POWERTech engines or a glow plug-type (B) for 300-Series engines installed in the air intake channel.

CAUTION: NEVER use Ether Starting Fluid when air intake heater is used to start the engine.

Activate the heating element (preheater position) for 30 seconds maximum then start the engine.




CD30750 -UN-03SEP99

DPSG,CD03523,19 -19-09JUL99-2/4

Coolant heater

Connect plug of coolant heater (A) to a power source (110 or 220 V).

At an ambient temperature of -15°C (5°F), the heating process takes approximatively 2 hours. Extend heating period if ambient temperature is lower.




LX1017768 -UN-24OCT97

DPSG,CD03523,19 -19-09JUL99-3/4

Fuel preheater

Fuel preheater (A) switches ON and OFF automatically in relation to the ambient temperature.



LX1017708 -UN-09OCT97

DPSG,CD03523,19 -19-09JUL99-4/4

Operating the Engine

USING A BOOSTER BATTERY OR CHARGER

A 12-volt booster battery can be connected in parallel with battery(ies) on the unit to aid in cold weather starting. ALWAYS use heavy duty jumper cables.


CAUTION: Gas given off by batteries is explosive. Keep sparks and flames away from batteries. Before connecting or disconnecting a battery charger, turn charger off. Make last connection and first disconnection at a point away from battery. Always connect **NEGATIVE (-)** cable last and disconnect this cable first.

IMPORTANT: Be sure polarity is correct before making connections. Reversed polarity will damage electrical system. Always connect positive to positive and negative to ground. Always use 12-volt booster battery for 12-volt electrical systems and 24-volt booster battery/batteries for 24-volt electrical systems.


1. Connect booster battery or batteries to produce the required system voltage for your engine application.

NOTE: To avoid sparks, **DO NOT** allow the free ends of jumper cables to touch the engine.

2. Connect one end of jumper cable to the **POSITIVE (+)** post of the booster battery.
3. Connect the other end of the jumper cable to the **POSITIVE (+)** post of battery connected to starter.
4. Connect one end of the other jumper cable to the **NEGATIVE (-)** post of the booster battery.
5. ALWAYS complete the hookup by making the last connection of the **NEGATIVE (-)** cable to a good ground on the engine frame and away from the battery(ies).
6. Start the engine. Disconnect jumper cables immediately after engine starts. Disconnect **NEGATIVE (-)** cable first.



12-Volt System



24-Volts System

A—12-Volt Machine battery/batteries
B—12-Volt Booster battery/batteries
C—Booster cable
D—Cable to starter motor

TS204 -UN-23AUG88

RG4678 -UN-14DEC88

RG4698 -UN-14DEC88

DPSG_CD03523.20 -19-09JUL99-1/1

Operating the Engine

ENGINE OPERATION

Warming engine

Operate engine at high idle for 1 to 2 minutes before applying the load.

NOTE: This procedure does not apply to standby generator sets where the engine is loaded immediately upon reaching rated speed.

Normal engine operation

Compare engine coolant temperature and engine oil pressure with specifications below:

Minimum oil pressure at full load rated speed¹—Specification

Pressure 275 kPa (2.75 bar; 40 psi)

Coolant temperature range—Specification

Temperature 82°—94°C (180°—202°F)

Stop engine immediately if coolant temperature is above or oil pressure below specifications or if there are any signs of part failure. Symptoms that may be early signs of engine problems could be:

- Sudden loss of power

- Unusual noise or vibration
- Excessive black exhaust fumes
- Excessive fuel consumption
- Excessive oil consumption
- Fluid leaks

Recommendation for turbocharger engines

Should the engine stall when operating under load, IMMEDIATELY restart it to prevent overheating of turbocharger components.

Idling engine

Avoid excessive engine idling. Prolonged idling may cause the engine coolant temperature to fall below its normal range. This, in turn, causes crankcase oil dilution, due to incomplete fuel combustion, and permits formation of gummy deposits on valves, pistons and piston rings. It also promotes rapid accumulation of engine sludge and unburned fuel in the exhaust system. If an engine will be idling for more than 5 minutes, stop and restart later.

NOTE: Generator set applications have the governor locked at a specified speed and do not have a slow idle function. These engines idle at no load governed speed (fast idle).

¹Oil at normal operating temperature of 115°C (240°F).

DPSG.CD03523.21 -19-09JUL99-1/1

STANDBY POWER UNITS

To assure that your engine will deliver efficient standby operation when needed, start engine and run at rated speed (with 50%—70% load) for 30 minutes every

2 weeks. DO NOT allow engine to run an extended period of time with no load.

DPSG.CD03523.22 -19-09JUL99-1/1

Operating the Engine

STOPPING THE ENGINE

1. Before stopping, run engine for at least 2 minutes at fast idle and no load.
2. Stop the engine.

DPSG.CD03523.23 -19-09JUL99-1/1

Maintenance

OBSERVE SERVICE INTERVALS

Using hour meter as a guide, perform all services at the hourly intervals indicated on following pages. At each scheduled maintenance interval, perform all previous maintenance operations in addition to the ones specified. Keep a record of hourly intervals and services performed using charts provided in Maintenance Records Section.

IMPORTANT: Recommended service intervals are for normal operating conditions. Service **MORE OFTEN** if engine is operated under adverse conditions. Neglecting maintenance can result in failures or permanent damage to the engine.

DPSG,CD03523,24 -19-09JUL99-1/1

USE CORRECT FUELS, LUBRICANTS AND COOLANT

IMPORTANT: Use only fuels, lubricants, and coolants meeting specifications outlined in Fuels, Lubricants, and Coolant Section when servicing your John Deere Engine.

Consult your John Deere engine distributor, servicing dealer or your nearest John Deere Parts Network for recommended fuels, lubricants, and coolant. Also available are necessary additives for use when operating engines in tropical, arctic, or any other adverse conditions.



TS100 -UN-23AUG88

DPSG,CD03523,25 -19-09JUL99-1/1

Maintenance

MAINTENANCE INTERVAL CHART

Item	10 H / daily	500 H	1000 H / 1 year	2000 H / 2 years	2500 H / 3 years	As required
Check engine oil and coolant level	•					
Check air filter restriction indicator ^a	•					
Change engine oil and filter ^b		•				
Replace fuel filter element		•				
Check belt tension and automatic tensioner ^c		•	•			
Check and adjust valve clearance ^d			•	•		
Clean crankcase vent tube			•			
Check air intake hoses, connections and system			•			
Check vibration damper (6 cyl.) ^e				•		
Check engine speed and speed droop governor				•		
Drain and flush cooling system ^f				•	•	
Drain water and sediment from fuel filter						•
Clean filter element (see note a)						•
Test thermostat and injection nozzles (see your dealer) ^g						•

^aClean air filter element when restriction indicator is red. Replace filter element after 6 cleanings or once a year.

^bChange oil and filter after the first 100 hours of operation, then every 500 hours thereafter. Change oil and filter at least once a year.

^cCheck belt tension every 500 hours on 300-Series engines and on POWERTech engines with manual tensioner. Check automatic belt tensioner every 1000 hours/1 year on POWERTech engines when equipped.

^dHave your authorized servicing dealer or engine distributor adjust valve clearance as follows. After the first 500 hours of operation then every 1000 hours thereafter on 300-Series engines. Every 2000 hours on POWERTech engines.

^eHave your authorized dealer or engine distributor replace the vibration damper every 4500 hours/5 years.


^fDrain and flush cooling system every 2500 hours/3 years when John Deere COOL-GARD coolant is used. Otherwise every 2000 hours/2 years.

^gContact your dealer when thermostat or injection nozzles are suspected to be defective. Replace injection nozzles every 5000 hours and thermostat every 10000 hours.


DPSG.CD03523.26 -19-09JUL99-1/1

Maintenance/Daily or every 10 hours


DAILY PRESTARTING CHECKS



POWERTech engine




300-Series engine



Do the following **BEFORE STARTING THE ENGINE** for the first time each day:

IMPORTANT: DO NOT top up with fresh oil until the oil level is **BELOW** the add mark.

1. Check engine oil level on dipstick (A). Add as required, using seasonal viscosity grade oil. (See



FD000047

FD000047 -UN-13MAR96

DIESEL ENGINE OIL). Add oil at rocker arm cover filler cap (B).

IMPORTANT: DO NOT fill above the crosshatch area. Oil levels anywhere within crosshatch are considered in the acceptable operating range.


Continued on next page

DPSG,CD03523,27 -19-12JUL99-1/3

Maintenance/Daily or every 10 hours



TS281 -UN-23AUG88



CD30756 -UN-26AUG99

2. **CAUTION:** Explosive release of fluids from pressurized cooling system can cause serious burns.

Only remove filler cap when engine is cold or when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

Remove radiator cap (E) and check coolant level which should be at bottom of filler neck. Fill radiator with proper coolant solution if level is low. (See DIESEL ENGINE COOLANT). Check overall cooling system for leaks.


DPSG,CD03523,27 -19-12JUL99-2/3

3. If air filter has a dust unloading valve (C), squeeze valve tip to release any trapped dirt particles.
4. Check air intake restriction indicator (D). When indicator is red, air filter needs to be cleaned.


IMPORTANT: Maximum air intake restriction is 6.25 kPa (0.06 bar; 1.0 psi) (25 in. H₂O). A clogged air cleaner element will cause excessive intake restriction and a reduced air supply to the engine.

5. Make a thorough inspection of the engine compartment.

NOTE: Wipe all fittings, caps and plugs before performing any maintenance to reduce the chance of system contamination.



RG4687 -UN-20DEC88



CD30757 -UN-26AUG99

DPSG,CD03523,27 -19-12JUL99-3/3

Maintenance/500 hours



CHANGING ENGINE OIL AND FILTER

NOTE: Change engine oil and filter for the first time after 100 hours maximum of operation, then every 500 hours thereafter. Change oil and filter at least once a year.


1. Run engine approximately 5 minutes to warm up oil. Shut engine off.
2. Open oil pan drain valve (A).
3. Drain crankcase oil from engine while warm.
4. Remove and discard oil filter element (B) using a suitable filter wrench.
5. Remove oil filter packing and clean filter mounting pad.

IMPORTANT: Filtration of oils is critical to proper lubrication. Always change filter regularly. Use filters meeting John Deere performance specifications.

6. Oil the new packing and install a new filter element. Hand tighten element according to values printed on filter element. If values are not provided, tighten element approximately 3/4 — 1-1/4 turn after packing contacts filter housing. DO NOT overtighten filter element.
7. Close oil pan drain valve.



POWERTEch engine



300-Series engine

Continued on next page

DPSG.CD03523.29 -19-12JUL99-1/2

Maintenance/500 hours



8. Fill engine crankcase with correct John Deere engine oil through rocker arm cover opening (C); see DIESEL ENGINE OIL.

To determine the correct oil fill quantity for your engine, see "Engine Oil Quantities" in Specifications Section.

NOTE: Crankcase oil capacity may vary slightly.
ALWAYS fill crankcase to full mark or within crosshatch on dipstick, whichever is present. **DO NOT** overfill.

IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This will help insure adequate lubrication to engine components before engine starts.

9. Start engine and run to check for possible leaks.
10. Stop engine and check oil level after 10 minutes. If necessary, top up.




FD000047


FD000047 -UN-13MAR96

DPSG,CD03523,29 -19-12JUL99-2/2

REPLACING FUEL FILTER ELEMENT



X9811 -JUN-23AUG88



A—Retaining ring

B—Filter element

C—Drain plug

D—Bleed plug

CAUTION: CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

1. Thoroughly clean fuel filter assembly and surrounding area.
2. Loosen drain plug (C) and drain fuel into a suitable container.

NOTE: Lifting up on retaining ring as it is rotated helps to get it past raised locators.

3. Firmly grasp the retaining ring (A) and rotate it clockwise 1/4 turn. Remove ring with filter element (B).

IMPORTANT: Do not dump the old fuel into the new filter element. This could cause fuel injection problem.

A plug is provided with the new element for plugging the used element.

4. Inspect filter mounting base for cleanliness. Clean as required.

NOTE: Raised locators on fuel filter canister must be indexed properly with slots in mounting base for correct installation.

5. Install new filter element dry onto mounting base. Be sure element is properly indexed and firmly seated on base. It may be necessary to rotate filter for correct alignment.
6. Install retaining ring onto mounting base making certain dust seal is in place on filter base. Hand tighten ring (about 1/3 turn) until it "snaps" into the detent. DO NOT overtighten retaining ring.

NOTE: The proper installation is indicated when a "click" is heard and a release of the retaining ring is felt.

7. Bleed the fuel system.

DPSG,CD03523,30 -19-12JUL99-1/1

Maintenance/500 hours

CHECKING BELT (300-SERIES ENGINES)

1. Inspect belt for cracks, fraying, or stretched out areas. Replace as necessary.
2. Check belt tension using one of following methods:

a) Use of JDG529 Tension Gauge (A)**Belt tension—Specification**

New belt.....	578—622 N (130—140 lb-force)
Used belt	378—423 N (85—94 lb-force)

NOTE: Belt is considered used after 10 minutes of operation.




b) Use of tension tester (B) and straight edge (C)

A 89 N (20 lb) force applied halfway between pulleys should deflect belt by 19 mm (0.75 in.).

3. If adjustment is necessary, loosen alternator nuts (D) and (E). Pull alternator frame outward until belt is correctly tensioned.

IMPORTANT: Do not pry against the alternator rear frame. Do not tighten or loosen belts while they are hot.

4. Tighten alternator bracket nuts firmly.
5. Run engine for 10 minutes then recheck belt tension.



CD30646 -UN-Q4MAY98

DPSG,CD03523,31 -19-12JUL99-1/1

Maintenance/500 hours

CHECKING BELT (POWERTECH ENGINES WITH MANUAL TENSIONER)


Inspect belt for cracks, fraying, or stretched out areas. Replace if necessary.

NOTE: Belt adjustment is measured using a gauge stamped on the top edge of the alternator bracket.

1. Loosen cap screws (B) and (C).
2. Slide alternator in slot by hand to remove all excess slack in belt.

IMPORTANT: Do not pry against alternator rear frame.

3. Using the gauge (A) on the alternator bracket, stretch belt by prying outward on alternator front frame. Stretch the belt 1 gauge unit for a used belt and 1.5 gauge units for a new belt.
4. Tighten cap screws (B) and (C).



A—Belt gauge
B—Cap screw
C—Cap screw


DPSG,CD03523,57 -19-16AUG99-1/1

Maintenance/1000 hours/1 year

CLEANING CRANKCASE VENT TUBE


If you operate the engine in dusty conditions, clean the tube at shorter intervals.

1. Remove and clean crankcase vent tube (A).
2. Install the vent tube. Be sure the O-ring fits correctly in the rocker arm cover bore for elbow adapter. Tighten hose clamp securely.



DPSG,CD03523,32 -19-12JUL99-1/1

CHECKING AIR INTAKE SYSTEM



IMPORTANT: The air intake system must not leak. Any leak, no matter how small, may result in engine failure due to abrasive dirt and dust entering the intake system.


1. Inspect all intake hoses (piping) for cracks. Replace as necessary.
2. Check clamps on piping (A) which connect the air filter, engine and, if present, turbocharger and air-to-air radiator. Tighten clamps as necessary.
3. Test air restriction indicator (B) for proper operation. Replace indicator as necessary.

Continued on next page

DPSG,CD03523,33 -19-12JUL99-1/2

Maintenance/1000 hours/1 year

- 4. If engine has a rubber dust unloading valve (C), inspect the valve on bottom of air filter for cracks or plugging. Replace as necessary.
- 5. Service air filter as necessary.




RG4687 -UN-20DEC88

DPSG,CD03523,33 -19-12JUL99-2/2

CHECKING AUTOMATIC BELT TENSIONER (POWERTECH ENGINES)

It drive systems equipped with automatic (spring) belt tensioners cannot be adjusted or repaired. The automatic belt tensioner is designed to maintain proper belt tension over the life of the belt. If tensioner spring tension is not within specification, replace tensioner assembly.

- **Checking belt wear**
The belt tensioner is designed to operate within the limit of arm movement provided by the cast stops (A) and (B) when correct belt length and geometry is used. If the tensioner stop on swing arm (A) is hitting the fixed stop (B), check mounting brackets (alternator, belt tensioner, idler pulley, etc.) and the belt length. Replace belt as needed (see REPLACING FAN AND ALTERNATOR BELTS).



RG8098 -UN-18NOV97

Continued on next page


DPSG,CD03523,34 -19-13JUL99-1/2

Maintenance/1000 hours/1 year

- **Checking tensioner spring tension**

A belt tension gauge will not give an accurate measure of the belt tension when automatic spring tensioner is used. Measure tensioner spring tension using a torque wrench and procedure outlined below:

- Release tension on belt using a breaker bar and socket on tension arm. Remove belt from pulleys.
- Release tension on tension arm and remove breaker bar.
- Put a mark (A) on swing arm of tensioner as shown.
- Measure 21 mm (0.83 in.) from (A) and put a mark (B) on tensioner mounting base.
- Rotate the swing arm using a torque wrench until marks (A) and (B) are aligned.
- Record torque wrench measurement and compare with specification below. Replace tensioner assembly as required.



RG7977 -JUN-14NOV97

Spring—Specification

Force..... 18—22 N•m (13—16 lb-ft)


DPSG,CD03523,34 -19-13JUL99-2/2

CHECK AND ADJUST ENGINE VALVE CLEARANCE (300-SERIES ENGINES)

NOTE: Valve clearance must be adjusted after the first 500 hours of operation, then every 1000 hours thereafter.

Adjust engine valve clearance as follows or have your authorized servicing dealer or engine distributor adjust the engine valve clearance.

1. Remove rocker arm cover and crankcase vent tube.
2. Using JDE83 or JDG820 Flywheel Turning Tool (A), rotate engine flywheel in running direction (clockwise viewed from water pump) until No.1 piston (front) has reached top dead center (TDC) on compression stroke. Insert timing pin JDE81-4 (B) into flywheel bore.



C1207544 -JUN-14MAY98

Continued on next page

DPSG,CD03523,35 -19-13JUL99-1/4

Maintenance/1000 hours/1 year



3. Check and adjust valve clearance to specifications according to following procedures.

Valve clearance (engine cold)—Specification

Intake.....	0.35 mm (0.014 in.)
Exhaust.....	0.45 mm (0.018 in.)

NOTE: If rocker arm is equipped with adjusting screw and lock nut (A), tighten lock nut to 27 N·m (20 lb-ft) after adjusting valve clearance.

4. Reinstall rocker arm cover and crankcase vent tube.




DPSG.CD03523.35 -19-13JUL99-2/4

• 3-Cylinder Engine:

NOTE: Firing order is 1-2-3.

- Lock No. 1 piston at TDC compression stroke (D).
- Adjust valve clearance on No. 1 and 2 exhaust valves and No. 1 and 3 intake valves.
- Rotate flywheel 360°. Lock No. 1 piston at TDC exhaust stroke (E).
- Adjust valve clearance on No. 3 exhaust valve and No. 2 intake valve.



A—Front of engine
B—Exhaust valve
C—Intake valve
D—No.1 Piston at TDC compression stroke
E—No.1 Piston at TDC exhaust stroke

Continued on next page


DPSG.CD03523.35 -19-13JUL99-3/4

Maintenance/1000 hours/1 year

• 4-Cylinder Engine:

NOTE: Firing order is 1-3-4-2.

- Lock No. 1 piston at TDC compression stroke (B).
- Adjust valve clearance on No. 1 and 3 exhaust valves and No. 1 and 2 intake valves.
- Rotate flywheel 360°. Lock No. 4 piston at TDC compression stroke (C).
- Adjust valve clearance on No. 2 and 4 exhaust valves and No. 3 and 4 intake valves.



A—Front of engine
 B—No.1 Piston at TDC compression stroke
 C—No.4 Piston at TDC compression stroke
 E—Exhaust valve
 I—Intake valve

RG4776 -JUN-31OCT197


DPSG,CD03523,35 -19-13JUL99-4/4

Maintenance/2000 hours/2 years

CHECK AND ADJUST ENGINE VALVE CLEARANCE (POWERTECH ENGINE)

Adjust engine valve clearance as follows or have your authorized servicing dealer or engine distributor adjust the engine valve clearance.

- 1. Remove rocker arm cover and crankcase vent tube.
- 2. Using JDE83 or JDG820 Flywheel Turning Tool (A), rotate engine flywheel in running direction (clockwise viewed from water pump) until No.1 piston (front) has reached top dead center (TDC) on compression stroke. Insert timing pin JDE81-4 (B) into flywheel bore.



CD30544 -UN-19MAY98


DPSG,CD03523,36 -19-13JUL99-1/4

- 3. Check and adjust valve clearance to specifications according to following procedures.

Valve clearance (engine cold)—Specification

Intake.....	0.35 mm (0.014 in.)
Exhaust.....	0.45 mm (0.018 in.)

- 4. If valves need adjusting, loosen the lock nut on rocker arm adjusting screw. Turn adjusting screw until feeler gauge slips with a slight drag. Hold the adjusting screw from turning with screwdriver and tighten lock nut to 27 N•m (20 lb-ft). Recheck clearance again after tightening lock nut. Readjust clearance as necessary
- 5. Reinstall rocker arm cover and crankcase vent tube.



RG7408 -UN-08AUG98

Continued on next page


DPSG,CD03523,36 -19-13JUL99-2/4

Maintenance/2000 hours/2 years

• 4-Cylinder Engine:

NOTE: Firing order is 1-3-4-2.

- Lock No. 1 piston at TDC compression stroke (B).
- Adjust valve clearance on No. 1 and 3 exhaust valves and No. 1 and 2 intake valves.
- Rotate flywheel 360°. Lock No. 4 piston at TDC compression stroke (C).
- Adjust valve clearance on No. 2 and 4 exhaust valves and No. 3 and 4 intake valves.



A—Front of engine
B—No.1 Piston at TDC compression stroke
C—No.4 Piston at TDC compression stroke
E—Exhaust valve
I—Intake valve


RG4776 -UN-31OCT97

DPSG,CD03523.36 -19-13JUL99-3/4

• 6-Cylinder Engine:

NOTE: Firing order is 1-5-3-6-2-4.

- Lock No. 1 piston at TDC compression stroke (B).
- Adjust valve clearance on No. 1, 3, and 5 exhaust valves and No. 1, 2, and 4 intake valves.
- Rotate flywheel 360°. Lock No. 6 piston at TDC compression stroke (C).
- Adjust valve clearance on No. 2, 4, and 6 exhaust valves and No. 3, 5, and 6 intake valves.



A—Front of engine
B—No.1 Piston at TDC compression stroke
C—No.6 Piston at TDC compression stroke
E—Exhaust valve
I—Intake valve

RG4777 -UN-31OCT97

DPSG,CD03523.36 -19-13JUL99-4/4

Maintenance/2000 hours/2 years


CHECKING ENGINE SPEED

NOTE: Most engines for generator set application (1500 rpm for 50 Hz or 1800 rpm for 60 Hz) run only at fast idle and therefore they do not have slow idle.

Fast idle—Specification

50 Hz Generator set.....	1550—1580 rpm
60 Hz Generator set.....	1865—1890 rpm

NOTE: Fast idle is settled by the factory then the idle adjusting screw (A) is sealed to prevent from tampering. Fast idle adjustment can only be done by an authorized fuel system agent.




CD30763 -UN-24SEP99

DPSG,CD03523,38 -19-13JUL99-1/1

ADJUST SPEED DROOP GOVERNOR

1. Warm engine to normal operating temperature.
2. Run engine at fast idle.
3. Apply full load.
4. If specified power cannot be obtained, turn screw (B) to adjust droop until the requested power is reached.

NOTE: If surging exists upon removing the load, turn screw (B) clockwise to eliminate.



CD30764 -UN-24SEP99

DPSG,CD03523,39 -19-13JUL99-1/1

Maintenance/2000 hours/2 years

CHECKING CRANKSHAFT VIBRATION DAMPER (6-CYLINDER ENGINE ONLY)


1. Remove belts (shown removed).
2. Grasp vibration damper with both hands and attempt to turn it in both directions. If rotation is felt, damper is defective and should be replaced.

IMPORTANT: The vibration damper assembly is not repairable and should be replaced every 4500 hours or 5 years, whichever occurs first.

3. Check vibration damper radial runout by positioning a dial indicator so probe contacts damper outer circumference.
4. With engine at operating temperature, rotate crankshaft using JDG820 or JDE83 Flywheel Turning Tool.
5. Note dial indicator reading. If runout exceeds specifications given below, replace vibration damper.

Damper—Specification

Maximum radial runout..... 1.50 mm (0.060 in.)



RG8018 -JUN-15JAN99



DPSG,CD03523,40 -19-13JUL99-1/1

Maintenance/2500 hours/3 years

DRAIN AND FLUSH COOLING SYSTEM

NOTE: Drain and flush cooling system every 2500 hours/3 years when John Deere COOL-GARD coolant is used. Otherwise every 2000 hours/2 years.


CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


- 1 Slowly open the radiator cap.
2. Remove engine block drain plug (A).
3. On POWERTech engines, remove oil cooler housing drain plug (B).
4. Open radiator drain valve (C). Drain all coolant from radiator.
5. Close all drain orifices after coolant has drained.
6. Fill the cooling system with clean water. Run engine until water passes through the thermostat to stir up possible rust or sediment.
7. Stop engine and immediately drain the water from system before rust and sediment settle.
8. After draining water, close all drain orifices and fill the cooling system with clean water and TY15979 John Deere Heavy Duty Cooling System Cleaner or equivalent cleaner. Follow manufacturer's directions on label.
9. After cleaning the cooling system, drain cleaner and fill with water to flush the system. Run engine until water passes through the thermostat, then drain out flushing water.




T5281 -UN-23AUG88



RG4894 -UN-14DEC88



ZX015192



CD30765 -UN-27AUG99

Continued on next page

DPSG.CD03523.41 -19-13JUL99-1/3

Maintenance/2500 hours/3 years


- 10. Check cooling system hoses for proper condition.
Replace as necessary.
- 11. Close all drain orifices and fill the cooling system with
specified coolant (see DIESEL ENGINE COOLANT).

Cooling system capacity—Specification

CD3029DF128.....	14.5 L (15.5 qt)
CD4039DF008.....	16.5 L (17.5 qt)
CD4039TF008.....	16.5 L (17.5 qt)
CD4045DF158.....	20 L (21 qt)
CD4045HF158.....	25 L (26.5 qt)
CD4045TF158.....	25 L (26.5 qt)
CD4045TF258.....	25 L (26.5 qt)
CD6068HF158.....	29 L (30.5 qt)
CD6068TF158.....	26 L (27.5 qt)
CD6068TF258.....	26 L (27.5 qt)

DPSG,CD03523,41 -19-13JUL99-2/3

- 12. When refilling cooling system, loosen temperature
sensor (B) or plug at the rear of cylinder head to
allow air to escape.
- 13. Run engine until it reaches operating temperature
then check coolant level and entire cooling system for
leaks.



CD30643 -UN-04MAY98


DPSG,CD03523,41 -19-13JUL99-3/3

Maintenance/As required

ADDITIONAL SERVICE INFORMATION

This manual does not allow a complete repair of your engine. If you want more detailed service information the following publications are available from your regular parts channel.

- PC2451 — Parts Catalog
- CTM3274 — Component Technical Manual for 300-Series engines (English)
- CTM104 — Component Technical Manual for POWERTech engines (English)
- CTM67 — Component Technical Manual for OEM Engine accessories (English only)
- CTM77 — Component Technical Manual for Alternators and Starter Motors (English only)




RG4624 -JUN-15DEC88

DPSG.CD03523.42 -19-15JUL99-1/1

DO NOT MODIFY FUEL SYSTEM

IMPORTANT: Modification or alteration of the injection pump, the injection pump timing, or the fuel injectors in ways not recommended by the manufacturer will terminate the warranty obligation to the purchaser.

Do not attempt to service injection pump or fuel injectors yourself. Special training and special tools are required (see your authorized servicing dealer or engine distributor).



RG4624 -JUN-15DEC88

DPSG.CD03523.43 -19-15JUL99-1/1

Maintenance/As required

**CLEAN OR REPLACE AIR FILTER
(ONE-PIECE)**

Clean air filter when restriction indicator (A) is red. Air filter can be cleaned up to six times. Thereafter, or at least once a year, it must be replaced.

Proceed as follows:


1. Thoroughly clean all dirt around air filter area.
2. Loosen clamp (B) then remove air filter.

IMPORTANT: Never reinstall an air filter which shows evidence of bad condition (punched, dented...) allowing no filtered air to enter the engine.


3. Clean air filter with compressed air working from "clean" to "dirty" side.

NOTE: Compressed air must not exceed 600 kPa (6 bar; 88 psi).

4. Mark air filter to keep track of each cleaning operation.
5. Fully depress air restriction indicator reset button and release to reset indicator.
6. Check air system entirely for proper condition (see CHECKING AIR INTAKE SYSTEM).




CD30766 -UN-06SEP99



DPSG,CD03523,44 -19-15JUL99-1/1

Maintenance/As required

CLEAN OR REPLACE AIR FILTER ELEMENT

CD30772 -UN-27AUG99

- A—Primary element
 B—Secondary (safety) element
 C—Air restriction indicator
 D—Wing nut

Clean air filter when restriction indicator (C) is red. Replace both primary (A) and secondary (B) filter elements every 6 primary element cleaning or at least once a year.

Proceed as follows:

1. Thoroughly clean all dirt around air filter area.
2. Remove wing nut (D) and remove primary element (A) from canister.

IMPORTANT: Do not attempt to clean the secondary (safety) element (B). It must be only replaced as recommended.

3. Thoroughly clean all dirt from inside canister.

IMPORTANT: If primary element shows evidence of bad condition (punched,

dented...), replace both the primary and the secondary elements.

4. Clean primary element with compressed air working from "clean" to "dirty" side.

NOTE: Compressed air must not exceed 600 kPa (6 bar; 88 psi).

5. Mark air filter to keep track of each cleaning operation.
6. Fully depress air restriction indicator reset button and release to reset indicator.
7. Check air system entirely for proper condition (see CHECKING AIR INTAKE SYSTEM).

DPSG.CD03523.58 -19-16AUG99-1/1

50-3

112699
PN=65

Maintenance/As required


REPLACING FAN AND ALTERNATOR BELT (POWERTECH ENGINES)

NOTE: Refer to *CHECKING BELT TENSIONER SPRING TENSION AND BELT WEAR* for additional information on the belt tensioner.


1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
2. On engines with automatic belt tensioner, release tension on belt using a breaker bar and socket on tension arm.

On engines with manual tensioner, loosen cap screws holding the alternator.

3. Remove poly-vee belt from pulleys and discard belt.
4. Install new belt, making sure belt is correctly seated in all pulley grooves. Refer to belt routing at right for your application.
5. Apply tension to belt (see *CHECKING BELT*).
6. Start engine and check belt alignment.



Installation on 4 cyl. engines



Installation on 6 cyl. engines

ALT—Alternator
CP—Crankshaft Pulley
FD—Fan Drive
I—Idler Pulley
T—Tensioner
WP—Water Pump

CD30769 -UN-01SEP99

CD30770 -UN-01SEP99

DPSG,CD03523.45 -19-15JUL99-1/1

*Maintenance/As required***CHECKING FUEL FILTER**

Periodically the fuel filter should be checked for water or debris.



IMPORTANT: Drain water into a suitable container and dispose of properly.

1. Loosen drain plug (B) at bottom of fuel filter two or three turns.
2. Loosen air bleed plug two full turns (A) on fuel filter base and drain water from bottom until fuel starts to drain out.
3. When fuel starts to drain out, tighten drain plug securely.

After draining water from the fuel filter, the filter must be primed by bleeding all air from the fuel system. Operate primer lever of the fuel supply pump (C) until fuel flow is free from air bubbles.

5. Tighten bleed plug securely, continue operating hand primer until pumping action is not felt. Push hand primer inward (toward engine) as far as it will go.

If the fuel system needs further bleeding of air, see BLEEDING THE FUEL SYSTEM.



DPSG,CD03523,28 -19-12JUL99-1/1

Maintenance/As required

BLEEDING THE FUEL SYSTEM



CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Whenever the fuel system has been opened up for service (lines disconnected or filters removed), it will be necessary to bleed air from the system.

1. Loosen the air bleed screw (A) two full turns by hand on fuel filter base.
2. Operate supply pump primer lever (B) until fuel flow is free from air bubbles.
3. Tighten bleed plug securely, continue operating hand primer until pumping action is not felt. Push hand primer inward (toward engine) as far as it will go.
4. Start engine and check for leaks.

If engine will not start, it may be necessary to bleed air from fuel system at fuel injection pump or injection nozzles as explained next.



X9811 -UN-23AUG88

FG68013A -UN-15JAN89


Continued on next page

DPSG.CD03523,46 -19-10AUG99-1/2

Maintenance/As required

- **At Fuel Injection Pump:**


- Slightly loosen fuel return line connector (C) at fuel injection pump.
- Operate fuel supply pump primer lever until fuel, without air bubbles, flows from fuel return line connection.
- Tighten return line connector to 16 N•m (12 lb-ft).
- Leave hand primer in the inward position toward cylinder block.



CD30771 -UN-24SEP99

- **At Fuel Injection Nozzles:**

- Using two open-end wrenches, loosen fuel line connection at injection nozzle.
- Crank engine over with starting motor (but do not start engine), until fuel free from bubbles flows out of loosened connection. Retighten connection to 27 N•m (20 lb-ft).
- Repeat procedure for remaining injection nozzles (if necessary) until all air has been removed from fuel system.



RG7725 -UN-08JAN97

If engine still will not start, see your authorized servicing dealer or engine distributor.

DPSG,CD03523,46 -19-10AUG99-2/2

Troubleshooting

ENGINE TROUBLESHOOTING

Symptom	Problem	Solution
Engine cranks but will not start	Incorrect starting procedure.	Verify correct starting procedure.
	No fuel.	Check fuel in tank and manual shut-off valve.
	Exhaust restricted.	Check and correct exhaust restriction.
	Fuel filter plugged or full of water.	Replace fuel filter or drain water from filter.
	Injection pump not getting fuel or air in fuel system.	Check fuel flow at supply pump or bleed fuel system.
	Faulty injection pump or nozzles.	Consult authorized diesel repair station for repair or replacement.
Engine hard to start or will not start	Engine starting under load.	Remove load.
	Improper starting procedure.	Review starting procedure.
	No fuel.	Check fuel tank.
	Air in fuel line.	Bleed fuel line.
	Cold weather.	Use cold weather starting aids.
	Slow starter speed.	See "Starter Cranks Slowly".
	Crankcase oil too heavy.	Use oil of correct viscosity.
	Improper type of fuel.	Consult fuel supplier; use proper type fuel for operating conditions.
	Water, dirt or air in fuel system.	Drain, flush, fill and bleed system.
	Clogged fuel filter.	Replace filter element.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.

Continued on next page

DPSG,CD03523,49 -19-10AUG99-1/5

55-1

112699
PN=70

Troubleshooting

Symptom	Problem	Solution
Engine knocks	Injection pump shut-off not reset.	Turn key switch to "OFF" then to "ON".
	Low engine oil level.	Add oil to engine crankcase.
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Low coolant temperature.	Remove and check thermostat.
Engine runs irregularly or stalls frequently	Engine overheating.	See "Engine Overheats".
	Low coolant temperature.	Remove and check thermostat.
	Clogged fuel filter.	Replace fuel filter element.
	Water, dirt or air in fuel system.	Drain, flush, fill and bleed system.
Below normal engine temperature	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.
	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check gauge, sender and connections.
Lack of power	Engine overloaded.	Reduce load.
	Intake air restriction.	Service air cleaner.
	Clogged fuel filter.	Replace filter element.
	Improper type of fuel.	Use proper fuel.
	Overheated engine.	See "Engine Overheats".
	Below normal engine temperature.	Remove and check thermostat.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Dirty or faulty injection nozzles.	Have authorized servicing dealer or engine distributor check injectors.

Continued on next page

DPSG.CD03523.49 -19-10AUG99-2/5

Troubleshooting

Symptom	Problem	Solution
	Injection pump out of time.	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning.	See your authorized servicing dealer or engine distributor.
	Leaking exhaust manifold gasket.	See your authorized servicing dealer or engine distributor.
	Defective aneroid control line.	See your authorized servicing dealer or engine distributor.
	Restricted fuel hose.	Clean or replace fuel hose.
	Low fast idle speed.	See your authorized servicing dealer or engine distributor.
Low oil pressure	Low oil level.	Add oil.
	Improper type of oil.	Drain and fill crankcase with oil of proper viscosity and quality.
High oil consumption	Crankcase oil too light.	Use oil of correct viscosity.
	Oil leaks.	Check for leaks in lines, gaskets, and drain plug.
	Restricted crankcase vent tube.	Clean vent tube.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
Engine emits white smoke	Improper type of fuel.	Use proper fuel.
	Low engine temperature.	Warm up engine to normal operating temperature.
	Defective thermostat.	Remove and check thermostat.
	Defective injection nozzles.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.

Continued on next page

DPSG.CD03523,49 -19-10AUG99-3/5

Troubleshooting

Symptom	Problem	Solution
Engine emits black or grey exhaust smoke	Improper type of fuel.	Use proper fuel.
	Clogged or dirty air cleaner.	Service air cleaner.
	Engine overloaded.	Reduce load.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
	Turbocharger not functioning.	See your authorized servicing dealer or engine distributor.
Engine overheats	Engine overloaded.	Reduce load.
	Low coolant level.	Fill radiator to proper level, check radiator and hoses for loose connections or leaks.
	Faulty radiator cap.	Have serviceman check.
	Stretched poly-vee belt or defective belt tensioner.	Check automatic belt tensioner and check belts for stretching. Replace as required.
	Low engine oil level.	Check oil level. Add oil as required.
	Cooling system needs flushing.	Flush cooling system.
	Defective thermostat.	Remove and check thermostat.
	Defective temperature gauge or sender.	Check coolant temperature with thermometer and replace, if necessary.
High fuel consumption	Incorrect grade of fuel.	Use correct grade of fuel.
	Improper type of fuel.	Use proper type of fuel.
	Clogged or dirty air cleaner.	Service air cleaner.

Continued on next page

DPSG.CD03523.49 -19-10AUG99-4/5

Troubleshooting

Symptom	Problem	Solution
	Engine overloaded.	Reduce load.
	Improper valve clearance.	See your authorized servicing dealer or engine distributor.
	Injection nozzles dirty.	See your authorized servicing dealer or engine distributor.
	Engine out of time.	See your authorized servicing dealer or engine distributor.
	Defective turbocharger.	See your authorized servicing dealer or engine distributor.
	Low engine temperature.	Check thermostat.

DPSG,CD03523,49 -19-10AUG99-5/5

Troubleshooting

ELECTRICAL TROUBLESHOOTING

Symptom	Problem	Solution
Undercharged system	Excessive electrical load from added accessories.	Remove accessories or install higher output alternator.
	Excessive engine idling.	Increase engine rpm when heavy electrical load is used.
	Poor electrical connections on battery, ground strap, starter or alternator.	Inspect and clean as necessary.
	Defective battery.	Test battery.
	Defective alternator.	Test charging system.
Battery uses too much water	Cracked battery case.	Check for moisture and replace as necessary.
	Defective battery.	Test battery.
	Battery charging rate too high.	Test charging system.
Battery will not charge	Loose or corroded connections.	Clean and tighten connections.
	Sulfated or worn-out battery.	See your authorized servicing dealer or engine distributor.
	Stretched poly-vee belt or defective belt tensioner.	Adjust belt tension or replace belts.
Starter will not crank	Engine under load	Remove load
	Loose or corroded connections.	Clean and tighten loose connections.
	Low battery output voltage.	See your authorized servicing dealer or engine distributor.
	Faulty start circuit relay.	See your authorized servicing dealer or engine distributor.
	Blown fuse.	Replace fuse.

Continued on next page

DPSG.C003523.50 -19-10AUG99-1/2

55-6

112699
PN=75

Troubleshooting

Symptom	Problem	Solution
Starter cranks slowly	Low battery output.	See your authorized servicing dealer or engine distributor.
	Crankcase oil too heavy.	Use proper viscosity oil.
	Loose or corroded connections.	Clean and tighten loose connections.
Entire electrical system	Faulty battery connection.	Clean and tighten connections.
	Sulfated or worn-out battery.	See your authorized servicing dealer or engine distributor.
	Blown fuse.	Replace fuse.

DPSG,CD03523,50 -19-10AUG99-2/2

Storage

ENGINE STORAGE GUIDELINES


1. John Deere engines can be stored outside for up to three (3) months with no long term preparation IF COVERED BY WATERPROOF COVERING.
2. John Deere engines can be stored in a standard overseas shipping container for up to three (3) months with no long term preparation.
3. John Deere engines can be stored inside, warehoused, for up to six (6) months with no long term preparation.
4. John Deere engines expected to be stored more than six (6) months, long term storage preparation MUST BE taken. (See PREPARING ENGINE FOR LONG TERM STORAGE).
5. For John Deere engines not yet installed in machines, run a line from a container of AR41937 Nucle Oil (from AR41785 Engine Storage Kit) to the fuel transfer pump intake, and another line from the fuel return manifold to the tank, so that Nucle Oil is circulated through the injection system during cranking.

DPSG,CD03523,51 -19-10AUG99-1/1

USE AR41785 ENGINE STORAGE KIT

See your John Deere servicing dealer or engine distributor for an AR41785 Engine Storage Kit. Closely follow instructions provided with this kit.

IMPORTANT: Inhibitors can easily change to gas. Seal or tape each opening immediately after adding inhibitor.



DPSG,CD03523,52 -19-10AUG99-1/1

Storage

PREPARING ENGINE FOR LONG TERM STORAGE

The following storage preparations are good for long term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.

IMPORTANT: Any time your engine will not be used for over six (6) months, the following recommendations for storing it and removing it from storage will help to minimize corrosion and deterioration. Use the AR41785 Engine Storage Kit. Follow recommended service procedure included with storage kit.

1. Change engine oil and replace filter. Used oil will not give adequate protection. (See CHANGING ENGINE OIL AND FILTER).
2. Service air cleaner. (See CLEAN OR REPLACE AIR FILTER).
3. Draining and flushing of cooling system is not necessary if engine is to be stored only for several months. However, for extended storage periods of a year or longer, it is recommended that the cooling system be drained, flushed, and refilled. Refill with appropriate coolant. (See DIESEL ENGINE COOLANT).
4. Drain fuel tank and add 30 ml (1 oz) of inhibitor to the fuel tank for each 15 L (4 U.S. gal) of tank capacity. Completely drain fuel filter and close fuel valve, if equipped.
5. Add 30 ml (1 oz) of inhibitor to the engine crankcase for each 0.95 L (1 qt) of crankcase oil.
6. Disconnect air intake piping from the manifold. Pour 90 ml (3 oz) of inhibitor into intake system and reconnect the piping.
7. Crank the engine several revolutions with starter (do not allow the engine to start).
8. Remove fan/alternator belt, if desired.
9. Remove and clean battery. Store them in a cool, dry place and keep them fully charged.
10. Clean the exterior of the engine with salt-free water and touchup any scratched or chipped painted surfaces with a good quality paint.
11. Coat all exposed (machined) metal surfaces with grease or corrosion inhibitor if not feasible to paint.
12. Seal all openings on engine with plastic bags and tape supplied in storage kit. Follow instructions supplied in kit.
13. Store the engine in a dry protected place. If engine must be stored outside, cover it with a waterproof canvas or other suitable protective material and use a strong waterproof tape.

DPSG,CD03523,53 -19-10AUG99-1/1

Storage

REMOVING ENGINE FROM LONG TERM STORAGE

Refer to the appropriate section for detailed services listed below or have your authorized servicing dealer or engine distributor perform services that you may not be familiar with.

1. Remove all protective coverings from engine. Unseal all openings in engine and remove covering from electrical systems.
2. Remove the battery from storage. Install battery (fully charged) and connect the terminals.
3. Install fan/alternator belt if removed.
4. Fill fuel tank.

Perform all appropriate prestarting checks. (See DAILY PRESTARTING CHECKS).

IMPORTANT: DO NOT operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

6. Crank engine for 20 seconds with starter (do not allow the engine to start). Wait 2 minutes and crank engine an additional 20 seconds to assure bearing surfaces are adequately lubricated.
7. Start engine and run at no load for several minutes. Warm up carefully and check all gauges before placing engine under load.
8. On the first day of operation after storage, check overall engine for leaks and check all gauges for correct operation.

DPSG.CD03523.54 -19-10AUG99-1/1

Specifications

GENERAL ENGINE SPECIFICATIONS

ITEM	UNIT OF MEASURE	3029DF128	4039DF008	4039TF008
Number of Cylinders		3	4	4
Fuel		Diesel	Diesel	Diesel
Bore	mm	106.5	106.5	106.5
Stroke	mm	110	110	110
Displacement	L	2.9	3.9	3.9
Compression Ratio		17.8:1	17.8:1	17.8:1
POWER* @ 1500 rpm (Prime)	kW (hp)	26 (35)	35 (48)	55 (75)
POWER* @ 1500 rpm (Standby)	kW (hp)	30 (41)	38 (52)	61 (83)
POWER* @ 1800 rpm (Prime)	kW (hp)	30 (41)	41 (56)	67 (91)
POWER* @ 1800 rpm (Standby)	kW (hp)	34 (46)	47 (64)	73 (99)
Width (overall)	mm	582	588	588
Length (overall)	mm	888	1016	1016
Height (overall)	mm	931	960	979
Weight (dry) ^b	kg	345	410	455
Engine oil quantity	L	6	12	12
Engine coolant quantity	L	14.5	16.5	16.5

*With Fan

^bApproximate

Continued on next page

DPSG.CD03523.55 -19-10AUG99-1/3

Specifications












ITEM	UNIT OF MEASURE	4045HF158	4045TF158	4045TF258	4045DF158
Number of Cylinders		4	4	4	4
Fuel		Diesel	Diesel	Diesel	Diesel
Bore	mm	106.5	106.5	106.5	106.5
Stroke	mm	127	127	127	127
Displacement	L	4.5	4.5	4.5	4.5
Compression Ratio		17.0:1	17.0:1	17.0:1	17.6:1
POWER* @ 1500 rpm (Prime)	kW (hp)	88 (120)	61 (83)	72 (98)	41 (56)
POWER* @ 1500 rpm (Standby)	kW (hp)	96 (131)	68 (92)	80 (109)	42 (57)
POWER* @ 800 rpm (Prime)	kW (hp)	108 (147)	72 (98)	80 (109)	48 (65)
POWER* @ 1800 rpm (Standby)	kW (hp)	120 (163)	79 (107)	88 (120)	51 (69)
Width (overall)	mm	798	668	668	668
Length (overall)	mm	1356	1219	1219	1219
Height (overall)	mm	1136	1010	1010	1010
Weight (dry) ^b	kg	446	436	436	391
Engine oil quantity	L	12	12	12	8
Engine coolant quantity	L	25	25	25	20
*With Fan					
^b Approximate					
Continued on next page					
DPSG.CD03523.55 -19-10AUG99-2/3					

Specifications

ITEM	UNIT OF MEASURE	6068HF158	6068TF158	6068TF258
Number of Cylinders		6	6	6
Fuel		Diesel	Diesel	Diesel
Bore	mm	106.5	106.5	106.5
Stroke	mm	127	127	127
Displacement	L	6.8	6.8	6.8
Compression Ratio		17.0:1	17.0:1	17.0:1
POWER* @ 1500 rpm (Prime)	kW (hp)	134 (182)	92 (125)	105 (143)
POWER* @ 1500 rpm (Standby)	kW (hp)	148 (201)	101 (137)	116 (158)
POWER* @ 1800 rpm (Prime)	kW (hp)	164 (223)	108 (147)	124 (169)
POWER* @ 1800 rpm (Standby)	kW (hp)	187 (254)	119 (162)	137 (186)
Width (overall)	mm	798	668	668
Length (overall)	mm	1476	1383	1383
Height (overall)	mm	1136	1032	1032
Weight (dry) ^b	kg	613	593	593
Engine oil quantity	L	19.5	19.5	19.5
Engine coolant quantity	L	29	26	26
*With Fan				
^b Approximate				
DPSG,CD03523,55 -19-10AUG99-3/3				

Specifications

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

SAE Grade and Head Markings	1 or 2 ^b 	5 	5.1 	5.2 	8 	8.2 
SAE Grade and Nut Markings	2 	5 			8 	

Size	Grade 1				Grade 2 ^b				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	240	175	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	400	300	510	375	400	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.



















Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

TS1656 -19-02APR97

DX,TORQ1 -19-20JUL94-1/1

Specifications

METRIC BOLT AND CAP SCREW TORQUE VALUES

Property Class and Head Markings	4.8  	8.8  	9.8  	10.9  	12.9  
Property Class and Nut Markings	5  	10  	10  	12  	

Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	255	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

DX.TORQ2 -19-20JUL94-1/1

TS1657 -19-02APR97

Index



	Page		Page
A		Fuel system	
Air filter		Bleeding	50-6
Clean or replace (one-piece)	50-2	Fuel	
Clean or replace element	50-3	Diesel	10-1
Air intake system		Handling and storing	10-1
Checking	35-1		
B		I	
Belt		Identification views	01-1
Check automatic tensioner	35-2	Inch torque values	65-4
Check tension	30-4		
Replace (POWERTech)	50-4	L	
Break-in engine oil	10-2	Lubricant	
C		Mixing	10-4
Coolant		Storage	10-3
Diesel engine	10-4	M	
Drain and flush cooling system	45-1	Maintenance records	02-1
Warm temperature climates	10-5	Maintenance	
Crankcase vent tube		1000 hours/1 year	
Cleaning	03-1, 35-1	Check and adjust valve clearance	
D		(300-Series)	35-3
Damper	40-4	Checking air intake system	35-1
Diesel engine oil	10-3	Checking automatic belt tensioner	
Diesel fuel	10-1	(POWERTech)	35-2
E		Cleaning crankcase vent tube	03-1, 35-1
Engine oil		2000 hours/2 years	
Break-In	10-2	Adjust speed droop governor	40-3
Diesel	10-3	Adjust valve clearance (POWERTech)	40-1
Draining	30-1	Check engine speed	40-3
Engine speed	40-3	Damper check	40-4
F		2500 hours/3 years	
Fuel filter		Drain and flush cooling system	45-1
Replacement	30-3	50 hours/2 weeks	
		Checking fuel filter	50-5
		500 hours	
		Changing engine oil and filter	30-1
		Checking belt	30-4
		Replace fuel filter	30-3
		As required	
		Additional service information	50-1
		Clean or replace air filter (one-piece)	50-2
		Clean or replace air filter element	50-3
		Do not modify fuel system	50-1

Index

	Page		Page
Replace fan and alternator belts (POWERTech)	50-4	V	
Daily or every 10 hours	25-1	Valve clearance	
Observe service intervals	20-1	Adjust (300-Series)	35-3
Use correct fuel, lubricant and coolant	20-1	Adjust (POWERTech)	40-1
Metric torque values	65-5		
Mixing lubricants	10-4		
O			
Operating the engine			
Break-in period	15-1		
Engine operation	15-4		
Standby power units	15-4		
Starting the engine	15-1		
Stopping the engine	15-5		
Using a booster battery or charger	15-3		
R			
Record keeping			
Engine option codes	03-3		
Engine serial number plate	03-1		
POWERTech medallion	03-1		
Record engine serial number	03-2		
Record fuel injection pump model number ...	03-5		
S			
Specifications			
Engine	65-1		
Storage			
Engine	60-1		
Storing fuel	10-1		
Storing lubricants	10-3		
T			
Torque values			
Inch.	65-4		
Metric	65-5		
Troubleshooting			
Electrical	55-6		
Engine	55-1		

Index-2

112699
PN=2



Installation, Service & Maintenance Manual

for AC generators with the following prefixes:

UCI; UCM; UCD 224 & 274 .

SAFETY PRECAUTIONS

Before operating the generating set, read the generating set operation manual and this generator manual and become familiar with it and the equipment.

SAFE AND EFFICIENT OPERATION CAN ONLY BE ACHIEVED IF THE EQUIPMENT IS CORRECTLY OPERATED AND MAINTAINED.

Many accidents occur because of failure to follow fundamental rules and precautions.

ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.

- Ensure installation meets all applicable safety and local electrical codes. Have all installations performed by a qualified electrician.
- Do not operate the generator with protective covers, access covers or terminal box covers removed.
- Disable engine starting circuits before carrying out maintenance.
- Disable closing circuits and/or place warning notices on any circuit breakers normally used for connection to the mains or other generators, to avoid accidental closure.

Observe all **IMPORTANT, CAUTION, WARNING, and DANGER** notices, defined as:

Important ! Important refers to hazard or unsafe method or practice which can result in product damage or related equipment damage.

Caution ! Caution refers to hazard or unsafe method or practice which can result in product damage or personal injury.



Warning !

Warning refers to a hazard or unsafe method or practice which **CAN** result in severe personal injury or possible death.



Danger !

Danger refers to immediate hazards which **WILL** result in severe personal injury or death.

Due to our policy of continuous improvement, details in this manual which were correct at time of printing, may now be due for amendment. Information included must therefore not be regarded as binding.

FOREWORD

The function of this book is to provide the user of the Stamford generator with an understanding of the principles of operation, the criteria for which the generator has been designed, and the installation and maintenance procedures. Specific areas where the lack of care or use of incorrect procedures could lead to equipment damage and/or personal injury are highlighted, with **WARNING** and/or **CAUTION** notes, and it is **IMPORTANT** that the contents of this book are read and understood before proceeding to fit or use the generator.

The Service, Sales and technical staff of Newage International are always ready to assist and reference to the company for advice is welcomed.



Warning !

Incorrect installation, operation, servicing or replacement of parts can result in severe personal injury or death, and/or equipment damage.

Service personnel must be qualified to perform electrical and mechanical service.

EC DECLARATION OF INCORPORATION

All Stamford generators are supplied with a declaration of incorporation for the relevant EC legislation, typically in the form of a label as below.

EC DECLARATION OF INCORPORATION

IN ACCORDANCE WITH THE SUPPLY OF MACHINERY (SAFETY) REGULATIONS 1992 AND THE SUPPLY OF MACHINERY (SAFETY) (AMENDMENT) REGULATIONS 1994 IMPLEMENTING THE EC MACHINERY DIRECTIVE 89/392/EEC AS AMENDED BY 91/368/EEC.

THIS STAMFORD A.C. GENERATOR WAS
MANUFACTURED BY OR ON BEHALF OF
NEWAGE INTERNATIONAL LTD
BARNACK ROAD STAMFORD LINCOLNSHIRE ENGLAND.

THIS COMPONENT MACHINERY MUST NOT BE PUT INTO SERVICE UNTIL THE MACHINERY INTO WHICH IT IS TO BE INCORPORATED HAS BEEN DECLARED IN CONFORMITY WITH THE PROVISIONS OF THE SUPPLY OF MACHINERY (SAFETY) REGULATIONS 1995/MACHINERY DIRECTIVE.

FOR AND ON BEHALF OF NEWAGE INTERNATIONAL LIMITED

NAME: LAWRENCE HAYDOCK

POSITION: TECHNICAL DIRECTOR

SIGNATURE:

THIS COMPONENT MACHINERY CARRIES THE CE MARK FOR COMPLIANCE WITH THE STATUTORY REQUIREMENTS FOR THE IMPLEMENTATION OF THE FOLLOWING DIRECTIVES

The EMC Directive 89/336/EEC

WARNING! This Component Machinery shall not be used in the Residential, Commercial and Light Industrial environment unless it also conforms to the relevant standard (EN 50081 - 1) REFER TO FACTORY FOR DETAILS

ii) The Low Voltage Directive 73/23/EEC as amended by 93/68/EEC

Under the EC Machinery Directive section 1.7.4. It is the responsibility of the generator set builder to ensure the generator identity is clearly displayed on the front cover of this book.



ELECTROMAGNETIC COMPATIBILITY

Additional Information

European Union

Council Directive 89/336/EEC

For installations within the European Union, electrical products must meet the requirements of the above directive, and Newage ac generators are supplied on the basis that:

- They are to be used for power-generation or related function.
- They are to be applied in one of the following environments:

Portable (open construction - temporary site supply)
Portable (enclosed - temporary site supply)
Containerised (temporary or permanent site supply)
Ship-borne below decks (marine auxiliary power)
Commercial vehicle (road transport / refrigeration etc)
Rail transport (auxiliary power)
Industrial vehicle (earthmoving, cranes etc)
Fixed installation (industrial - factory / process plant)
Fixed installation (residential, commercial and light industrial - home / office / health)
Energy management (Combined heat and power and/or peak lopping)
Alternative energy schemes

- The standard generators are designed to meet the 'industrial' emissions and immunity standards. Where the generator is required to meet the residential, commercial and light industrial emissions and immunity standards reference should be made to Newage document reference N4/X/011, as additional equipment may be required.
- The installation earthing scheme involves connection of the generator frame to the site protective earth conductor using a minimum practical lead length.
- Maintenance and servicing with anything other than factory supplied or authorised parts will invalidate any Newage liability for EMC compliance.
- Installation, maintenance and servicing is carried out by adequately trained personnel fully aware of the requirements of the relevant EC directives.

CONTENTS

SAFETY PRECAUTIONS

FOREWORD		1
CONTENTS		2&3
SECTION 1	INTRODUCTION	4
1.1	INTRODUCTION	4
1.2	DESIGNATION	4
1.3	SERIAL NUMBER LOCATION AND IDENTITY NUMBER LOCATION	4
1.4	RATING PLATE AND CE MARKING	4
SECTION 2	PRINCIPLE OF OPERATION	5
2.1	SELF-EXCITED AVR CONTROLLED GENERATORS	5
2.2	PERMANENT MAGNET GENERATOR (PMG) EXCITED - AVR CONTROLLED GENERATORS	5
2.3	AVR ACCESSORIES	5
2.4	TRANSFORMER CONTROLLED GENERATORS	5
SECTION 3	APPLICATION OF THE GENERATOR	6
SECTION 4	INSTALLATION - PART 1	8
4.1	LIFTING	8
4.2	ASSEMBLY	8
4.2.1	NO FOOT OPTION	8
4.2.2	TWO BEARING GENERATORS	9
4.2.3	SINGLE BEARING GENERATORS	9
4.3	EARTHING	9
4.4	PRE-RUNNING CHECKS	9
4.4.1	INSULATION CHECK	9
4.4.2	DIRECTION OF ROTATION	10
4.4.3	VOLTAGE AND FREQUENCY	10
4.4.4	AVR SETTINGS	10
4.4.4.1	TYPE SX460 AVR	10
4.4.4.2	TYPE SX440 AVR	10
4.4.4.3	TYPE SX421 AVR	11
4.4.4.4	TYPE MX341 AVR	11
4.4.4.5	TYPE MX321 AVR	11
4.4.5	TRANSFORMER CONTROLLED EXCITATION SYSTEM (Series 5)	12
4.5	GENERATOR SET TESTING	12
4.5.1	TEST METERING/CABLING	12
4.6	INITIAL START-UP	12
4.7	LOAD TESTING	13
4.7.1	AVR CONTROLLED GENERATORS - AVR ADJUSTMENTS	13
4.7.1.1	UFRO (Under Frequency Roll Off) (AVR Types SX460, SX440, SX421, MX341 and MX321)	13
4.7.1.2	EXC TRIP (Excitation Trip)	14
4.7.1.3	OVER/V (Over Voltage)	14
4.7.1.4	TRANSIENT LOAD SWITCHING ADJUSTMENTS	14
4.7.1.5	RAMP BUILD UP TIME	15
4.7.2	TRANSFORMER CONTROLLED GENERATORS - TRANSFORMER ADJUSTMENT	15
4.8	ACCESSORIES	15
SECTION 5	INSTALLATION - PART 2	16
5.1	GENERAL	16
5.2	GLANDING	16
5.3	EARTHING	16
5.4	PROTECTION	16
5.5	COMMISSIONING	16

CONTENTS

SECTION 6	ACCESSORIES	17
6.1	REMOTE VOLTAGE ADJUST (ALL AVR TYPES)	17
6.2	PARALLEL OPERATION	17
6.2.1	DROOP	17
6.2.1.1	SETTING PROCEDURE	18
6.2.2	ASTATIC CONTROL	18
6.3	MANUAL VOLTAGE REGULATOR (MVR) - MX341 and MX321 AVR	18
6.4	OVERVOLTAGE DE-EXCITATION BREAKER SX421 and MX321 AVR	18
6.4.1	RESETTING THE BREAKER	19
6.5	CURRENT LIMIT - MX321 AVR	19
6.5.1	SETTING PROCEDURE	19
6.6	POWER FACTOR CONTROLLER (PFC3)	20
SECTION 7	SERVICE AND MAINTENANCE	21
7.1	WINDING CONDITION	21
7.2	BEARINGS	22
7.3	AIR FILTERS	22
7.3.1	CLEANING PROCEDURE	22
7.4	FAULT FINDING	22
7.4.1	SX460 AVR - FAULT FINDING	22
7.4.2	SX440 AVR - FAULT FINDING	23
7.4.3	SX421 AVR - FAULT FINDING	23
7.4.4	TRANSFORMER CONTROL - FAULT FINDING	23
7.4.5	MX341 AVR - FAULT FINDING	24
7.4.6	MX321 AVR - FAULT FINDING	24
7.4.7	RESIDUAL VOLTAGE CHECK	25
7.5	SEPARATE EXCITATION TEST PROCEDURE	25
7.5.1	GENERATOR WINDINGS, ROTATING DIODES and PERMANENT MAGNET GENERATOR (PMG)	25
7.5.1.1	BALANCED MAIN TERMINAL VOLTAGES	25
7.5.1.2	UNBALANCED MAIN TERMINAL VOLTAGES	26
7.5.2	EXCITATION CONTROL TEST	26
7.5.2.1	AVR FUNCTION TEST	26
7.5.2.2	TRANSFORMER CONTROL	27
7.5.3	REMOVAL AND REPLACEMENT OF COMPONENT ASSEMBLIES	27
7.5.3.1	REMOVAL OF PERMANENT MAGNET GENERATOR (PMG)	27
7.5.3.2	REMOVAL OF BEARINGS	27
7.5.3.3	REMOVAL OF ENDBRACKET AND EXCITER STATOR	27
7.5.3.4	REMOVAL OF THE ROTOR ASSEMBLY	28
7.6	RETURNING TO SERVICE	28
SECTION 8	SPARES AND AFTER SALES SERVICE	29
8.1	RECOMMENDED SPARES	29
8.2	AFTER SALES SERVICE	29
SECTION 9	PARTS IDENTIFICATION	30
	TYPICAL SINGLE BEARING GENERATOR (Fig. 11)	31
	TYPICAL TWO BEARING GENERATOR (Fig. 12)	33
	TYPICAL TWO BEARING (SERIES 5) GENERATOR (Fig. 13)	35
	ROTATING RECTIFIER ASSEMBLY (Fig. 14)	36

SECTION 1

INTRODUCTION

1.1 INTRODUCTION


The UC22/27 range of generators is of brushless rotating field design, available up to 660V/50Hz (1500 rpm) or 60Hz (1800 rpm), and built to meet BS5000 Part 3 and international standards.

All the UC22/27 range are self-excited with excitation power derived from the main output windings, using either the SX460/SX440/SX421 AVR. The UC22 is also available with specific windings and a transformer controlled excitation system.

A permanent magnet generator (PMG) powered excitation system is available as an option using either the MX341 or MX321 AVR.

Detailed specification sheets are available on request.

1.2 DESIGNATION



1.4 RATING PLATE

The generator has been supplied with a self adhesive rating plate label to enable fitting after final assembly and painting.

It is intended that this label will be stuck to the outside of the terminal box on the left hand side when viewed from the N.D.E. To assist with squarely positioning the label, location protrusions have been made in the sheet metalwork.

A CE Mark label is also supplied loose for fitment after final assembly and painting. This should be attached to an external surface of the Generator at a suitable location where it will not be obscured by the customer's wiring or other fittings.

The surface in the area where a label is to be stuck must be flat, clean, and any paint finish be fully dry before attempting to attach label. Recommended method for attaching label is peel and fold back sufficient of the backing paper to expose some 20 mm of label adhesive along the edge which is to be located against the sheet metal protrusions. Once this first section of label has been carefully located and stuck into position the backing paper can be progressively removed, as the label is pressed down into position. The adhesive will achieve a permanent bond in 24 hours.

1.3 SERIAL NUMBER LOCATION AND IDENTITY

NUMBER LOCATION

Each generator is metal stamped with it's own unique serial number, the location of this number is described below.

UCI and UCM generators have their serial number stamped into the upper section of the drive end frame to end bracket adaptor ring, shown as item 31 in the parts lists at the back of this book.


UCD generators have their serial number stamped into the top of the drive end adaptor /fan shroud casting. If for any reason this casting is removed, it is imperative that care is taken to refit it to the correct generator to ensure correct identification is retained.

Inside the terminal box two adhesive rectangular labels have been fixed, each carrying the generators unique identity number. One label has been fixed to the inside of the terminal box sheet metal work, and the second label fixed to the main frame of the generator.

SECTION 2

PRINCIPLE OF OPERATION

2.1 SELF-EXCITED AVR CONTROLLED GENERATORS




The main stator provides power for excitation of the exciter field via the SX460 (SX440 or SX421) AVR which is the controlling device governing the level of excitation provided to the exciter field. The AVR responds to a voltage sensing signal derived from the main stator winding. By controlling the low power of the exciter field, control of the high power requirement of the main field is achieved through the rectified output of the exciter armature.

The SX460 or SX440 AVR senses average voltage on two phases ensuring close regulation. In addition it detects engine speed and provides voltage fall off with speed, below a pre-selected speed (Hz) setting, preventing over-excitation at low engine speeds and softening the effect of load switching to relieve the burden on the engine.

The SX421 AVR in addition to the SX440 features has three phase rms sensing and also provides for over voltage protection when used in conjunction with an external circuit breaker (switchboard mounted).

2.2 PERMANENT MAGNET GENERATOR (PMG) EXCITED - AVR CONTROLLED GENERATORS



The permanent magnet generator (PMG) provides power for excitation of the exciter field via the AVR (MX341 or MX321) which is the controlling device governing the level of excitation provided to the exciter field. The AVR responds to a voltage sensing signal derived, via an isolating transformer in the case of MX321 AVR, from the main stator winding. By controlling the low power of the exciter field, control of the high power requirement of the main field is achieved through the rectified output of the exciter armature.

The PMG system provides a constant source of excitation power irrespective of main stator loading and provides high motor starting capability as well as immunity to waveform distortion on the main stator output created by non linear loads, e.g. thyristor controlled dc motor.

The MX341 AVR senses average voltage on two phases ensuring close regulation. In addition it detects engine speed and provides an adjustable voltage fall off with speed, below a pre-selected speed (Hz) setting, preventing over-excitation at low engine speeds and softening the effect of load switching to relieve the burden on the engine. It also provides over-excitation protection which acts following a time delay, to de-excite the generator in the event of excessive exciter field voltage.

The MX321 provides the protection and engine relief features of the MX341 and additionally incorporates 3 phase rms sensing and over-voltage protection.

The detailed function of all the AVR circuits is covered in the load testing (subsection 4.7).


2.3 AVR ACCESSORIES

The SX440, SX421, MX341 and MX321 AVRs incorporate circuits which, when used in conjunction with accessories, can provide for parallel operation either with 'droop' or 'astatic' control, VAR/ PF control and in the case of the MX321 AVR, short circuit current limiting.

Function and adjustment of the accessories which can be fitted inside the generator terminal box are covered in the accessories section of this book.

Separate instructions are provided with other accessories available for control panel mounting.

2.4 TRANSFORMER CONTROLLED GENERATORS



The main stator provides power for excitation of the exciter field via a transformer rectifier unit. The transformer combines voltage and current elements derived from the main stator output to form the basis of an open-loop control system, which is self regulating in nature. The system inherently compensates for load current magnitude and power factor and provides short circuit maintenance in addition to a good motor starting performance.



Three phase generators normally have a three phase transformer control for improved performance with unbalanced loads but a single phase transformer option is available.

No accessories can be provided with this control system.

SECTION 3

APPLICATION OF THE GENERATOR

The generator is supplied as a component part for installation in a generating set. It is not, therefore, practicable to fit all the necessary warning/hazard labels during generator manufacture. The additional labels required are packaged with this Manual, together with a drawing identifying their locations. (See below).



It is the responsibility of the generating set manufacturer to ensure that the correct labels are fitted, and are clearly visible.

The generators have been designed for use in a maximum ambient temperature of 40°C and altitude less than 1000m above sea level in accordance with BS5000.

Ambients in excess of 40°C and altitudes above 1000m can be tolerated with reduced ratings - refer to the generator nameplate for rating and ambient. In the event that the generator is required to operate in an ambient in excess of the nameplate value or at altitudes in excess of 1000 metres above sea level, refer to the factory.

The generators are of air-ventilated screen protected drip-proof design and are not suitable for mounting outdoors unless adequately protected by the use of canopies. Anti-condensation heaters are recommended during storage and for standby duty to ensure winding insulation is maintained in good condition.

When installed in a closed canopy it must be ensured that the ambient temperature of the cooling air to the generator does not exceed that for which the generator has been rated.

The canopy should be designed such that the engine air intake to the canopy is separated from the generator intake, particularly where the radiator cooling fan is required to draw air into the canopy. In addition the generator air intake to the canopy should be designed such that the ingress of moisture is prohibited, preferably by use of a 2 stage filter.

The air intake/outlet must be suitable for the air flow given in the following table with additional pressure drops less than or equal to those given below:

Frame	Air Flow		Additional (intake/outlet) Pressure Drop
	50Hz	60Hz	
UC22	0.216m³/sec	0.281m³/sec	6mm water gauge
	458cfm	595cfm	0.25"
UCD22	0.25m³/sec	0.31m³/sec	6mm water gauge
	530cfm	657cfm	0.25"
UC27	0.514m³/sec	0.610m³/sec	6mm water gauge
	1090cfm	1308cfm	0.25"
UCD27	0.58m³/sec	0.69m³/sec	6mm water gauge
	1230cfm	1463cfm	0.25"

Important ! Reduction in cooling air flow or inadequate protection to the generator can result in damage and/or failure of windings.

Dynamic balancing of the generator rotor assembly has been carried out during manufacture in accordance with BS 6861 Part 1 Grade 2.5 to ensure vibration limits of the generator are in accordance with BS 4999 Part 142.

The main vibration frequencies produced by the generator are as follows:-

4 pole	1500 rpm	25 Hz
4 pole	1800 rpm	30 Hz

However, vibrations induced by the engine are complex and contain frequencies of 1.5, 3, 5 or more times the fundamental frequency of vibration. These induced vibrations can result in generator vibration levels higher than those derived from the generator itself. It is the responsibility of the generating set designer to ensure that the alignment and stiffness of the bedplate and mountings are such that the vibration limits of BS5000 Part 3 are not exceeded.

In standby applications where the running time is limited and reduced life expectancy is accepted, higher levels than specified in BS5000 can be tolerated, up to a maximum of 18mm/sec.

Two bearing generators open coupled require a substantial bedplate with engine/generator mounting pads to ensure a good base for accurate alignment. Close coupling of engine to generator can increase the overall rigidity of the set. For the purposes of establishing set design the bending moment at the engine flywheel housing to generator adaptor interface should not exceed 1000ft.lb. (140 kgm). A flexible coupling, designed to suit the specific engine/generator combination, is recommended to minimise torsional effects.

Belt driven applications of two bearing generators require the pulley diameter and design to be such that the side load or force applied to the shaft is central to the extension and does not exceed the values given in the table below:-

Frame	Side Load		Shaft extension mm
	kgf	N	
UC22	408	4000	110
UC27	510	5000	140

In instances where shaft extensions greater than specified in the table have been supplied reference must be made to the factory for appropriate loadings.

Alignment of single bearing generators is critical and vibration can occur due to the flexing of the flanges between the engine and generator. As far as the generator is concerned the maximum bending moment at this point must not exceed 1000ft.lb. (140 kgm). A substantial bedplate with engine/generator mounting pads is required.

It is expected that the generator will be incorporated into a generating set operating in an environment, where the maximum shock load experienced by the generator will not exceed 3g in any plane. If shock loads in excess of 3g are to be encountered, anti-vibration mountings must be incorporated into the generating set to ensure they absorb the excess.

The maximum bending moment of the engine flange must be checked with the engine manufacturer.

Generators can be supplied without a foot, providing the option for customers own arrangement. See SECTION 4.2.1 for assembly procedure.

Torsional vibrations occur in all engine-driven shaft systems and may be of a magnitude to cause damage at certain critical speeds. It is therefore necessary to consider the torsional vibration effect on the generator shaft and couplings.

It is the responsibility of the generator set manufacturer to ensure compatibility, and for this purpose drawings showing the shaft dimensions and rotor inertias are available for customers to forward to the engine supplier. In the case of single bearing generators coupling details are included.

Important ! Torsional incompatibility and/or excessive vibration levels can cause damage or failure of generator and/or engine components.

The terminal box is constructed with removable panels for easy adaptation to suit specific glanding requirements. Within the terminal box there are insulated terminals for line and neutral connections and provision for earthing. Additional earthing points are provided on the generator feet.

The neutral is NOT connected to the frame.

The main stator winding has leads brought out to the terminals in the terminal box.



Warning !

No earth connections are made on the generator and reference to site regulations for earthing must be made. Incorrect earthing or protection arrangements can result in personal injury or death.

Fault current curves (decrement curves), together with generator reactance data, are available on request to assist the system designer to select circuit breakers, calculate fault currents and ensure discrimination within the load network.




Warning !

Incorrect installation, service or replacement of parts can result in severe personal injury or death, and/or equipment damage. Service personnel must be qualified to perform electrical and mechanical service.

SECTION 4

INSTALLATION - PART 1

4.1 LIFTING






Warning ! Incorrect lifting or inadequate lifting capacity can result in severe personal injury or equipment damage. **MINIMUM LIFTING CAPACITY REQUIRED IS 750Kg.** Generator lifting lugs should **NOT** be used for lifting the complete generator set.

Two lifting lugs are provided for use with a shackle and pin type lifting aid. Chains of suitable length and lifting capacity must be used. Lifting points are designed to be as close to the centre of gravity of the generator as possible, but due to design restrictions it is not possible to guarantee that the generator frame will remain horizontal while lifting. Care is therefore needed to avoid personal injury or equipment damage. The correct lifting arrangement is shown on the label attached to the lifting lug. (See sample below).

IMPORTANT

REFER TO SERVICE MANUAL BEFORE REMOVING COVERS. IT IS THE GENERATOR SET MANUFACTURER'S RESPONSIBILITY TO FIT THE SELF ADHESIVE WARNING LABELS SUPPLIED WITH THE GENERATOR. THE LABEL SHEET CAN BE FOUND WITH THE INSTRUCTION BOOK.



Single bearing generators are supplied fitted with a rotor retaining bar at the non-drive end of the shaft.

To remove retaining bar:

1. Remove the four screws holding the sheet metal cover at the non drive end and remove cover
2. Remove central bolt holding the retaining bar to the shaft
3. Refit sheet metal cover.

Once the bar is removed, to couple the rotor to engine, the rotor is free to move in the frame, and care is needed during coupling and alignment to ensure the frame is kept in the horizontal plane.

Generators fitted with a PMG excitation system are not fitted with retaining bar. Refer to frame designation to verify generator type (subsection 1.2)

4.2 ASSEMBLY

During the assembly of the generator to the engine it will be necessary firstly to carefully align, then rotate, the combined generator rotor - engine crankshaft assembly, as part of the construction process, to allow location, insertion and tightening of the coupling bolts. This requirement to rotate the combined assemblies exists for both single and two bearing units.

During the assembly of single bearing units it is necessary to align the generator's coupling holes with the engine flywheel holes; it is suggested that two diametrically opposite location dowel pins are fitted to the engine flywheel, over which the generator coupling can slide into final location into the engine flywheel spigot recess. The dowels must be removed and replaced by coupling bolts before the final bolt tightening sequence.

While fitting and tightening the coupling bolts it will be necessary to rotate the engine crankshaft - generator rotor assembly. Care should be taken to ensure that rotation is carried out in an approved manner that ensures safe working practice when reaching inside the machine to insert or tighten coupling bolts, and that no component of the assembly is damaged by non-approved methods of assembly rotation.

Engine manufacturers have available a proprietary tool or facility designed to enable manual rotation of the crankshaft assembly. This must always be used, having been engineered as an approved method of assembly rotation, engaging the manually driven pinion with the engine flywheel starter ring-gear.

Caution ! Before working inside the generator, during the aligning and fitting of coupling bolts, care should be taken to lock the assembly to ensure there is no possibility of rotational movement.

4.2.1 NO FOOT OPTION

Generators can be supplied without a foot providing the option for customers own arrangement.

For details of mounting this arrangement, see the general arrangement drawing supplied with the generator. Alternatively refer to Newage International for a copy of the latest general arrangement drawing showing the 'NO FOOT OPTION' appropriate to your generator.

4.2.2 TWO BEARING GENERATORS

flexible coupling should be fitted and aligned in accordance with the coupling manufacturer's instruction.

If a close coupling adaptor is used the alignment of machined faces must be checked by offering the generator up to the engine. Shim the generator feet if necessary. Ensure adaptor guards are fitted after generator/engine assembly is complete. Open coupled sets require a suitable guard, to be provided by the set builder.

In the case of belt driven generators, ensure alignment of drive and driven pulleys to avoid axial load on the bearings. Screw type tensioning devices are recommended to allow accurate adjustment of belt tension whilst maintaining pulley alignment. Side loads should not exceed values given in SECTION 3.

Belt and pulley guards must be provided by the set builder.

Important ! Incorrect belt tensioning will result in excessive bearing wear.

Caution ! Incorrect guarding and/or generator alignment can result in personal injury and/or equipment damage.

4.2.3 SINGLE BEARING GENERATORS

Alignment of single bearing generators is critical. If necessary shim the generator feet to ensure alignment of the machined surfaces.

For transit and storage purposes the generator frame spigot and rotor coupling plates have been coated with a rust preventative. This MUST BE removed before assembly to engine.

A practical method for removal of this coating is to clean the mating surface areas with a de-greasing agent based on a petroleum solvent.

Care should be taken not to allow any cleaning agent to come into prolonged contact with skin.

The sequence of assembly to the engine should generally be as follows:

1. On the engine check the distance from the coupling mating face on the flywheel to the flywheel housing mating face. This should be within $\pm 0.5\text{mm}$ of nominal dimension. This is necessary to ensure that a thrust is not applied to the a.c. generator bearing or engine bearing.
2. Check that the bolts securing the flexible plates to the coupling hub are tight and locked into position. Torque tightening is 24.9kgfm (244Nm; 180 lb ft).
- 2a. **UCD224 Only**
Torque tightening is 15.29 kgfm (150Nm; 110 lb ft).

3. Remove covers from the drive end of the generator to gain access to coupling and adaptor bolts.
4. Check that coupling discs are concentric with adaptor spigot. This can be adjusted by the use of tapered wooden wedges between the fan and adaptor. Alternatively the rotor can be suspended by means of a rope sling through the adaptor opening.
5. Offer the a.c. generator to engine and engage both coupling discs and housing spigots at the same time, finally pulling home by using the housing and coupling bolts. Use heavy gauge washers between bolt head and discs on disc to flywheel bolts.
6. Tighten coupling disc to flywheel. Refer to engine manual for torque setting of disc to flywheel bolts.
7. Remove wooden wedges.

Caution ! Incorrect guarding and/or generator alignment can result in personal injury and/or equipment damage.

4.3 EARTHING

The generator frame should be solidly bonded to the generating set bedplate. If antivibration mounts are fitted between the generator frame and its bedplate a suitably rated earth conductor (normally one half of the cross sectional area of the main line cables) should bridge across the antivibration mount.



Warning !

Refer to local regulations to ensure that the correct earthing procedure has been followed.

4.4 PRE-RUNNING CHECKS

4.4.1 INSULATION CHECK

Before starting the generating set, both after completing assembly and after installation of the set, test the insulation resistance of windings.

The AVR should be disconnected during this test.

A 500V Megger or similar instrument should be used. Disconnect any earthing conductor connected between neutral and earth and megger an output lead terminal U, V or W to earth. The insulation resistance reading should be in excess of 5Mw to earth. Should the insulation resistance be less than 5Mw the winding must be dried out as detailed in the Service and Maintenance section of this Manual.

Important ! The windings have been H.V. tested during manufacture and further H.V. testing may degrade the insulation with consequent reduction in operating life. Should it be necessary to demonstrate H.V. testing, for customer acceptance, the tests must be carried out at reduced voltage levels i.e. Test Voltage= 0.8 (2 X Rated Voltage + 1000)

4.4.2 DIRECTION OF ROTATION

The generator is supplied to give a phase sequence of U V W with the generator running clockwise looking at the drive end (unless otherwise specified at the time of ordering). If the generator phase rotation has to be reversed after the generator has been despatched apply to factory for appropriate wiring diagrams.

UCI224, UCI274, UCM224, UCM274

Machines are fitted with bi-directional fans and are suitable for running in either direction of rotation.

UCD224, UCD274

Machines are fitted with uni-directional fans and are suitable for running in one direction only.

4.4.3 VOLTAGE AND FREQUENCY

Check that the voltage and frequency levels required for the generating set application are as indicated on the generator nameplate.

Three phase generators normally have a 12 ends out reconnectable winding. If it is necessary to reconnect the stator for the voltage required, refer to diagrams in the back of this manual.

4.4.4 AVR SETTINGS

To make AVR selections and adjustments remove the AVR cover and refer to 4.4.4.1, 4.4.4.2, 4.4.4.3, 4.4.4.4 or 4.4.4.5 depending upon type of AVR fitted. Reference to the generator nameplate will indicate AVR type (SX460, SX440, SX421, MX341 or MX321).

Most of the AVR adjustments are factory set in positions which will give satisfactory performance during initial running tests. Subsequent adjustment may be required to achieve optimum performance of the set under operating conditions. Refer to 'Load Testing' section for details.

4.4.4.1 TYPE SX460 AVR

The following 'jumper' connections on the AVR should be checked to ensure they are correctly set for the generating set application.

Refer to Fig. 1 for location of selection links.

1. Frequency selection

50Hz operation LINK C-50
60Hz operation LINK C-60

2. External hand trimmer selection

No external hand trimmer LINK 1-2

External hand trimmer required - REMOVE LINK 1-2 and connect trimmer across terminals 1 and 2.

3. AVR Input Selection

High voltage (220/240V) Input NO LINK
Low voltage (110/120V) Input LINK 3-4

Refer to diagram in the back of this manual to determine wiring.




Fig. 1

4.4.4.2 TYPE SX440 AVR

The following 'jumper' connections on the AVR should be checked to ensure they are correctly set for the generating set application.

Refer to Fig. 2 for location of selection links.

1. Frequency selection terminals

50Hz operation LINK C-50
60Hz operation LINK C-60

2. Stability selection terminals

Frame UC22 LINK A-C
Frame UC27 LINK B-C

3. Sensing selection terminals

LINK 2-3
LINK 4-5
LINK 6-7

4. Excitation Interruption Link

LINK K1-K2




Fig. 2

4.4.3 TYPE SX421 AVR

The following 'jumper' connections on the AVR should be checked to ensure they are correctly set for the generating set application.

Refer to Fig. 3 for location of selection links.

1. Frequency selection terminals

50Hz operation LINK C-50

60Hz operation LINK C-60

2. Stability selection terminals

Depending upon kW output LINK B-D

or LINK A-C

or LINK B-C

3. Terminals K1 - K2

Excitation circuit breaker closed




Fig. 3

4.4.4.4 TYPE MX341 AVR

The following 'jumper' connections on the AVR should be checked to ensure they are correctly set for the generating set application.

Refer to Fig. 4 for location of setting links.

1. Frequency selection terminals

50Hz operation LINK 2-3

60Hz operation LINK 1-3

2. Stability selection terminals

Frame UC22 LINK A-C

Frame UC27 LINK B-C

3. Sensing selection terminals *

LINK 2-3

LINK 4-5

LINK 6-7

4. Excitation Interruption Link

LINK K1-K2




Fig. 4

4.4.4.5 TYPE MX321 AVR

The following 'jumper' connections on the AVR should be checked to ensure they are correctly set for the generating set application.

Refer to Fig. 5 for location of setting links.




Fig. 5

1. Frequency selection terminals

50Hz operation LINK 2-3

60Hz operation LINK 1-3

2. Stability selection terminals

Frame UC22 LINK A-C

Frame UC27 LINK B-C

3. Terminals K1 - K2

Excitation circuit breaker closed.

If this option not fitted, K1 - K2 linked at auxiliary terminal block.

4.4.5 TRANSFORMER CONTROLLED EXCITATION SYSTEM (Series 5)

This control system is identified with the digit 5 as the last digit of the frame size quoted on the nameplate.

The excitation control is factory set for the specific voltage shown on the nameplate and requires no adjustment.

4.5 GENERATOR SET TESTING



Warning !

During testing it may be necessary to remove covers to adjust controls exposing 'live' terminals or components. Only personnel qualified to perform electrical service should carry out testing and/or adjustments.

4.5.1 TEST METERING/CABLING

Connect any instrument wiring and cabling required for initial test purposes with permanent or spring-clip type connectors.

Minimum instrumentation for testing should be line - line or line to neutral voltmeter, Hz meter, load current metering and kW meter. If reactive load is used a power factor meter is desirable.

Important ! When fitting power cables for load testing purposes, ensure cable voltage rating is at least equal to the generator rated voltage. The load cable termination should be placed on top of the winding lead termination and clamped with the nut provided.

Caution ! Check that all wiring terminations for internal or external wiring are secure, and fit all terminal box covers and guards. Failure to secure wiring and/or covers may result in personal injury and/or equipment failure.

4.6 INITIAL START-UP



Warning !

During testing it may be necessary to remove covers to adjust controls exposing 'live' terminals or components. Only personnel qualified to perform electrical service should carry out testing and/or adjustments. Refit all access covers after adjustments are completed.

On completion of generating set assembly and before starting the generating set ensure that all engine manufacturer's pre-running procedures have been completed, and that adjustment of the engine governor is such that the generator will not be subjected to speeds in excess of 125% of the rated speed.

Important ! Overspeeding of the generator during initial setting of the speed governor can result in damage to the generator rotating components.

In addition remove the AVR access cover (on AVR controlled generators) and turn VOLTS control fully anti-clockwise. Start the generating set and run on no-load at nominal frequency. Slowly turn VOLTS control potentiometer clockwise until rated voltage is reached. Refer to Fig. 6a, 6b, 6c, 6d or 6e for control potentiometer location.

Important ! Do not increase the voltage above the rated generator voltage shown on the generator nameplate.

The STABILITY control potentiometer will have been pre-set and should normally not require adjustment, but should this be required, usually identified by oscillation of the voltmeter, refer to Fig. 6a, 6b, 6c, 6d or 6e for control potentiometer location and proceed as follows:-

1. Run the generating set on no-load and check that speed is correct and stable
2. Turn the STABILITY control potentiometer clockwise, then turn slowly anti-clockwise until the generator voltage starts to become unstable.

The correct setting is slightly clockwise from this position (i.e. where the machine volts are stable but close to the unstable region).




Fig. 6a




Fig. 6b




Fig. 6c




Fig. 6d




Fig. 6e

4.7 LOAD TESTING



Warning !

During testing it may be necessary to remove covers to adjust controls exposing 'live' terminals or components. Only personnel qualified to perform electrical service should carry out testing and/or adjustments. Refit all access covers after adjustments are completed.

4.7.1 AVR CONTROLLED GENERATORS - AVR ADJUSTMENTS

Refer to Fig. 6a, 6b, 6c, 6d or 6e for control potentiometer locations.

Having adjusted VOLTS and STABILITY during the initial start-up procedure, other AVR control functions should not normally need adjustment.

If however, poor voltage regulation on-load or voltage collapse is experienced, refer to the following paragraphs on each function to a) check that the symptoms observed do indicate adjustment is necessary, and b) to make the adjustment correctly.

4.7.1.1 UFRO (Under Frequency Roll Off) (AVR Types SX460, SX440, SX421, MX341 and MX321)

The AVR incorporates an underspeed protection circuit which gives a voltage/speed (Hz) characteristic as shown:




Fig. 7

The UFRO control potentiometer sets the "knee point".

Symptoms of incorrect setting are a) the light emitting diode (LED) indicator, just above the UFRO Control potentiometer, being permanently lit when the generator is on load, and b) poor voltage regulation on load, i.e. operation on the sloping part of the characteristic.

Clockwise adjustment lowers the frequency (speed) setting of the "knee point" and extinguishes the LED. For Optimum setting the LED should illuminate as the frequency falls just below nominal frequency, i.e. 47Hz on a 50Hz generator or 57Hz on a 60Hz generator.

Important ! With AVR Types MX341 and MX321. If the LED is illuminated and no output voltage is present, refer to EXC TRIP and/or OVER/V sections below.

4.7.1.2 EXC TRIP (Excitation Trip) AVR Types MX341 and MX321

An AVR supplied from a permanent magnet generator inherently delivers maximum excitation power on a line to line or line to neutral short circuit or large overload. In order to protect the generator windings the AVR incorporates an over excitation circuit which detects high excitation and removes it after a pre-determined time, i.e. 8-10 seconds.

Symptoms of incorrect setting are the generator output collapses on load or small overload, and the LED is permanently illuminated.

The correct setting is 70 volts \pm 5% between terminals X and XX.

4.7.1.3 OVER/V (Over Voltage) AVR Type SX421, MX321

Over voltage protection circuitry is included in the AVR to remove generator excitation in the event of loss of AVR sensing input.

The MX321 has both internal electronic de-excitation and provision of a signal to operate an external circuit breaker.

The SX421 only provides a signal to operate an external breaker, which MUST be fitted if over voltage protection is required.

Incorrect setting would cause the generator output voltage to collapse at no-load or on removal of load, and the LED to be illuminated.

The correct setting is 300 volts \pm 5% across terminals E1, E0. Clockwise adjustment of the OVER/V control potentiometer will increase the voltage at which the circuit operates.

4.7.1.4 TRANSIENT LOAD SWITCHING ADJUSTMENTS AVR Types SX421, MX341 and MX321

The additional function controls of DIP and DWELL are provided to enable the load acceptance capability of the generating set to be optimised. The overall generating set performance depends upon the engine capability and governor response, in conjunction with the generator characteristics.

It is not possible to adjust the level of voltage dip or recovery independently from the engine performance, and there will always be a 'trade off' between frequency dip and voltage dip.

DIP

AVR Types SX421, MX341 and MX321

AVR Types SX421, MX341 and MX321

The dip function control potentiometer adjusts the slope of the voltage/speed (Hz) characteristic below the knee point as shown below:




Fig. 8

DWELL

AVR Type MX321

The dwell function introduces a time delay between the recovery of voltage and recovery of speed.

The purpose of the time delay is to reduce the generator kW below the available engine kW during the recovery period, thus allowing an improved speed recovery.

Again this control is only functional below the "knee point", i.e. if the speed stays above the knee point during load switching there is no effect from the DWELL function setting.

Clockwise adjustment gives increased recovery time.




Fig. 9

The graphs shown above are representations only, since it is impossible to show the combined effects of voltage regulator and engine governor performance.

4.7.1.5 RAMP

AVR Type MX321

The RAMP potentiometer enables adjustment of the time taken for the generator's initial build up to normal rated voltage during each start and run up to speed. The potentiometer is factory set to give a ramp time of three seconds, which is considered to be suitable for most applications. This time can be reduced to one second by turning the pot. fully counter clockwise, and increased to eight seconds by turning the pot. fully clockwise.

4.7.2 TRANSFORMER CONTROLLED GENERATORS - TRANSFORMER ADJUSTMENT

Normally no adjustment is required but should the no-load voltage and/or on-load voltage be unacceptable, adjustment of the transformer air gap can be made as follows.

Stop the generator. Remove transformer cover box. (Normally left hand side of the terminal box when viewed from the non drive end).

Loosen the three transformer mounting bolts along the top of the transformer.

Start the set with a voltmeter connected across the main output terminals.

Adjust the air gap between the transformer top lamination section and the transformer limbs to obtain required voltage on no-load. Slightly tighten the three mounting bolts. Switch load on and 'off' two or three times. Application of load will normally raise the voltage setting slightly. With the load 'off' recheck the no-load voltage.

Readjust air gap and finally tighten mounting bolts.

Refit the access cover.



Warning !

Failure to refit covers can result in operator personal injury or death.

4.8 ACCESSORIES

Refer to the "ACCESSORIES" - Section 6 of this Manual for setting up procedures related to generator mounted accessories.

If there are accessories for control panel mounting supplied with the generator refer to the specific accessory fitting procedures inserted inside the back cover of this book.

SECTION 5

INSTALLATION - PART 2

5.1 GENERAL

The extent of site installation will depend upon the generating set build, e.g. if the generator is installed in a canopied set with integral switchboards and circuit breaker, on site installation will be limited to connecting up the site load to the generating set output terminals. In this case reference should be made to the generating set manufacturer's instruction book and any pertinent local regulations.

If the generator has been installed on a set without switchboard or circuit breaker the following points relating to connecting up the generator should be noted.

5.2 GLANDING

The terminal box is most conveniently glanded on either the right or left hand side. Both panels are removable for drilling/punching to suit glands/or glanding boxes. If single core cables are taken through the terminal box side panel an insulated or non-magnetic gland plate should be fitted.

Incoming cables should be supported from either below or above the box level and at a sufficient distance from the centre line of the generating set so as to avoid a tight radius at the point of entry into the terminal box panel, and allow movement of the generator set on its anti-vibration mountings without excessive stress on the cable.

Before making final connections, test the insulation resistance of the windings. The AVR should be disconnected during this test.

A 500V Megger or similar instrument should be used. Should the insulation resistance be less than 5M Ω the windings must be dried out as detailed in the Service and Maintenance section of this manual.

When making connections to the terminals the incoming cable termination should be placed on top of the winding lead termination(s) and clamped with the nut provided.

Important ! To avoid the possibility of swarf entering any electrical components in the terminal box, panels must be removed for drilling.

5.3 EARTHING

The neutral of the generator is not bonded to the generator frame as supplied from the factory. An earth terminal is provided inside the terminal box adjacent to the main terminals. Should it be required to operate with the neutral earthed a substantial earth conductor (normally equivalent to one half of the section of the line conductors) must be connected between the neutral and the earth terminal inside the terminal box. Additional earth terminals are provided on the generator feet. These should be already bonded to the generating set bedplate by the generating set builder, but will normally be required to be connected to the site earth system.

Caution ! Reference to local electricity regulations or safety rules should be made to ensure correct earthing procedures have been followed.

5.4 PROTECTION

It is the responsibility of the end user and his contractors/sub-contractors to ensure that the overall system protection meets the needs of any inspectorate, local electricity authority or safety rules, pertaining to the site location.

To enable the system designer to achieve the necessary protection and/or discrimination, fault current curves are available on request from the factory, together with generator reactance values to enable fault current calculations to be made.



Warning !

Incorrect installation and/or protective systems can result in personal injury and/or equipment damage. Installers must be qualified to perform electrical installation work.

5.5 COMMISSIONING

Ensure that all external cabling is correct and that all the generating set manufacturer's pre-running checks have been carried out before starting the set.

The generator AVR controls will have been adjusted during the generating set manufacturer's tests and should normally not require further adjustment.

Should malfunction occur during commissioning refer to Service and Maintenance section 'Fault Finding' procedure (subsection 7.4).

SECTION 6

ACCESSORIES

Generator control accessories may be fitted, as an option, in the generator terminal box. If fitted at the time of supply, the wiring diagram(s) in the back of this book shows the connections. When the options are supplied separately, fitting instructions are provided with the accessory.

The following matrix indicates availability of accessories with the differing AVRs.

Note the SX460 is not suitable for operation with accessories.

AVR Model	Parallel-ing Droop or Astatic	Manual Voltage Regulator	VAr/PF Control	Current Limit
SX440	✓	✗	✓	✗
SX421	✓	✗	✓	✗
MX341	✓	✓	✓	✗
MX321	✓	✓	✓	✓

6.1 REMOTE VOLTAGE ADJUST (ALL AVR TYPES)

A remote voltage adjust (hand trimmer) can be fitted.

SX460 Remove link 1-2 on the AVR and connect adjuster to terminals 1 and 2.

SX440, SX421 Remove link 1-2 at the auxiliary terminals
MX341 and MX321 and connect adjuster to terminals 1 and 2.

6.2 PARALLEL OPERATION

Understanding of the following notes on parallel operation is useful before attempting the fitting or setting of the droop kit accessory. When operating in parallel with other generators or the mains, it is essential that the phase sequence of the incoming generator matches that of the busbar and also that all of the following conditions are met before the circuit breaker of the incoming generator is closed on to the busbar (or operational generator).

1. Frequency must match within close limits.
2. Voltages must match within close limits.
3. Phase angle of voltages must match within close limits.
A variety of techniques, varying from simple synchronising lamps to fully automatic synchronisers, can be used to ensure these conditions are met.

Important ! Failure to meet conditions 1, 2, and 3 when closing the circuit breaker, will generate excessive mechanical and electrical stresses, resulting in equipment damage.

Once connected in parallel a minimum instrumentation level per generator of voltmeter, ammeter, wattmeter (measuring total power per generator), and frequency meter is required in order to adjust the engine and generator controls to share kW in relation to engine ratings and kVAr in relation to generator ratings.

It is important to recognise that:


1. True kW are derived from the engine, and speed governor characteristics determine the kW sharing between sets
 2. kVAr are derived from the generator, and excitation control characteristics determine the kVAr sharing.
- Reference should be made to the generating set manufacturer's instructions for setting the governor controls.

6.2.1 DROOP

The most commonly used method of kVAr sharing is to create a generator voltage characteristic which falls with decreasing power factor (increasing kVAr). This is achieved with a current transformer (C.T.) which provides a signal dependent on current phase angle (i.e. power factor) to the AVR.

The current transformer has a burden resistor on the AVR board, and a percentage of the burden resistor voltage is summed into the AVR circuit. Increasing droop is obtained by turning the DROOP control potentiometer clockwise.

The diagrams below indicate the effect of droop in a simple two generator system:-



Generally 5% droop at full load current zero p.f. is sufficient to ensure kVAR sharing.

If the droop accessory has been supplied with the generator it will have been tested to ensure correct polarity and set to a nominal level of droop. The final level of droop will be set during generating set commissioning.

The following setting procedure will be found to be helpful.

6.2.1.1 SETTING PROCEDURE

Depending upon available load the following settings should be used - all are based on rated current level.

0.8 P.F. LOAD (at full load current) SET DROOP TO 3%
Zero P.F. LOAD (at full load current) SET DROOP TO 5%

Setting the droop with low power factor load is the most accurate. Run each generator as a single unit at rated frequency or rated frequency + 4% depending upon type of governor and nominal voltage. Apply available load to rated current of the generator. Adjust 'DROOP' control potentiometer to give droop in line with above table. Clockwise rotation increases amount of droop. Refer to Fig 9a, 9b, 9c or 9d for potentiometer locations.

Note 1)

Reverse polarity of the C.T. will raise the generator voltage with load. The polarities S1-S2 shown on the wiring diagrams are correct for clockwise rotation of the generator looking at the drive end. Reversed rotation requires S1-S2 to be reversed.

Note 2)

The most important aspect is to set all generators equal. The precise level of droop is less critical.

Note 3)

A generator operated as a single unit with a droop circuit set at rated load 0.8 power factor is unable to maintain the usual +/- 0.5% regulation. A shorting switch can be connected across S1-S2 to restore regulation for single running.

Important ! LOSS OF FUEL to an engine can cause its generator to motor with consequent damage to the generator windings. Reverse power relays should be fitted to trip main circuit breaker. LOSS OF EXCITATION to the generator can result in large current oscillations with consequent damage to generator windings. Excitation loss detection equipment should be fitted on trip main circuit breaker.

6.2.2 ASTATIC CONTROL

The 'droop' current transformer can be used in a connection arrangement which enables the normal regulation of the generator to be maintained when operating in parallel.

This feature is only supplied from the factory as a fitted droop kit, however, if requested at the time of order, the diagrams inside the back cover of this book will give the necessary site connections. The end user is required to provide a shorting switch for the droop current transformer secondary.

Should the generator be required to be converted from standard droop to 'astatic' control, diagrams are available on request.

The setting procedure is exactly the same as for DROOP (Subsection 6.2.1.1)

Important ! When using this connection arrangement a shorting switch is required across each C.T. burden (terminals S1 and S2.) The switch must be closed a) when a generating set is not running and b) when a generating set is selected for single running.

6.3 MANUAL VOLTAGE REGULATOR (MVR) - MX341 and MX321 AVR

This accessory is provided as an 'emergency' excitation system, in the event of an AVR failure.

Powered from the PMG output the unit is manually set, but automatically controls the excitation current, independent of generator voltage or frequency.

The unit is provided with 'MANUAL', 'OFF', 'AUTO' switching facility.

'MANUAL'

- position connects the exciter field to the MVR output. Generator output is then controlled by the operator adjusting the excitation current.

'OFF'

- disconnects the exciter field from both MVR and the normal AVR.

'AUTO'

- connects the exciter field to the normal AVR and the generator output is controlled at the pre-set voltage under AVR control.

Switching mode of operation should be carried out with the generator set stationary to avoid voltage surges on the connected load, although neither the MVR nor AVR will be damaged should the switching be carried out with the set running.

6.4 OVERVOLTAGE DE-EXCITATION BREAKER SX421 and MX321 AVR

This accessory provides positive interruption of the excitation power in the event of overvoltage due to loss of sensing or internal AVR faults including the output power device.

With the MX321 AVR this accessory is supplied loose for fitting in the control panel.

In the case of the SX421 the circuit breaker is always supplied and will normally be fitted in the generator.

Important ! When the circuit breaker is supplied loose, the AVR is fitted with a link on terminals K1-K2 to enable operation of the AVR. When connecting the circuit breaker this link must be removed.

6.4.1 RESETTING THE BREAKER

In the event of operation of the circuit breaker, indicated by loss of generator output voltage, manual resetting is required. When in the "tripped" state the circuit breaker switch lever shows "OFF". To reset move the switch lever to the position showing "ON".

When fitted in the generator, access to the breaker is gained by removal of the AVR access cover.



Danger !

Terminals which are LIVE with the generating set running are exposed when the AVR access cover is removed. Resetting of the circuit breaker MUST be carried out with the generating set stationary, and engine starting circuits disabled.

The circuit breaker is mounted on the AVR mounting bracket either to the left or to the right of the AVR depending upon AVR position. After resetting the circuit breaker replace the AVR access cover before restarting the generating set. Should resetting of a circuit breaker not restore the generator to normal operation, refer to subsection 7.5.




Fig. 9a




Fig. 9b




Fig. 9c




Fig. 9d

6.5 CURRENT LIMIT - MX321 AVR

These accessories work in conjunction with the AVR circuits to provide an adjustment to the level of current delivered into a fault. One current transformer (CT) per phase is fitted to provide current limiting on any line to line or line to neutral fault.

Note: The W phase CT can also provide "DROOP". Refer to 6.2.1.1 for setting droop independent of current limit.

Adjustment means is provided with the "I/LIMIT" control potentiometer on the AVR. Refer to Fig. 9d for location. If current limit transformers are supplied with the generator the limit will be set in accordance with the level specified at the time of order, and no further adjustment will be necessary. However, should the level need to be adjusted, refer to the setting procedure given in 6.5.1.

6.5.1 SETTING PROCEDURE

Run the generating set on no-load and check that engine governor is set to control nominal speed.

Stop the generating set. Remove the link between terminals K1-K2 at the auxiliary terminal block and connect a 5A switch across the terminals K1-K2.

Turn the "I/LIMIT" control potentiometer fully anticlockwise. Short circuit the stator winding with a bolted 3 phase short at the main terminals. An AC current clip-on ammeter is required to measure the winding lead current.

With the switch across K1-K2 open start the generating set.

Close the switch across K1-K2 and turn the "I/LIMIT" control potentiometer clockwise until required current level is observed on the clip-on ammeter. As soon as correct setting is achieved open the K1-K2 switch.

Should the current collapse during the setting procedure, the internal protective circuits of the AVR will have operated. In this event shut down the set and open the K1-K2 switch. Restart the set and run for 10 minutes with K1-K2 switch open, to cool the generator windings, before attempting to resume the setting procedure.

Important ! Failure to carry out the correct COOLING procedure, may cause overheating and consequent damage to the generator windings.

6.6 POWER FACTOR CONTROLLER (PFC3)

This accessory is primarily designed for those generator applications where operation in parallel with the mains supply is required.

Protection against loss of mains voltage or generator excitation is not included in the unit and the system designer must incorporate suitable protection.

The electronic control unit requires both droop and kVAr current transformers. When supplied with the generator, wiring diagrams inside the back cover of this manual show the connections and the additional instruction leaflet provided gives details of setting procedures for the power factor controller (PFC3).

The unit monitors the power factor of the generator current and adjusts excitation to maintain the power factor constant.

This mode can also be used to control the power factor of the mains if the point of current monitoring is moved to the mains cables. Refer to the factory for appropriate details.

It is also possible to operate the unit to control kVAr of the generator if required. Refer to the factory for appropriate details.

SECTION 7

SERVICE AND MAINTENANCE



Warning !

Service and fault finding procedures present hazards which can result in severe personal injury or death. Only personnel qualified to perform electrical and mechanical service should carry out these procedures. Ensure engine starting circuits are disabled before commencing service or maintenance procedures. Isolate any anti-condensation heater supply.

As part of routine maintenance procedures, periodic attention to winding condition (particularly when generators have been idle for a long period) and bearings is recommended. (Refer to subsections 7.1 and 7.2 respectively).

7.1 WINDING CONDITION

The condition of the windings can be assessed by measurement of insulation resistance to earth.

Care should be taken when dealing with windings which are suspected of being excessively damp or dirty. The initial measurement of insulation resistance should be established using a low voltage (500V) megger type instrument and if manually powered the handle should initially be turned slowly.

Full megger tests or any other form of high voltage test should not be applied until the windings have been dried out and if necessary cleaned.

Caution ! The AVR should be disconnected and the resistance temperature detector (R.T.D.) leads grounded during this test.

Important ! The windings have been H.V. tested during manufacture and further H.V. testing may degrade the insulation with consequent reduction in operating life. Should it be necessary to demonstrate H.V. testing, for customer acceptance, the tests must be carried out at reduced voltage levels i.e. (Test Voltage = 0.8 (2 X Rated Voltage + 1000)).

A 500V megger or similar instrument should be used. Disconnect any earthing conductor connected between neutral and earth and megger an output lead terminal U, V or W to earth. The insulation resistance reading should be in excess of 1.0M Ω to earth. Should the insulation resistance be less than 1.0M Ω the winding must be dried out as detailed below.

The above insulation resistance value is quoted for windings at an ambient temperature of approximately 20°C.

It should be noted that as winding temperature increases, values of insulation resistance may significantly reduce. Therefore, the reference values for insulation resistance can only be established with windings at a temperature of approximately 20°C.

Should the values be less than quoted, drying out the generator windings is essential.

Drying out may be carried out by directing warm air from a fan

heater or similar apparatus into the generator air inlets and/or outlets.

During drying, air must be able to flow freely through the generator in order to carry off the moisture.

Alternatively, the alternator main stator windings may be short circuited with a bolted 3 phase short at the main terminals and the generating set run with the AVR disconnected at terminals X and XX. A DC supply is connected to the leads X and XX (X must be connected to the positive of the DC supply and XX to the negative of the DC supply). The DC supply must be variable from 0-24V and capable of supplying 1.0 amp. An AC current clip-on ammeter or similar instrument is required to measure the main stator winding current.

Set the DC supply voltage to zero. Start the generating set and slowly increase the DC voltage to pass current through the main stator winding. The current level should not exceed the rated current of the generator.

Important ! The short circuit must not be applied with the AVR connected in circuit.
Current in excess of the rated generator current will cause damage to the windings.

During drying, the resistance should be measured at regular intervals, typically every 15 minutes and a graph plotted of insulation resistance against time. The shape of the resulting curve will be similar to Fig 1 below.

Fig 1 illustrates a typical curve for a generator which has absorbed a considerable amount of moisture. The curve indicates a temporary increase in resistance, a fall, and then a gradual rise to a steady figure. If windings are not very damp the dotted portion of the curve may not appear.




Fig. 10

Drying should be continued after point "A" has been reached for at least one hour.

Once the winding insulation resistance has been raised to the highest achievable level the I.R. (Insulation resistance) should be measured using a 500V megger or similar type instrument.

It is recommended that the main stator insulation resistance is checked as follows:-

1. Separate the three neutral leads.
2. ground V and W phase and megger U phase to ground
ground U and W phase and megger V phase to ground
ground U and V phase and megger W phase to ground

The generator must not be put into service if the following minimum values cannot be achieved.

INSULATION RESISTANCE	1.0 Meg Ohm
------------------------------	-------------

If the minimum value of I.R. cannot be achieved rewinding or refurbishment of the main stator winding will be necessary.

7.2 BEARINGS

All bearings are supplied sealed for life and are, therefore, not regreasable.

Important ! The life of a bearing in service is subject to the working conditions and the environment.

Important ! Long stationary periods in an environment where there is vibration can cause false brinnelling which puts flats on the ball and grooves on the races.
Very humid atmospheres or wet conditions can emulsify the grease and cause corrosion.

Important ! High axial vibration from the engine or misalignment of the set will stress the bearing.

The bearing, in service, is affected by a variety of factors that together will determine the bearing life. We recommend that the health of the bearings be monitored, using 'spike energy' vibration monitoring equipment. This will allow the timely replacement of bearings, that exhibit a deteriorating trend, during a major engine overhaul.

If excessive heat, noise or vibration is detected, change the bearing as soon as practicable. Failure to do so could result in bearing failure.


In the event that 'spike energy' vibration monitoring equipment is not available, it is strongly recommend that consideration be given to changing the bearing during each 'major engine overhaul'.

Belt driven application will impose an additional load on bearings. The bearing life will therefore be significantly affected. It is important that the side load limits given in SECTION 3 are not exceeded and the health of the bearing is monitored more closely.

7.3 AIR FILTERS

The frequency of filter maintenance will depend upon the severity of the site conditions. Regular inspection of the elements will be required to establish when cleaning is necessary.

7.3.1 CLEANING PROCEDURE

 Danger !	Removal of filter elements enables access to LIVE parts. Only remove elements with the generator out of service.
--	---

Remove the filter elements from the filter frames. Immerse or flush the element with a suitable detergent until the element is clean. Dry elements thoroughly before refitting.

7.4 FAULT FINDING

Important ! Before commencing any fault finding procedure examine all wiring for broken or loose connections.

Four types of excitation control system, involving four types of AVR, can be fitted to the range of generators covered by this manual. The systems can be identified by a combination of AVR type, where applicable, and the last digit of the generator frame size designation. Refer to the generator nameplate then proceed to the appropriate subsection as indicated below:-

DIGIT	EXCITATION CONTROL	SUBSECTION
6	SX460 AVR	7.4.1
4	SX440 AVR	7.4.2
4	SX421 AVR	7.4.3
5	Transformer control	7.4.4
3	MX341 AVR	7.4.5
3	MX321 AVR	7.4.6

7.4.1 SX460 AVR - FAULT FINDING

No voltage build-up when starting set	1. Check speed 2. Check residual voltage. Refer to subsection 7.4.7. 3. Follow Separate Excitation Test Procedure to check generator and AVR.
Unstable voltage either on no-load or with load	1. Check speed stability. 2. Check stability setting. Refer to subsection 4.6.
High voltage either on no-load or with load	1. Check speed. 2. Check that generator load is not capacitive (leading power factor).
Low voltage no-load	1. Check speed. 2. Check link 1-2 or external hand trimmer leads for continuity.
Low voltage on-load	1. Check speed. 2. Check UFRO setting. Refer to subsection 4.7.1.1. 3. Follow Separate Excitation Procedure to check generator and AVR. Refer to subsection 7.5.

7.4.2 SX440 AVR - FAULT FINDING

No voltage build-up when starting set.	<ol style="list-style-type: none"> 1. Check link K1-K2 on auxiliary terminals. 2. Check speed. 3. Check residual voltage. Refer to subsection 7.4.7. 4. Follow Separate Excitation Test Procedure to check generator and AVR. Refer to subsection 7.5.
Unstable voltage either on no-load or with load.	<ol style="list-style-type: none"> 1. Check speed stability. 2. Check stability setting. Refer to subsection 4.6.
High voltage either on no-load or with load	<ol style="list-style-type: none"> 1. Check speed. 2. Check that generator load is not capacitive (leading power factor).
Low voltage no-load	<ol style="list-style-type: none"> 1. Check speed. 2. Check link 1-2 or external hand trimmer leads for continuity.
Low voltage on-load	<ol style="list-style-type: none"> 1. Check speed. 2. Check UFRO setting. Refer to subsection 4.7.1.1. 3. Follow Separate Excitation Procedure to check generator and AVR. Refer to subsection 7.5.

7.4.3 SX421 AVR - FAULT FINDING

No voltage build-up when starting set	<ol style="list-style-type: none"> 1. Check circuit breaker 'ON'. Refer to subsection 6.4.1. 2. Check speed. 3. Check residual voltage. Refer to subsection 7.4.7. 4. Follow Separate Excitation Procedure to check generator and AVR. Refer to subsection 7.5.
Unstable voltage either on no-load or with load	<ol style="list-style-type: none"> 1. Check speed stability. 2. Check stability setting. Refer to subsection 4.6.
High voltage either on no-load or with load	<ol style="list-style-type: none"> 1. Check speed. 2. Check link 1-2 or external hand trimmer leads for continuity. Check continuity of leads 7-8 and P3-P2 for continuity. 3. Check that generator load is not capacitive (leading power factor).
Low voltage no-load	<ol style="list-style-type: none"> 1. Check speed. 2. Check link 1-2 or external hand trimmer leads for continuity.

Low voltage on-load	<ol style="list-style-type: none"> 1. Check speed. 2. Check UFRO setting. Refer to subsection 4.7.1.1. 3. Follow Separate Excitation to check generator and AVR. Refer to subsection 7.5.
Excessive voltage/speed dip on-load switching	<ol style="list-style-type: none"> 1. Check governor response. 2. Refer to generating set manual. Check 'DIP' setting. Refer to subsection 4.7.1.4.

7.4.4 TRANSFORMER CONTROL - FAULT FINDING

No voltage build-up when starting set	<ol style="list-style-type: none"> 1. Check transformers rectifiers. 2. Check transformer secondary winding for open circuit.
Low voltage	<ol style="list-style-type: none"> 1. Check speed. 2. Check transformer air gap setting. Refer to subsection 4.7.2.
High voltage	<ol style="list-style-type: none"> 1. Check speed. 2. Check transformer air gap setting. Refer to subsection 4.7.2. 3. Check transformer secondary winding for short circuited turns.
Excessive voltage drop on-load	<ol style="list-style-type: none"> 1. Check speed drop on-load. 2. Check transformer rectifiers. Check transformer air gap setting. Refer to subsection 4.7.2.

7.4.5 MX341 AVR - FAULT FINDING

No voltage build-up when starting set	<ol style="list-style-type: none"> 1. Check link K1-K2 on auxiliary terminals. 2. Follow Separate Excitation Test Procedure to check machine and AVR. Refer to subsection 7.5.
Loss of voltage when set running	<ol style="list-style-type: none"> 1. First stop and re-start set. If no voltage or voltage collapses after short time, follow Separate Excitation Test Procedure. Refer to subsection 7.5.
Generator voltage high followed by collapse	<ol style="list-style-type: none"> 1. Check sensing leads to AVR. 2. Refer to Separate Excitation Test Procedure. Refer to subsection 7.5.
Voltage unstable either on no-load or with load	<ol style="list-style-type: none"> 1. Check speed stability. 2. Check "STAB" setting. Refer to Load Testing section for procedure. Refer to subsection 4.6.
Low voltage on-load	<ol style="list-style-type: none"> 1. Check speed. 2. If correct check "UFRO" setting. Refer to subsection 4.7.1.1.
Excessive voltage/speed dip on load switching	<ol style="list-style-type: none"> 1. Check governor response. Refer to generating set manual. Check "DIP" setting. Refer to subsection 4.7.1.4.
Sluggish recovery on load switching	<ol style="list-style-type: none"> 1. Check governor response. Refer to generating set manual.

7.4.6 MX321 AVR - FAULT FINDING

No voltage build-up when starting set	<ol style="list-style-type: none"> 1. Check link K1-K2 on auxiliary terminals. Follow Separate Excitation Test Procedure to check machine and AVR. Refer to subsection 7.5.
Voltage very slow to build up	<ol style="list-style-type: none"> 1. Check setting of ramp potentiometer. Refer to 4.7.1.5.
Loss of voltage when set running	<ol style="list-style-type: none"> 1. First stop and re-start set. If no voltage or voltage collapses after short time, follow Separate Excitation Test Procedure. Refer to subsection 7.5.
Generator voltage high followed by collapse	<ol style="list-style-type: none"> 1. Check sensing leads to AVR. 2. Refer to Separate Excitation Test Procedure. Refer to subsection 7.5.
Voltage unstable either on no-load or with load	<ol style="list-style-type: none"> 1. Check speed stability. 2. Check "STAB" setting. Refer to Load Testing section for procedure. Refer to subsection 4.6.
Low voltage on-load	<ol style="list-style-type: none"> 1. Check speed. 2. If correct check "UFRO" setting. Refer to subsection 4.7.1.1.
Excessive voltage/speed dip on load switching	<ol style="list-style-type: none"> 1. Check governor responses. Refer to generating set manual. Check "DIP" setting. Refer to subsection 4.7.1.4.
Sluggish recovery on load switching	<ol style="list-style-type: none"> 1. Check governor response. Refer to generating set manual. Check "DWELL" setting. Refer to Load Testing section 4.7.1.4.

7.4.7 RESIDUAL VOLTAGE CHECK

This procedure is applicable to generators with either SX460 or SX440 or SX421 AVR.

With the generator set stationary remove AVR access cover and leads X and XX from the AVR.

Start the set and measure voltage across AVR terminals 7-8 on SX460 AVR or P2-P3 on SX440 or SX421 AVR.

Stop the set, and replace leads X and XX on the AVR terminals. If the measured voltage was above 5V the generator should operate normally.

If the measured voltage was under 5V follow the procedure below.

Using a 12 volt d. c. battery as a supply clip leads from battery negative to AVR terminal XX, and from battery positive through a 1000V 1A diode to AVR terminal X. See Fig. 10.

Important ! A diode must be used as shown below to ensure the AVR is not damaged.




Fig. 11

Important ! If the generating set battery is used for field flashing the generator main stator neutral must be disconnected from earth.

Restart the set and note output voltage from main stator, which should be approximately nominal voltage, or voltage at AVR terminals 7 and 8 on SX460, P2-P3 on SX440 or SX421 which should be between 170 and 250 volts.

Stop the set and unclip battery supply from terminals X and XX. Restart the set. The generator should now operate normally. If no voltage build-up is obtained it can be assumed a fault exists in either the generator or the AVR circuits. Follow the SEPARATE EXCITATION TEST PROCEDURE to check generator windings, rotating diodes and AVR. Refer to subsection 7.5.

5 SEPARATE EXCITATION TEST PROCEDURE

The generator windings, diode assembly and AVR can be checked using the appropriate following section.

7.5.1 GENERATOR WINDINGS, ROTATING DIODES and PERMANENT MAGNET GENERATOR (PMG)

7.5.2 EXCITATION CONTROL TEST.

7.5.1 GENERATOR WINDINGS, ROTATING DIODES and PERMANENT MAGNET GENERATOR (PMG)

Important ! The resistances quoted apply to a standard winding. For generators having windings or voltages other than those specified refer to factory for details. Ensure all disconnected leads are isolated and free from earth.

Important ! Incorrect speed setting will give proportional error in voltage output.

CHECKING PMG

Start the set and run at rated speed.

Measure the voltages at the AVR terminals P2, P3 and P4. These should be balanced and within the following ranges:-

50Hz generators - 170-180 volts

60Hz generators - 200-216 volts

Should the voltages be unbalanced stop the set, remove the PMG sheet metal cover from the non drive end bracket and disconnect the multipin plug in the PMG output leads. Check leads P2, P3, P4 for continuity. Check the PMG stator resistances between output leads. These should be balanced and within +/-10% of 2.3 ohms. If resistances are unbalanced and/or incorrect the PMG stator must be replaced. If the voltages are balanced but low and the PMG stator winding resistances are correct - the PMG rotor must be replaced.

CHECKING GENERATOR WINDINGS AND ROTATING DIODES

This procedure is carried out with leads X and XX disconnected at the AVR or transformer control rectifier bridge and using a 12 volt d.c. supply to leads X and XX.

Start the set and run at rated speed.

Measure the voltages at the main output terminals U, V and W. If voltages are balanced and within +/-10% of the generator nominal voltage, refer to 7.5.1.1.

Check voltages at AVR terminals 6, 7 and 8. These should be balanced and between 170-250 volts.

If voltages at main terminals are balanced but voltage at 6, 7 and 8 are unbalanced, check continuity of leads 6, 7 and 8. Where an isolating transformer is fitted (MX321 AVR) check transformer windings. If faulty the transformer unit must be replaced.

If voltages are unbalanced, refer to 7.5.1.2.

7.5.1.1 BALANCED MAIN TERMINAL VOLTAGES

If all voltages are balanced within 1% at the main terminals, it can be assumed that all exciter windings, main windings and main rotating diodes are in good order, and the fault is in the AVR or transformer control. Refer to subsection 7.5.2 for test procedure.

If voltages are balanced but low, there is a fault in the main excitation windings or rotating diode assembly. Proceed as follows to identify:-

Rectifier Diodes

The diodes on the main rectifier assembly can be checked with a multimeter. The flexible leads connected to each diode should be disconnected at the terminal end, and the forward and reverse resistance checked. A healthy diode will indicate a very high resistance (infinity) in the reverse direction, and a low resistance in the forward direction. A faulty diode will give a full deflection reading in both directions with the test meter on the 10,000 ohms scale, or an infinity reading in both directions.

On an electronic digital meter a healthy diode will give a low reading in one direction, and a high reading in the other.

Replacement of Faulty Diodes

The rectifier assembly is split into two plates, the positive and negative, and the main rotor is connected across these plates. Each plate carries 3 diodes, the negative plate carrying negative biased diodes and the positive plate carrying positive biased diodes. Care must be taken to ensure that the correct polarity diodes are fitted to each respective plate. When fitting the diodes to the plates they must be tight enough to ensure a good mechanical and electrical contact, but should not be overtightened. The recommended torque tightening is 4.06 - 4.74Nm (36-42lb in).

Surge Suppressor

The surge suppressor is a metal-oxide varistor connected across the two rectifier plates to prevent high transient reverse voltages in the field winding from damaging the diodes. This device is not polarised and will show a virtually infinite reading in both directions with an ordinary resistance meter. If defective this will be visible by inspection, since it will normally fail to short circuit and show signs of disintegration. Replace if faulty.

Main Excitation Windings

If after establishing and correcting any fault on the rectifier assembly the output is still low when separately excited, then the main rotor, exciter stator and exciter rotor winding resistances should be checked (see Resistance Charts), as the fault must be in one of these windings. The exciter stator resistance is measured across leads X and XX. The exciter rotor is connected to six studs which also carry the diode lead terminals. The main rotor winding is connected across the two rectifier plates. The respective leads must be disconnected before taking the readings.

Resistance values should be within +/-10% of the values given in the table below:-

Frame Size	Main Rotor	Exciter Stator			Exciter Rotor
		Type 1	Type 2*	Type 3**	
UC22C	0.59	21	28	138	0.142
UC22D	0.64	21	28	138	0.142
UC22E	0.69	20	30	155	0.156
UC22F	0.83	20	30	155	0.156
UC22G	0.94	20	30	155	0.156
UC27C	1.14	20	-	-	0.156
UC27D	1.25	20	-	-	0.156
UC27E	1.4	20	-	-	0.182
UC27F	1.6	20	-	-	0.182
UC27G	1.76	20	-	-	0.182
UC27H	1.92	20	-	-	0.182
UC27J	2.2	20	-	-	0.182

* Used with 1 phase transformer controlled 3 phase or 1 phase generators.

** Used with 3 phase transformer controlled 3 phase generators.

7.5.1.2 UNBALANCED MAIN TERMINAL VOLTAGES

If voltages are unbalanced, this indicates a fault on the main stator winding or main cables to the circuit breaker. NOTE: Fault on the stator winding or cables may also cause noticeable load increase on the engine when excitation is applied. Disconnect the main cables and separate the winding leads U1-U2, U5-U6, V1-V2, V5-V6, W1-W2, W5-W6 to isolate each winding section. (U1-L1, U2-L4 on single phase generators).

Measure each section resistance - values should be balanced and within +/-10% of the value given below:-

AVR CONTROLLED GENERATORS				
Frame Size	SECTION RESISTANCES			
	Winding 311	Winding 17	Winding 05	Winding 06
UC22C	0.09	0.14	0.045	0.03
UC22D	0.065	0.1	0.033	0.025
UC22E	0.05	0.075	0.028	0.02
UC22F	0.033	0.051	0.018	0.012
UC22G	0.028	0.043	0.014	0.01
UC27C	0.03	0.044	-	-
UC27D	0.023	0.032	-	-
UC27E	0.016	0.025	-	-
UC27F	0.012	0.019	-	-
UC27G	0.011	0.013	-	-
UC27H	0.08	0.014	-	-
UC27J	0.07	0.012	-	-

TRANSFORMER CONTROLLED GENERATORS					
Frame Size	SECTION RESISTANCES, 3 PHASE WINDINGS				
	380V	400V	415V	416V	460V
	50Hz	50Hz	50Hz	60Hz	60Hz
UC22C	0.059	0.078	0.082	0.055	0.059
UC22D	0.054	0.056	0.057	0.049	0.054
UC22E	0.041	0.053	0.053	0.038	0.041
UC22F	0.031	0.031	0.033	0.025	0.031
UC22G	0.022	0.026	0.028	0.021	0.022

Measure insulation resistance between sections and each section to earth.

Unbalanced or incorrect winding resistances and/or low insulation resistances to earth indicate rewinding of the stator will be necessary. Refer to removal and replacement of component assemblies subsection 7.5.3.

7.5.2 EXCITATION CONTROL TEST

7.5.2.1 AVR FUNCTION TEST

All types of AVR's can be tested with this procedure:

1. Remove exciter field leads X & XX (F1 & F2) from the AVR terminals X & XX (F1 & F2).
2. Connect a 60W 240V household lamp to AVR terminals X & XX (F1 & F2).
3. Set the AVR VOLTS control potentiometer fully clockwise.
4. Connect a 12V, 1.0A DC supply to the exciter field leads X & XX (F1 & F2) with X (F1) to the positive.

5. Start the generating set and run at rated speed.

Check that the generator output voltage is within +/-10% of rated voltage.

Voltages at AVR terminals 7-8 on SX460 AVR or P2-P3 on SX440 or SX421 AVR should be between 170 and 250 volts. If the generator output voltage is correct but the voltage on 7-8 (or P2-P3) is low, check auxiliary leads and connections to main terminals.

Voltages at P2, P3, P4 terminals on MX341 and MX321 should be as given in 7.5.1.

The lamp connected across X-XX should glow. In the case of the SX460, SX440 and SX421 AVRs the lamp should glow continuously. In the case of the MX341 and MX321 AVRs the lamp should glow for approximately 8 secs. and then turn off. Failure to turn off indicates faulty protection circuit and the AVR should be replaced. Turning the "VOLTS" control potentiometer fully anti-clockwise should turn off the lamp with all AVR types.

If the lamp fail to light the AVR is faulty and should be replaced.

Important ! After this test turn VOLTS control potentiometer fully anti-clockwise.

7.5.2.2 TRANSFORMER CONTROL

The transformer rectifier unit can only be checked by continuity, resistance checks and insulation resistance measurement.

Two phase transformer

Separate primary leads T1-T2-T3-T4 and secondary leads 10-11. Examine windings for damage. Measure resistances across T1-T3 and T2-T4. These will be a low value but should be balanced. Check that there is resistance in the order of 8 ohms between leads 10 and 11. Check insulation resistance of each winding section to earth and to other winding sections.

Low insulation resistance, unbalanced primary resistance, open or short circuited winding sections, indicates the transformer unit should be replaced.

Three phase transformer

Separate primary leads T1-T2-T3 and secondary leads 6-7-8 and 10-11-12.

Examine windings for damage. Measure resistances across T1-T2, T2-T3, T3-T1. These will be low but should be balanced. Check that resistances are balanced across 6-10, 7-11 and 8-12 and in the order of 18 ohms.

Check insulation resistance of each winding section to earth and to other winding sections.

Low insulation resistance, unbalanced primary or secondary winding resistances, open or short circuited winding sections indicates the transformer unit should be replaced.

Rectifier units - Three phase and single phase

With the leads 10-11-12-X and XX removed from the rectifier unit (lead 12 is not fitted on single phase transformer rectifier units), check forward and reverse resistances between terminals 10-X, 11-X, 12-X, 10-XX, 11-XX and 12-XX with a multimeter.

A low forward resistance and high reverse resistance should be read between each pair of terminals. If this is not the case the unit is faulty and should be replaced.

7.5.3 REMOVAL AND REPLACEMENT OF COMPONENT ASSEMBLIES

METRIC THREADS ARE USED THROUGHOUT

Caution ! When lifting single bearing generators, care is needed to ensure the generator frame is kept in the horizontal plane. The rotor is free to move in the frame and can slide out if not correctly lifted. Incorrect lifting can cause serious personal injury.

7.5.3.1 REMOVAL OF PERMANENT MAGNET GENERATOR (PMG)

1. Remove 4 screws holding the sheet metal cylindrical cover at the non-drive end and remove the cover.
2. Disconnect the in line connector from the PMG stator (3 wires go to this connector). It may be necessary to cut off the nylon cable tie first.
3. Remove the 4 threaded pillars and clamps holding the PMG stator onto the end bracket.
4. Tap the stator out of the 4 spigots and withdraw. The highly magnetic rotor will attract the stator. Take care to avoid contact which may damage the windings.
5. Remove the bolt in the centre from the rotor shaft and pull off the rotor. It may be necessary to gently tap the rotor away. Take care to tap gently and evenly - the rotor has ceramic magnets which are easily broken by shock.

Important ! The rotor assembly must not be dismantled.

Replacement is a reversal of the above procedure.

7.5.3.2 REMOVAL OF BEARINGS

Important ! Position the main rotor so that a full pole face of the main rotor core is at the bottom of the stator bore.

NOTE: Removal of the bearings may be effected either after the rotor assembly has been removed OR more simply by removal of endbracket(s). Refer to 7.5.3.3. and 7.5.3.4.

The bearings are pre-packed with grease and sealed for life.

The bearing(s) are a press fit and can be removed from the shaft with 3 leg or 2 leg manual or hydraulic bearing pullers.

SINGLE BEARING ONLY: Before trying to pull off the bearing remove the small circlip retaining it.

When fitting new bearings use a bearing heater to expand the bearing before fitting to the shaft. Tap the bearing into place ensuring that it contacts the shoulder on the shaft.

Refit the retaining circlip on single bearing generators.

7.5.3.3 REMOVAL OF ENDBRACKET AND EXCITER STATOR

1. Remove exciter leads X+, XX- at the AVR.
2. Slacken 4 bolts (2 each side) situated on horizontal centre line holding the terminal box.
3. Remove 2 bolts holding lifting lug, at the non-drive end, and remove lug.

4. Remove sheet metal cylindrical cover (4 screws) over PMG (if fitted)
or
Remove shallow sheet metal cover (4 screws) at the non-drive end.
5. Ease up the terminal box and support clear of the non-drive endbracket.
6. Remove 6 bolts holding the non-drive endbracket to the stator bar assembly. The endbracket is now ready for removal.
7. Replace the lifting lug onto the endbracket and sling the endbracket on a hoist to facilitate lifting.
8. Tap the endbracket around its perimeter to release from the generator. The endbracket and exciter stator will come away as a single assembly.
9. Remove the 4 screws holding the exciter stator to the endbracket and gently tap the exciter stator to release it. Replacement is a reversal of the above procedure.

7.5.3.4 REMOVAL OF THE ROTOR ASSEMBLY

Remove the permanent magnet generator. Refer to 7.5.3.1 or

Remove the four screws holding the sheet metal cover at the non drive end and remove cover.

Caution ! With the PMG rotor removed single bearing generator rotors are free to move in the frame. Ensure frame is kept in the horizontal plane when lifting.

TWO BEARING GENERATORS

1. Remove 2 screws holding the sheet metal cover around the adaptor at the drive end and remove the cover.
2. Remove the bolts holding the adaptor to the endbracket at the drive end.
3. Tap off the adaptor. It may be preferred to sling the adaptor first depending on its size and weight.
4. Remove the screens and louvres (if fitted) at each side on the drive end.

Now ensure that the rotor is positioned with a full pole face at the bottom centre line. This is to avoid damage to the bearing exciter, or rotor winding, by limiting the possible rotor downward movement to the air gap length.

5. Remove 6 bolts holding drive endbracket onto adaptor ring DE. The bolt heads face towards the non-drive end. The top bolt passes through the centre of the lifting lug.
6. Tap the drive endbracket away from the adaptor ring DE and withdraw the endbracket.
7. Ensure the rotor is supported at the drive end on a sling.
8. Tap the rotor from the non-drive end to push the bearing clear of the endbracket and its position within an 'O' ring.
9. Continue to push the rotor out of the stator bore, gradually working the sling along the rotor as it is withdrawn, to ensure that it is fully supported all the time.

SINGLE BEARING GENERATORS

1. Remove the screws, screens and louvres (if fitted) at each side on drive end adaptor.
2. UCI224, UCI274, UCM224, UCM274, UCD274 Only

Remove 6 bolts holding the adaptor at the drive end. It may be preferred to sling the adaptor on a hoist. The bolt heads face towards the non-drive end. The top bolt passes through the centre of the lifting lug.

2a. UCD224 Only

Remove 6 bolts holding the adaptor at the drive end. It may be preferred to sling the adaptor on a hoist.

3. UCI224, UCI274, UCM224, UCM274, UCD274 Only

Tap the adaptor away from stator bar adaptor ring.

3a. UCD224 Only

Tap the adaptor away from stator bar assembly.

ALL SINGLE BEARING GENERATORS

4. Ensure the rotor is supported at drive end on a sling.
5. Tap the rotor from the non-drive end to push the bearing clear of the endbracket and its position within an 'O' ring.
6. Continue to push the rotor out of the stator bore, gradually working the sling along the rotor as it is withdrawn, to ensure that it is fully supported at all times.

Replacement of rotor assemblies is a reversal of the procedures above.

Before commencing re-assembly, components should be checked for damage and bearing(s) examined for loss of grease.

Fitting of new bearing(s) is recommended during major overhaul.

Before replacement of a single bearing rotor assembly, check that the drive discs are not damaged, cracked or showing other signs of fatigue. Also check that the holes in the discs for drive fixing screws are not elongated.

Damaged or worn components must be replaced.

Caution ! When major components have been replaced, ensure that all covers and guards are securely fitted, before the generator is put into service.

7.6 RETURNING TO SERVICE

After rectification of any faults found, remove all test connections and reconnect all control system leads.

Restart the set and adjust VOLTS control potentiometer on AVR controlled generators by slowly turning clockwise until rated voltage is obtained.

Refit all terminal box covers/access covers and reconnect heater supply.

Caution ! Failure to refit all guards, access covers and terminal box covers can result in personal injury or death.

SECTION 8

SPARES AND AFTER SALES SERVICE

8.1 RECOMMENDED SPARES

Service parts are conveniently packaged for easy identification. Genuine parts may be recognised by the Nupart name.

We recommend the following for Service and Maintenance. In critical applications a set of these service spares should be held with the generator.

AVR Controlled Generators

1. Diode Set (6 diodes with surge suppressor)	RSK	2001
2. AVR SX440	E000	24030
AVR SX460	E000	24602
AVR SX421	E000	24210
AVR MX321	E000	23212
AVR MX341	E000	23410
3. Non drive end Bearing	UC22 051	01032
	UC27 051	01049
4. Drive end Bearing	UC22 051	01044
	UC27 051	01050

Transformer Controlled Generators (UC22 Only)

1. Diode Set (6 diodes with surge suppressor)	RSK	2001
2. Diode Assembly	E000	22006
Non drive end Bearing	UC22 051	01032
4. Drive end Bearing	UC22 051	01044

When ordering parts the machine serial number or machine identity number and type should be quoted, together with the part description. For location of these numbers see paragraph 1.3.

Orders and enquiries for parts should be addressed to:

Newage International Limited
Nupart Department
PO Box 17, Barnack Road
TAMFORD
Lincolnshire
PE9 2NB
ENGLAND

Telephone: 44 (0) 1780 484000

Fax: 44 (0) 1780 766074

Or any of our subsidiary companies listed on the back cover.

8.2 AFTER SALES SERVICE

A full technical advice and on-site service facility is available from our Service Department at Stamford or through our Subsidiary companies. A repair facility is also available at our Stamford Works.


PARTS LIST

TYPICAL SINGLE BEARING GENERATOR

Plate Ref.	Description	Plate Ref.	Description
1	Stator	25	Main Rectifier Assembly - Reverse
2	Rotor	26	Varistor
3	Exciter Rotor	27	Diode - Forward Polarity
4	Exciter Stator	28	Diode - Reverse Polarity
5	N.D.E. Bracket	29	Lifting Lug - D.E.
6	Cover N.D.E.	30	Lifting Lug - N.D.E.
7	Bearing 'O' Ring N.D.E.	31	Frame to Endbracket Adaptor Ring
8	Bearing N.D.E.	32	Main Terminal Panel
9	Bearing Circlip N.D.E.	33	Terminal Link
10	D.E. Bracket/Engine Adaptor	34	Edging Strip
11	D.E. Screen	35	Fan
12	Coupling Disc	36	Foot Mounting Spacer
13	Coupling Bolt	37	Cap Screw
14	Foot	38	AVR Access Cover
15	Frame Cover Bottom	39	AVR Anti-Vibration Mounting Assembly
16	Frame Cover Top	40	Auxiliary Terminal Assembly
17	Air Inlet Cover		
18	Terminal Box Lid		
19	Endpanel D.E.		
20	Endpanel N.D.E.		
21	AVR		
22	Side Panel		
23	AVR Mounting Bracket		
24	Main Rectifier Assembly - Forward		

N.D.E. Non Drive End
 D.E. Drive End
 PMG Permanent Magnet Generator
 AVR Automatic Voltage Regulator

Fig. 11.
TYPICAL SINGLE BEARING GENERATOR



31


PARTS LIST

TYPICAL TWO BEARING GENERATOR

Plate Ref.	Description	Plate Ref.	Description
1	Stator	25	Main Rectifier Assembly - Reverse
2	Rotor	26	Varistor
3	Exciter Rotor	27	Diode - Forward Polarity
4	Exciter Stator	28	Diode - Reverse Polarity
5	N.D.E. Bracket	29	Lifting Lug - D.E.
6	Cover N.D.E.	30	Lifting Lug - N.D.E.
7	Bearing 'O' Ring N.D.E.	31	Frame to Endbracket Adaptor Ring
8	Bearing N.D.E.	32	Main Terminal Panel
9	Bearing Wave Washer D.E.	33	Terminal Link
10	D.E. Bracket	34	Edging Strip
11	D.E. Screen	35	Fan
12	Bearing D.E.	36	Foot Mounting Spacer
14	Foot	37	Cap Screw
15	Frame Cover Bottom	38	AVR Access Cover
16	Frame Cover Top	39	AVR Anti-Vibration Mount
17	Air Inlet Cover	40	Auxiliary Terminal Assembly
18	Terminal Box Lid	42	PMG Exciter Rotor
19	Endpanel D.E.	43	PMG Exciter Stator
20	Endpanel N.D.E.	44	PMG Bolt
21	AVR	45	PMG Pillar
22	Side Panel	46	PMG Clamp
23	AVR Mounting Bracket	47	PMG Dowel
24	Main Rectifier Assembly - Forward		

N.D.E. Non Drive End
 D.E. Drive End
 PMG Permanent Magnet Generator
 AVR Automatic Voltage Regulator

Fig. 12.
TYPICAL TWO BEARING GENERATOR



PARTS LIST
TYPICAL TWO BEARING (SERIES 5) GENERATOR

Plate Ref.	Description	Plate Ref.	Description
1	Stator	25	Main Rectifier Assembly - Reverse
2	Rotor	26	Varistor
3	Exciter Rotor	27	Diode - Forward Polarity
4	Exciter Stator	28	Diode - Reverse Polarity
5	N.D.E. Bracket	29	Lifting Lug - D.E.
6	Cover N.D.E.	30	Lifting Lug - N.D.E.
7	Bearing 'O' Ring N.D.E.	31	Frame to Endbracket Adaptor Ring
8	Bearing N.D.E.	32	Main Terminal Panel
9	Bearing Wave Washer D.E.	33	Terminal Link
10	D.E. Bracket	34	Edging Strip
11	D.E. Screen	35	Fan
12	Bearing D.E.	36	Foot Mounting Spacer
13		37	Cap Screw
14	Foot		
15	Frame Cover Bottom		
16	Frame Cover Top		
17	Air Inlet Cover		
18	Terminal Box Lid		
19	Endpanel D.E.		
20	Endpanel N.D.E.		
21	Series 5 Control Gear		
22	Side Panel		
23			
24	Main Rectifier Assembly - Forward		


N.D.E.

Non Drive End

D.E.

Drive End

Fig. 13.
TYPICAL TWO BEARING (SERIES 5) GENERATOR



35

Fig. 14.
ROTATING RECTIFIER ASSEMBLY





Plate Ref.	Description	Qty
1	Hub	1
2	Fin	2
3	Diode (fwd)	3
4	Diode (rev)	3
5	Hx. Screw	6
6	Hx. Nut	6
7	Pl. Washer	8
8	SC. L/Washer	8
9	Varistor	1
10	Hx. Screw	2

NOTES:

Fitting of Diodes.

1. Underside of diodes to be smeared with Midland Silicone 'Heat Sink' compound type MS2623. This compound **must not** be applied to the diode threads.
2. Diodes to be tightened to a torque of 2.03 - 2.37 Nm.
3. For Nupart rectifier service kit see page 28.

This manual is available in the following languages on request:
English, French, German, Italian and Spanish.

Denne manual er til rådighed på følgende sprog: engelsk, fransk, tysk, italiensk og spansk.

Denne håndboken er tilgjengelig på de følgende språkene: engelsk, fransk, tysk, italiensk og spansk.

Sur simple demande, ce manuel vous sera fourni dans l'une des langues suivantes: anglais, français, allemand, italien, espagnol.

Dieses Handbuch ist auf Anfrage in den folgenden Sprachen erhältlich: Englisch, Französisch, Deutsch, Italienisch, Spanisch.

Deze handleiding is op verzoek leverbaar in de volgende talen: Engels, Frans, Duits, Italiaans, Spaans.

Este manual pode também ser obtido nas seguintes línguas: inglês, francês, alemão, italiano e espanhol.

Tämä käsikirja on saatavissa pyynnöstä seuraavilla kielillä: Englanti, ranska, saksa, italia, espanja.

Il presente manuale è disponibile, su richiesta, nelle seguenti lingue: inglese, francese, tedesco, italiano e spagnolo.

Este manual también puede solicitarse en los siguientes idiomas: inglés, francés, alemán, italiano e español.

Αυτό το εγχειρίδιο οδηγιών χρήσεως διατίθεται στις ακόλουθες γλώσσες κατόπιν αιτήσεως: Αγγλικά, Γαλλικά, Γερμανικά, Ιταλικά, Ισπανικά.

A.C. GENERATOR WARRANTY

WARRANTY PERIOD

A.C. Generators

In respect of a.c. generators the Warranty Period is eighteen months from the date when the goods have been notified as ready for despatch by N.I. or twelve months from the date of first commissioning (whichever is the shorter period).

DEFECTS AFTER DELIVERY

We will make good by repair or, at our option, by the supply of a replacement, any fault which under proper use appears in the goods within the period specified on Clause 12, and is found on examination by us to be solely due to defective material and workmanship; provided that the defective part is promptly returned, carriage paid, with all identification numbers and marks intact, or our works or, if appropriate to the Dealer who supplied the goods.

Any part repaired or replaced, under warranty, will be returned by N.I. free of charge (via sea freight if outside the UK).

We shall not be liable for any expenses which may be incurred in removing or replacing any part sent to us for inspection or in fitting any replacement supplied by us. We shall be under no liability for defects in any goods which have not been properly installed in accordance with N.I. recommended installation practices as detailed in the publications 'N.I. Installation, Service and Maintenance Manual' and 'N.I. Application Guidelines', or which have been improperly stored or which have been repaired, adjusted or altered by any person except ourselves or our authorised agents, or in any second-hand goods, proprietary articles or goods not of our own manufacture although supplied by us, such articles and goods being covered by the warranty (if any) given by the separate manufacturers.

Any claim under this clause must contain fully particulars of the alleged defect, the description of the goods, the date of purchase, and the name and address of the Vendor, the Serial Number (as shown on the manufacturers identification plate) or for Spares the order reference under which the goods were supplied.

Our judgement in all cases of claims shall be final and conclusive and the claimant shall accept our decision on all questions as to defects and the exchange of a part or parts.

Our liability shall be fully discharged by either repair or replacement as above, and in any event shall not exceed the current list price of the defective goods.

Our liability under this clause shall be in lieu of any warranty or condition implied by law as to the quality or fitness for any particular purpose of the goods, and save as expressly provided in this clause we shall not be under any liability, whether in contract, tort or otherwise, in respect of defects in goods delivered or for any injury, damages or loss resulting from such defects or from any work undone in connection therewith.

MACHINE SERIAL NUMBER

NEWAGE INTERNATIONAL LIMITED

REGISTERED OFFICE AND ADDRESS:

PO BOX 17
BARNACK ROAD
STAMFORD
LINCOLNSHIRE
PE9 2NB ENGLAND

Telephone: 44 (0) 1780 484000

Fax: 44 (0) 1780 484100

Web site: www.newagestamford.com

SUBSIDIARY COMPANIES



1 AUSTRALIA: NEWAGE ENGINEERS PTY. LIMITED
PO Box 6027, Baulkham Hills Business Centre,
Baulkham Hills NSW 2153.
Telephone: Sydney (61) 2 9680 2299
Fax: (61) 2 9680 1545

2 CHINA: WUXI NEWAGE ALTERNATORS LIMITED
Plot 49-A, Xiang Jiang Road
Wuxi High - Technical Industrial Dev. Zone
Wuxi, Jiangsu 214028
PR of China
Tel: (86) 510 5216212
Fax: (86) 510 5217673

3 GERMANY: NEWAGE ENGINEERS G.m.b.H.
Rotenbrückenweg 14, D-22113 Hamburg.
Telephone: Hamburg (49) 40 714 8750
Fax: (49) 40 714 87520

4 INDIA: C.G. NEWAGE ELECTRICAL LIMITED
C33 Midc, Ahmednagar 414111, Maharashtra.
Telephone: (91) 241 778224
Fax: (91) 241 777494

5 ITALY: NEWAGE ITALIA S.r.l.
Via Triboniano, 20156 Milan.
Telephone: Milan (39) 02 380 00714
Fax: (39) 02 380 03664

6 JAPAN: NEWAGE INTERNATIONAL JAPAN
8 - 5 - 302 Kashima
Hachioji-shi
Tokyo, 192-03
Telephone: (81) 426 77 2881
Fax: (81) 426 77 2884

7 NORWAY: NEWAGE NORGE A/S
Økern Naeringspark, Kabeigt. 5
Postboks 28, Økern, 0508 Oslo
Telephone: Oslo (47) 22 97 44 44
Fax: (47) 22 97 44 45

8 SINGAPORE: NEWAGE ASIA PACIFIC PTE LIMITED
10 Toh Guan Road #05-03
TT International Tradepark
Singapore 608838
Telephone: Singapore (65) 794 3730
Fax: (65) 898 9065
Telex: RS 33404 NEWAGE

9 SPAIN: STAMFORD IBERICA S.A.
Ctra. Fuenlabrada-Humanes, km.2
Poligono Industrial "Los Linares"
C/Pico de Almanzor, 2
E-28970 HUMANES DE MADRID (Madrid)
Telephone: Madrid (34) 91 604 8987/8928
Fax: (34) 91 604 81 66

10 U.S.A.: NEWAGE LIMITED
4700 Main St, N.E.
Fridley
Minnesota 55421
Telephone: (1) 800 367 2764
Fax: (1) 800 863 9243


© 1998 Newage International Limite
Printed in England.



GE Fanuc Automation

Series 90™-30 PLCs

The Series 90™-30 PLCs are a family of controllers, I/O systems and specialty modules designed to meet the demand for versatile industrial solutions. With its single overall control architecture, the Series 90-30 has been the PLC of record in over 200,000 applications, such as high-speed packaging, material handling, complex motion control, water treatment, continuous emissions monitoring, mining, food processing, elevator control, injection molding and many more.



Thanks to its modular design, the Series 90-30 offers unmatched versatility. Configure just the system you need, saving critical space and reducing cost.

With over 100 I/O modules, the Series 90-30 PLC can be adapted to a wide range of applications.

- Digital interfaces for push buttons, switches, proximity sensors, relays, contactors and many other devices
- Analog modules with varying degrees of resolution for flow, temperature or pressure applications
- Direct connect wiring or remote termination
- Local or remote I/O systems

Series 90-30 Ethernet communications provide a real-time link between the plant floor and the boardroom. You can begin with an Ethernet-enabled CPU, or at a later date, choose from our selection of rack-mounted Ethernet modules. The Series 90-30 Ethernet module supports both SRTP and Modbus TCP/IP application protocols.

The scaleable processing power in the Series 90-30 CPU creates a clear upgrade path. Create the system that's ideal today, while leaving open the option of creating a more powerful system tomorrow — without having to change your application software.

Motion control integrated into the Series 90-30 fosters high performance point-to-point applications.

A variety of Series 90-30 field bus interfaces enables distributed control and/or I/O. Choose from Ethernet EGD, Profibus-DP™, Genius®, DeviceNet™ and Interbus-S™ modules. Field Bus interface modules are easy to install and quick to configure. Plug them into an existing system or design a new system around them.

Ease of programming is a strong suit of the Series 90-30. Choose the programming options that meet your needs: Windows®-based IEC programming, advanced C or State Logic®. Floating point math, PID, indirect addressing, array moves and sequencing are just a few of the over 200 instructions available.

The Series 90-30 stands out among small controls for offering redundancy options. The Series 90-30 is the low-cost solution for high availability applications, with redundant CPUs and power supplies.

Easy trouble shooting and machine setup using a handheld PDA. CIMPLICITY® Machine Edition Logic Developer PDA software allows you to interface a Palm® handheld device to your Series 90-30 controller. With Logic Developer PDA, you can monitor/change data, view diagnostics, force ON/OFF, and configure machine setup — saving you time and increasing productivity.

Ordering Information

Description	Catalog Number	Description	Catalog Number		
Discrete Input Modules	IC693MDL230	120 VAC Isolated Input (8 Points)	IC693MDL646	24 VDC Input, Neg/Pos Logic, 1 msec Filter (16 Points)	
	IC693MDL231	240 VAC Isolated Input (8 Points)	IC693MDL648	48 VDC Input, Neg/Pos Logic, 1 msec Filter, Neg/Pos Logic (16 Points)	
	IC693MDL240	120 VAC Input (16 Points)	IC693MDL653	24 VDC Input, Neg/Pos Logic, 2msec Filter (32 Points)	
	IC693MDL241	24 VAC/VDC Input (16 Points)	IC693MDL654	5/12 VDC (TTL) Input, Neg/Pos Logic, (32 Points)	
	IC693MDL632	125 VDC Input (8 Points)	IC693MDL655	24 VDC Input, Neg/Pos Logic, 1 ms, (32 Points)	
	IC693MDL634	24 VDC Input, Neg/Pos Logic (8 Points)	IC693ACC300	Input Simulator Module (8 Points)	
	IC693MDL645	24 VDC Input, Neg/Pos Logic (16 Points)			
	Discrete Output Modules	IC693MDL310	120 VAC Output, 0.5 Amp (12 Points)	IC693MDL740	12/24 VDC Output, 0.5 Amp, Positive Logic (16 Points)
IC693MDL330		120/240 VAC Output, 2 Amp (8 Points)	IC693MDL741	12/24 VDC Output, 0.5 Amp, Negative Logic (16 Points)	
IC693MDL340		120 VAC Output, 0.5 Amp (16 Points)	IC693MDL742	12/24 VDC Output, 1 Amp, Positive Logic (16 Points), Fused	
IC693MDL390		120/240 VAC Isolated Output, 2 Amp (5 Points)	IC693MDL748	48 VDC Output, 0.5 Amps, Positive Logic (8 Points)	
IC693MDL730		12/24 VDC Output, 2 Amp, Positive Logic (8 Points)	IC693MDL750	12/24 VDC Output, Negative Logic (32 Points)	
IC693MDL731		12/24 VDC Output, 2 Amp, Negative Logic (8 Points)	IC693MDL751	12/24 VDC Output, Positive Logic (32 Points)	
IC693MDL732		12/24 VDC Output, 0.5 Amp, Positive Logic (8 Points)	IC693MDL752	5/12/24 VDC (TTL) Output, Negative Logic, (32 Points)	
IC693MDL733		12/24 VDC Output, 0.5 Amp, Negative Logic (8 Points)	IC693MDL753	12/24 VDC Output, Positive Logic (32 Points)	
IC693MDL734		125 VDC Output, (6 Points)			
Relay Output Module		IC693MDL930	Relay Output, Isolated, 4 Amp (8 Points)	IC693MDL940	Relay Output, 2 Amp (16 Points)
		IC693MDL931	Relay Output, 8 Amp Form B/C contacts, Isolated in 2 Groups of 4 (8 Points)		
Mixed Discrete Module		IC693MOR390	Mixed I/O, 24 VDC Input (8 points), Relay Output (8 points)	IC693MAR590	Mixed I/O, 120 VAC Input (8 Points), Relay Output (8 Points)
Analog Input Modules	IC693ALG220	Analog Input, Voltage/Current, 4 Channels	IC693ALG222	Analog Input, Voltage 16 Single/8 Differential Channels	
	IC693ALG221	Analog Input, Current, 4 Channels	IC693ALG273	Analog Input, Current, 16 Single Channels	
Analog Output Modules	IC693ALG390	Analog Output, Voltage, 2 Channels	IC693ALG392	High Density Analog Output (8 Channels)	
	IC693ALG391	Analog Output, Current, 2 Channels			
Mixed Analog Modules	IC693ALG442	Analog Combo Module 4IN/2OUT			
Motion Modules	IC693APU300	High Speed Counter (HSC)	IC693APU305	High Speed Counter with Gray Code Encoder or an A QUAD 8 Encoder Input	
	IC693APU301	Axis Positioning Module (APM), 1 Axis	IC693DSM302	Digital Servo Motion Controller, 2 Axis	
Specialty Modules	IC693APU302	Axis Positioning Module (APM), 2 Axis	IC693DSM314	Digital Servo Motion Controller, 1-2 Axis of Digital Servo or 1-4 Axis Analog Servo	
	IC693MDL760	Solenoid Valve Output (11 Points)/24 VDC Output, 0.5 Amp, Positive Logic (5 Points)	IC693PTM101	Power Transducer Module, CT and PT Interface 120/240 VAC (1m cable)	
	IC693PCM301	Programmable Coprocessor Module, 192 KB (47 KB Basic or C Program), 2 Serial Ports	IC693TCM302	Temperature Control Module, (8) TC In and (8) 24 VDC Solid State Outputs	
	IC693PCM311	Programmable Coprocessor Module, 640 KB (640 KB Basic or C Program), 2 Serial Ports	IC693TCM303	Temperature Control Module Extended Temperature Range, (8) TC In and (8) 24 VDC Solid State Outputs	
	IC693PTM100	Power Transducer Module, CT and PT Interface 120/240 VAC (0.5m Cable)			
	IC693BEM301	Genius Bus Controller (Supports I/O and Diagrams)	IC693PSM200	Profibus DP Master Module	
Communications Modules	IC693CMM302	Communication Module, Genius (1 Kbyte) GCM+ (No Diagram Support)	IC693PSM301	Profibus DP Slave Module	
	IC693CMM311	Communications Module, CCM, RTU, SNP, and SNPx Protocols	IC693DNM302	DeviceNet Master Module	
	IC693CMM321	Ethernet Interface TCP/IP Module, 10Mbps (Supports SRTP and Modbus TCP/IP, No EGD)	IC693DNS201	DeviceNet Slave Module	
	IC693CPU311	5-Slot Base with CPU in Base (5KBytes User Program), Not Expandable	IC693CPU380	CPU 380 Module (240KBytes Configurable User Memory, 4K I/O, 8 Racks), No Built-In Serial Ports, Logic Execution is .22msec/K	
Controllers	IC693CPU313	5-Slot Base with Turbo CPU in Base (Logic Execution is .6 msec), 1K Registers, (12KBytes User Program), Not Expandable	IC693CPU383	CPU 383 Module (240KBytes Configurable User Memory 4K I/O, 8 Racks), 2 Built-In Serial Ports, Logic Execution is .22msec/K	
	IC693CPU323	10-Slot Base with Turbo CPU in Base (Logic Execution is .6 msec) 12KBytes User Program, Not Expandable	IC693CPU384	CPU 384 Module (240KBytes Configurable User Memory 4K I/O, 8 Racks), No Built-In Serial Ports, Built-In 10Mbps Ethernet, Supports SRTP, Channels and EGD, Logic Execution is .22msec/K	
	IC693CPU350	CPU 350 Module (32KBytes User Memory, 4K I/O, 8 Racks), No Built-In Serial Ports, Logic Execution is .22msec/K	IC693CPU374	CPU 374 Module (240KBytes Configurable User Memory), No Built-In Serial Ports, Built-In 10/100Mbps with Built-In Switch, Ethernet Supports SRTP, EGD and No Channel Support; Logic Execution is .22msec/K	
Backplanes	IC693CHS391	Base, CPU, 10 Slots, Use with CPU331/CSE301 and above	IC693CHS397	Base, CPU, 5 Slots (use with CPU331/CSE301 and above)	
	IC693CHS392	Base, Expansion, 10 Slots	IC693CHS398	Base, Expansion, 5 Slots	
	IC693CHS393	Base, Remote Expansion, 10 Slots (700 ft.)	IC693CHS399	Base, Remote Expansion, 5 Slots (700 ft.)	
Power Supplies	IC693PWR321	Power Supply, 120/240 VAC, 125 VDC, Standard, 30 Watts	IC693PWR322	Power Supply, 12 VDC, High Capacity, 30 Watts	
	IC693PWR322	Power Supply, 24/48 VDC, Standard, 30 Watts	IC693PWR323	Redundant Power Supply Base (RPSB) with 0.1 meter cable to connect to Power Supply Adapter Module	
	IC693PWR328	Power Supply, 48 VDC, Standard, 30 Watts	IC693ACC341	Redundant Power Supply Base with 0.5 meter cable to connect to Power Supply Adapter Module	
	IC693PWR330	Power Supply, 120/240 VAC, 125 VDC, High Capacity, 30 Watts	IC693ACC350	Redundant Power Supply Adapter (RPSA) Module. The RPSA replaces the power supply on a CPU base or expansion base and connects to a Redundant Power Supply Base.	
	IC693PWR331	Power Supply, 24 VDC, High Capacity, 30 Watts			
Accessories	IC693ACC301	Replacement Battery, CPU & PCM (Qty. 2)	IC693CBL301	Rack to Rack Expansion Cable, 2 Meters	
	IC693ACC302	High Capacity Battery Pack	IC693CBL302	Rack to Rack Expansion Cable, 15 Meters	
	IC200ACC003	EZ Program Store Flash Device (for CPU374 only)	IC693CBL312	Rack to Rack Expansion Cable, 0.15 Meters, Shielded	
	IC693ACC310	Filler Module, Blank Slot	IC693CBL313	Rack to Rack Expansion Cable, 8 Meters	
	IC693CBL300	Rack to Rack Expansion Cable, 1 Meter	IC693CBL314	Rack to Rack Expansion Cable, 15 Meters, Shielded	
	IC646MPP001	Logic Developer - PLC Professional	IC646MPH101	Logic Developer PDA Software Tool with Cable Adapter	
	IC646MPS361	Logic Developer - PLC Standard			



FANUC

GE Fanuc Automation

GE Fanuc Automation Information Centers

12A Industrial Avenue Unit 300 648 2001 St. John, NY 14154

Phone: 716 434-1000 Fax: 716 434-1001

Ask For Mr. 3611-3521 1955

© 2003 GE Fanuc Automation Americas, Inc. All Rights Reserved. Series 30, VersaPro and LogicMaster are trademarks and Genius is a registered trademark of GE Fanuc Automation Americas, Inc. Profibus-DP is a trademark of Profibus International. DeviceNet is a trademark of the Open DeviceNet Vendor Association, Inc. Interbus-S is a trademark of Phoenix Contact. Windows is a registered trademark of Microsoft Corporation. State Logic is a registered trademark of Adatek, Inc. Palm is a trademark of Palm, Inc.

For detailed technical specifications and product ordering information, please visit the GE Fanuc e-catalog at:

www.gefanuc.com

GE
10/10/0000



GE Fanuc Automation

Programmable Control Products

Series 90TM-30 PLC Installation and Hardware Manual

GFK-0356Q

August 2002

GFL-002

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alarm Master	Field Control	Modelmaster	Series 90
CIMPLICITY	GENet	Motion Mate	Series One
CIMPLICITY Control	Genius	PowerMotion	Series Six
CIMPLICITY PowerTRAC	Genius PowerTRAC	ProLoop	Series Three
CIMPLICITY 90-ADS	Helpmate	PROMACRO	VuMaster
CIMSTAR	Logicmaster	Series Five	Workmaster

©Copyright 1998—2002 GE Fanuc Automation North America, Inc.
All Rights Reserved.

RFI Standards

The Series 90-30 PLC and its associated modules have been tested and found to meet or exceed the requirements of FCC Rule, Part 15, Subpart J. The Federal Communications Commission (FCC) requires the following note to be published according to FCC guidelines.

NOTE

This equipment generates, uses, and can radiate radio frequency energy and if not installed in accordance with this instruction manual, may cause harmful interference to radio communications. It has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules, which are designed to provide reasonable protection against harmful interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

The following note is required to be published by the Canadian Department of Communications.

NOTE

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications.

The following statements are required to appear in the *Series 90_-30 Installation Manual* and the *Series 90_-30 I/O Specifications Manual* for Class I Div 2 Hazardous Locations.

1. EQUIPMENT LABELED WITH REFERENCE TO CLASS I, GROUPS A, B, C, and D, DIV. 2 HAZARDOUS LOCATIONS IS SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C, D OR NON-HAZARDOUS LOCATIONS ONLY.
2. WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2:
3. WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.
4. ALL UNUSED SLOTS IN ALL BASEPLATES MUST BE POPULATED WITH FILLER MODULES, IC693ACC310, OR EQUIVALENT.

Preface

This manual describes the GE Fanuc Series 90-30 Programmable Logic Controller (PLC). It contains a description of hardware components and provides basic hardware installation procedures. The Series 90-30 PLC is a member of the Series 90_ family of Programmable Logic Controllers from GE Fanuc.

For a list of product standards, refer to data sheet GFK-0867B or later, *GE Fanuc Approvals, Standards, General Specifications* which lists all of the standards for GE Fanuc products. Installation instructions in this manual are provided for installations that do not require special procedures for noisy or hazardous environments. For installations that must conform to more stringent requirements (such as CE Mark), see GFK-1179, *Installation Requirements for Conformance to Standards*.

What's New in This Manual

- Added the model 374 CPU, which supports connection to an Ethernet network through two built-in 10BaseT/100BaseTx auto-negotiating full-duplex Ethernet ports. Models 364 (release 9.10 and later) and 374 are the only Series 90-30 CPUs that support Ethernet Global Data. Note that the CPU374 is supported only by the Windows®-based programmers.
- Other corrections and clarifications as necessary.

Related Publications

For more information on Series 90-30 products, refer to these publications. (For a publication to product catalog number cross-reference refer to Appendix G):

GFK-0255 - Series 90™ PCM and Support Software User's Manual

GFK-0256 - MegaBasic™ Programming Reference Manual

GFK-0293 - Series 90™ -30 High Speed Counter User's Manual

GFK-0401 - Workmaster® II PLC Programming Unit Guide to Operation

GFK-0402 - Series 90™ -30 and 90-20 PLC Hand-Held Programmer User's Manual

GFK-0412 - Genius® Communications Module User's Manual

GFK-0466 - Logicmaster 90™ Series 90™ -30/20/Micro Programming Software User's Manual

GFK-0467 - Series 90™ -30/20/Micro Programmable Controllers Reference Manual

GFK-0487 - Series 90™ PCM Development Software (PCOP) User's Manual

GFK-0499 - CIMPLICITY® 90-ADS Alphanumeric Display System User's Manual

GFK-0356Q

v

Preface

GFK-0582 - Series 90™ PLC Serial Communications User's Manual
 GFK-0631 - Series 90™ -30 I/O LINK Interface User's Manual
 GFK-0641 - CIMPPLICITY® 90-ADS Alphanumeric Display System Reference Manual
 GFK-0664 - Series 90™-30 PLC Axis Positioning Module Programmer's Manual
 GFK-0685 - Series 90™ Programmable Controllers Flow Computer User's Manual
 GFK-0695 - Series 90™-30 Enhanced Genius) Communications Module User's Manual
 GFK-0726 - Series 90™-30 PLC State Logic Processor User's Guide
 GFK-0732 - Series 90™-30 PLC ECLiPS User's Manual
 GFK-0747 - Series 90™-30 PLC OnTOP User's Guide
 GFK-0750 - OnTop for Series 90™-30 (State Logic) Program User's Manual
 GFK-0781 - Motion Mate™ APM300 for Series 90™-30 PLC Follower Mode User's Manual
 GFK-0823 - Series 90™ -30 I/O LINK Master Module User's Manual
 GFK-0828 - Series 90™ -30 Diagnostic System User's Manual
 GFK-0840 - Motion Mate™ APM300 for Series 90™ -30 PLC Standard Mode User's Manual
 GFK-0867 - GE Fanuc Product Agency Approvals, Standards, General Specifications
 GFK-0898 - Series 90™ -30 PLC I/O Module Specifications
 GFK-1028 - Series 90™ -30 I/O Processor Module User's Manual
 GFK-1034 - Series 90™ -30 Genius® Bus Controller User's Manual
 GFK-1037 - Series 90™ -30 FIP Remote I/O Scanner User's Manual
 GFK-1056 - Series 90™ -30 State Logic Control System User's Manual
 GFK-1186 - TCP/IP Ethernet Communications for the Series 90_-30 PLC Station Manager Manual
 GFK-1179 - Series 90™ PLC Installation Requirements for Conformance to Standards
 GFK-1464 - Motion Mate DSM302 for Series 90™-30 PLCs User's Manual
 GFK-1466 - Temperature Control Module for the Series 90™-30 PLC User's Manual
 GFK-1541 - TCP/IP Ethernet Communications for the Series 90™ PLC User's Manual

Contents

Chapter 1	Overview of the Series 90-30 PLC	1-1
	The Basic Parts of a Series 90-30 PLC.....	1-1
	Assembling a Basic Series 90-30 PLC System	1-2
	What else would be needed to make this basic system functional?	1-6
	What if the application requires more than five modules?	1-6
	What if the application requires more than ten modules?	1-7
	What is the Difference Between Expansion and Remote baseplates?.....	1-8
	What if I need to cover more than 700 feet (213 meters)?	1-9
Chapter 2	Installation	2-1
	Receiving your Products - Visual Inspection	2-1
	Pre-installation Check	2-1
	Warranty Claims.....	2-1
	Working with Series 90-30 Modules.....	2-2
	Module Features.....	2-2
	Installing a Module.....	2-3
	Removing a Module.....	2-4
	Installing a Module's Terminal Board	2-5
	Removing a Module's Terminal Board.....	2-6
	I/O Module Terminal Board Posts	2-7
	Installing and Removing Terminal Boards with Holding Screws	2-7
	Baseplate Mounting.....	2-8
	Mounting a Baseplate to a Panel	2-8
	Mounting a Baseplate to a 19" Rack	2-8
	Grounding Procedures	2-11
	System Grounding Procedures	2-11
	Ground Conductors	2-11
	Series 90-30 PLC Equipment Grounding.....	2-12
	Baseplate Safety Grounding.....	2-12
	Grounding 19" Rack-Mounted Baseplates	2-13
	Programmer Grounding.....	2-13
	Module Shield Grounding.....	2-14
	Shield Grounding Information for CPUs with External Port Connections.....	2-14
	CPU351 and 352 Shield Grounding	2-14
	CPU363, CPU364, and CPU374 Shield Grounding.....	2-16
	Additional Modules with Shield Grounding Requirements	2-16
	General Wiring Guidelines	2-17
	Discrete I/O Module Connection Methods.....	2-18
	Connections to I/O Module Terminal Boards	2-18
	Terminal Block Quick Connect Installation for 16-Point Discrete Modules	2-19
	Installation of 32-Point Discrete, 50-Pin Connector Modules	2-19
	Using Weidmuller #912263 Terminal Block	2-19
	Using a Generic Terminal Block or Strip.....	2-20
	Direct Method	2-20
	Installation of Discrete 32-Point, Dual 24-Pin Connector Modules.....	2-20
	Using a TBQC.....	2-20

Contents

With a Generic Terminal Block/Strip.....	2-20
Direct Method	2-21
General Wiring Methods for Analog Modules.....	2-21
Analog Input Module Wiring Methods	2-21
Using a Generic Terminal Block or Strip.....	2-21
Direct Method	2-21
TBQC not Recommended for Analog Modules	2-22
Analog Output Module Wiring	2-22
General	2-22
Using a Generic Terminal Block or Strip.....	2-22
Direct Method	2-22
TBQC not Recommended for Analog Modules	2-22
AC Power Source Connections.....	2-23
AC Input Wiring to AC/DC Power Supplies	2-23
Power Supply Overvoltage Protection Devices.....	2-24
Special Installation Instructions for Floating Neutral (IT) Systems	2-25
Definition of Floating Neutral Systems.....	2-25
Use These Special Installation Instructions for Floating Neutral Systems.....	2-26
DC Power Source Connections.....	2-27
DC Input Wiring to AC/DC and DC-Only Power Supplies.....	2-27
+24 VDC Output (All Supplies).....	2-27
Basic Installation Procedure	2-28
Chapter 3 Baseplates	3-1
Baseplate Types	3-1
Common Baseplate Features	3-1
Two Baseplate Sizes.....	3-2
Baseplate Terms.....	3-3
CPU Baseplates.....	3-4
Embedded CPU Baseplates (Figures 3-2 and 3-3).....	3-4
Modular CPU Baseplates (Figures 3-4 and 3-5)	3-6
Expansion Baseplates (Figures 3-6 and 3-7).....	3-7
Remote Baseplates (Figures 3-8 and 3-9).....	3-8
I/O Bus Expansion Cables.....	3-10
Differences Between Remote and Expansion Racks.....	3-11
Mixing Expansion and Remote Baseplates in a System	3-11
Termination Requirement for Expansion or Remote System	3-12
Powering Down Individual Expansion or Remote Baseplates	3-12
Series 90-30 PLC Backplane	3-12
Rack Number DIP Switch on Expansion and Remote Baseplates.....	3-13
Expansion and Remote Baseplates Connection Example.....	3-15
Baseplate Mounting Dimensions	3-16
Embedded CPU (311, 313, and 323) Baseplate Dimensions	3-16
Modular CPU, Expansion, and Remote Baseplate Dimensions	3-18

Contents

	Load Ratings, Temperature, and Mounting Position	3-19
	Baseplate Adapter Brackets for 19" Rack Mounting	3-20
	Baseplate Comparison Table	3-22
Chapter 4	Power Supplies.....	4-1
	Power Supply Categories	4-1
	Power Supply Feature Comparison.....	4-1
	AC/DC Input Power Supplies	4-2
	IC693PWR321 Standard Power Supply, 120/240 VAC or 125 VDC Input	4-2
	IC693PWR330 High Capacity Power Supply, 120/240 VAC/125 VDC Input	4-4
	Field Wiring Connections for the AC/DC Input Power Supplies.....	4-5
	Isolated 24 VDC Supply Output Connections.....	4-6
	DC Input Only Power Supplies.....	4-7
	IC693PWR322 Standard Power Supply, 24/48 VDC Input	4-7
	Calculating Input Power Requirements for IC693PWR322	4-8
	IC693PWR328 Standard Power Supply, 48 VDC Input	4-10
	Calculating Input Power Requirements for IC693PWR328.....	4-11
	Input Power/Current Calculation for IC693PWR328 Power Supply	4-12
	IC693PWR331 High Capacity Power Supply, 24 VDC Input	4-13
	Current Derating for Higher Temperatures	4-14
	Calculating Input Power Requirements for IC693PWR331	4-15
	Field Wiring Connections to the DC Input-Only Power Supplies	4-15
	Common Series 90-30 Power Supply Features.....	4-16
	Status Indicator Lights on all Power Supplies.....	4-16
	Input Overvoltage Protection Devices.....	4-16
	Output Voltage Connections to Backplane (All Supplies).....	4-17
	Overcurrent Protection (all Supplies).....	4-18
	Timing Diagram	4-18
	CPU Serial Port Connector on Power Supply (All Supplies).....	4-19
	CPU Serial Port Information	4-19
	Backup Battery for RAM Memory (All Supplies).....	4-20
Chapter 5	CPUs	5-1
	CPU Types for Series 90-30 PLCs	5-1
	Embedded CPUs.....	5-1
	Modular CPUs.....	5-2
	General CPU Features	5-3
	Microprocessor.....	5-3
	CPU Serial Port (Connector on Power Supply).....	5-3
	Memory Volatility.....	5-4
	RAM Memory	5-5
	RAM Memory Backup/Backup Battery Information.....	5-5
	Programmable Read-Only Memory (PROM) Types.....	5-5
	Uses of PROM devices in the 90-30 CPUs.....	5-5

Contents

CPU Firmware.....	5-6
Determining CPU Revision Levels (Versions)	5-7
EPROM and EEPROM User Program Storage Options.....	5-8
Comparing EPROM and EEPROM Features.....	5-8
Procedure for Creating an EPROM.....	5-9
Flash Memory.....	5-9
Series 90-30 CPU Capacities.....	5-10
User Memory Addresses (References).....	5-10
Difference Between a Memory Address and a Nickname.....	5-10
User Memory Reference Types.....	5-11
Application Program Compatibility	5-12
CPU Time-of-Day (TOD) Clock Accuracy.....	5-12
Breakfree SNP Protocol	5-13
350–374 CPUs.....	5-13
Compatibility With Hand-Held Programmer (HHP) and Memory Card.....	5-13
350–374 CPU Advanced Features.....	5-14
Details of 350 – 374 CPU Advanced Features	5-14
Hardware Features of the 350–364 CPUs.....	5-18
CPU350 and CPU360 Hardware Features	5-18
CPU Firmware Upgrade.....	5-18
CPU351, CPU352, and CPU363 Hardware Features.....	5-19
CPU Firmware Upgrade.....	5-19
Keyswitch.....	5-19
Shield Ground Connection Tab.....	5-20
Serial Ports	5-20
Serial Port Front Panel Connectors	5-20
Serial Port Status LEDs.....	5-20
Protocols Supported	5-21
Pin Assignments for CPU351, CPU352, and CPU363 Serial Ports 1 & 2	5-22
CPU364 Hardware Features.....	5-23
LED Indicators.....	5-23
Ethernet Restart Pushbutton.....	5-23
Keyswitch.....	5-24
Front Panel Connectors	5-24
Shield Ground Connection Tab.....	5-24
Firmware Upgrade.....	5-24
CPU374 Hardware Features.....	5-25
LED Indicators.....	5-25
Ethernet Restart Pushbutton.....	5-25
Keyswitch.....	5-26
Front Panel Connectors	5-26
Shield Ground Connection Tab.....	5-26
Firmware Upgrade.....	5-26
CPU Data Sheets.....	5-27
CPU311 Catalog Number IC693CPU311	5-28
CPU313 Catalog Number IC693CPU313	5-29
CPU323 Catalog Number IC693CPU323	5-30
CPU331 Catalog Number IC693CPU331	5-31

Contents

CPU340	Catalog Number IC693CPU340	5-32
CPU341	Catalog Number IC693CPU341	5-33
CPU350	Catalog Number IC693CPU350	5-34
CPU351	Catalog Number IC693CPU351	5-35
CPU352	Catalog Number IC693CPU352	5-36
CPU360	Catalog Number IC693CPU360	5-37
CPU363	Catalog Number IC693CPU363	5-38
CPU364	Catalog Number IC693CPU364	5-39
CPU374	Catalog Number IC693CPU374	5-40
Chapter 6	Memory Backup/Battery Backup	6-1
	Backup Battery for RAM Memory (All Supplies).....	6-1
	Battery Replacement Instructions	6-2
	Battery Replacement/Memory Protection Factors	6-3
	The Importance of Backing up Your Program.....	6-3
	Factors Affecting Battery Life	6-4
	Low Battery Warning Methods.....	6-4
	Operating Without a Memory Backup Battery	6-6
	RAM Memory Battery Backup Connection Path	6-8
	Super Capacitor Memory Backup.....	6-8
	Maintaining RAM Memory During Storage or Shipment of a CPU.....	6-9
	Modular CPUs.....	6-9
	Embedded CPUs	6-9
	Battery Accessory Kit (IC693ACC315).....	6-9
	Battery Accessory Kit Installation.....	6-10
	External Battery Module (IC693ACC302)	6-10
	Batteries in Power Supplies on Expansion or Remote Racks	6-11
Chapter 7	Input/Output Modules	7-1
	Basic I/O Module Types	7-1
	Discrete I/O Modules.....	7-2
	Discrete I/O Module Point Density	7-2
	Standard Density Discrete I/O Module Features	7-2
	Wiring Standard Density (16-Point or Less) Discrete Modules.....	7-4
	Discrete Relay Output Module Protection	7-4
	High Density (32-Point) Discrete Module Features	7-4
	Wiring Methods for 32-Point Discrete I/O Modules.....	7-6
	Modules with Single 50-Pin Connector	7-6
	Modules with Dual 24-Pin Connectors	7-7
	Analog Module Features.....	7-8
	Wiring Methods for Analog Modules	7-9
	Analog Input Module Wiring Methods	7-9
	Analog Output Module Wiring	7-10
	I/O Module Power Supply Current Draw	7-10

Contents

I/O Module Wire Routing	7-11
Grouping Modules to Keep Wires Segregated	7-11
IC693DVM300 Digital Valve Driver Module	7-12
Indicator LEDs	7-12
DVM Specifications	7-13
Fuses	7-13
Chapter 8 Option Modules	8-1
Third-Party Option Modules and the Accompany Program	8-1
Option Modules Discussed in this Chapter	8-1
IC693CMM301 Genius Communications Module (GCM)	8-2
Status LEDs	8-3
GCM Documentation	8-3
IC693CMM302 Enhanced Genius Communications Module (GCM+)	8-4
Status LEDs	8-5
GCM+ Documentation	8-5
IC693BEM331 Genius Bus Controller (GBC)	8-6
Number of Genius Bus Controllers	8-7
Status LEDs	8-7
Compatibility	8-7
Series 90-30 PLC	8-7
Series Six PLC	8-7
Genius Hand-Held Monitor	8-8
Hand-Held Programmer	8-8
Genius I/O Blocks	8-8
Genius Bus	8-8
Diagnostics	8-8
Datagrams	8-9
Global Data	8-9
Sending Global Data	8-9
Receiving Global Data	8-9
Genius Bus Controller Documentation	8-9
IC693BEM340 FIP Bus Controller (FBC) Module	8-10
Status LEDs	8-11
Serial Port	8-11
FIP Bus Connectors	8-11
IC693BEM330 FIP Remote I/O Scanner Module	8-12
Features of the Remote I/O Scanner	8-12
FIP Bus Interface	8-13
Module Description	8-13
Connectors	8-14
LEDs	8-14
FIP Remote I/O Scanner Documentation:	8-14
IC693APU301/302 Motion Mate Axis Positioning Module (APM)	8-15

Contents

APM Cables	8-16
Motion Mate APM Module Documentation	8-16
IC693DSM302 Motion Mate Digital Servo Module (DSM302)	8-17
Features	8-18
IC693DSM302 Documentation	8-18
IC693DSM314 Motion Mate Digital Servo Module (DSM314)	8-20
Features	8-21
IC693DSM314 Documentation	8-22
IC693APU300 High Speed Counter (HSC) Module	8-23
IC693BEM320 I/O LINK Interface (Slave) Module	8-24
IC693BEM321 I/O LINK Master Module	8-25
Compatibility	8-26
IC693APU305 I/O Processor Module	8-27
Module Features	8-28
IC693CMM321 Ethernet Interface Module	8-29
IC693PCM300/301/311 Programmable Coprocessor Module (PCM)	8-31
IC693CMM311 Communications Coprocessor Module (CMM)	8-34
IC693ADC311 Alphanumeric Display Coprocessor (ADC)	8-35
IC693TCM302/303 Temperature Control Modules (TCM)	8-37
Connections	8-37
LED Indicators	8-38
Internal Fuse	8-38
Automatic Data Transfers Between TCM and PLC	8-38
Comparison of TCM302 and TCM303 Modules	8-39
IC693PTM100/101 Power Transducer (PTM)	8-40
Difference Between PTM100 and PTM101	8-40
Capabilities	8-40
Operating Modes	8-40
Automatic Data Transfers Between PTMPM and PLC	8-41
Compatibility	8-41
Dimensions	8-42
PTMPM Indicator LEDs	8-42
General Mounting Information	8-42
Baseplate Type and Allowable Number of PTMPM Modules	8-43
Power Supply Requirement	8-43
Memory Requirement	8-43
Configuration	8-43
Ordering Information	8-43
Documentation	8-43
Chapter 9 State Logic Products	9-1
State Logic Overview	9-1
State Logic Products	9-1
Baseplates and Power Supply, I/O, and Option Modules	9-1

Contents

Wiring Diagram.....	10-14
PCM to Programmer Cable Installation	10-15
IC690CBL705 Workmaster II (PS/2) to PCM, ADC, CMM Cable	10-16
Function of cable.....	10-16
Cable Specifications.....	10-16
Wiring Diagram.....	10-16
PCM to Programmer Cable Installation	10-17
IC690CBL714A Multidrop Cable	10-18
Purpose.....	10-18
Specifications	10-18
IC690CBL714A Multi-Drop Cable Wiring Diagram.....	10-19
Connection Diagrams for IC690CBL714A Cable.....	10-20
IC693CBL300/301/302/312/313/314 I/O Bus Expansion Cables	10-22
Description	10-22
Cable Lengths.....	10-22
Function of Cables	10-22
Connecting the Cables.....	10-23
Important Notes About I/O Bus Expansion Cables	10-23
Cable Application Suggestions.....	10-23
Using Standard Cables	10-23
Using Custom Built cables.....	10-24
Building Custom Length I/O Bus Expansion Cables	10-24
Two Types of Custom Built Cables	10-24
Components Needed to Build Custom Length I/O Bus Expansion Cables	10-24
Expansion Port Pin Assignments.....	10-25
I/O Expansion Bus Termination.....	10-25
Shield Treatment	10-26
Alert for Users of Early Remote Baseplate Versions	10-26
Making a 100% Shielded Cable	10-27
Wiring Diagrams	10-28
Application Examples	10-31
Expansion System Cable Connections	10-31
Remote and Expansion System Cable Connection Example.....	10-31
IC693CBL303 Hand-Hand Programmer and Converter (IC690ACC900) Cable	10-33
Function of cable.....	10-33
Cable Specifications	10-33
Wiring Diagram.....	10-34
Connecting the Cable	10-34
IC693CBL304/305 Port Expansion (WYE) Cables for PCM, ADC, and CMM.....	10-35
Function of cable	10-35
Cable Specifications	10-35
Wiring Information.....	10-36
IC693CBL306/307 Extension Cables (50-Pin) for 32 Point Modules.....	10-38
Function of cable	10-38
Cable Specifications	10-38
IC693CBL308/309 I/O Cables (50-Pin) for 32 Point Modules	10-40
Specifications	10-40
Wiring Information.....	10-40

Contents

IC693CBL310 I/O Interface Cable (24-Pin) for 32 Point Modules.....	10-42
Function of cable.....	10-42
Replacement/Obsolescence Information.....	10-43
Connector Depth for Cable IC693CBL310.....	10-43
IC693CBL311/317/319/320 I/O Interface Cables for Power Mate APM Modules.....	10-45
Function of cable.....	10-45
Specifications.....	10-45
Wiring Information.....	10-46
IC693CBL315 I/O Interface Cable (24-Pin) for 32 Point Modules.....	10-49
Function of cable.....	10-49
Building Custom Length Cables for 24-Pin Connectors.....	10-49
Replacement/Obsolescence Information.....	10-51
Connector Depth for IC693CBL315.....	10-51
IC693CBL316 Serial Cable, 9-Pin D-Shell to RJ-11 Connector.....	10-53
Description.....	10-53
Typical Applications.....	10-53
IC693CBL321/322/323 I/O Faceplate Connector to Terminal Block Connector, 24-Pin.....	10-54
Function of cable.....	10-54
Cable Specifications.....	10-54
Connector Depth.....	10-55
IC693CBL327/328 I/O Interface Cables with Right Angle 24-Pin Connector.....	10-57
Description.....	10-57
Applications.....	10-57
Specifications.....	10-58
Connector Depth for Cables IC693CBL327/328.....	10-58
Building Custom Length 24-pin Connector Cables.....	10-59
Connector Depth for Custom Built Cables.....	10-60
Possible Uses for These Cables (Factory or Custom Built).....	10-61
IC693CBL329/330/331/332/333/334 Cables 24-Pin I/O Faceplate Connector to Terminal Block Connector.....	10-62
Description.....	10-62
Connector Depth.....	10-63
Applications.....	10-64
IC693CBL340/341 PTM Interface Cables.....	10-65
Documentation.....	10-67
 Chapter 11	
Programmer Hardware Products.....	11-1
Products Discussed in this Chapter.....	11-1
IC640WMI310/320 Work Station Interface Boards.....	11-2
Replacing Workmaster Computers.....	11-3
IC690ACC900 RS-422/RS-485 to RS-232 Converter.....	11-3
IC690ACC901 Miniconverter Kit.....	11-4
IC693PRG300 Hand-Held Programmer (HHP).....	11-5
HHP Features.....	11-6

Contents

	HHP Memory Card (IC693ACC303).....	11-6
	HHP Modes of Operation.....	11-6
	Documentation.....	11-6
	IC693PIF301/400 Personal Computer Interface (PCIF) Cards	11-7
	IC655CCM590 Isolated Repeater/Converter	11-8
	IC690ACC903 Port Isolator	11-8
Chapter 12	System Design	12-1
	Introduction.....	12-1
	Step 1: Planning Your System.....	12-1
	Step 2: Determining I/O Requirements	12-1
	Additional I/O Module Selection Factors.....	12-2
	Step 3: Selecting Option Modules.....	12-2
	Step 4: Selecting a CPU	12-4
	Step 5: Selecting Baseplates.....	12-5
	Step 6: Selecting Power Supplies	12-6
	Reducing PLC Module Count by Using Other GE Fanuc Products	12-7
	Designing For Safety	12-8
	Protection From Electrical Shock.....	12-8
	Fire Prevention	12-8
	Protection From Mechanical Hazards	12-8
	Protection From Electrical Failure	12-8
	Protection From Design Changes or Overrides.....	12-9
	Safety Documentation	12-10
	Guarding Against Unauthorized Operation.....	12-10
	Labeling, Guarding, and Lighting Issues.....	12-10
	Equipment Accessibility Issues.....	12-10
	Number of Modules Per Series 90-30 PLC System.....	12-11
	Calculating Power Supply Loading	12-12
	Load Requirements for Hardware Components	12-12
	Power Supply Loading Calculation Examples	12-14
	Scan (Sweep) Time Calculation.....	12-15
	Major Design Factors Affecting Scan Time.....	12-16
	Where to Find Scan Time Information.....	12-16
	Calculating PLC Heat Dissipation	12-17
	System Layout Guidelines	12-17
	Benefits of a Good Layout - Safe, Reliable, and Accessible.....	12-17
	PLC Rack Location and Clearance Requirement.....	12-17
	Location of Modules in the PLC Racks	12-18
	Allowable Module Locations	12-19
	Series 90-30 PLC Layout Example.....	12-20
	PLC Mounting Position	12-21
	Recommended Upright Mounting Orientation.....	12-21
	Derated Horizontal Mounting Orientation	12-21

Contents

Chapter 13	Maintenance and Troubleshooting	13-1
	Troubleshooting Features of Series 90-30 Hardware.....	13-1
	Indicator Lights (LEDs) and Terminal Board	13-1
	Module LED Indicators	13-2
	Troubleshooting Features of Programming Software.....	13-3
	Ladder Screens	13-3
	Configuration Screens	13-3
	Fault Tables	13-3
	System Status References.....	13-3
	Reference Tables	13-4
	Override feature.....	13-4
	Sequential Event Recorder (SER), DOIO functional instruction	13-4
	Replacing Modules	13-5
	Series 90-30 Product Repair.....	13-5
	Module Fuse List.....	13-6
	Spare/Replacement Parts	13-7
	Preventive Maintenance Suggestions.....	13-8
	Getting Additional Help and Information.....	13-9
Appendix A	Serial Ports and Cables.....	A-1
	RS-422 Interface	A-1
	Cable and Connector Specifications.....	A-2
	Series 90 PLC Serial Port.....	A-3
	Workmaster Serial Port.....	A-4
	RS-232/RS-485 Converter	A-7
	IC690ACC901 Miniconverter Kit.....	A-7
	IC690ACC900 Obsolete Converter.....	A-7
	Serial Cable Diagrams	A-8
	RS-232 Point-to-Point Connections	A-8
	RS-422 Point-to-Point Connection.....	A-10
	Multidrop Connections.....	A-10
Appendix B	IC690ACC900 Converter	B-1
	Features.....	B-1
	Functions.....	B-1
	Location in System	B-2
	Installation.....	B-2
	Cable Description.....	B-3
	RS-232 Interface Pin Assignments.....	B-4
	RS-422/RS-485 Interface Pin Assignments	B-5
	Logic Diagram	B-6
	Jumper Configuration	B-7

Contents

	Example of Cable Configurations	B-9
Appendix C	IC655CCM690 Isolated Repeater/Converter	C-1
	Description of the Isolated Repeater/Converter	C-1
	Logic Diagram of the Isolated Repeater/Converter	C-3
	Pin Assignments for the Isolated Repeater/Converter	C-4
	System Configurations	C-5
	Simple Multidrop Configuration	C-6
	Complex Multidrop Configuration	C-6
	Rules for Using Repeater/Converters in Complex Networks	C-7
	Cable Diagrams	C-8
Appendix D	IC690ACC901 Miniconverter Kit	D-1
	Description of Miniconverter	D-1
	Pin Assignments	D-2
	Pin Assignments, RS-232 Port	D-2
	Pin Assignments, RS-422 Port	D-2
	System Configurations	D-3
	Cable Diagrams (Point-To-Point)	D-3
Appendix E	IC690ACC903 Port Isolator	E-1
	Connectors	E-2
	Logic Diagram	E-3
	Installation	E-4
	Specifications	E-7
Appendix F	Calculating Series 90-30 Heat Dissipation	F-1
	Overview	F-1
	Information Required	F-1
	Procedure	F-2
	Step 1: Basic Method to Calculate Module Dissipation	F-2
	Step 2: Calculation for PLC Power Supplies	F-3
	Step 3: Output Calculations for Discrete Output Modules	F-3
	Step 4: Input Calculations for Discrete Input Modules	F-4
	Step 5: Final Calculation	F-6
	Other Information Related to Enclosure Sizing	F-6
Appendix G	Catalog Number to Publication Cross-Reference	G-1
	General System Information	G-2
	Analog I/O Modules	G-2
	Baseplates	G-2
	Communications Modules	G-3

Contents

CPU Modules, CPU311-CPU341	G-3
CPU Modules, CPU350 - CPU374	G-4
Digital Valve Driver Module	G-5
Discrete I/O Modules	G-5
Genius Modules	G-6
Motion Modules	G-6
Other Option Modules	G-6
Power Supply Modules	G-7
Programming Device	G-7
State Logic Products	G-7
Publication Revision Letters	G-8
Other Sources of Information	G-8
Appendix H Terminal Block Quick Connect Components	H-1
Terminal Block Quick Connect Components for 16-Point Modules	H-2
Terminal Blocks	H-2
Cable Current Rating	H-2
Cable Selection and Cross-Reference	H-3
I/O Face Plate for 16-Point Modules	H-3
I/O Face Plate Installation	H-3
Module Wiring Information	H-4
Cable Information	H-4
Connector Pin Orientation and Connection to Module Terminal	H-5
Terminal Block Information	H-5
IC693ACC329 TBQC Terminal Block	H-6
IC693ACC330 TBQC Terminal Block	H-7
IC693ACC331 TBQC Terminal Block	H-8
IC693ACC332 TBQC Terminal Block	H-9
IC693ACC333 TBQC Terminal Block	H-10
Terminal Block Quick Connect Components for 32-Point Modules	H-11
Terminal Block	H-12
Cable Selection and Cross-Reference	H-12
Cable Current Rating	H-12
Cable Data	H-13
Terminal Block Data	H-13
IC693ACC337 TBQC Terminal Block	H-13
Appendix I SNP Multidrop	I-1
SNP Multidrop Overview	I-1
Multidrop Cables	I-2
Limitations	I-2
Cable and Connector Specifications	I-2
MultiDrop Cable Wiring Diagram	I-3

Contents

	SNP Multidrop Examples	I-4
	Configuring and Connecting a Programmer to a Multidrop Network	I-5
	Assigning a PLC SNP ID to a PLC with Logicmaster	I-6
	Connecting your Logicmaster Programmer to a PLC on a Multidrop System.....	I-6
	SNP Multidrop Troubleshooting.....	I-7
Appendix J	Ethernet Transceivers	J-1
	IC649AEA102 Ethernet 10BASE-T Transceiver	J-1
	Power Requirement	J-1
	LED Indicator Lights.....	J-1
	IC649AEA103 Ethernet 10BASE2 Transceiver	J-2
	Power Requirement	J-2
	LED Indicator Light	J-2
Appendix K	Tables and Formulas	K-1
	AWG to Metric Wire Size Conversion	K-2
	Temperature Conversion	K-3
	Formulas.....	K-3
	Conversion Information	K-4
	English and Metric Equivalents.....	K-5
Appendix L	44A420084-001 EMI Line Filter.....	L-1
	44A720084-001 Optional EMI Line Filter	L-1
	44A720084-001 Line Filter Mounting Dimensions.....	L-3

Contents

Figure 1-1. Five-Slot CPU Baseplate	1-3
Figure 1-2. Power Supply Module.....	1-3
Figure 1-3. CPU Module	1-4
Figure 1-4. I/O Module.....	1-4
Figure 1-5. Assembling the System.....	1-5
Figure 1-6. A Basic System.....	1-6
Figure 1-7. Ten-Slot Rack	1-6
Figure 1-8. I/O Bus Expansion Cable.....	1-7
Figure 1-9. Connecting Expansion and Remote Baseplates	1-8
Figure 1-10. Connecting PLCs Using GBC or CMM Modules	1-9
Figure 2-1. Features of Series 90-30 Module	2-2
Figure 2-2. Installing a Module	2-3
Figure 2-3. Removing a Module.....	2-4
Figure 2-4. Installing an I/O Module's Terminal Board.....	2-5
Figure 2-5. Removing a Module's Terminal Board	2-6
Figure 2-6. Terminal Board with Holding Screws	2-7
Figure 2-7. IC693ACC308 Front Mount Adapter Bracket Installation.....	2-9
Figure 2-8. Dimensions for 19-inch Rack Mounting Using IC693ACC308 Adapter Bracket.....	2-9
Figure 2-9. IC693ACC313 Recessed Mount Adapter Bracket.....	2-10
Figure 2-10. Recommended System Grounding.....	2-11
Figure 2-11. Baseplate Grounding.....	2-12
Figure 2-12. CPU 351 or 352 - Attaching Shield Ground Wire	2-14
Figure 2-13. CPU 351 or 352 - Mounting the Shield Grounding Bracket and Wire.....	2-15
Figure 2-14. CPU 363, CPU364, or CPU374 - Attaching Ground Wire.....	2-16
Figure 2-15. Power Supply Terminal Boards	2-24
Figure 2-16. Overvoltage Protection Devices and Jumper Strap.....	2-24
Figure 3-1. Common Baseplate Features.....	3-2
Figure 3-2. Models IC693CPU311 and IC693CPU313 (5-Slot) Embedded CPU Baseplates	3-5
Figure 3-3. Model IC693CPU323 (10-slot) Embedded CPU Baseplate	3-5
Figure 3-4. IC693CHS397 5-Slot Modular CPU Baseplate	3-6
Figure 3-5. IC693CHS391 10-Slot Modular CPU Baseplate	3-6
Figure 3-6. IC693CHS398 5-Slot Expansion Baseplate.....	3-7
Figure 3-7. IC693CHS392 10-Slot Expansion Baseplate.....	3-8
Figure 3-8. IC693CHS399 5-Slot Remote Baseplate	3-9
Figure 3-9. IC693CHS393 10-Slot Remote Baseplate	3-9
Figure 3-10. I/O Bus Expansion Cables	3-10

Contents

Figure 3-11. Rack Number Selection Switch (Shown with Rack 2 Selected).....	3-13
Figure 3-12. Example of Connecting Expansion Baseplates.....	3-14
Figure 3-13. Example of Connecting Expansion and Remote Baseplates.....	3-15
Figure 3-14. Model 311 and 313 5-Slot Baseplate Dimensions and Spacing Requirements	3-16
Figure 3-15. Model 323 10-Slot Baseplate Dimensions and Spacing Requirements	3-17
Figure 3-16. Modular CPU, Expansion, and Remote 5-Slot Baseplate Dimensions and Spacing Requirements.....	3-18
Figure 3-17. Modular CPU, Expansion, and Remote 10-Slot Baseplate Dimensions and Spacing Requirements.....	3-18
Figure 3-18. IC693ACC308 Front Mount Adapter Bracket Installation.....	3-20
Figure 3-19. Dimensions for 19" Rack Mounting Using IC693ACC308 Adapter Bracket.....	3-21
Figure 3-20. IC693ACC313 Recessed Mount Adapter Bracket.....	3-21
Figure 4-1. Standard AC/DC Input Power Supply - IC693PWR321	4-2
Figure 4-2. High Capacity AC/DC Input Power Supply - IC693PWR330	4-4
Figure 4-3. Overvoltage Protection Devices and Jumper Strap.....	4-6
Figure 4-4. Series 90-30 24/48 VDC Input Power Supply - IC693PWR322	4-7
Figure 4-5. Typical Efficiency Curve for 24/48 VDC Power Supply	4-8
Figure 4-6. Series 90-30 48 VDC Input Power Supply - IC693PWR328	4-10
Figure 4-7. Typical Efficiency Curve for IC693PWR328 Power Supply	4-11
Figure 4-8. Series 90-30 24 VDC Input High Capacity Power Supply - IC693PWR331	4-13
Figure 4-9. 5 VDC Current Output Derating for Temperatures above 50°C (122°F)	4-14
Figure 4-10. Overvoltage Protection Devices and Jumper Strap.....	4-17
Figure 4-11. Interconnection of Power Supplies	4-17
Figure 4-12. Timing Diagram for all Series 90-30 Power Supplies	4-18
Figure 4-13. Serial Port Connector.....	4-19
Figure 4-14. Backup Battery for RAM Memory	4-20
Figure 5-1. Models 311 and 313 (5-Slot) Embedded CPU Baseplates.....	5-2
Figure 5-2. IC693CHS397 5-Slot Modular CPU Baseplate.....	5-3
Figure 5-3. CPU Serial Port Connector on Power Supply.....	5-4
Figure 5-4. CPUs 351, 352, and 363	5-19
Figure 6-1. Backup Battery for RAM Memory	6-1
Figure 6-2. Installing the Battery Accessory Kit	6-10
Figure 7-1. Example of Series 90-30 Standard Density Discrete Output Module.....	7-3
Figure 7-2. Example of 32-Point I/O Module (IC693MDL654) With Dual Connectors	7-5
Figure 7-3. Example of 32-Point I/O Module (IC693MDL653) With Single Connector	7-5
Figure 7-4. 50-PIN, 32 Point I/O Module Connection Method.....	7-6
Figure 7-5. Example of Series 90-30 Analog Current Output Module.....	7-9
Figure 7-6. IC693DVM300 Digital Valve Driver Module.....	7-12

Contents

Figure 8-1. The IC693CMM301 GCM Module	8-2
Figure 8-2. Genius Bus Wiring Schematic	8-3
Figure 8-3. Example of Genius Communications Network.....	8-3
Figure 8-4. Enhanced Genius Communications Module.....	8-4
Figure 8-5. Genius Bus Controller Module	8-6
Figure 8-6. Example of FIP I/O System Configuration.....	8-10
Figure 8-7. Series 90-30 FIP Bus Controller	8-11
Figure 8-8. Example of FIP Remote I/O Scanner System Configuration.....	8-12
Figure 8-9. FIP Bus Interface Module	8-13
Figure 8-10. Motion Mate APM Module	8-15
Figure 8-11. Example of Motion Mate APM Servo System	8-16
Figure 8-12. Motion Mate DSM302 Module	8-17
Figure 8-13. Motion Mate DSM314 Module	8-20
Figure 8-14. High Speed Counter (HSC)	8-23
Figure 8-15. Example of a Series 90-30 PLC in a Fanuc I/O LINK Configuration	8-24
Figure 8-16. Example of I/O LINK Master System Configuration.....	8-25
Figure 8-17. I/O Processor Module	8-27
Figure 8-18. Ethernet Interface Module	8-29
Figure 8-19. Programmable Coprocessor Module (PCM).....	8-31
Figure 8-20. Communications Control Module.....	8-34
Figure 8-21. Alphanumeric Display Coprocessor Module (ADC).....	8-35
Figure 8-22. IC693TCM302/303 Temperature Control Module (TCM).....	8-37
Figure 8-23. IC693PTM100/101 Components.....	8-41
Figure 8-24. IC693PTM100/101 Component Mounting.....	8-42
Figure 9-1. AD693CMM301 State Logic Serial Communications Module.....	9-2
Figure 9-2. IC693CBL305 WYE Cable	9-3
Figure 9-3. IC693SLP300 State Logic Processor Module for Series 90-30.....	9-4
Figure 9-4. State Logic Processor Module User Details	9-6
Figure 9-5. Model CSE311 or CSE313 5-Slot Embedded CPU Baseplate	9-9
Figure 9-6. Model CSE323 10-Slot Embedded CPU Baseplate.....	9-9
Figure 9-7. CPU Models CSE 331 or CSE 340.....	9-10
Figure 9-8. Serial Port Connector.....	9-11
Figure 10-1. Serial Port to Work Station Interface Board Cable Connection	10-8
Figure 10-2. Series 90 PLC to Workmaster II Serial Cable	10-9
Figure 10-3. Example of Multidrop Configuration with Converter	10-10
Figure 10-4. Series 90 PLC to Programmer 8-Wire Multidrop, Serial Data Configuration.....	10-11
Figure 10-5. PCM, ADC, or CMM to Workmaster or PC-XT Serial Cable	10-12

Contents

Figure 10-6. PCM to Workmaster Computer or PC-XT Personal Computer.....	10-13
Figure 10-7. PCM, ADC, or CMM to Workmaster or PC-AT Serial Cable	10-14
Figure 10-8. PCM to PC-AT Personal Computer.....	10-15
Figure 10-9. PCM, ADC, or CMM to Workmaster II or PS/2 Serial Cable.....	10-16
Figure 10-10. PCM to Workmaster II Computer or PS/2 Computer.....	10-17
Figure 10-11. Connecting Diagram for Multidrop Cable IC690CBL714A.....	10-19
Figure 10-12. Multidrop Arrangement for Series 90-30 Redundant System.....	10-20
Figure 10-13. Connecting CPU and APM to Programmer with IC690CBL714A Cable	10-20
Figure 10-14. Multidrop Arrangement for Series 90-70 TMR Redundant System.....	10-21
Figure 10-15. Detail of I/O Bus Expansion Cables	10-22
Figure 10-16. How to use Split-Ring Ferrules for Foil and Braided Cable Shield.....	10-26
Figure 10-17. Point-To-Point Cable Wiring for Continuous Shield Custom Length Cables	10-28
Figure 10-18. Point-To-Point Cable Wiring Diagram for Applications Requiring Less Noise Immunity.....	10-28
Figure 10-19. Earlier Versions of Remote Baseplate Custom WYE Cable Wiring Diagram	10-29
Figure 10-20. Current Remote baseplate (IC693CHS393/399) Custom Wye Cable Wiring Diagram	10-30
Figure 10-21. Example of Connecting Expansion Baseplates.....	10-31
Figure 10-22. Example of Connecting Expansion and Remote Baseplates.....	10-32
Figure 10-23. Wiring Connections for IC693CBL303 and Custom-Built Cables.....	10-34
Figure 10-24. Hand-Held Programmer Cable Connection to a Series 90-30 PLC	10-34
Figure 10-25. Wye Cable.....	10-35
Figure 10-26. Wye Cable Connections.....	10-36
Figure 10-27. 32 Point I/O Module to Weidmuller Terminal Block Assembly	10-39
Figure 10-28. IC693CBL310 Cable	10-42
Figure 10-29. Dimensions for Depth of Connector in front of PLC.....	10-44
Figure 10-30. I/O Connector Cable Specifications.....	10-45
Figure 10-31. IC693CBL315 Cable	10-49
Figure 10-32. Dimensions for Depth of Connector in front of PLC.....	10-52
Figure 10-33. IC693CBL316A Serial Cable Illustration and Connector Pinouts	10-53
Figure 10-34. Connector Orientation on I/O Faceplate	10-55
Figure 10-35. I/O Faceplate to Terminal Block Cable	10-55
Figure 10-36. Dimensions for Depth of Connector in front of PLC.....	10-56
Figure 10-37. IC693CBL327/328 Cables	10-57
Figure 10-38. Dimension for Depth of Connector for IC693CBL327/328	10-58
Figure 10-39. Dimensions for Depth of Connector in front of PLC for Custom Built Cables.....	10-61
Figure 10-40. IC693CBL329/330/331/332/333/334 Cables	10-62
Figure 10-41. Dimension for Depth of Connector.....	10-63
Figure 10-42. Figure IC693CBL340/341 PTM Interface Cables	10-65

Contents

Figure 10-43. PTM Component Mounting and Cable Connection.....	10-65
Figure 11-1. WSI Board for the Workmaster II Computer.....	11-2
Figure 11-2. Location of WSI in a Series II 90-30 PLC System.....	11-2
Figure 11-3. Example of IC690ACC900 Converter Connection.....	11-3
Figure 11-4. IC690ACC901 Series 90 SNP Port to RS-232 Adapter.....	11-4
Figure 11-5. Hand-Held Programmer for the Series 90-30 PLC.....	11-5
Figure 11-6. Example of PCIF Interface to Series 90-30 I/O.....	11-7
Figure 12-1. Hard-Wired MCR Circuit Example.....	12-9
Figure 12-2. Allowable Location of Modules.....	12-19
Figure 12-3. Series 90-30 Example Layout.....	12-20
Figure 12-4. Recommended PLC Mounting Orientation.....	12-21
Figure 12-5. Derated PLC Mounting Orientation.....	12-21
Figure 13-1. Relationship of Indicator Lights to Terminal Board Connections.....	13-1
Figure A-1. Series 90 PLC, RS-422 Serial Port Connector Configuration.....	A-3
Figure A-2. Workmaster RS-232 Serial Port Connector Configuration.....	A-4
Figure A-3. IBM-AT/XT Serial Port.....	A-5
Figure A-4. IBM-AT (compatibles) Personal Computer to Series 90 PLCs.....	A-9
Figure A-5. Workmaster or IBM-XT (compatibles) Personal Computer to Series 90 PLCs.....	A-9
Figure A-6. Typical RS-422, Host to PLC Connection, with Handshaking.....	A-10
Figure A-7. Workmaster II/Series 90 PLC Multidrop Connection.....	A-11
Figure A-8. Workmaster/Series 90 PLC Multidrop Connection.....	A-12
Figure A-9. IBM-AT/Series 90 PLC Multidrop Connection.....	A-12
Figure A-10. IBM-XT/Series 90 PLC Multidrop Connection.....	A-13
Figure B-1. Front and Rear View of Converter.....	B-2
Figure B-2. Typical Configuration with Series 90-70 PLC.....	B-3
Figure B-3. Typical Configuration with Series 90-30 PLC.....	B-4
Figure B-4. RS-422/RS-485 to RS-232 Converter Logic Diagram.....	B-6
Figure B-5. Location of Jumpers for User Options.....	B-7
Figure C-1. Isolated/Repeater Converter.....	C-2
Figure C-2. RS-422 Isolated Repeater/RS-232 Converter Logic Diagram.....	C-3
Figure C-3. Example RS-422 Isolated Repeater/RS-232 Converter Connection.....	C-5
Figure C-4. Simple System Configuration Using the Isolated Repeater/Converter.....	C-6
Figure C-5. Complex System Configuration Using the Isolated Repeater/Converter.....	C-6
Figure C-6. Cable A; RS-232 CMM To Converter.....	C-8
Figure C-7. Cable B; RS-422 CMM To Converter.....	C-8
Figure C-8. Cable C; RS422 Twisted Pair.....	C-9
Figure C-9. Cable D; RS-422 Twisted Pair.....	C-10

Contents

Figure C-10. Cable E; RS-232 Converter to CMM	C-10
Figure D-1. Series 90 SNP to RS-232 Miniconverter	D-1
Figure D-2. Miniconverter to PC-AT	D-3
Figure D-3. Miniconverter to Workmaster II, PC-XT, PS/2	D-3
Figure D-4. Miniconverter to 9-Pin Workmaster or PC-XT Computer.....	D-4
Figure E-2. IC690ACC903 Block Diagram	E-3
Figure E-3. RS-485 Port Isolator in PLC Network.....	E-4
Figure E-4. Mounting Port Isolator to Panel	E-4
Figure E-5. Multidrop Configuration Connecting Devices with 15-Pin Ports and 25-Pin Ports.....	E-5
Figure E-6. Cable for Supplying External Power Through the Port Isolator.....	E-6
Figure H-1. Typical TBQC Terminal Block.....	H-1
Figure H-2. TBQC Faceplate.....	H-5
Figure H-3. IC693ACC329 TBQC Terminal Block.....	H-6
Figure H-4. IC693ACC330 TBQC Terminal Block.....	H-7
Figure H-5. IC693ACC331 TBQC Terminal Block.....	H-8
Figure H-6. IC693ACC332 TBQC Terminal Block.....	H-9
Figure H-7. IC693ACC333 TBQC Terminal Block.....	H-10
Figure H-8. IC693MDL654 32-Point Module.....	H-11
Figure H-9. IC693ACC337 TBQC Terminal Block.....	H-13
Figure I-1. Series 90-30 Multidrop Example.....	I-1
Figure I-2. Multidrop Cable Wiring Diagram	I-3
Figure I-3. Connecting CPU and APM to Programmer with IC690CBL714A Cable.....	I-4
Figure I-4. Multidrop Arrangement for Series 90-70 TMR Redundant System.....	I-4
Figure I-5. Multidrop Arrangement for Series 90-30 Redundant System	I-5
Figure J-1. IC649AEA102 Ethernet 10BASE-T Transceiver	J-1
Figure J-2. IC649AEA103 Ethernet 10BASE2 Transceiver	J-2
Figure L-1. 44A720084-001 Line Filter Connections to Series 90-30 Power Supply	L-2
Figure L-2. Equivalent Circuit for 44A720084-001 Line Filter	L-2
Figure L-3. 44A720084-001 Line Filter Mounting Dimensions	L-3

Contents

Table 3-1. Rack Number Selection Switch Settings.....	3-13
Table 3-2. Series 90-30 Baseplate Comparison.....	3-22
Table 4-1. Power Supply Comparison.....	4-1
Table 4-2. IC693PWR321 Power Supply Capacities.....	4-2
Table 4-3. Specifications for IC693PWR321 Standard AC/DC Input Power Supply.....	4-3
Table 4-4. IC693PWR330 Power Supply Capacities.....	4-4
Table 4-5. Specifications for IC693PWR330 High Capacity AC/DC Input Power Supply.....	4-5
Table 4-6. IC693PWR322 Power Supply Capacities.....	4-7
Table 4-7. Specifications for IC693PWR322 Power Supply.....	4-8
Table 4-8. IC693PWR328 Power Supply Capacities.....	4-10
Table 4-9. Specifications for IC693PWR328 Power Supply.....	4-11
Table 4-10. IC693PWR331 Power Supply Capacities.....	4-13
Table 4-11. Specifications for IC693PWR331 Power Supply.....	4-14
Table 5-1. CPU Firmware and PROM Configurations.....	5-6
Table 5-2. EPROM and EEPROM Catalog Numbers.....	5-9
Table 5-3. Series 90-30 CPU Capacities.....	5-10
Table 5-4. Range and Size of User References for CPU Models 311-341.....	5-11
Table 5-5. Range and Size of User References for CPU Models 350 through 374.....	5-12
Table 5-6. Port 1 (RS-232).....	5-22
Table 5-7. Port 2 (RS-485).....	5-22
Table 7-1. IC693DVM300 Specifications.....	7-13
Table 7-2. IC693DVM300 Connections.....	7-14
Table 7-3. Series 90-30 Discrete I/O Modules.....	7-15
Table 7-4. Series 90-30 Analog I/O Modules.....	7-16
Table 8-1. Comparison of TCM302 and TCM303.....	8-39
Table 9-1. System Specifications for Series 90-30 State Logic CPUs.....	9-12
Table 10-1. Series 90-30 Cable Cross-Reference.....	10-1
Table 10-2. Expansion Port Pin Assignments.....	10-25
Table 10-3. Wire List for 32 Point I/O Cables.....	10-40
Table 10-4. Wire List for 24-Pin Connectors.....	10-43
Table 10-5. Catalog Numbers for 24-Pin Connector Kits.....	10-46
Table 10-6. I/O Cable Wire Coding for IC693CBL311 and IC693CBL319.....	10-47
Table 10-7. I/O Cable Wire Coding for IC693CBL317 and IC693CBL320.....	10-48
Table 10-8. Catalog Numbers for 24-Pin Connector Kits.....	10-50
Table 10-9. Wire List for 24-Pin Connectors.....	10-51
Table 10-10. Catalog Numbers for 24-Pin Connector Kits.....	10-59

Contents

Table 10-11. Wire List for 24-Pin Connectors	10-60
Table 10-12. TBQC Cable Cross-Reference Table	10-63
Table 11-1. Personal Computer Interface Card Comparison Table.....	11-7
Table 12-1. Power Supply Feature Comparison Table.....	12-6
Table 12-2. Maximum Number of Modules Per System.....	12-11
Table 12-3. Load Requirements (in milliamps).....	12-12
Table 13-1. Fuse List for Series 90-30 Modules	13-6
Table 13-2. Spare/Replacement Parts	13-7
Table A-1. Connector/Cable Specifications	A-2
Table A-2. Series 90 PLC, RS-422 Serial Port Pin-out.....	A-4
Table A-3. Workmaster RS-232 Serial Port Pins-out.....	A-5
Table A-4. IBM-AT/XT Serial Port Pins-out.....	A-6
Table B-1. RS-232 Interface for Converter	B-4
Table B-2. RS-422/RS-485 Interface for Converter.....	B-5
Table B-3. Jumper Configuration for RS-422/RS-485 to RS-232 Converter.....	B-8
Table B-4. Specifications for IC690ACC900 Converter.....	B-9
Table C-1. Isolated Repeater/Converter Pin Assignments	C-4
Table D-1. Miniconverter RS-232 Port	D-2
Table D-2. Miniconverter RS-422 Port	D-2
Table D-3. Miniconverter Specifications	D-4
RS-485 Connectors.....	E-2
Table H-1. TBQC Terminal Block Selection Table	H-2
Table I-1. Connector and Cable Specifications	I-2
Table K-1. Standard ASCII (American Standard Code for Information Interchange) Codes	K-1
Table K-2. AWG to Metric Wire Size Conversion	K-2
Table K-3. Celsius to Fahrenheit Conversion.....	K-3
Table K-4. General Conversions	K-4
Table K-5. Length Equivalents.....	K-5
Table K-6. Area Equivalents	K-5
Table K-7. Volume Equivalents I.....	K-6
Table K-8. Volume Equivalents II.....	K-6

Chapter 1

Overview of the Series 90-30 PLC

The Series 90™-30 Programmable Logic Controller (PLC) is a member of the GE Fanuc Series 90 PLC family.

The Basic Parts of a Series 90-30 PLC

The Series 90-30 PLC is very versatile because (1) it is programmable, and (2) it is assembled from a wide variety of modular, plug-together components. Therefore, by choosing the correct components and developing an appropriate program, the PLC can be used for an almost unlimited variety of applications. Although there are many choices of individual hardware components to use in a system, there are just a few basic categories. Each of these component categories is covered in detail in a separate chapter in this manual. They are introduced in this chapter so you can see how they fit together:

- Baseplates
- Power Supplies
- CPUs
- I/O Modules
- Option Modules
- Cables

Baseplates

The baseplates are the foundation of the PLC system because most other components mount on them. As a basic minimum, every system has at least one baseplate, which usually contains the CPU (in which case, it is referred to as “the CPU Baseplate”). Many systems require more modules than can be mounted on one baseplate, so there are also Expansion and Remote baseplates that connect together. The three categories of baseplates, CPU, Expansion, and Remote, are available in two sizes, 5-slot and 10-slot, named according to the number of modules they can hold.

Power Supply Modules

Every baseplate must have its own power supply. The power supply always mounts in a baseplate’s left-most slot. There are several power supply models available to meet a variety of requirements.

CPUs

The CPU is the manager of the PLC. Every PLC system must have one. A CPU uses the instructions in its firmware and application program to direct the PLC's operation and to monitor the system to make sure there are no basic faults. Some Series 90-30 CPUs are built into baseplates, but most are contained in plug-in modules. In some cases, the CPU resides in a Personal Computer using a Personal Computer Interface Card that interfaces to Series 90-30 Input, Output, and Option modules.

Input and Output (I/O) Modules

These modules enable the PLC to interface with input and output field devices such as switches, sensors, relays, and solenoids. They are available in both discrete and analog types.

Option Modules

These modules extend the capability of the PLC beyond the basic functions. These provide such things as communications and networking options, motion control, high speed counting, temperature control, interfacing to operator interface stations, etc.

Cables

These connect the PLC components together or to other systems. Many standard prefabricated cables are available from GE Fanuc. They are primarily used to:

- Interconnect baseplates
- Connect a programmer to the CPU or to an option module
- Connect option modules to field devices or other systems.

Assembling a Basic Series 90-30 PLC System

Let's assemble, on paper, a basic system using the following components:

- Baseplate
- Power Supply module
- CPU module
- Some I/O modules

We'll start with the **baseplate**. To keep it simple, we'll use a 5-slot size. Note that a 5-slot baseplate actually has six slots, but the power supply slot is not numbered. Note also, that this baseplate has a CPU slot, which is slot number 1, and it has an expansion connector on the right end, which is used for connecting to another baseplate if the system has more than one baseplate.




Figure 1-1. Five-Slot CPU Baseplate

Next, we'll add a **power supply** module. It mounts in the unnumbered slot on the left end of the baseplate. This slot has a unique connector that will only fit a power supply module.




Figure 1-2. Power Supply Module

1

Then add a **CPU module**. A CPU module can only mount in baseplate slot 1, next to the power supply. Slot 1 has a unique connector that will only fit CPU or special Option modules.




Figure 1-3. CPU Module

To finish, we will add some **I/O modules** to baseplate slots 2 through 5.




Figure 1-4. I/O Module




Figure 1-5. Assembling the System

1

When assembled, the system will look like this:




Figure 1-6. A Basic System

An assembly of baseplate and modules such as this one is called a “Rack.”

What else would be needed to make this basic system functional?

- To make this basic system functional, you would need:
- **Mounting.** Safe, secure mounting for the PLC in a protective enclosure.
 - **Wiring.** This includes properly installed incoming power to the power supply, as well as wiring from the I/O modules to field devices such as switches, sensors, solenoids, relays, etc.
 - **Program.** An application program for the PLC to run. This is developed with GE Fanuc PLC programming software.

What if the application requires more than five modules?

You could use a 10-slot baseplate, shown in the next picture:




Figure 1-7. Ten-Slot Rack

What if the application requires more than ten modules?

You can add one or more Expansion or Remote racks to this system. Some CPUs can support up to seven additional racks. If you added seven additional 10-slot racks, you could have 70 more modules.

Racks are interconnected in a “daisy-chain” cabling arrangement. This interconnection system is called the “I/O Expansion Bus.” The connections are made from one baseplate’s I/O Bus Expansion Connector (shown in the figure above) to the next one’s. The I/O Bus Expansion Cables, shown below, have a double connector on one end to facilitate these connections.




Figure 1-8. I/O Bus Expansion Cable

The next figure shows a system that has a CPU baseplate, one Expansion rack and three Remote racks. Notice that the last rack, the one at the end of the I/O Expansion Bus, must be terminated. A convenient way of terminating the bus is with an IC693ACC307 I/O Bus Terminator Plug, as shown.




Figure 1-9. Connecting Expansion and Remote Baseplates


What is the Difference Between Expansion and Remote baseplates?

The main factor to consider is distance. How far will the baseplate be from the CPU baseplate? If the cabling distance from the CPU baseplate is 50 feet (15 meters) or less, use an Expansion baseplate. The Expansion baseplate is preferable because of its higher communication speed with the CPU baseplate. However, if a baseplate must be located where it requires a cabling distance from the CPU rack in excess of 50 feet, an Expansion baseplate will not work - a Remote baseplate must be used. The limit for a Remote baseplate is a cabling distance of 700 feet (213 meters) from the CPU baseplate to the farthest Remote baseplate.

What if I need to cover more than 700 feet (213 meters)?

You can cover much greater distances by using Series 90-30 communications option modules. For example, Genius Bus Controller Modules (GBC) can communicate at distances up to 7,500 feet (2,286 meters) over a shielded twisted-pair cable, as shown in Example 1 below. Or, serial communications with Communications Coprocessor Modules (CMM) using the RS-485 standard can cover up to 4,000 feet (1,219 meters), as shown in Example 2 below. And virtually unlimited communication distances can be attained with modems and telephone lines or radio transmitters. Also, there are numerous networking options available such as Ethernet or WorldFIP.

Example 1 - GBC



Example 2 - CMM




Figure 1-10. Connecting PLCs Using GBC or CMM Modules

Chapter 2

Installation

This chapter discusses installation details only. Other information about the products such as hardware descriptions and specifications, is covered in the applicable chapters.

Important Note

Series 90-30 PLCs must be mounted in a protective enclosure.

*The installation instructions described in this chapter apply to PLC installations that do not require special procedures for noisy or hazardous environments. For installations that must conform to more stringent requirements (such as CE Mark), see GFK-1179, *Installation Requirements for Conformance to Standards*. Also see GFK-0867, *GE Fanuc Product Agency Approvals, Standards, General Specifications*.*

Receiving your Products - Visual Inspection

When you receive your Series 90-30 PLC system, carefully inspect all shipping containers for damage that may have occurred during shipping. If any part of the system is damaged, notify the carrier immediately. The damaged shipping container should be saved as evidence for inspection by the carrier.

As the consignee, it is your responsibility to register a claim with the carrier for damage incurred during shipment. However, GE Fanuc will fully cooperate with you if such action is necessary.

Pre-installation Check

After unpacking Series 90-30 PLC racks, cables, modules, etc., **record all serial numbers**. Serial numbers are printed on the module packaging. Serial numbers are required to make a claim during the warranty period of the equipment. All software product registration cards should be completed and returned to GE Fanuc. See "Module Features" in this chapter for location of module serial numbers. See "Common Baseplate Features" in chapter 3 for location of baseplate serial numbers.

You should verify that all components of the system have been received and that they agree with your order. If the parts received do not agree with your order, call Programmable Control Customer Service at 1-800-432-7521. A Customer Service representative will provide further instructions.

If you require assistance with your installation, GE Fanuc's Technical Support department offers expert help. Call the support number for your area from the list in Chapter 13, "Maintenance and Troubleshooting." The GE Fanuc web site support address is www.gefanuc.com/support/plc.

Warranty Claims

Record the serial number of the defective item and contact your distributor for instructions.

Working with Series 90-30 Modules

Module Features




Figure 2-1. Features of Series 90-30 Module

1. Pivot hook
2. Circuit board holding tabs (two on each side of module)
3. Catalog number and description section of label (Includes MAC address for CPU374.)
4. Certification (UL, CE, etc.) section of label
5. Module connector - plugs into baseplate backplane connector
6. Release lever - spring loaded
7. Ventilation openings in module case (top and bottom)
8. Front cover holding tabs (two on each side of module)
9. Front cover (shown) or terminal board (for I/O modules).
10. Front cover faceplate or hinged cover for terminal board.
11. Lens cap (some modules do not have).
12. Lens cap holding tabs (one on each side of module)
13. Module label
14. Serial Number - used to determine module warranty status. (On some modules, the Serial Number may be on a small tag on the back of the module.)

Installing a Module

Warning

Do not insert or remove modules with power applied. This could cause the PLC to stop or malfunction. Injury to personnel and damage to the module or baseplate may result. Also, attempts to force a module into an improper slot type will result in damage to the module and/or the baseplate. Modules will mount in the correct slot type easily, with a minimum of force.

Use the following instructions as a guide when inserting a module into a baseplate slot.

- Check that module catalog number matches slot configuration. Each slot is, or will be, assigned a particular module type during configuration. A Power Supply module must be installed in the left end unnumbered slot only, and a CPU module and some special Option modules can only be installed in Slot 1 of a CPU baseplate. I/O Modules and most Option modules install in slots numbered 2 and higher.
- Grasp the module firmly with terminal board toward you and with rear pivot hook facing away from you.
- Align the module with the desired baseplate slot and connector. Tilt the module upwards so that top rear pivot hook of the module engages the baseplate's top module retainer.
- Swing the module downward until the module's connector engages the baseplate's backplane connector, and the release lever on the bottom of the module snaps into place in the baseplate's bottom module retainer.
- Visually inspect the module to be sure that it properly seated.




Figure 2-2. Installing a Module

Removing a Module

Warning

Do not insert or remove modules with power applied. This could cause the PLC to stop or malfunction. Injury to personnel and damage to the module or baseplate may result. Also potentially dangerous voltages from user devices may be present on a module's screw terminals even though power to the rack is turned off. Care must be taken any time that you are handling the module's removable terminal board or any wires connected to it.

- If the module has wiring, remove the module's terminal board (NOTE: You do not have to unwire the terminal board) or cables. The procedure for removing a terminal board is described later in this section.
- Locate the release lever at the bottom of the module and firmly press it up, towards the module.
- While holding the module firmly at its top and fully depressing release lever, swing (pivot) the module upward (release lever must be free of its retaining slot).
- Disengage pivot hook at the top rear of the module by moving the module up and away from the baseplate.




Figure 2-3. Removing a Module

Note

Modules in expansion or remote baseplates can be added, removed, or replaced while the PLC is in RUN mode if power is first removed from the expansion or remote baseplate. I/O data to/from this baseplate will not be updated while power is removed.

Installing a Module's Terminal Board

Note: Modules IC693MDL730F (and later) and IC693MDL731F (and later) have special terminal boards that are equipped with holding screws. For Installation and Removal instructions, please see the section "Installing and Removing Terminal Boards with Holding Screws" later in this chapter.

To install a terminal board (circled numbers refer to drawing below):

- Hook the pivot hook ①, located on the bottom of the terminal board, to the lower slot on the module.
- Push the terminal board toward the module ② until it snaps into place.
- Open the terminal board cover ③ and ensure that the latch on the module is securely holding the terminal board in place.

Caution

Compare the module catalog number on the label on the back of the hinged door (see Figure 2-6) and the label on the side of the module (see below) to ensure that they match. If a wired terminal board is installed on the wrong module type, damage to the module may occur when the system is powered up.





Figure 2-4. Installing an I/O Module's Terminal Board

Removing a Module's Terminal Board

To remove a terminal board:

- Open the plastic terminal board cover.
- Push up on the jacking lever to release the terminal block.



- Grasp pull-tab and pull it towards you until contacts have separated from module housing and bottom pivot hook has disengaged.




Figure 2-5. Removing a Module's Terminal Board

I/O Module Terminal Board Posts

The terminal board has three posts on the left side. The top and bottom posts hold the terminal board cover in place. The middle post keeps the terminal board wiring in place. If you do not require it to hold the wiring in place, the middle post can be easily snapped off. (Be careful that you do not inadvertently snap it off if you need it to keep your wiring in place.)

Installing and Removing Terminal Boards with Holding Screws

Discrete output modules IC693MDL730F (and later) and IC693MDL731F (and later) have a special terminal board that is equipped with holding screws, shown in the figure below. These screws prevent the terminal board-to-module connections from deteriorating in applications where the PLC is subjected to severe vibration.




Figure 2-6. Terminal Board with Holding Screws

- **Removing:** To Remove these terminal boards, first loosen the two holding screws on the front of the terminal board, then follow the standard removal instructions in the section "Removing an I/O Module's Terminal Board." The holding screws are held captive in the terminal board and do not have to be completely removed.
- **Installing:** To install these terminal boards, follow the standard installation instructions in the section "Installing an I/O Module's Terminal Board," then tighten the two holding screws to 8 to 10 inch-pounds (1 Newton-meter) of torque.

Baseplate Mounting

Warning

Be sure to follow baseplate grounding instructions in this chapter. Failure to properly ground the PLC can result in improper operation, damage to equipment, and injury to personnel.

Mounting a Baseplate to a Panel


- Use four good-quality 8-32 x 1/2 (4 x 12mm) machine screws, lock washers and flat washers. Install the screws in four tapped holes. The “Baseplates” chapter has the applicable dimensions and mounting clearances. Alternately, 10-slot baseplates can be mounted in standard 19-inch racks by using the appropriate adapter. This is also discussed in the “Baseplates” chapter.
- A vertical mounting orientation is preferred for maximum heat dissipation. Other mounting orientations will require derating the Power Supply current capabilities. See Chapter 12, “System Design,” for details.
- All baseplates must be grounded. The “Baseplate Safety Grounding” section of this chapter has details.
- The Rack Number Selection switch must be set on each Expansion or Remote baseplate. A CPU baseplate does not require this switch. Rack numbers should be assigned by the system designer. Failure to set the Rack Number Selection switches properly will result in system malfunction. See the “Baseplates” chapter for details on setting these switches.

Mounting a Baseplate to a 19" Rack

Two optional Baseplate Adapter Brackets allow a 10-slot baseplate to be mounted in a 19 inch rack. Each baseplate installation requires only one of the adapter brackets.

- **IC693ACC308 Front Mount Adapter Bracket.** Used to mount a baseplate to the front face of a 19" rack. Install the adapter bracket by inserting the tabs at the top and bottom of the adapter bracket into the corresponding slots at the top and bottom of the plastic baseplate cover. NOTE: Although Figure 2-7 shows the plastic baseplate cover removed, this is for illustration purposes only. It is not necessary to remove the cover to install the bracket. With the bracket in place, insert and tighten the two screws (included with the bracket) through the back of the baseplate holes into the threaded holes in the bracket.


- **IC693ACC313 Recessed Mount Adapter Bracket.** Used to recess mount a baseplate inside a 19" rack. A baseplate mounts on the rear panel of this adapter bracket using four 8-32 (4mm) screws, nuts, lock washers, and flat washers. The Adapter Bracket bolts through its four slotted holes to the face of the 19" rack using applicable hardware (lock washers recommended).



Note: Baseplate is shown with cover removed for illustration purposes. It is not necessary to remove the baseplate cover to install the bracket.

Figure 2-7. IC693ACC308 Front Mount Adapter Bracket Installation

Dimensions for rack mounting a 10-slot baseplate with the IC693ACC308 Front Mount Adapter Bracket are shown in the following figure.



DIMENSIONS IN INCHES (MILLIMETERS IN PARENTHESES)

Figure 2-8. Dimensions for 19-inch Rack Mounting Using IC693ACC308 Adapter Bracket

2




Figure 2-9. IC693ACC313 Recessed Mount Adapter Bracket

Grounding Procedures

System Grounding Procedures

Warning

In addition to the following grounding information, we strongly urge that you follow all applicable codes that apply to your area. For example, in the United States, most areas have adopted the National Electrical Code standard and specify that all wiring conform to its requirements. In other countries, different codes will apply. For maximum safety to personnel and property you must follow these codes. Failure to do so can mean injury or death to personnel, damage to property, or both.

All components of a programmable logic control system and the devices it is controlling must be properly grounded. This is particularly important for the following reasons.

- A low resistance path from all parts of a system to earth minimizes exposure to shock in the event of short circuits or equipment malfunction.
- The Series 90-30 PLC system requires proper grounding for correct operation.

Ground Conductors

- Ground conductors should be connected in a tree fashion with branches routed to a central earth ground point, shown in the figure below. This ensures that no ground conductor carries current from any other branch. This method is shown in the following figure.
- Ground conductors should be as short and as large in size as possible. Braided straps or ground cables (typically green insulation with a yellow tracer - AWG #12 (3.3 mm²) or larger) can be used to minimize resistance. Conductors must always be large enough to carry the maximum short circuit current of the path being considered.




Figure 2-10. Recommended System Grounding

Series 90-30 PLC Equipment Grounding

Equipment grounding recommendations and procedures are listed below. These grounding procedures must be properly followed for safe, proper operation of your Series 90-30 PLC system.

Baseplate Safety Grounding

The following recommendations are offered, but applicable safety codes for your area or equipment type should also be consulted. The baseplate's metal back must be grounded using a separate conductor; the baseplate mounting screws are not considered to an acceptable ground connection by themselves. Use a minimum AWG #12 (3.3 mm²) wire with a ring terminal and star lock washer under the head of one of the baseplate's two lower mounting holes. These two holes have openings to the side to allow connecting a wire and ring terminal under the head of a mounting screw. Connect the other end of this ground wire to a tapped hole in the panel that the baseplate is mounted to, using a machine screw, star lock washer, and flat washer. Alternately, if your panel has a ground stud, it is recommended you use a nut and star lock washer for each wire on the ground stud to ensure adequate grounding. Where connections are made to a painted panel, the paint should be removed so clean, bare metal is exposed at the connection point. Terminals and hardware used should be rated to work with the aluminum baseplate material.




Figure 2-11. Baseplate Grounding

Warning

All baseplates must be grounded to minimize electrical shock hazard. Failure to do so can result in severe personal injury.

All baseplates grouped together in a Series 90-30 PLC system must have a common ground connection. This is especially important for baseplates that are not mounted in the same control cabinet.

Grounding 19" Rack-Mounted Baseplates

There are two Adapter Brackets used for mounting a 10-slot Series 90-30 baseplate to a 19" Rack. Regardless of which of the two Adapter Brackets is used, the 19" Rack should be grounded as per the instructions in "System Grounding Procedures," including Figure 2-10. (For details on the Adapter Brackets, see the "Mounting a Baseplate to a 19" Rack" section earlier in this chapter.)

Nineteen-Inch Rack-mounted PLC baseplates should be grounded according to the guidelines in the "Baseplate Safety Grounding" section, using a separate ground wire from the PLC baseplate as shown in the previous figure (Fig. 2-11).

- If using the **Recessed Mount Adapter Bracket (IC693ACC313)**, the ground wire can be installed as shown in Figure 2-11 with the ground attached to the Recessed Mount Adapter Bracket. An additional ground wire connecting the Adapter Bracket to a solid chassis ground on the 19" Rack should be installed. Use the same or equivalent hardware and paint removal scheme as shown in Figure 2-11.
- If using the **Surface Mount Adapter Bracket (IC693ACC308)**, the ground wire should be run from the baseplate as shown in Figure 2-11, to a solid chassis ground on the 19" Rack. Use the same or equivalent hardware and paint removal scheme as shown in Figure 2-11.

Programmer Grounding

For proper operation, the computer (programmer) running the PLC software must have a ground connection in common with the CPU baseplate. Normally, this common ground connection is provided by ensuring that the programmer's power cord is connected to the same power source (with the same ground reference point) as the baseplate. If it is not possible to ensure this common ground scheme, use a port isolator (IC690ACC903) between the programmer and PLC serial connection. If the programmer ground is at a different potential than the PLC ground, a shock hazard could exist. Also, damage to the ports or converter (if used) could occur when the programmer serial cable is connected between the two.

Warning

Failure to follow programmer grounding recommendations could result in personal injury, equipment damage, or both.

Module Shield Grounding

In general, the aluminum PLC baseplate is used for module shield grounding. On some Series 90-30 modules, shield connections to the user terminal connector on the module are routed to the baseplate through the module's backplane connector. Other modules, such as CPUs 351, 352, 363, 364, and 374 require a separate shield ground. These are discussed in the next several sections.

Shield Grounding Information for CPUs with External Port Connections

CPUs with external port connections, the 351, 352, 363, 364, and 374 must have a separate shield ground connection to provide shielding for these ports. Because the design of the ground connection for the CPU351 and 352 is different from that of the CPU363, 364, and 374, each grounding method is discussed in a separate section.

CPU351 and 352 Shield Grounding

The CPU 351 or 352 module must be connected to frame ground at the slot where it is installed. Two methods are provided for making this ground connection. Each CPU comes with an EMC Grounding Kit (44A737591-G01) that contains a ground wire, grounding bracket, and screws.

1. The connection from the CPU to frame ground can be made using the ground wire (part number 44A735970-001R01) that comes with the module in the EMC Grounding Kit. This wire has a stab-on connector on one end for connection to a mating terminal on the bottom of the CPU, and a ring terminal on the other end for connection to a grounded enclosure. Where the ring terminal contacts a painted enclosure panel, either a star lock washer can be installed between the terminal and the panel to cut through the paint, or the paint can be scraped away down to clean, bare metal to ensure a good contact. **Note: The star lock washer method is suitable for a shield ground, but not suitable for a safety ground.**




Figure 2-12. CPU 351 or 352 - Attaching Shield Ground Wire

2. The second method, which can be used for systems in noisy environments consists of installing the green ground wire *and* the optional grounding bracket (part number 44C715646-001R01). This bracket attaches to the CPU using two #4 thread-rolling screws (part number N666P9004B6) and to the grounded enclosure using two #6 thread-rolling screws (part number N666P13006B6). Two holes must be drilled in the enclosure for mounting this bracket. Also, if the bracket will be attached to a painted surface, the paint should be removed down to bare metal under the bracket to ensure good contact between the bracket and the surface. See the next figure.




Figure 2-13. CPU 351 or 352 - Mounting the Shield Grounding Bracket and Wire

Note: When the grounding bracket is used, pin 1 of the cable connector that plugs into the Port 2 connector should not be connected. A metal connector shell must be used on the cable for this port, and the cable shield must be terminated at the metal shell instead of pin 1 of the connector.

CPU363, CPU364, and CPU374 Shield Grounding

The CPU363, CPU364, and CPU374 modules must be connected to frame ground at the slot where they are installed. Each module comes with a grounding wire for this purpose. These modules do not support or require the use of a grounding bracket. If the ring terminal on the grounding wire is to be mounted to a painted surface, remove the paint under the ring terminal to ensure good contact, or place a star lock washer between the ring terminal and the painted surface. See the next figure.

Note: The star lock washer method is suitable for a shield ground, but not suitable for a safety ground.




Figure 2-14. CPU 363, CPU364, or CPU374 - Attaching Ground Wire

Additional Modules with Shield Grounding Requirements

Some of the Series 90-30 Option modules, such as the FIP Remote I/O Scanner (IC693BEM330), and DSM modules (IC693DSM302 and IC693DSM314) also have shield grounding requirements. These modules come equipped with suitable grounding hardware. Please refer to each module's user's manual for grounding instructions. Appendix G contains a product to publication cross-reference to help you identify the correct manual.

General Wiring Guidelines

Warning

In addition to the following wiring suggestions, we strongly urge that you follow all wiring and safety codes that apply to your area or your type of equipment. For example, in the United States, most areas have adopted the National Electrical Code standard and specify that all wiring conform to its requirements. In other countries, different codes will apply. For maximum safety to personnel and property you must follow these codes. Failure to do so can lead to personal injury or death, property damage or destruction, or both.

Color Coding Wires

These color codes are commonly used in industrial equipment manufactured in the United States. They are cited here as a reference. Where they are in conflict with codes that apply to your area or your type of equipment, you should follow your applicable codes instead. Besides satisfying code requirements, wire color coding makes testing and troubleshooting safer, faster, and easier.

- Green or green with stripe- Ground
- Black - Primary AC
- Red - Secondary AC
- Blue - DC
- White - Common or neutral
- Yellow - Secondary power source not controlled by the main disconnect. Alerts maintenance personnel that there may be power present (from an external source) even if the equipment is disconnected from its main power source.

Wire Routing

To reduce noise coupling among PLC wires, it is recommended you keep electrically noisy wiring, such as AC power wiring and Discrete Output Module wiring, physically separated from low-level signal wiring such as DC and Analog Input module wiring or communications cables. This can be accomplished by grouping separately, where practical, the following categories of wiring:

- **AC power wiring.** This includes the AC input to the PLC power supply, as well as other AC devices in the control cabinet.
- **Analog Input or Output Module wiring.** This should be shielded to further reduce noise coupling. See the *Series 90-30 I/O Module Specifications Manual*, GFK-0898 for details.
- **Discrete Output Module wiring.** These often switch inductive loads that produce noise spikes when switched off.
- **DC Input Module wiring.** Although suppressed internally, these low-level inputs should be further protected against noise coupling by observing these wiring practices.
- **Communications Cables.** Wiring such as Genius Bus or serial cables should be kept away from noise-producing wiring.

Where AC or Output wiring bundles must pass near noise-sensitive signal wiring bundles, avoid running them beside each other. Route them so that, if they have to cross, they do so at a right angle. This will minimize coupling between them.

Grouping Modules to Keep Wires Segregated

If practical, grouping similar modules together in the PLC racks can help keep wiring segregated. For example, one rack could contain only AC modules, and a different rack only DC modules, with further grouping in each rack by input and output types. For smaller systems, as an example, the left end of a rack could contain Analog modules, the middle could contain DC modules, and the right end could contain AC modules.

Discrete I/O Module Connection Methods

- For modules with 16 points or less, the standard method is to use the removable terminal board which comes with these modules. The removable terminal board makes it easy to prewire field wiring to the user supplied input and output devices, and to replace modules in the field without disturbing existing field wiring.
- Some discrete 16-point I/O modules can be used with an optional Terminal Block Quick Connect (TBQC) assembly. This assembly contains a module faceplate, with built-in connector, that replaces the removable terminal board. The assembly also contains a DIN-rail mounted terminal block and a cable to connect the module to the terminal block. The advantage of this method is that it saves about two hours of wiring time per module compared with hand wiring from a module's removable terminal board to a user-supplied, panel-mounted terminal block or strip.
- Older 32-point I/O modules have one 50-pin connector on the front of the module that is either connected by a cable with a connector on each end to a Weidmuller panel-mounted terminal block (Weidmuller catalog no. 912263), or is connected by a cable with stripped, tinned leads to a user-supplied terminal block or strip.
- Newer 32-point I/O modules have two 24-pin connectors on the front of the module. These module may be wired in one of three ways. (1) Use a pair of cables (IC693CBL327/328 - see data sheet in "Cables" chapter) to connect the module to a user-supplied, panel-mounted terminal block or strip. These cables have a 24-pin connector on one end, and stripped, tinned leads with wire markers on the other end. (2) Use a pair of dual-connector cables to connect the module to a Terminal Block Quick Connect (TBQC) terminal block (IC693ACC377). See Appendix H for details. (3) Make your own custom cables. Instructions are found in the IC693CBL327/328 data sheet in Chapter 10.

Connections to I/O Module Terminal Boards

Series 90-30 PLC I/O terminal boards have either 10 or 20 screw terminals that will accept from two AWG #22 (0.36 mm²) to two AWG #16 (1.3 mm²), or one AWG #14 (2.1 mm²) copper 90°C (194°F) wire(s). Each terminal can accept solid or stranded wires, but the wires into any given terminal should be the same type (both solid or both stranded) to ensure a good connection. Wires are routed to and from the terminals out of the bottom of the terminal board cavity. The suggested torque for the I/O terminal board connection screws is from 9.6 in-lbs to 11.5 in-lbs (1.1–1.3 Newton-meters).

For 24 volt DC input modules, an internal 24 volt power connection is provided on the terminal board to supply a limited number of input devices. Also, a 24 volt DC output is available on the power supply module's terminal board to supply a limited number of output devices.

Terminal Block Quick Connect Installation for 16-Point Discrete Modules

The Terminal Block Quick Connect (TBQC) Assembly is an option for certain Series 90-30 discrete I/O modules. See Appendix H for more information.

- Remove standard terminal board from module.
- Install TBQC faceplate (it has a 24-pin connector).
- Mount the TBQC terminal block. It has a 24-pin connector and a terminal strip, and mounts on a standard 35 mm DIN-rail.
- Connect a TBQC cable between the TBQC faceplate connector on the module and the connector on the TBQC terminal block.
- Wire I/O devices to the terminal block.

Installation of 32-Point Discrete, 50-Pin Connector Modules

These 50-Pin modules are an older design and are not generally used on new systems, unless to fulfill standardization requirements. They are mainly used as replacements for existing installations. For new installations, we recommend the dual 24-pin connector style because they have additional features not found on the older modules (LED indicators, TBQC), and it is much easier to fabricate custom-length cables for them. Installation information is provided here for the convenience of those still using these modules.

Using Weidmuller #912263 Terminal Block

Note: The TBQC is not available for these modules, but you may purchase a Weidmuller #912263 from your electronics distributor for this application.

- Mount the Weidmuller#912263 terminal block. It has a 50-pin connector and a terminal strip, and mounts on a standard 35 mm DIN-rail.
- Connect an IC693CBL306/307 cable between the module's faceplate connector and the connector on the Weidmuller terminal block. See Chapter 10 for cable data.
- Wire I/O devices to the terminal block. See the *Series 90-30 PLC I/O Module Specifications Manual*, GFK-0898, for pin-out information.

Using a Generic Terminal Block or Strip

- Mount terminal block/strip to the enclosure panel.
- Connect an IC693CBL308 or 309 cable, or a custom made cable, to the module's faceplate connector and wire the stripped ends of the cable to the terminal block/strip. See Chapter 10 for cable data.
- Wire I/O devices to the terminal block/strip.

Direct Method

- Connect an IC693CBL308 or 309 cable, or a custom made cable, to the module's faceplate connector and wire the stripped ends of the cable directly to the field devices. See Chapter 10 for cable data. See the Series 90-30 PLC I/O Module Specifications Manual, GFK-0898, for pin-out information.

Installation of Discrete 32-Point, Dual 24-Pin Connector Modules

Using a TBQC

- Mount two TBQC terminal blocks. Each has a 24-pin connector and a terminal strip, and mounts on a standard 35 mm DIN-rail.
- Connect a pair of TBQC cables (IC693CBL329 - 334) between the module's faceplate connector and the connectors on the two TBQC terminal blocks. Note that both a right side and left side cable is required. See Appendix H for a list of cables.
- Wire I/O devices to the terminal blocks. See the Series 90-30 PLC I/O Module Specifications Manual, GFK-0898, for pin-out information.

The Terminal Block Quick Connect (TBQC) Assembly is an option for certain Series 90-30 discrete I/O modules. See Appendix H for more information.

With a Generic Terminal Block/Strip

- Mount terminal block/strip to the enclosure panel.
- Connect an IC693CBL327/328 cables, or a custom made cables, to the module's faceplate connectors, and wire the stripped ends of the cables to the terminal block/strip. Note that both a right side and left side cable is required. See Appendix H for a list of cables. See Chapter 10 for cable data sheets.
- Wire I/O devices to the terminal block/strip. See the Series 90-30 PLC I/O Module Specifications Manual, GFK-0898, for pin-out information.

Direct Method

- Connect an IC693CBL327/328 cable, or a custom made cable, to the module's faceplate connectors, and wire the stripped ends of the cable directly to the field devices. See Chapter 10 for cable data. See the *Series 90-30 PLC I/O Module Specifications Manual*, GFK-0898, for pin-out information.

General Wiring Methods for Analog Modules

Twisted, shielded instrumentation cable is strongly recommended for analog module input or output signal connections. Proper grounding of the shield is also important. For maximum electrical noise suppression, the cable shield should only be grounded at one end of the cable. For Input modules, ground the end that is in the noisiest environment (which often is at the field device end). For Output modules, ground at the module end. See GFK-0898, *Series 90-30 PLC I/O Module Specifications*, for more shield grounding information.

Analog Input Module Wiring Methods

Correcting electrical noise problems can sometimes be a trial-and-error routine. However, in general, it is generally best to ground the cable shield as close to the source of the noise as possible, which is usually at the device end. In troubleshooting noise problems, sometimes it is beneficial to experiment with the shield grounding point location. Remember, the cable shield should be grounded at one end only. Also, it is best to keep the length of stripped cable leads as short as possible to minimize the length of unshielded conductors that will be exposed to the noisy environment. See the *Series 90-30 PLC I/O Module Specifications Manual*, GFK-0898 for additional details.

Using a Generic Terminal Block or Strip

- Mount a terminal strip inside the control enclosure and run a shielded cable from the terminal strip to each input circuit on the module's terminal board terminals.
- Connect each cable's shield to the metal panel next to the terminal strip. Do not connect the shields at the module end (cut shield off at module end of cable and insulate with shrink tubing).
- Wire the field device to the terminal strip with a shielded cable, grounding the shield at the device end only (cut shield off at terminal strip end of cable and insulate with shrink tubing). Also, keep the length of exposed (outside of shield) leads at the terminal strip and device ends as short as possible.

Direct Method

- Run a shielded cable from the field device (transducer, potentiometer, etc.) directly to the module.
- Connect the conductors to the applicable screws on the module's terminal board.

- Ground the shield at the field device end, exposing a minimum amount of conductor to the noisy environment. Do not connect the shield at the module end (cut shield off at module end of cable and insulate with shrink tubing).

TBQC not Recommended for Analog Modules

The Terminal Block Quick Connect (TBQC) Assembly is not recommended for use with analog modules due to cable shielding requirements.

Analog Output Module Wiring

General

Each output should be connected using a good quality shielded wire with the cable shield grounded at the module end. See GFK-0898, *Series 90-30 PLC I/O Module Specifications*, for more information.

Using a Generic Terminal Block or Strip

- Mount a terminal strip inside the control enclosure and run a shielded cable from the terminal strip to each output circuit on the module's terminal board terminals.
- Ground each cable's shield at the module end only. Do not connect the shields at the terminal strip end (cut shields off at terminal strip end of cables and insulate with shrink tubing).
- Wire the field device to the terminal strip with shielded cables, grounding the shields at the terminal strip end only (cut shields off at field device end of cables and insulate with shrink tubing). Also, keep the length of exposed (outside of shield) leads at the terminal strip and device ends as short as possible.

Direct Method

- Run a shielded cable from each field device (transducer, potentiometer, etc.) directly to the module.
- Connect the conductors to the applicable screws on the module's terminal board.
- Ground the shield at the module end only, exposing a minimum amount of conductor to the noisy environment. Do not connect the shield at the device end (cut shield off at device end of cable and insulate with shrink tubing).

TBQC not Recommended for Analog Modules

The Terminal Block Quick Connect (TBQC) Assembly is not recommended for use with analog modules due to cable shielding requirements.

AC Power Source Connections

AC Input Wiring to AC/DC Power Supplies

Warning

If the same AC power source is used to provide AC power to other baseplates in a Series 90-30 PLC System, ensure that all AC input connections are identical at each rack. Do not cross Line 1 (L1) and Line 2 (L2). A resulting difference in potential can injure personnel or cause damage to equipment. Each baseplate must be connected to a common ground.

Ensure that the protective cover is installed over all terminal boards. During normal operation with an AC power source either 120 VAC or 240 VAC is present on the AC Power Supply. The cover protects against accidental shock hazard which could cause severe or fatal injury to the operator or maintenance personnel.

Both the Standard (IC693PWR321) and High Capacity (IC693PWR330) AC/DC power supplies currently have six terminals for user connections. Early versions of some Series 90-30 power supplies had five terminals (see next figure). The wiring methods for both five-terminal and six-terminal types is similar, except that step 3 below does not apply to the five-terminal type.

The power supply terminal boards will accept one AWG #14 (2.1 mm²) or two AWG #16 (1.3 mm²) copper 75_C (167_F) wires. Each terminal can accept solid or stranded wires, but the wires in any given terminal should be the same type. The suggested torque for the power supply terminal board is 12 in-lbs (1.36 Newton-meters). Open the door protecting the terminal board and make the following connections from the AC power source, and ground connections (system grounding requirements are described in detail later in this chapter).

1. These are wide range supplies that can operate from an AC power source within the nominal range of 100 VAC to 240 VAC at 50/60 Hz. This may vary -15% to +10% for a total maximum range of 85 VAC to 264 VAC. These are auto-ranging supplies that do not require jumper or switch settings for selection of power source voltage.
2. Connect the hot and neutral wires or lines L1 and L2 to the upper two terminals on the terminal board. Connect the safety ground wire to the ground terminal, which is the third terminal from the top, and is marked with a ground symbol.
3. For power supplies with six terminals, the factory jumper between the 3rd and 4th terminals (see figure below), should be left in place for normal installations. However, this jumper must be removed and external surge suppressors installed in installations with a "Floating Neutral" input. Please see the section "Special Instructions for Floating Neutral (IT) Systems" later in this chapter for details.
4. After all connections to Power Supply terminal board have been completed, the protective cover plate should be carefully reinstalled.




Figure 2-15. Power Supply Terminal Boards

Power Supply Overvoltage Protection Devices

The overvoltage protection devices for this power supply are connected internally to pin 4 on the user terminal board. This pin is normally connected to frame ground (pin 3) with the supplied jumper strap which is installed at the factory. If overvoltage protection is not required *or* is supplied upstream, this feature can be disabled by leaving pin 4 unconnected by removing the jumper strap. Also, this jumper must be removed and external surge suppressors installed in installations with a "Floating Neutral" input, please see the following section "Special Instructions for Floating Neutral (IT) Systems" later in this chapter.

If you want to Hi-pot test this supply, overvoltage protection *must be disabled* during the test by removing the terminal board strap. Re-enable overvoltage protection after testing by reinstalling the strap.




Figure 2-16. Overvoltage Protection Devices and Jumper Strap

Special Installation Instructions for Floating Neutral (IT) Systems

When the AC input power supplies listed below are installed in a system where the Neutral line is **not** referenced to Protective Earth Ground, these special installation instructions must be followed to prevent damage to the power supply.


IC693PWR321S (or later version)

IC693PWR330A (or later version)

Definition of Floating Neutral Systems

A *Floating Neutral System* is a system of power distribution wiring where Neutral and Protective Earth Ground are **not** tied together by a negligible impedance. In Europe this is referred to as an IT system (see IEC950). In a *Floating Neutral System*, voltages measured from input terminals to protective earth ground may exceed the 264 Volts AC maximum input voltage specified in the power supply specifications in Chapter 24 in this manual.


Example of Floating Neutral System



This system **must** be installed using the special installation instructions on the following page.

Systems in which one leg of the power distribution wiring is tied to Protective Earth or a tap between two legs of the power distribution wiring is tied to Protective Earth are **not** *Floating Neutral Systems*.

Examples of Non-Floating Neutral System



These non-floating neutral systems **do not** require these special installation instructions.

Use These Special Installation Instructions for Floating Neutral Systems

1. The input power terminals should be wired according to the instructions in the “AC Power Source Connections” section of this chapter.
2. The factory installed jumper between terminals 3 and 4 of the Power Supply module **must** be removed if using one of the Power Supplies that have this feature. See the “Overvoltage Protection Devices” section of the “Power Supplies” chapter for details.
3. Voltage surge protection devices, such as MOVs, **MUST** be installed between the following terminals:
 - From L1 to earth ground
 - From L2 (Neutral) to earth ground

The voltage surge devices must be rated such that the system is protected from power line transients that exceed $Line\ voltage + 100V + (N-PE)_{MAX}$.

The expression $N-PE$ refers to the voltage potential between neutral and Protective Earth (PE) ground.

For example, in a 240 Volt AC system with neutral floating 50V above earth ground, the transient protection should be rated at:

$$240V + 100V + 50V = 390V$$

DC Power Source Connections

DC Input Wiring to AC/DC and DC-Only Power Supplies

DC Input power can range from 12 to 30 VDC for the 24 VDC supply, 18 to 56 VDC for the 24/48 VDC supply or 100 to 150 VDC for the 125 VDC supply. All Series 90-30 power supplies have DC input capabilities. The following connection information applies to all of them:

Connect the + and - wires from the power source to the top terminals on the terminal board (+ to the top terminal, - to the second terminal). Connect the third terminal from the top to system ground.

+24 VDC Output (All Supplies)

The bottom two terminals are connected to the isolated 24 volt DC output that can be used to supply power to input circuits (within power limitations of the supply).

Warning

If the same DC input power source is used to provide power to two or more power supplies in a Series 90-30 PLC System, ensure that connection polarity is identical at each rack (top terminal + and second terminal -). Do not cross the Positive (+) and Negative (-) lines. A resulting difference in potential can injure personnel or cause damage to equipment. Also, each baseplate must be connected to a common system ground, described earlier in this chapter.

Basic Installation Procedure

Note: Series 90-30 PLCs must be mounted in a protective enclosure. The enclosure should be capable of properly dissipating the heat produced by all of the devices mounted inside it. For details on calculating heat dissipation, refer to Appendix F.

The system design, which includes producing the layout and wiring drawings, should be completed before beginning the installation procedure. This section offers a basic step-by-step approach to installing a Series 90-30 PLC system. Some steps refer to earlier sections of this chapter for additional details. An attempt was made to place the steps in an order that will make the process as efficient as possible. However, due to the wide variance in system designs, this order may not be the most efficient for your system, so you may wish modify this procedure to fit your needs.

1. Gather the schematics, layouts, prints, and other information for the job.

Warning

To avoid the possibility of electrical shock to personnel or damage to your PLC, we recommend that you shut off all power to the system before mounting and wiring the PLC. Also, keep all electronic components away from the area while drilling and tapping to keep metal chips and filings out of these sensitive components.

2. From the layout drawing, determine where the baseplate(s) will be mounted. Lay out the hole locations, either using the dimensions given on your layout drawing or from the "Baseplates" chapter of this manual.
3. Mark the hole locations for the baseplate safety ground wire (see "Baseplate Safety Ground" in this chapter).
4. Mark the hole locations for module shield ground connections (if any). See "Module Shield Ground" (and accompanying sections) in this chapter for instructions.
5. Finish laying (marking hole locations) out the rest of the system. This includes any terminal blocks you will be using. DIN-rail mounted terminal blocks for some of the 32-point I/O modules are manufactured by Weidmuller. DIN-rail mounted GE Fanuc Terminal Block Quick Connect (TBQC) assemblies are optional for some of the 16-point and 32-point discrete I/O modules. If using these TBQCs, refer to Appendix H for data. Also, APM and DSM modules use DIN-rail mounted terminal blocks.

Note

We recommend drilling and tapping all holes before mounting any components. This will avoid getting chips and filings in the components.

6. Drill and tap the marked holes. For baseplate mounting, use 8-32 or 4mm size.
7. Mount the baseplates. Use good quality 8-32 x 1/2 inch or 4 x 12mm size screws. We recommend using star lock washers and flat washers under the screw heads (star lock washer should be located between screw head and flat washer) to ensure a tight baseplate ground connection, and to keep the screws from loosening. Connect each baseplate ground wire as shown in the "Baseplate Safety Ground" section of this chapter.
8. If you have Expansion or Remote racks, determine the correct rack number for each one, then set the rack numbers using the Rack Number Selection dual in-line package (DIP) switch on

the baseplate. Please refer to the “Baseplates” chapter for details on setting these DIP switches. Rack numbers should be assigned by the system programmer because they correspond to system configuration settings and program memory addressing.

9. If you have more than one baseplate (rack), connect the I/O Bus Expansion Cables between the I/O Bus Expansion Connectors, which are located on the right end of the baseplates. The cables are connected in a “daisy-chain” arrangement from one baseplate to the other. This is made possible by the fact that the cables have a dual connector on one end. Therefore, when the cable is plugged into a baseplate connector, the second connector on that end of the cable provides a socket for connecting to the next cable. The data sheet for the I/O Bus Expansion cables (IC693CBL300 etc.) in the “Cables” chapter has sample wiring figures.
10. On the last I/O Bus Expansion Connector, plug in an I/O Bus Expansion Terminator, Catalog Number IC693ACC307 (unless using a cable with built-in terminator resistors, which would either be GE Fanuc cable IC693CBL302, or your own custom-built cable).
11. Install the modules in their correct slots using your system layout drawings. (The label on the side of each module identifies the module type and catalog number.) Refer to the section “Installing Modules” if you are not familiar with how to do this.
12. Connect cables to Option modules. Route cables away from noise-producing wires. See the “Wire Routing” section of this chapter.
13. Be sure to follow the information in the “Wiring Guidelines” section of this chapter to protect the system from electrical noise. Install the power wires to the Power Supply and I/O modules:
 - **I/O modules with removable terminal boards.** You can wire the terminal boards in-place on the modules or remove them from the modules before wiring. Although removing them may help make wiring easier (a previous section “Working with Removable Terminal Boards” shows how to remove a terminal board), care should be taken to avoid mixing them (each terminal board has the catalog number of the module printed on it, and the hinged cover has a wiring diagram for that module type). If you are using wire duct, routing each module’s wires through the opening in the duct directly under the module will help to keep each terminal board in its correct position.
 - **I/O Modules with terminal blocks.** Some modules use terminal blocks that mount to the enclosure panel. This includes all 32-point modules and, can include other I/O modules if they are fitted with the optional Terminal Block Quick Connect Assembly. Connect the terminal blocks to the connectors on the modules with the provided cables.
14. Connect the signal (switches, sensors, solenoids, etc.) wires to the terminal boards, or terminal blocks/strips. If wiring to terminal boards, these can be removed for ease of wiring, if desired. See the section “Removing a Module’s Terminal Board.”
15. When finished wiring the I/O terminal boards (if used and if you removed them for ease of wiring), re-install them on the modules, being careful to match each one with the correct module.



GE Fanuc Automation

Programmable Control Products



GE Fanuc Automation

***P.O. Box 8106
Charlottesville, VA 22906***

GFZ-0085

***Series 90TM-30
Programmable Controller
Troubleshooting Guide***



GE Fanuc Automation

Programmable Control Products

Series 90TM-30 Programmable Controller Troubleshooting Guide

GFZ-0085

August 1993

Notice

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained in this document does not purport to cover all details or variations in hardware and software, nor to provide for every contingency in connection with installation, operation and maintenance. This document may describe features not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness or usefulness of the information contained in this document. No warranties of merchantability of fitness for purpose shall apply.

The following are trademarks of GE Fanuc Automation North America, Inc.

Alarm Master	CIMSTAR	Helpmate
PROMACRO	Series Six	CIMPLICITY
GENet	Logicmaster	Series One
Series 90	CIMPLICITY 90-ADS	Genius
Modelmaster	Series Three	VuMaster
ProLoop	CIMPLICITY PowerTRAC	Series Five
Workmaster	Genius Power TRAC	

© Copyright 1993 GE Fanuc Automation North America, Inc.

All Rights Reserved.

Safety Considerations

General Warnings When Troubleshooting

Stand clear of controlled equipment when power is applied. If the problem is intermittent, sudden unexpected machine motion could occur, causing injury. Also reference NFPA 70E Part II for additional guidelines for safety practices.

Never reach into a machine to operate a switch since unexpected motion could occur, causing injury.

Remove all electrical power at the Main Power Disconnect to ensure total power removal.

Always remove power before inserting or removing modules, or before connecting I/O cabling.

Preface

This guide describes a logical sequence for troubleshooting your Series 90–30 programmable controller. It includes the procedure for changing or adding a EPROM or EEPROM to your CPU. The Series 90–30 PLC is a member of the Series 90TM family of programmable logic controllers from GE Fanuc Automation.

Revisions to this Troubleshooting Guide

This is the first release of this Troubleshooting Guide. Included are models CPU 311, 313, 321, 323, 331 and 341.

Related Publications

Series 90TM–30 Programmable Controller Installation Manual (GFK–0356).

Series 90TM–30 and 90–20 PLC Hand–Held Programmer User's Manual (GFK–0402)

LogicmasterTM 90 Series 90–30 and 90–20 Programming Software User's Manual (GFK–0466)

Series 90TM–30/90–20 Programmable Controllers Reference Manual (GFK–0467)

We Welcome Your Comments and Suggestions

At GE Fanuc Automation, we strive to produce quality technical documentation. After you have used this troubleshooting guide, please take a few moments to write us with your comments and suggestions. Our address is: Manager Technical Publications, GE Fanuc Automation, PO Box 8106, Charlottesville, VA 22906

Drake C. Fink

Sr. Staff Systems Engineer


SYMBOLS USED IN THIS GUIDE

BEGIN AT THIS SYMBOL
ON THE FIRST CHART.




FOLLOW THE PATH WITH
THE CORRECT ANSWER IN
THE DIRECTION OF THE
ARROW


SYMBOLS USED THROUGHOUT THE GUIDE
ARE GEOMETRICALLY CODED




A DIAMOND ASKS A
QUESTION



A RECTANGLE TELLS
YOU TO DO SOMETHING



A NUMBERED BUBBLE WITH
AN ARROW INTO THE BUBBLE
INDICATES THAT THE
PROCEDURE IS CONTINUED
AT A CORRESPONDINGLY
NUMBERED BUBBLE ON THE
INDICATED PAGE NUMBER.



A NUMBERED BUBBLE WITH
AN ARROW OUT OF THE
BUBBLE INDICATES THE
START OF A PROCEDURE ON
THAT PAGE.]

Adding or Changing the EEPROM in the 90™-30

Application programs are normally developed in the CPU's RAM memory and executed from RAM memory. If additional program integrity is desired, or operation of the PLC without a battery is desired, an optional EEPROM or EPROM can be installed in a spare socket (labeled PROGRAM PROM) on the Model 311/313 backplane or in a socket on the model 331/341 CPU module. EEPROMs can be written to and read from. EPROMs can be read when installed in the PLC; however, they must be written to using an external PROM programming device.

Following is the procedure for adding or changing the EEPROM or EPROM. For clarity, the term PROM is used to refer to either an EEPROM or an EPROM.

1. Remove power from the system.
2. If 311/313
 - Remove all modules, including the power supply.
 - Remove the plastic cover.
3. If 331/341:
 - Remove CPU from backplane.
 - Remove front plate and bezel. Unsnap circuit board and remove from case.
4. If the socket is the type which has a screw near the top edge (some versions of 311/331), loosen screw at top of PROM socket (CCW twist;).
5. If present, remove old PROM from socket. Replace with or install new PROM. Orient the PROM so the end with a notch (the top of the prom) is toward the top edge of the backplane. Pin 1 of the prom is the first pin on the left as you move counter-clockwise from the notch. On the 311/331, correct installation orients the notch toward the screw.
6. When present, tighten screw at top of PROM socket (CW twist).
7. If 311/313:
 - Replace the plastic cover.
 - Replace all modules, including the power supply.

8. If 331 CPU: —|

- Assure jumper JP1, located at the bottom of the PROM socket, is in the 1–2 position for EPROM and the 3–2 position for EEPROM. This informs the CPU firmware which type of device is present.

9. If 331/341 CPU:

- Replace circuit board in case.
- Reinstall front plate and bezel.
- Replace CPU in backplane.


Changing the EEPROM (continued)

10. Apply power. The PLC follows the flowchart found in the "Power-Up Sequence" figure in the Power-Up and Power-Down Section of the *Series 90-30/90-20 Programmable Controllers Reference Manual* (GFK-0467) to determine if a program will be loaded from PROM to RAM.
11. For the EEPROM to be used by the CPU, the CPU configuration must be set to use EEPROM as the "Program Source". You may use the LM90 Configuration software or the HHP to accomplish this.
12. To store the program in RAM, you may use either the Hand-Held Programmer or Logicmaster 90-30, Rev 3.5 or higher. Refer to the instructions in the *HHP User's Manual* (GFK-0402) for HHP. To use Logicmaster 90-30, follow these instructions:
 - Start the LM90-30 Programmer Package
 - Activate the Utilities Menu (F9)
 - Select the EEPROM function (F10)
 - Select the WRITE operation
 - Verify the items you want to write to EEPROM are selected.
 - Press ENTER to start the operation. Refer to the *Logicmaster 90 Series 90-30 and 90-20 Programming Software User's Manual* (GFK-0466) for more information.

Notes and Precautions

1. **WARNING:** Do not discard the lithium–manganese dioxide battery in fire. Do not attempt to discharge the battery. The battery may burst or burn or release hazardous materials. Dispose of the battery as you would any hazardous material.
2. **CAUTION:** After a power fault, the system will come back on in the mode (*STOP*, *RUN/ENABLED*, *RUN/DISABLED*) in which it was operating before power loss, unless the power up configuration specifies a particular mode.
3. Not having a battery installed will not prevent the PLC from running. It will generate a PLC fault on power cycle that prevents the PLC from entering *RUN* mode automatically. Clearing this fault will enable the PLC to be placed in *RUN* mode.
4. To short the 'super cap' on a 311/321 PLC:
 - Remove power from the system.
 - Remove all modules, including the power supply.
 - Remove the plastic face plate.
 - Find component C20 along the left edge of the module. This is the 'super cap'. Short the positive (+) and negative (–) leads of this device.
 - Replace the plastic face plate.
 - Replace all modules.
 - Restore power to the system.
5. Supply (input) voltage tolerances for Series 90–30 power supplies:


IC693PWR321:	100 to 240 VAC 100 to 250 VDC (125 VDC nominal)
IC693PWR322:	18 to 56 VDC, 21 VDC minimum to start 24 VDC OR 48 VDC nominal
6. Total cable length must not exceed 50 feet between a CPU rack and an expansion rack. Length must not exceed 700 feet between a CPU rack and a remote rack. No termination plug is needed on a one-rack system.



PAGE 1


(Refer to the Preface for information on safety considerations, related publications and the symbols used in this guide.)


DIA30AL
GFZ-0085




PAGE 2

DIA30BL









*COLD START DELETES THE CONTENTS OF THE CPU'S MEMORY AND RESTORES COMMUNICATION PARAMETERS (BAUD RATE, PARITY, ETC.) TO THEIR DEFAULT VALUES.


PAGE 5


DIA30EL




PAGE 6









DIA30KL

PAGE 10



DIESEL STANDBY GENERATOR

LOCAL CONTROL PANEL FUNCTIONAL DESCRIPTION

FOR

Brisbane Water

May 2005

ABBREVIATIONS

G1 Generator 1 Diesel

1. GENERAL

- 1.1. The PLC for the above operation is a GE Fanuc IC693CPU350. This program has been designed for the use on G1. The operation below controls G1.
- 1.2. A mode selector switch selects how G1 shall operate :
 - 1.2.1. Off
 - 1.2.2. Manual Mode
 - 1.2.3. Test Mode.
 - 1.2.4. Automatic Mode.

2. MANUAL MODE

- 2.1. To operate G1 in MANUAL Mode.
- 2.2. Select this operation by turning the AUTO – TEST – MAN- OFF selector switch to the MANUAL position.
- 2.3. Press the MANUAL START push button to start the generator.
- 2.4. The generator will begin to crank.
 - 2.4.1. If it fails to start within the 10 seconds, the starter motor is stopped and a delay of 10 seconds before it will attempt to restart.
 - 2.4.2. The generator set is allowed 3 attempts to start.
 - 2.4.3. If it fails to start on the third attempt, the generator is locked out on FAIL TO START Alarm.
 - 2.4.4. When the generator starts, the starter motor is stopped by a stop cranking input which measures the speed of the generator.
 - 2.4.5. Once the generator has started, there is a 10 second time delay for the oil pressure to stabilise.
 - 2.4.6. If the oil pressure is not up to pressure after the 10 second time delay, the generator shall shut down on LOW OIL PRESS Alarm.
 - 2.4.7. Once the generator is running there is a 5 second warm up time before it is ready to accept load.

-
- 2.5. To Manual Transfer to Generator in the MANUAL Mode.
- 2.5.1. Start the generator and wait for the generator to run up to speed and voltage and ready to accept load.
 - 2.5.2. Press the MANUAL TRANSFER TO GEN push button.
 - 2.5.3. The MAINS ATS shall Open.
 - 2.5.4. After a 30 second delay the GEN ATS shall Close.
 - 2.5.5. If the MAINS ATS fails to Open.
 - 2.5.5.1. After a 5 second delay an Alarm shall be generated and the MAINS CONNECTED indicator shall flash to indicate the Alarm.
 - 2.5.5.2. The system shall return back to MAINS ATS operation.
 - 2.5.6. If the GEN ATS fails to Close.
 - 2.5.6.1. After a 5 second delay an Alarm shall be generated and the GENERATOR CONNECTED indicator shall flash to indicate the Alarm.
 - 2.5.6.2. The system shall return back to MAINS ATS operation.
- 2.6. To Manual Transfer to Mains in the MANUAL Mode.
- 2.6.1. The GENERATOR ATS is Closed.
 - 2.6.2. Press the MAN TRANSFER TO MAINS push button.
 - 2.6.3. The GEN ATS shall Open.
 - 2.6.4. After a 30 second delay the MAINS ATS shall Close.
 - 2.6.5. If the GEN ATS fails to Open.
 - 2.6.5.1. After a 5 second delay an Alarm shall be generated and the GENERATOR CONNECTED indicator shall flash to indicate the Alarm.
 - 2.6.5.2. The system shall return back to GEN ATS operation.
 - 2.6.6. If the MAINS ATS fails to Close.

2.6.6.1. After a 5 second delay an Alarm shall be generated and the MAINS CONNECTED indicator shall flash to indicate the Alarm.

2.6.6.2. The system shall return back to GEN ATS operation.

2.7. To stop the generator in the MANUAL Mode.

2.7.1. When the generator is running, it may be stopped by pressing the MANUAL STOP push button.

2.7.2. If the generator is still GEN ATS operation. The MANUAL TRANSFER TO MAINS is initiated.

2.7.3. When the GEN ATS is Open, the generator will enter the cool down time of 1 second.

2.7.4. After the cool down time, the generator will shut down.

2.7.5. Once the generator has shut down there is a 15 second delay before it may be restarted. This is to ensure the engine has mechanically stopped.

3. NON-PERMANENT SITE, MANUAL MODE

- 3.1. To operate G1 in a Non-Permanent Site Location in MANUAL Mode.
- 3.2. Connect the generator cables to the site generator CB ensuring the site generator CB is OFF. See BCC procedures.
- 3.3. A plug with shorting links is required to be installed. It is required to be plugged into the 27 Pin Station Plug.
 - 3.3.1. Pins 11 and 12 are required to be connected. This is to indicate that the Mains ATS is Closed. If they are not connected a MAINS ATS Alarm shall be indicated.
- 3.4. Select from the AUTO – TEST – MAN- OFF selector switch to the MANUAL position.
- 3.5. Press the MANUAL START push button to start the generator.
- 3.6. The generator will begin to crank.
 - 3.6.1. If it fails to start within the 10 seconds, the starter motor is stopped and a delay of 10 seconds before it will attempt to restart.
 - 3.6.2. The generator set is allowed 3 attempts to start.
 - 3.6.3. If it fails to start on the third attempt, the generator is locked out on FAIL TO START Alarm.
 - 3.6.4. When the generator starts, the starter motor is stopped by a stop cranking input which measures the speed of the generator.
 - 3.6.5. Once the generator has started, there is a 10 second time delay for the oil pressure to stabilise.
 - 3.6.6. If the oil pressure is not up to pressure after the 10 second time delay, the generator shall shut down on LOW OIL PRESS Alarm.
 - 3.6.7. Once the generator is running there is a 5 second warm up time before it is ready to accept load.
- 3.7. To connect the generator to the site load.
 - 3.7.1. Manually switch over to the generator supply via the site CB's. See BCC procedures.
 - 3.7.2. Do not use the MANUAL TRANSFER TO GEN or the MAN TRANSFER TO MAINS push buttons.

- 3.8. To disconnect the generator from the site load.
 - 3.8.1. Manually switch over to the mains supply via the site CB's. See BCC procedures.
 - 3.8.2. Do not use the MANUAL TRANSFER TO GEN or the MAN TRANSFER TO MAINS push buttons.
- 3.9. To stop the generator in the MANUAL Mode.
 - 3.9.1. When the generator is running, it may be stopped by pressing the MANUAL STOP push button.
 - 3.9.2. The generator will enter the cool down time of 1 second.
 - 3.9.3. After the cool down time, the generator will shut down.
 - 3.9.4. Once the generator has shut down there is a 15 second delay before it may be restarted. This is to ensure the engine has mechanically stopped.

4. TEST OPERATION

- 4.1. To operate the generator in the TEST Mode.
- 4.2. Select this operation by turning the AUTO – TEST – MAN- OFF selector switch to the TEST position.
- 4.3. If the selector is changed to MAN while the generator is operating on TEST, the system shall change to MANUAL TRANSFER TO GEN.
- 4.4. The generator shall begin to crank.
 - 4.4.1. If it fails to start within the 10 seconds, the starter motor is stopped and a delay of 10 seconds before it will attempt to restart.
 - 4.4.2. The generator is allowed 3 attempts to start.
 - 4.4.3. If it fails to start on the third attempt, the generator is faulted on FAIL TO START Alarm.
- 4.5. When the generator starts, the starter motor is stopped by a stop cranking input which measures the speed of the generator.
- 4.6. The MAINS ATS shall Open.
- 4.7. Once the generator has started, there is a 10 second time delay for the oil pressure to stabilise.
- 4.8. If the oil pressure is not up to pressure after the 10 second time delay, the generator shall shut down on LOW OIL PRESS Alarm.
- 4.9. Once the generator is running there is a 5 second warm up time before it is ready to accept load.
- 4.10. After the warm up time has expired and the MAINS ATS has been open for 30 seconds the GEN ATS shall Close.
- 4.11. If the MAINS ATS fails to Open.
 - 4.11.1. After a 5 second delay an Alarm shall be generated and the MAINS CONNECTED indicator shall flash to indicate the Alarm.
 - 4.11.2. The system shall shut down and return back to MAINS ATS operation.
- 4.12. If the GEN ATS fails to Close.

-
- 4.12.1. After a 5 second delay an Alarm shall be generated and the GENERATOR CONNECTED indicator shall flash to indicate the Alarm.
 - 4.12.2. The system shall shut down and return back to MAINS ATS operation.
 - 4.13. To stop the generator in the TEST Mode.
 - 4.13.1. Select this operation by turning the AUTO – TEST – MAN- OFF selector switch to the AUTO or OFF position.
 - 4.13.2. The GEN ATS shall Open.
 - 4.13.3. After a 30 second delay the MAINS ATS shall Close.
 - 4.13.4. If the GEN ATS fails to Open.
 - 4.13.4.1. After a 5 second delay an Alarm shall be generated and the GENERATOR CONNECTED indicator shall flash to indicate the Alarm.
 - 4.13.4.2. The system shall return back to GEN ATS operation.
 - 4.13.5. If the MAINS ATS fails to Close.
 - 4.13.5.1. After a 5 second delay an Alarm shall be generated and the MAINS CONNECTED indicator shall flash to indicate the Alarm.
 - 4.13.5.2. The system shall return back to GEN ATS operation.
 - 4.13.6. When the GEN ATS is Open, the generator will enter the cool down time of 5 minutes.
 - 4.13.7. After the cool down time, the generator will shut down.
 - 4.13.8. If a Mains Failure occurs during the cool down period the generator shall transfer back to the GENERATOR ATS without shutting down.
 - 4.13.9. Once the generator has shut down there is a 15 second delay before it may be restarted. This is to ensure the engine has mechanically stopped.

5. AUTOMATIC OPERATION

- 5.1. To operate the generator in the AUTO Mode.
- 5.2. Select this operation by turning the AUTO – TEST – MAN- OFF selector switch to the AUTO position.
- 5.3. The Phase Failure Relay from the clients switch board shall give a Start Signal for the generators to run.
- 5.4. The Remote Start Command.
 - 5.4.1. The generator shall begin to crank.
 - 5.4.1.1. If it fails to start within the 10 seconds, the starter motor is stopped and a delay of 10 seconds before it will attempt to restart.
 - 5.4.1.2. The generator is allowed 3 attempts to start.
 - 5.4.1.3. If it fails to start on the third attempt, the generator is faulted on FAIL TO START Alarm.
 - 5.4.2. When the generator starts, the starter motor is stopped by a stop cranking input which measures the speed of the generator.
 - 5.4.3. The MAINS ATS shall Open.
 - 5.4.4. Once the generator has started, there is a 10 second time delay for the oil pressure to stabilise.
 - 5.4.5. If the oil pressure is not up to pressure after the 10 second time delay, the generator shall shut down on LOW OIL PRESS Alarm.
 - 5.4.6. Once the generator is running there is a 5 second warm up time before it is ready to accept load.
 - 5.4.7. After the warm up time has expired and the MAINS ATS has been open for 30 seconds the GEN ATS shall Close.
 - 5.4.8. If the MAINS ATS fails to Open.
 - 5.4.8.1. After a 5 second delay an Alarm shall be generated and the MAINS CONNECTED indicator shall flash to indicate the Alarm.

-
- 5.4.8.2. The system shall shut down and return back to MAINS ATS operation.
 - 5.4.9. If the GEN ATS fails to Close.
 - 5.4.9.1. After a 5 second delay an Alarm shall be generated and the GENERATOR CONNECTED indicator shall flash to indicate the Alarm.
 - 5.4.9.2. The system shall shut down and return back to MAINS ATS operation.
 - 5.5. To stop the generator in the AUTO Mode.
 - 5.5.1. The Phase Failure Relay from the clients switch board shall give a Stop Signal for the generators to run.
 - 5.5.2. The Remote Stop Command.
 - 5.5.3. There is a 2 minute proving time for the Phase Failure Relay.
 - 5.5.4. After the 2 minute proving time the GEN ATS shall Open.
 - 5.5.5. After a 30 second delay the MAINS ATS shall Close.
 - 5.5.6. If the GEN ATS fails to Open.
 - 5.5.6.1. After a 5 second delay an Alarm shall be generated and the GENERATOR CONNECTED indicator shall flash to indicate the Alarm.
 - 5.5.6.2. The system shall return back to GEN ATS operation.
 - 5.5.7. If the MAINS ATS fails to Close.
 - 5.5.7.1. After a 5 second delay an Alarm shall be generated and the MAINS CONNECTED indicator shall flash to indicate the Alarm.
 - 5.5.7.2. The system shall return back to GEN ATS operation.
 - 5.5.8. When the GEN ATS is Open, the generator will enter the cool down time of 5 minutes.
 - 5.5.9. After the cool down time, the generator will shut down.
 - 5.5.10. If a Mains Failure occurs during the cool down period the generator shall transfer back to the GENERATOR ATS without shutting down.

5.5.11. Once the generator has shut down there is a 15 second delay before it may be restarted. This is to ensure the engine has mechanically stopped.

6. FAULT OPERATION

6.1. Emergency Stop Operation.

- 6.1.1. Operation of the Emergency Stop push button immediately shuts down the generator and Opens the Generator CB. The Emergency Stop is latched, and requires manual resetting to release the Emergency Stop push button.
- 6.1.2. After the Emergency Stop push button is released, a fault reset will need to be initiated to reset the PLC.

6.2. HIGH HIGH Alarm Operation.

- 6.2.1. The Generator CB is Opened immediately.
- 6.2.2. The generator is shut down immediately.
- 6.2.3. The following alarms will initiate a HIGH HIGH Alarm condition :-
 - 6.2.3.1. Emergency Stop Fault
 - 6.2.3.2. MEN Fault
 - 6.2.3.3. Low Oil Pressure Shutdown Fault, 10 Seconds Startup Delay
 - 6.2.3.4. High Engine Temperature Shutdown Fault, 30 Second Startup Delay
 - 6.2.3.5. Low Radiator Level Fault, 5 Second Delay
 - 6.2.3.6. Over Speed Fault

6.3. HIGH Alarm Operation

- 6.3.1. The Generator CB is Opened immediately.
- 6.3.2. Once the generator circuit breaker is opened, the generator will run through its normal cool down time and shut down.
- 6.3.3. The following alarms will initiate a HIGH Alarm condition:-
 - 6.3.3.1. Generator Under Speed Fault, 5 Second Delay
 - 6.3.3.2. Alternator Under Voltage Fault, 5 Second Delay
 - 6.3.3.3. Alternator Over Voltage Fault, 5 Second Delay

6.3.3.4. Generator CB Tripped Fault

6.3.3.5. Alternator High Temperature Fault, 30 Second Startup Delay

6.4. MEDIUM Alarm Operation.

6.4.1. A Normal Shutdown shall be Initiated.

6.4.2. If the GEN ATS does not Open then the Generator CB is Opened.

6.4.3. The following alarms will initiate a MEDIUM Alarm condition :-

6.4.3.1. Fuel Empty Level Fault, 5 Second Delay

6.4.3.2. Fail To Start Fault, 3 Attempts

6.5. LOW Alarm Operation.

6.5.1. A Warning has occurred on the generator. The generator will not shut down.

6.5.2. The following alarms will initiate a LOW Alarm condition :-

6.5.2.1. Low Oil Pressure Warning Alarm, 10 Seconds Startup Delay


6.5.2.2. High Engine Temperature Warning Alarm, 30 Second Startup Delay

6.5.2.3. Fuel Low Level Alarm, 5 Second Delay


6.5.2.4. Battery Charger AC Supply Failed Alarm, 60 Second Delay

6.5.2.5. Control Battery Low Volts Alarm, 30 Second Delay

6.5.2.6. Start Battery Low Volts Alarm, 60 Second Delay



SIDE ELEVATION





ALTERNATOR END ELEVATION

LEGEND	
ITEM	DESCRIPTION
1	ENGINE JOHN DEERE 6068T
2	ALTERNATOR STAMFORD UC274E
3	CONTROL SWITCHBOARD
4	RADIATOR
5	A/V MOUNTS (4 OFF)
6	ENGINE DRIP TRAY
7	STARTING BATTERY (382)
8	EXHAUST SILENCER (COWL TS30PR)
9	EXHAUST PIPE FLEXIBLE Ø75
10	FUEL TANK BASE FRAME 400 L
11	FUEL GAUGE (MECHANICAL)
12	FUEL FILL POINT (INSIDE ENCLOSURE)
13	ACOUSTIC ENCLOSURE (70dba @ 7m)
14	SIDE ACCESS DOORS (2 OFF)
15	AIR INLET GRILL
16	SWITCHBOARD ACCESS DOOR
17	PLENUM CHAMBER
18	AIR OUTLET GRILL
19	CABLE ENTRY ZONE
20	ANCHOR POINT
21	LIFTING POINTS
22	TRANSPORT SKID
23	FUEL TANK DRAIN (LOCKABLE)
24	OIL DRAIN (LOCKABLE)
25	DOOR CATCH
26	CATCHMENT TRAY DRAIN
27	CONTROL BATTERIES (2x12 VOLT)
28	BATTERY CHARGING SOLAR PANEL
29	DRAIN POINT LOCKABLE COVER
30	EXHAUST PROTECTOR CAGE
31	OUTPUT & CONTROL SOCKETS T.B.A.
32	SAFETY BARS

NOTE
 ENCLOSURE COLOUR : MIST GREEN
 BASE TANK COLOUR : MIST GREEN
 SKID BASE COLOUR : MIST GREEN


Division of Southside Engineering
 47 PROPRIETARY ST.
 TINGALPA
 BRISBANE, QLD. 4173
 Phone: (07) 3890 1744
 Fax: (07) 3390 9723

		PRINCIPAL ENGINEER		R.P.E.Q. NO.	DATE	DESIGN	SEPE	21.10.04	JOB FILE	BWS0137-02/03		 Brisbane City	PROJECT ATC PROJECT GENERATOR SP298	TITLE LYTTON RD GENERATOR ARRANGEMENT	SCALE 1:20	N° 1 OF 8 SHEETS	
		MANAGER ENGINEERING			DATE	DESIGN CHECKED			ACAD FILE	04.14860-600							
B	08.12.04	ISSUED FOR APPROVAL		MAF		DRAWN	MAF	21.10.04	SURVEY No.		FIELD BOOK						
A	08.12.04	ISSUED FOR REVIEW		MAF		DRAFTING CHECK	DC	21.10.04	SURVEYED		A.H. DATUM						
NO. DATE		AMENDMENT		INITIALS		PRODUCTION / NETWORK DELEGATE		DATE								DRAWING N°	AMEND.
						LEIGHTON CONTRACTORS										486/5/7-WR101/093	B




Division of Southside Engineering
47 PROPRIETARY ST.
TINGALPA
BRISBANE, QLD. 4173
Phone: (07) 3890 1744
Fax: (07) 3390 9723



B 21.12.04 ISSUED FOR APPROVAL A 28.12.04 ISSUED FOR APPROVAL VAL DATE 11-12-04	PRINCIPAL ENGINEER MANAGER ENGINEERING PRODUCTION / NETWORK DRAFTING CHECK	R.P.E.D. NO. DATE DESIGN 28.10.04 DESIGN CHECKED 08.12.04 DRAFTING CHECK	JOB FILE ACAD FILE SURVEY NO. SURVEYED	BRW30137-02/03 04.14880-800 FIELD BOOK http://www.pdf4free.com	PROJECT ATC PROJECT GENERATOR SP298	TITLE GENERATOR ELECTRICAL SCHEMATIC	SCALE NTS N° 2 OF 6 SHEETS DRAWING N° 486/5/7-WR101/094 AMEND. B
---	---	---	---	---	---	--	--



RATINGS SP298	
KWe	- 106
KVA	- 133
AMPS	- 132
VOLTAGE	- 415



Division of Southside Engineering
 47 PROPRIETARY ST.
 TINGALPA
 BRISBANE, QLD. 4173
 Phone: (07) 3890 1744
 Fax: (07) 3390 9723

			PRINCIPAL ENGINEER		R.P.E.Q. NO.	DATE	DESIGN	HJR	28.10.04	JOB FILE	BW30137-02/03		 Brisbane City	PROJECT ATC PROJECT GENERATOR SP298	TITLE GENERATOR ELECTRICAL SCHEMATIC	SCALE	NTS	N° 3	OF 6	SHEETS
C	11.01.05	SIGN DETAILS ADDED	WAO	MANAGER		DATE	DESIGN CHECKED			ACAD FILE	04.14880-601					DRAWING N°	486/5/7-WR101/095	AMEND. C		
B	23.12.04	ISSUED FOR APPROVAL	WAO	ENGINEERING			DRAWN	MAF	08.12.04	SURVEY No.		FIELD BOOK								
A	08.12.04	ISSUED FOR APPROVAL	MAF	PRODUCTION / NETWORK		DATE	DRAFTING CHECK			SURVEYED		A.H. DATUM								
NO.		DATE	AMENDMENT	INITIALS																




Division of Southside Engineering
47 PROPRIETARY ST.
TINGALPA
BRISBANE, QLD. 4173
Phone: (07) 3890 1744
Fax: (07) 3390 9723

B 30.12.04 ISSUED FOR APPROVAL	WD	PRINCIPAL ENGINEER	R.P.E.Q. NO.	DATE	DESIGN	HJR	28.10.04	JOB FILE	BW30137-02/03	PROJECT	ATC PROJECT GENERATOR SP298	TITLE	GENERATOR ELECTRICAL SCHEMATIC	SCALE NTS	N° 4 OF 6 SHEETS	AMEND.	B
A 08.12.04 ISSUED FOR REVIEW	MAF	MANAGER ENGINEERING	DATE	08.12.04	DESIGN CHECKED	MAF	08.12.04	ACAD FILE	04.14880-602	Brisbane Water	FIELD BOOK	A.H. DATUM	DRAWING N°	486/5/7-WR101/096			
NO DATE	AMENDMENT	INITIALS	PRODUCTION / NETWORK	DATE	DRAWING CHECK	DC	08.12.04	SURVEYED									



Division of Southside Engineering
47 PROPRIETARY ST.
TINGALPA
BRISBANE, QLD. 4173
Phone: (07) 3890 1744
Fax: (07) 3390 9723

B 30.12.04 ISSUED FOR APPROVAL		PRINCIPAL ENGINEER	R.P.E.Q. NO.	DATE	DESIGN	HJR	28.10.04	JOB FILE	BW30137-02/03	PROJECT		TITLE	SCALE NTS	N° 5 OF 6 SHEETS
B 08.12.04 ISSUED FOR REVIEW		MANAGER ENGINEERING	DATE	DESIGN CHECKED	MAF	08.12.04	ACAD FILE	04.14880-803		ATC PROJECT GENERATOR SP298		ALTERNATOR ELECTRICAL SCHEMATIC	DRAWING N°	AMEND.
NO. DATE		AMENDMENT	INITIALS	DATE	DRAFTING CHECK			SURVEY No.	FIELD BOOK	A.H. DATUM			486/5/7-WR101/097	B



Division of Southside Engineering
47 PROPRIETARY ST.
TINGALPA
BRISBANE, QLD. 4173
Phone: (07) 3890 1744
Fax: (07) 3390 9723

DESIGN	NAME	DATE
HJR		28.10.04
DRAWN	MAF	08.12.04
CHK'D.	DC	08.12.04
A	08.12.04	ISSUED FOR APPROVAL
NO.	DATE	AMENDMENT
		INITIALS

DIRECTOR OF P.D. & P.S.	DATE
ENGINEER IN CHARGE	DATE
SUPERVISING ENGINEER	R.P.E.Q. NO. DATE
CADD FILE	04.14860-604
JOB FILE	BW30137-02/03
SURVEY NO.	A.H. DATUM

PROJECT
ATC PROJECT
GENERATOR SP298

TITLE
GAC GOVERNOR
CONTROLS



**Brisbane
Water**



SCALE	NTS	N° 6 OF 6	SHEETS
DRAWING N°	486/5/7-WR101/105		
AMEND.	A		



INSPECTION & TEST PLAN

Project 14860 AUSTRALIA TRADE COAST PROJECT

**Generator Sets
For
Leighton Contractors
For
Brisbane Water**

**SEPE Document No. ITR 14860
Supply Contract Q1112-SA-009**

Prepared by S E Power Equipment
47 Proprietary St., Tingalpa
Brisbane, Qld, 4173
Telephone: (07) 3890 1744



INSPECTION AND TEST PLAN

Document Control

REVISION	DATE	PREPARED BY	APPROVED BY
C	13.12.04	David Cooper	Jim Pringle

Initials List

All personnel performing tests or signing ITP shall enter their name and sample signature and initials below.

Name	Company	Signature	Initials
FRANK MITCHELL	LEIGHTON		
PAUL HLAVKA	SE POWER		
Peter Renner	Brisbane Water		



INSPECTION AND TEST PLAN

DOCUMENT REGISTER

Document No	Testing	Manufacture // Workshop
010		Fuel Tank and Pipe Testing Schedule
011		Base / Tank Fabrication Procedure
012		Enclosure Fabrication Procedure
013		Engine / Alternator Assembly Procedure
014		Tank Base Assembly Procedure
015		Enclosure Assembly Procedure
	Factory Testing	
016	Electrical Functions Test Sheet	
017	Final Inspection Test Sheet	
018	Factory Load Test	
019	Transient Load Response Test Sheet	
020	Sound Pressure Level Factory Test Report	
	Site Acceptance Testing	
S016	Electrical Functions Test Sheet	
S017	Final Inspection Test Sheet	
S018	Factory Load Test	
S019	Transient Load Response Test Sheet	
S020	Sound Pressure Level Factory Test Report	



INSPECTION AND TEST PLAN

E. POWER EQUIPMENT**ITP and Procedures**

Subject: Inspection and Test Plan (Australia Trade Generator)

Sheet 1

1. PURPOSE

- 1.1 Description of methods and processes involved in the Manufacture, Testing and delivery of the Lytton Road, Viola and Serpentine pump station generators including factory testing of the generators resulting in the production of an ITP.

2. SCOPE

- 2.1 Detailed design mechanical G/A and electrical schematic.
- 2.2 Drawing of major components.
- 2.3 Manufacture skid tank base, switchboard and enclosure.
- 2.4 Assembly of skid tank base, switchboard and enclosure as approved in drawing package.
- 2.5 Workshop visual inspection and pre-testing of the works. Including factory testing up to pre commissioning stage.
- 2.6 Site delivery.
- 2.7 Site acceptance testing.

3. REFERENCES

- 3.1 All Drawings as per specifications supplied by Leighton Contractors Package for the Australia Trade Coast project.
- 3.2 All Design Drawings supplied by S.E. Power.
- 3.3 S.E. Power ITP and factory test sheets.
- 3.4 S.E. Power site acceptance testing document and test sheets.

4. DESCRIPTION

- 4.1 The project consists of three separable parts, Lytton, Viola and Serpentine Rd pump station generators.
- 4.2 The generators will be tested separately in the workshop.
- 4.3 The installation of the generators will follow the process of, manufacture, painting, assembly and factory testing.

5. PROCEDURE

- 5.1 Drawings for comment - One set of completed drawings for Lytton, Viola and Serpentine will be issued for comment.
- 5.2 A schematic showing the calculated design will be issued to Leighton Contractors for approval. Following approval of these drawings and return of the "For Comment" drawings, design will proceed.



INSPECTION AND TEST PLAN

E. POWER EQUIPMENT**ITP and Procedures**

Subject: Inspection and Test Plan Aust. Trade Generator

Sheet 1

- 5.3 Fabrication – Following approval to proceed and any amendments notes marked on the drawings that may affect final approval the sheet metal drawings will be issued for construction to the relative supplier.
- 5.4 Purchasing of materials – Major components and associated items will be purchased.
- 5.5 Sheet metal inspection – During construction the generators will be inspected for compliance to the approved drawings and specifications.
- 5.6 Factory Testing – Factory tests to the requirements of S.E. Power's factory test sheets will be fulfilled. This testing includes requirements detailed within the specifications. BW / Leightons Contractor's representative will inspect and confirm the process has been carried out and the generator is ready for delivery.
- 5.7 Delivery to site – Delivery to site will be via a specialised contractors for all of the generators. Leighton Contractors will approve delivery is acceptable prior to despatch.
- 5.8 Installation of generators and cables - By others.
- 5.9 Site acceptance testing – All installed equipment will be tested to the requirements of the specification prior to the starting of commissioning tests.
- 5.10 Site Commissioning – All site commissioning will be carried out by BW staff. S.E. Power and Leighton Contractors staff will assist with the operation of generators and controls.



INSPECTION AND TEST PLAN

E. POWER EQUIPMENT

P and Procedures

Subject: Inspection and Test Plan

Sheet 1 of 3

INSPECTION AND TEST PLAN – QUALITY STANDARD AS 9001/2002

Design, Manufacture and Testing

Client: Leighton Contractors	Approved By:
Project: Australia Trade Coast	Contract: Leighton Contractors / Aust. Trade Coast
Date: 1/12/04	Contract No: Q1112-SA-009
Component: Design Drafting and Commissioning	Site: Lytton Road SP 298
Unit: Generators	Technical Spec: BW 30137-02/03
	Annexure 4, Attachment 6 – Electrical Works

QP No	Section	Activity	Method or Reference	Acceptance	Inspect		
					SE	L	BW
1	Drawings	Mechanical Electrical	Specification Standard SE. Procedures	Design Intent	V <i>AL</i>	H	
2	Procurement	Engine Alternator Associated Items	Drawings and Acceptance Practise	Meets Specification and Drawing Components	V <i>AL</i>		
3	Manufacturing	Skid Base Enclosures Switchboard	Drawings and Acceptance Practise	Meets Specifications and Drawing Components	V <i>AL</i>	W	
4	Painting	Skid Base Enclosures Switchboard	Specification	Physical Check	V <i>AL</i>		
5	Assembly	Skid Base Enclosures Switchboard	SE Procedures	Specification SE Power drawings	V <i>AL</i>	H	
6	Testing	Generator Unit	ITR (Factory Test Sheets)	Specification SE Power drawings	V <i>AL</i> 16/12	H <i>AL</i> 16/12	HW <i>AL</i> 16/12
7	Delivery Site Testing	Place on slab Site acceptance testing	SP 298 SE SAT Document	As Per Leighton Requirement Specification SE SAT Document acceptance	V	H	

Symbols, Abbreviations, Definitions		
O	Operational Activity	V Verification
BW	Brisbane Water	W Witness Point
SE	S.E. Power Equipment	W Work Instruction
L	Leighton Contractors PL	QP Quality Procedure
		RC Release Certificate
		Hold Point Client Must Inspect
		Witness Point Notify Client of option to inspect item.



RETURN TO OFFICE

[illegible]

PROCEDURE: FUEL TANK

- 1 SEAL IN FUEL DRAIN PLUG
- 2 BLANK ALL HOLES AND ORIFICES
- 3 SCREW IN PRESSURE REGULATOR & VALVE
- 4 APPLY AIR TO VALVE AND ENSURE TANK
PRESSURE
- 5 REMAIN CONSTANT
- 6 DO SOAPY WATER TEST
- 7 CHECK ALL WELDS
- 8 RECORD IN ABOVE

PROCEDURE: PIPE TEST PRESSURE

- 1 BOLT 2 PIPES TOGETHER WITH GASKETS
- 2 CAP BOTH ENDS USING GASKETS
- 3 SCREW IN PRESSURE REGULATOR
- 4 APPLY AIR AND SET PRESSURE REGULATOR
- 5 SPRAY SOAPY WATER TO ALL WELDS
- 6 RECORD ABOVE



BASE TANK FABRICATION CHECKLIST

SP-298

Form 011

1	Check drawings	✓	Fuel - P/U and delivery socket	✓
2	Tack perimeter	✓	- fill point	✓
3	Check sizing	✓	- gauge	✓
4	Weld frame	✓	- breather	✓
5	Weld tank sheets	✓	- level switches	✓
6	Test tank SEPE Form 0078	✓	- drain	✓
7	Weld ancillary gear	✓	- bung drain	✓
8	Remove all splatter and clean up	✓	- locking point	✓
9	Remove sharp edges	✓	A/V Mounting	✓
10	Check all sockets	✓	Battery tray	✓
11	Have bungs installed	✓	Canopy bolt down holes	✓
12	Weld on SP No to RH Rear	✓	Switchboard mounting	✓
	bottom flange		Earth studs	✓
			Bolt down holes	✓
			Lifting lugs	✓
			Radiator stools	✓
			Tie back plates	N/A
			Cable tray stools	✓
			Ready for Painting	✓
			Colour: <i>MIST GREEN</i>	✓
			Type - Spray 2Pack	
			- Powdercoat	✓
			Special	



ENCLOSURE FABRICATION PROCEDURE CHECKLIST

SP 298

Form 012

Item	Procedure	Complete	Details	Complete
1	Check drawings and plan cutting sizes	✓	Check O/A Dimensions	✓
2	Wall Panels - Cut punch notch fold	✓	throughout fabrication	✓
3	Weld corners and clean up	✓	Captivated hoold down bolts	✓
4	Assemble and stand up panels	✓	Oil drain socket	✓
5	Weld and clean up	✓	Silencer mounting	✓
6	Gables and roof panels	✓	Door switch plates	✓
7	Doors and louvres	✓	Door catch plates	✓
8	Air ducts - exhaust penetration through roof	✓		
9	Check all welds	✓		
			Ready for painting.	✓
			Colour: <i>Mist Green</i>	✓
			Type - Spray 2 Pack	
			- Powdercoat	✓
			Special	



JOHN DEERE Engine		STAMFORD Alternator		
Model: 6068 T Serial No: 752250		Model: VCI 274H Serial No: X04H320265/1		
Item	Procedure	Complete	Details	Complete
1	Record serial numbers above	✓	Mount if Required:	
2	Check correct SAE	✓	- magnetic pick up	✓
3	Clean bolting flanges and drive plates	✓	- fuel filter	✓
4	Obtain correct bolts and washers	✓	- fuel pump	✓
5	Position and bolt together	✓	- governor/actuator	✓
6	Replace guards and covers	✓	- oil temp sender unit	✓
7	Stick safety labels and Ser# plate to alternator	✓	- oil temp warning switch	✓
8	All bolts are secure and tensioned correctly	✓	- water temp sender unit	✓
9	Touch up damaged paint work	✓	- oil temp shutdown switch	✓
			- switch gauges	✓
			- water level switch	✓
			- relay mount plate	✓
			for electricians	
			- exhaust guard if reqd	✓
AS - Std SE Power Procedure				
- Specification: _____				
Approved: _____		QA Inspected: _____		

Item	Procedure	Complete	Electrical	Complete
1	Check paint work	/	Bolt switchboard to stand	/
2	Cover paint on floor area	/	DC Engine wiring	/
3	Select A/V mounts	/	AC Engine wiring	/
4	Bolt down Eng/Alternator	/		
5	Fuel - P/U and Return tubes	/		
	- Flex lines	/		
	- Breather pipe	/		
	- Fill pipe and cap	/		
	- Level gauge	/		
	- Level Switches LOW	/		
	- Level Switches EMPTY	/		
6	Battery - Mount and clamp	/		
	- Cover	/		
	- Isolator switch	/		
	- Leads	/		
7	Cable Tray	/		
8	Seal drain bung	/		
9	Bolt to skid rails	/		
10	Mount switch board stand	/		


Item	Procedure	Complete
1	Clean out cavities	/
2	Cut and position insulation	/
3	Mount muffler	/
4	Wrap with high temp insulation	/
5	Cut and rivet perf sheets	/
6	Insulate and perf doors	/
7	Door seal and rubber on openings	/
8	Swing doors	/
9	Position splitters if required	N/A
10	Position plenum wall	/
11	Electrical - A. Power	/
	- B. Lights	/
	- C. Door Sw	/
	- D. Solar panel	/
12	Tape base to accept enclosure	/
13	Lift and position on base	/
14	Tighten hold down bolts	/
15	Check door operation	/
16	Mount door catches	/
17	Mount door open catches	/
18	Complete exhaust rain hood	/
19	Rain flap	/
20	Exhaust protection cage	/
21	Screw in louvre blades	/
22	Exhaust flex and piping to engine	/
23	Exhaust lagging inside canopy	/
24	Hook for S/B key	/
25	Hook for lead light	/
26	Fill in cable entry through wall	/
27	Serial # Tags	/
28	SE Stickers	/

Leighton Contractors


Project 14860

SP299

SPEED SWITCH




AVSR




GAC SPEED CONTROL


Gain




Stability



Droop



Idle





ELECTRICAL FUNCTION TEST SHEET **AS 3000 WIRING RULES** **Form 016**

CLIENT: LEIGHTON CONTRACTORS SP298
 SERIAL NO: 0412002
 ENGINE TYPE: 6068T
 ALTERNATOR TYPE: UCI 274 H
 CONTROLLER TYPE: _____

DATE: 10-12-04 / 16-12-04
 JOB NO: 14860
 ENG. SERIAL NO: 752250
 ALT. SERIAL NO: X04H320265/1

GENERATOR CONTROL FUNCTIONS	CODE	COMMENTS
CB Tripped / Alt. Overload		MANUAL TEST ONLY.
Genset Running	✓✓	
MEN Fault	✓✓	
Remote Start / Stop	✓✓	
Engine High Temp. Alarm	✓✓	
Engine High Temp. Shutdown	✓✓	
Low Water Level Alarm	✓✓	
Low Oil Pressure Alarm	✓✓	
Low Oil Pressure Shutdown	✓✓	
Start Fail Alarm	✓✓	
Status Lamps / Controls	✓✓	
Emergency Stop	✓✓	
Lamp Test	✓✓	
Fuel Low	✓✓	
Fuel Empty	✓✓	
Starter Motor Relay	✓✓	
Underspeed Shut Down	✓✓	
Overspeed Shut Down	✓✓	
Alarm Shut Down	✓✓	
Alt. Undervolts	✓✓	
Alt. Overvolts	✓✓	
Charger AC Failed	✓✓	
Control Batt. Low Volts	✓✓	
Start Batt. Low Volts	✓✓	
Engine Gauges	✓✓	
Enclosure Doors Open	✓✓	
Alternator High Temperature	NA -	
Audible Alarm / Mute	✓✓	
Remote ATS Controls	✓✓	

Code:

☐ = Data Recorded

N/A = Not Applicable

N/C = Not Compliant

Signed: _____

Technician Name: PAUL HLAUKA

Hayden Roth


[illegible]

Skid Base Assembly		
1	Welds continuous, neat and clean	✓ ✓
2	Bolts tightened	✓ ✓
3	Bearers completely secured	✓ ✓
4	No sharp corners	✓ ✓
5	Walkway mesh secured (if applicable)	NA
6	Levelling bolts supplied and tightened (if applicable)	
7	Inlet/outlet pipes blanked off for transport (if applicable)	
Engine Assembly		
1	Engine and fan correctly mounted	✓ ✓
2	Guards in place and secured	✓ ✓
3	Wiring looms securely fixed	✓ ✓
4	Magnetic pickup fitted and set to correct depth	✓ ✓
5	Exhaust pipe and silencer fitted correctly (if applicable)	✓ ✓
6	Dip stick in place	✓ ✓
7	Oil removed from engine	yes / no
8	Fuel and oil unions tightened	✓ ✓
9	Ancillary equipment fitted and labelled correctly	✓ ✓
10	Inlet/outlet flanges blanked off for transport	✓ ✓
11	Instrument panel securely fitted and labelled	✓ ✓
12	Cables and hoses secured for transport	✓ ✓
13	Oil/water leakage around the engine cleaned up	✓ ✓
14	Ancillary equipment secured for transport (if applicable)	✓ ✓
15	Batteries disconnected for transport (if applicable)	NA - IS
16	Air cleaner is properly mounted	✓ ✓
Alternator Assembly		
1	Alternator correctly mounted	✓ ✓
2	Alternator leads correctly mounted inside terminal box	✓ ✓
3	AVR mounted, connected properly and correctly set	✓ ✓
4	Earth stud fitted	✓ ✓
5	Coupling and adaptor properly fastened	✓ ✓
6	Cable box extension secured (if applicable)	
Radiator Assembly (Engine mounted/boose supply)		
1	Mounted bolts tightened	✓ ✓
2	Clamps on hoses tightened	✓ ✓
3	Ancillary equipment fitted and labelled correctly	✓ ✓
4	Drain plug and filter cap in place	✓ ✓
5	Wiring of ancillary control equipment securely fixed	✓ ✓
6	Water and inhibitor filled	yes / no
7	Electric wiring securely fixed (if applicable)	✓ ✓
8	All flanges fitted (if applicable)	✓ ✓



FINAL INSPECTION TEST SHEET GENERATING SET ASSEMBLY Form 017

9	Inlet/outlet flanges blanked off for transport	
Electrical Control Assembly		
1	Wiring properly terminated and numbered	✓✓
2	Control equipment mounting bolts tightened	✓✓
3	Equipment labels properly fixed	✓✓
4	Ancillary equipment fitted and labelled correctly	✓✓
5	Dust seals correctly fitted around doors	✓✓
6	Door hinges correctly fitted	✓✓
7	Door locks/keys provided	N/A
8	Internally cleaned or vacuumed	✓✓ + FWH
Paint Finish (generating set assemblies)		
1	Plant painted to specification	✓✓
2	Any blemishes removed or rectified	✓✓
3	Touch up paint match original colour	✓✓
Generating Set Enclosure		
1	Plant painted to specification	✓✓
2	Any blemishes removed or rectified	✓✓
3	Touch up paint match original colour	✓✓
4	Main label fitted	✓✓
5	Doors, locks and keys satisfactory	✓✓
6	Glass windows secured for transport	—
7	Cable gland plate fitted	✓✓
8	All loose equipment removed from inside	✓✓
9	Serial number tag fitted	✓
Other loose equipment (loose supply)		
1	Equipment removed from assemblies	(yes) no
2	Additional equipment to be transported	yes / no
3	Equipment properly packaged and/or shrink wrapped	yes / no
4	Any special transport markings fitted	yes / no
5	Any special documentation attached	yes / no

S E Power Equipment QA Officer:  Date: 16-12-04

Client Representative (if required): Date:



FACTORY LOAD TEST REPORT

Form 018

CLIENT: BRISBANE WATER SP298 DATE: 14-12-04 / 16-12-04
 SERIAL NO: 04 12 002 JOB NO/CONTRACT NO: 14860
 ENGINE TYPE: 6068T ENG. SERIAL NO: 752250
 ALTERNATOR TYPE: UCI 274 1H ALT. SERIAL NO: X 04H 320265/1
 GOVERNOR TYPE: G.A.C. CONTROLLER TYPE: _____
 OVERSPEED TYPE: G.A.C. UNDERSPEED TYPE: _____
 SHUTDOWN SOLENOID: G.A.C. ENGINE SHUTDOWN TEMP: _____
 LOW OIL PRESSURE SHUTDOWN: H03BS
 KVA: 133 (132+10%a) KW: 106 A @ UNITY PF: *8

TIME	1130	1145	1215	1245	1315	1000	RESTANT	1130	1200	1230	130
OIL PRESSURE	500	300	280	280	250	400	300	280	250	250	
OIL TEMPERATURE											
JACKET WATER TEMPERATURE	0	85	85→	85→90	90	70	80	85→90	90	90	
AMPS	0	70	100	139	150	44	70	100	139	150	
VOLTS LINE	240	240	240	240	240	240	240	240	240	240	
PHASE	415	415	415	415	415	415	415	415	415	415	
AMBIENT TEMPERATURE	35	35	35	35	35		28/30	30	30	30	
Hz	50	50	50	50	50	50	50	50	50	50	
LOAD%	0	50%	75%	100%	110%	25+%	50%	75%	100%	110%	
BATTERY VOLTAGE CURRENT						DRUMMER SHUT DOWN					
						RUN					

Code:

□ = Data Recorded

N/A = Not Applicable

N/C = Not Compliant

Signed: *Paul Hlavka*Technician Name: PAUL HLAVKA

1) SHUT DOWN ENGINE TO COMPLETE TESTING OF SP298



TRANSIENT LOAD RESPONSE TEST SHEET Form 019

TRANSIENT LOAD RESPONSE TEST SHEET

Transient Response for Load Changes: Load pf 0.8

% Change Electrical kW	0-25	0-50	0-75	0-100
Change in Electrical kW				
% Change Hz	.4	.8	.8	.8
% Change Volts	0	2	4	7
Recovery Secs	1	2	2	3


% Change Electrical kW	100-0	75-0	50-0	25-0
Change in Electrical kW				
% Change Hz	.6	.2	.2	.2
% Change Volts	.6	3	1	0
Recovery Secs	2	1	1	1



SOUND PRESSURE LEVEL FACTORY TEST REPORT

Form 020

CLIENT: LEIGHTON CONTRACTORS DATE: 16-12-04
 JOB NO: 14680 JOB TYPE: 14860
 ENGINE TYPE: JP 6068T ALTERNATOR TYPE: UCI 274 E
 SOUND PRESSURE LEVEL REQUIRED 70 dbA @ 7 m



POSITION	NO LOAD				POSITION	FULL LOAD			
	1m	3m	5m	7m		1m	3m	5m	7m
A					A	76			69
B					B	76			67
C					C				
D					D				

TESTING OFFICER: Paul Hlavka

TESTING TO BE COMPLETED ON SITE



FLASH
FLASH ET

Instructions English

CE ELECTREX hereby declares that its range of products complies with the EMC requirements of Directive 89/336/EEC and also the requirements regulating the energy measurement instruments CEI EN 61326.

1 SAFETY

This instrument was manufactured and tested in compliance with class 2 IEC 1010 and VDE 411 standards, in accordance with group B VDE 0110 standards for operating voltages lower or equal to 250 VACrms phase neutral.

In order to maintain this condition and to ensure safe operation, the user must comply with the indications and markings contained in the following instructions:

When the instrument is received, before beginning installation, check that it is still intact and no damage was incurred during transport.

Ensure that the operating voltage and mains voltage set are the same and then proceed with installation.

The power supply must not be earth connected.

The instrument is not fitted with a protection fuse on the power supply, thus the installer must care for the protection.

Maintenance and/or repairs must be carried out only by qualified, authorized personnel. If there is ever the suspicion that safe use is no longer possible, the instrument must be taken out of service and precautions taken against any accidental use.

Operation is no longer safe when:

- 1) There is clearly visible damage.
- 2) The instrument no longer functions.
- 3) After lengthy storage in unfavorable conditions.
- 4) After severe damages incurred during transport.

1.1 OPERATOR SAFETY

Read these instructions carefully before installing and using the instrument

The instrument described in this user manual is intended for use by properly trained staff only. Maintenance and/or repairs must be carried out only by authorized personnel.

For proper, safe use of the instrument and for maintenance and/or repair, it is essential that the persons instructed to carry out these procedures follow normal safety precautions.


1.2 SYMBOLS

READ THE INSTRUCTION



1.3 POWER SUPPLY

The instrument is fitted with a separated power supply with extended functioning range. The terminals for the power supply are numbered (13 and 14). Max 2,5 mm² cross-section cables must be used.




2 VOLTAGE AND CURRENT MEASUREMENT CONNECTIONS


Use cables with max cross-section of 2,5 mm², attach them to the terminals marked with VOLTS INPUT according to the below diagrams. It is necessary to use 3 CT with 5A secondary.

Connect the CT amperometric signal to the terminals marked with CURRENT INPUT according to the below diagrams. Use cables with a cross-section adequate to the CT output and to the distance to be covered. The terminals max cross-section is 2,5 mm². *N.B. The CT secondary must always short circuit when it is not connected to the instrument to avoid damages and risks for the operator.*


THE PHASE RELATIONSHIP AMONG VOLTAGE AND CURRENT SIGNALS MUST BE CAREFULLY RESPECTED. Disregard of this rule or of the wiring diagram will result in measurement error.



Delta Connection with 2 CTs




Delta Connection with 3 CTs




3 FIXING AND LOCKING

The connection terminals of the instrument are held in place by a plastic panel, which must be mounted using four screws (supplied). This set-up will prevent the disconnection of the current measurement terminals.



4 PULSE OUTPUT

The instrument is fitted with two impulse outputs proportional to the active and reactive power. The max cross-section of the cables to be used is 1,5 mm². Max values 27 Vdc 27 mA. The output location is described in figure.



Rev. 04/04






FLASH
FLASH ET

Instructions English

5 PROGRAMMING MODE

The procedure of instrument's programming allows to set-up the functions' parameters. To access the programming pages a button 'Program' is available at the instrument rear.



With this button it is possible to move from a field to another of a page and then move to next page.

With these 2 buttons it is possible modify the blinking selected field.

On define field either a functioning parameter or a numerical field.

With this button it is possible to move next page.


With this button it is possible to go back previous page.

Pressing again the button 'Program' to exit the Set-up allows to memorise parameters.

If at the first programming page, after pressed the button 'Program', on press the button on enter the counter reset page.

If at the first programming page, after pressed the button 'Program', on press the button on enter the average power reset page and maximum demand reset page.

6 INSTRUMENT SET-UP




FLASH
FLASH ET

Instructions English


7 INSTRUMENT PROGRAMMING

First programming page allows to set-up network configuration.



At the beginning on choose between just import **In** or import-export system **I-E**.
Then the connection: 4 wires with neutral **4W**, star **A** or 3 wires without neutral, delta **3W**, triangle **A**. Default setting is **4W** and just import **In**.

Next page allows set-up Low or High Voltage and parameters of Potential and Current Trasformer.




After selecting direct **LOW** on move to page A5, otherwise selecting on move to page A5, otherwise selecting **HIGH** for Medium or High Voltage, next 2 pages allow programming primary **Pr**, and secondary **SEC** voltage transformer with reference to the values printed on VT plate.

Default setting is **LOW**.

Page A5 allows set-up primary **Pr**, and secondary **SEC** current transformer as printed on CT plate. Default setting is Pri=1 and Sec=1.

Next page allows programming the integration time (from 1 up to 60 minutes) for measure of average power and maximum demand.



Programming in the range from 1 to 60 minutes.

8 RS485 PROGRAMMING

WARNING: ALL MODIFICATIONS TO THE SETTINGS OF THE INSTRUMENT BECOME ACTIVE ONLY WHEN EXITING THE SETTING MENU WITH THE "PROGRAM" PUSH BUTTON ON THE BACK.

The COM port setting pages are following the measuring set up pages. To join them use the



push button to go on from one page to the other and the



back.


The first page is:



Where:

- E1 is the page identifier.
- 2 is the Modbus Address of the instrument (can be changed)
- 0.10 is a programmable delay in the instrument answer. It is the minimum time from request to answer.
- Modbus protocol communication.

The second page is:



Where:


- E2 is the page identifier
- 8 is the number of bit (Fixed)
- n is the parity (n, 0, E)
- 2 is the number of stop bit (1 or 2)
- 38400 is the communication baud rate (from 2400 up to 38400)

9 CONNECTING OPTIONAL COMPONENTS



All the options must be inserted with the instrument off

The options of the Flash instrument are fixed mechanically to the back anchor plate of the instrument, where are accessible the RJ45 connectors for the electrical connection. The window concerning the setting of the option characteristics appears only when one of the options is inserted in the instrument.




CN1 = 4-20 mA Module or Hardware Key
CN2 = RS485 Interface or RS232 Interface





FLASH
FLASH ET

Instructions English




10 HARDWARE KEY




The use of the hardware key allows the user to add functionalities to the instrument (for example, the key "ET UPGRADE" transforms a Flash in a Flash ET). In order to do so, once the key is inserted into the instrument off, follow the procedure:

- 1) Turn on the instrument and verify if on the display appears "UPG" (if the key is not valid, it is showed an error message "Error");
- 2) Wait for the key reading and check the residual credits number (if the number is zero on the display appears "dEniEd");
- 3) When the instrument is ready to execute the updating, on the display appears "ConFirm" blinking.

Pressing the button , the instrument enables the supplementary functions and updates the key decreasing the credits number.

NOTES: During the updating it is showed "LoAdinG". Pressing any button during the updating, it is showed "AborEd" and the instrument is not updated. If all the supplementary functions which can be enabled are already active, on the display appears "no nEEd" blinking.

11 DIMENSIONS (MM)



12 TECHNICAL CHARACTERISTICS

Display:	backlit 256 segments 63x65 mm LCD with white electroluminescent lamp.
Measurement sections:	Voltage input: 500 Vrms (max 1,7 crest factor); Input overload: 800 Vrms; max 900 Vrms for 1 second; Current Input: 5 Arms (1,7 crest factor); Input overload: 20 Arms; max 100 Arms for 1 second;
Power supply:	85-265 Vac (100-374 Vdc)
Frequency:	45-65 Hz
Accuracy:	Class 1 on the active power in compliance with CEI EN 61036; 0,5% on the voltage and current measurements; RMS up to the 31 st harmonic
Outputs:	2 digital outputs for impulse or alarms (DIN 43864 27 Vdc 27mA - 1000 Imp./kWh)
Protection level:	Front panel = IP51
Temperature Range:	from 0°C to +50°C
Humidity:	Max 90% without condensate
Counters:	power counters with resolution 0,0001 kWh up to 99.999.999.999 kWh (serial)
Mounting:	96x96mm panel



December 4, 1996

GFK-1003C

IMPORTANT PRODUCT INFORMATION

READ THIS INFORMATION FIRST

Installation Information Power Supply and I/O modules

Wire Connection Information

Wire connection information for power supply connections and I/O module connections is detailed below. Each terminal can accept solid or stranded wires, but the wires into any given terminal should be the same type and size.

Power Supply

Use one AWG #14 (2.1 mm²) or two AWG #16 (1.3 mm²) copper conductors rated for 75 degrees C (167 degrees F) only. The suggested torque for the power supply terminal board is 12 in-lbs (1.36 Nm).


I/O Modules

All IC693 I/O terminal boards have 20 screw terminals and will accept from two AWG #22 (.35 mm²) to one AWG #14 (2.1 mm²) or two AWG #16 (1.3 mm²) copper wires rated for 90 degrees C (194 degrees F) only. The suggested tightening torque for the terminal boards ranges from 9.6 to 11.5 in-lbs (1.09 Nm to 1.3 Nm). Wires are routed to and from the terminals out of the bottom of the terminal board cavity.


Overvoltage Protection Devices for AC/DC Power Supplies

Applicable to IC693PWR321 and IC693PWR330. The overvoltage protection devices (MOVs) for this power supply are connected internally to pin 4 (fourth screw from top) on the user terminal board. ***This pin is normally connected to frame ground (pin 3) with the supplied jumper strap which is installed at the factory.*** If overvoltage protection is not required or is supplied externally, this feature can be disabled by leaving pin 4 unconnected by removing the jumper strap. If you require Hi-pot testing of this supply, overvoltage protection ***must be disabled*** during the test by removing the terminal board strap. Re-enable overvoltage protection after testing by reinstalling the strap.

For more information on Hi-pot testing, contact the PLC Technical Support Hotline at 1-800-GE FANUC (1-800-433-2682), or International direct dial 804-978-6036.



Overvoltage Protection Devices and Jumper Strap



DEEP SEA ELECTRONICS PLC

5103/5

BATTERY
CHARGER

DESCRIPTION

The model 5100 series 3 Amp and 5 Amp **battery chargers** are designed for permanent connection to automotive batteries, maintaining them in a fully charged condition without overcharging. The chargers are also capable of rapidly recharging the batteries at a current up to the full rated output. The charger may also be used to supply a standing load attached to the battery. The charger output may be factory set to account for the standing load.

The charger is designed for reliability, ease of installation and accessibility during routine servicing. It features radio frequency suppression and its smooth output **linear mode design** has a low ripple voltage making the charger suitable for use with electronic equipment.

The charger has both **Overload** and **Short Circuit protection** features, achieved by limiting the current to a safe value during these conditions. It will automatically recover after the condition is removed.

If a short circuit or a severe overload is applied such that the voltage falls below four volts for longer than 10 seconds, then the **Charge Fail Alarm** relay will energise and the charge fail contact will close.

If the charger is inadvertently reverse connected to the battery then the fuse-link on the circuit board will rupture. This should be replaced with a 10A quick blow type.

The **electronic control** circuit ensures that the charger can remain operating during engine cranking and running, operating in parallel with the charge alternator where necessary.

The charger features a **boost charge** facility to enable rapid recharging of discharged batteries or to allow periodic equalisation of battery cells. When the 'boost mode select' terminals are connected together the charger output will rise by 0.35V per cell.




CAUTION!

Boost mode must only be used in accordance with the battery manufacturers instructions otherwise cell damage or an increased maintenance requirement will occur.



Note

The 'Charger On' LED will illuminate even if the fuse has ruptured.



SPECIFICATION

DC OUTPUT:

12 V DC or 24V DC Nominal
(specified on ordering)

AC INPUT:

220 - 250 V AC 50/60Hz (Specified on ordering)

OUTPUT CURRENT:

3Amps or 5Amps electronically limited

(specified on ordering).

OPERATING TEMPERATURE

RANGE:

-10 to +60°C

INDICATIONS:

'Charger On' LED.

PROTECTIONS:

Short Circuit, Over Voltage,
Over-current, Reverse Polarity,
Reverse Power


BOOST MODE:

+0.35V per Cell above Float voltage.


OPERATION:

The charger will supply current to the battery until the battery terminal voltage is equal to the set float voltage, at which point only a trickle charge current is present. When the battery voltage falls due to a load being applied and the battery being discharged, the charger will once again supply current to restore the voltage of the battery to the float voltage.

CASE DIMENSIONS



TYPICAL CONNECTIONS



Battery Type	12Volt	24Volt
Lead Acid	13.7V	27.4V
Planté	13.5V	27.0V
Sealed Lead Acid	13.6V	27.2V
Nicad (9 or 18 Cells)	13.0V	26.0V
Nicad (10 or 20 Cells)	14.5V	29.0V

(These are standard settings. Please ensure that the quoted values are suitable for the intended battery. Refer to battery manufacturer for details.)

Deep Sea Electronics plc
Highfield House, Hunmanby Industrial Estate, North Yorkshire, YO14 0PH, England
Tel: +44 (0) 1723 890099 Fax: +44 (0) 1723 893303 E-mail: sales@deepseapl.com



Brisbane Water

Projects Branch
Australia Trade Coast Sewer project

Factory Inspection Test

Testing Document

Test for

Generators

SP 298 & SP 299

Test Date:	
Project Manager:	Andrew Bannink
Construction Manager:	
Inspector:	Peter Rennex
Contract Number:	
Contractor:	SE Power/ LCPL
Test location:	SE Power

1 Factory Test

1.1 **Fire safety**

- Provide all necessary PPE (Personal Protective Equipment) and tools to carry out the works **safely** and comply with all relevant Australian Standards, Workplace Health and Safety requirements. The followings are minimum requirements for safety, but not limited to:-
- Carry out and document a Hazard/Risk Assessment, followed by a JSA (Job Safety Analysis) and then develop a SWP (Standard Work Procedure) prior to undertaking works.
- Obtain all the necessary work permits prior to works being carried out.

Task	Outcome		
1/ PPE in Place Includes mat, Rescue bag, Safety Shoes, Safety Glasses, Long clothing	OK	No	N/A
Notes:	X		

1.2 **Safety signs**

Task	Outcome		
Inside of both engine compartment doors to read "hearing protection to be worn when engine is running"	OK	No	N/A
Sign or stencil to be placed on the floor indicating there is (xxxx litres) of diesel under the floor.	OK	No	N/A
Batteries are to be located away from fuel filling points.	OK	No	N/A
Diesel fuel filler point to be indicated as such i.e., "Fuel Filler Point".	OK	No	N/A
Catches are to be fitted to main unit access doors to hold doors open while personnel are working inside unit. The open doors will provide for personnel working inside the unit, including light, ventilation and visibility of personnel from outside the unit.	OK	No	N/A
A sign shall be fitted to the main unit access doors "Open and Secure both doors while working inside this unit".	OK	No	N/A
Install a sign on the engine manifold advising "Warning surface may be HOT".	OK	No	N/A
Place a sign in clear sight of a person opening the doors of the unit "Warning this machine starts automatically and remotely".	OK	No	N/A
Alarm to be fitted to warn of imminent start up (with mute button).	OK	No	N/A
An Emergency Stop Button to be installed within reach from either side of the engine	OK	No	N/A

A standard Brisbane Water electrical switchboard warning sign is to be attached to the outside of the switchboard compartment. This sign provides Brisbane Water ID and phone number.

OK	No	N/A
	X	

Notes:

Alarm does not activate as a notice to starting of unit. Is this operationally required as most units are within residential areas

1.3 Other

Task	Outcome		
The switchboard compartment must totally preclude access to by unauthorised personnel, i.e., children playing or the like.	OK	No	N/A
		X	
The engine exhaust shall have a cage placed over the exhaust to preclude materials being placed inside the exhaust. This cage to be same colour as genset acoustic enclosure	OK	No	N/A
	X		
Covers over Litto-Vearn powerlock sockets (might not be in Leightons spec, but we need them anyway)	OK	No	N/A
		X	
No provision for drawings in Sw/bd. (drawing Pocket	OK	No	N/A
		X	
Outlet issues - 10 amp inlet socket / 15 amp GPO's (Equipment to be fit for purpose Clause 2.2 AS3000	OK	X	N/A
Fuel lines across sharp edges.	OK	No	N/A
	X		
Have Approved Design Changes been accepted by Brisbane Water Projects and Networks	OK	No	N/A
	X		
Notes: See Defects List Below			

1.4 Testing

Task	Outcome		
Noise test	OK	No	N/A
		X	
Load test	OK	No	N/A
	X		
Transient load	OK	No	N/A
	X		
Fuel tank and filler	OK	No	N/A
	X		

Notes:

Testing to be completed on site

Fuel tank and filler checked to be accessible and fully sealed. Breather from the fuel tank needs to be larger

1.5 Point to Point Inspection

Task	Outcome		
Is a copy of contractors point to point test available.	OK	No	N/A
		X	
Note (copy must be sited and given to Electrical inspector prior to Test)			
Notes:			
Copy's or inspection documents not provided or sighted			

1.6 Cabinet Inspection

Task	Outcome		
Date of Metal work inspection...../...../.....			
Inspector.....			
Check IP Rating (Contractor to provide)	OK	No	N/A
			X
Check for tightness on Bolts	OK	No	N/A
	X		
Is the cabinet as per construction drawing	OK	No	N/A
	X		
Are all cabinet locks as per Brisbane water spec	OK	No	N/A
		X	
Notes:			
Locks on doors not supplied			

1.7 Welding

Task	Outcome		
Is all welding as per spec	OK	No	N/A
	X		
Notes:			

1.8 Labelling and Indication

Task	Outcome		
	OK	No	N/A
All cores Using correct Ferruls		X	
Is all Labelling as per spec		X	
Check all indication lamps for correct colour and operation	X		
Notes:			

1.9 Settings

Task	Outcome		
	OK	No	N/A
List all settings on all components			
To Be provided By SE Power			
Notes:			

1.10 Defects Factory Test

List all Defects:

Within Contract

- All OHS Labels as per Qld WH&S legislation. These include Hearing Protection signs
- Exhaust Flap Sticking Open
- Padlocks on Doors and filling Points not in place
- Coolant Leaking during test causing high engine temp alarm
- Air Bleed pipe from Fuel tank to small needs to be larger to prevent/ Minimise Blow Back
- Labelling incorrect (spelling)
- GPO's in engine bay should be 10amp not 15 Amp
- No Labelling on Cables coming from CB 12 and 13
- No label to prevent Non Authorised persons as defined under the Electrical Safety Act from opening the switch board
- Internal Lighting must have battery Back up. I do not believe the current Main Battery supply is acceptable as if battery removed the lighting will not operate

Non contractual

- Inside of both engine compartment doors to read "hearing protection to be worn when engine is running"
- Sign or stencil to be placed on the floor indicating there is (xxxx litres) of diesel under the floor.
- Diesel fuel filler point to be indicated as such i.e., "Fuel Filler Point".
- A sign shall be fitted to the main unit access doors "Open and Secure both doors while working inside this unit".
- Install a sign on the engine manifold advising "Warning surface may be HOT".
- Place a sign in clear sight of a person opening the doors of the unit "Warning this machine starts automatically and remotely".
- Alarm to be fitted to warn of imminent start up (with mute button).
- An Emergency Stop Button to be installed within reach from either side of the engine.
- A standard Brisbane Water electrical switchboard warning sign is to be attached to the outside of the switchboard compartment. This sign provides Brisbane Water ID and phone number.

Access to the following:

- The switchboard compartment must totally preclude access to by unauthorised personnel, From under the switchboard area
- Covers over Litto-Veam powerlock sockets (might not be in Leightons spec, but we need them anyway)
- Outlet issues - 10 amp inlet socket / 15 amp GPO's (Equipment to be fit for purpose Clause 2.2 AS3000.
- No provision for drawings

Notes:

Note:**Construction Manager**

All defects to be notified to contractor using **PM-04E** for Contractual defects and **PM-04F** for non Contractual Defects


End of Factory test

Factory Test

Date of Test	
Electrical Inspector	
Pass / Fail	
Defects to be rectified By	
Contractor Sign:	
Date:	

Factory Test

Defects Issued:	Date:
	Sign:
Defects Rectified:	Date:
	Sign:



Main Switch Board




Connection Plugs




Indication Panel




Penetration Holes from engine to Generator




engine bay




Fuel Filler



No Labels on Cables



Insufficient protection



No entry exclusion





Leighton Contractors Pty Limited
ACN 000 893 667

Stanwell Magnesium Plant
50 Park Road, Milton QLD 4064
PO Box 217
Albion BC QLD 4010
Telephone: (07) 3367 5700
Facsimile: (07) 3367 5799
E-mail: smp@smgproject.net

To: Brisbane Water
TC Beirne Centre - L2 - 315
Brunswick St Mall

Transmittal No: 003928487
Date: 9 December 2004

Page 1 of 1

FORTITUDE VALLEY, QLD 4006

Ph/Fx

Attn: Reg McGirr

Transmitted by: Courier
Reason for issue: Issued for Information
Transmitted herewith are the following: Disk

Item	Doc ID	Document No	Rev	Phase	Title	Copies
1.		Disk			Standby Generator Software on disk	1

Comments: ** CONTRACT: BW 30137-02/03**

STANDBY GENERATOR SOFTWARE (ON DISK)

REFER ANY QUERIES TO: Frank Mitchell
Ph: 07 3367 5771 Fax: 07 3367 5799 E-mail: smp@smgproject.net

PLEASE ACKNOWLEDGE RECEIPT BY SIGNING, DATING AND RETURNING A COPY OF THIS TRANSMITTAL.

Yours faithfully

Receipt Acknowledged and Date


M West
Leighton Contractors Pty Ltd


Reg McGirr
Brisbane Water

14 December 2004

 *** TX REPORT ***

TRANSMISSION OK

TX/RX NO 2079
 CONNECTION TEL 033675799
 SUB-ADDRESS
 CONNECTION ID
 ST. TIME 14/12 14:36
 USAGE T 00'13
 PGS. 1
 RESULT OK



Leighton Contractors Pty Limited
 ACN 000 893 667
 Stanwell Magnesium Plant
 50 Park Road, Milton QLD 4064
 PO Box 217
 Albion BC QLD 4010
 Telephone: (07) 3367 5700
 Facsimile: (07) 3367 5799
 E-mail: smp@smgproject.net

To: **Brisbane Water**
 TC Beirne Centre - L2 - 315
 Brunswick St Mall

Transmittal No: 003928487
 Date: 9 December 2004

Page 1 of 1

FORTITUDE VALLEY, QLD 4006

Ph/Fx

Attn: Reg McGirr

Transmitted by: Courier
 Reason for issue: Issued for Information
 Transmitted herewith are the following: Disk

Item	Doc ID	Document No	Rev	Phase	Title	Copies
1.		Disk			Standby Generator Software on disk	1

Comments: ** CONTRACT: BW 30137-02/03**

STANDBY GENERATOR SOFTWARE (ON DISK)

REFER ANY QUERIES TO: Frank Mitchell
 Ph: 07 3367 5771 Fax: 07 3367 5799 E-mail: smp@smgproject.net

PLEASE ACKNOWLEDGE RECEIPT BY SIGNING, DATING AND RETURNING A COPY OF THIS TRANSMITTAL.

Yours faithfully

Receipt Acknowledged and Date

M West
 Leighton Contractors Pty Ltd

Reg M McGirr
 Brisbane Water

14 December 2004

2.3



Brisbane Water
Cathodic Protection System Manual

BRISBANE WATER
CATHODIC PROTECTION SYSTEM MANUAL
FOR
SP298 LYTTON RD SEWERAGE PUMP STATION.

CONTENTS

1.0	Introduction.....	3
2.0	Corrosion and Cathodic Protection.....	3
3.0	Pump Details.....	4
3.1	Size:.....	4
3.2	Coating:.....	4
3.3	Length:.....	4
3.4	Location:.....	4
3.5	Construction Drawings:.....	4
4.0	CATHODIC PROTECTION DETAILS.....	4
4.1	Type of Cathodic Protection:.....	4
4.2	Rectifier:.....	4
4.3	Cathode:.....	4
4.4	Anodes:.....	4
4.5	Test Points:.....	4
4.6	Associated Drawings:.....	5
4.7	Associated Standards:.....	5
4.8	Government Regulations:.....	5
5.0	Performed Testing.....	5
6.0	Conclusion.....	5
7.0	Maintenance.....	5
8.0	Potential Commissioning Data.....	6
	Appendices.....	7
	Appendix A:.....	7
	• Structure potential levels (Form 37).....	7
	• Loop potentials.....	7
	• Standard cathodic protection unit Drg # xxxxxxxxx.....	7
	• Submersible pump station general layout Drg #xxxxxxx.....	7
	Appendix B:.....	7
	• Photos.....	7

1.0 INTRODUCTION.

Steel when immersed or covered in water has a tendency to corrode (or rust) as the oxidised form is more stable than the metal.

Because of this, precaution must be taken to stop or minimise the corrosion reaction to an acceptable level consistent with the design life of the structure. This is normally achieved by the use of protective coatings that control the corrosion reaction by isolating the steel from its surrounding environment.

However, it is not practical to achieve a perfect coating and coating damage will always occur with time. Because of this, corrosion may occur at imperfections in the paint coating, causing further deterioration in the coating as well as loss of metal.

As a result of this, periodic maintenance or an additional method of protection used to prevent this deterioration and corrosion occurring must rectify the coating defects. This additional protection is achieved by the cathodic protection system.

2.0 CORROSION AND CATHODIC PROTECTION.

Corrosion is an electrochemical process in that it is accompanied by a flow of electrical current.

Corrosion occurs on the surface of metals at active areas known as anodes, which are electrically continuous with less active or passive areas known as cathodes. The electric current flows from the anode through the electrolyte to the cathode, with the circuit being completed by the electrical continuity between the cathode and anode. In practice anodes and cathodes are generally part of the same metallic surface and individual anodic areas may be small.

In applying cathodic protection an external current is applied to the surface so that the entire surface to be protected acts as a cathode. This involves the use of an auxiliary anode and when the current flow from this anode is sufficient, no part of the structure acts as an anode.

An external source of direct current such as a transformer rectifier is used in conjunction with an anode consisting of material with a very slow corrosion rate.

While it is the flow of current which achieves the cathodic protection of the surface it is impractical to measure these currents over individual anodic areas to determine when cathodic protection has been achieved. However, with the flow of cathodic protection current, the structure becomes more negative with respect to the surrounding electrolyte. Because of this, it is possible to state values of metal/electrolyte potential at which corrosion does not occur. This metal/electrolyte potential is generally measured against a standard reference electrode which allows a reproducible potential at which corrosion does not occur to be quoted.

3.0 PUMP DETAILS.

3.1 SIZE:

2 X 68.0 kW submersible pumps.

3.2 COATING:

Enamel coated.

3.3 LENGTH:

N/A

3.4 LOCATION:

Lytton Road Lytton UBD 142 L13

3.5 CONSTRUCTION DRAWINGS:

486/5/25- S101: Standard Sewerage Pump Station Cathodic Protection Unit.

4.0 CATHODIC PROTECTION DETAILS

4.1 TYPE OF CATHODIC PROTECTION:

Impressed Current.

4.2 RECTIFIER:

Standard 24 Volt, 5.0 amp direct current output enclosed board inside the stainless steel switchboard. Rectifier has a 240V supply from the stainless steel switchboard distribution panel.

4.3 CATHODE:

The cathode point is located on the pump motor, the ladder and the pipes. Two zinc reference are fitted to the pipes in the well and one near the ladder. The cathode point is where the cabling from the rectifier is attached to the structure under cathodic protection.

4.4 ANODES:

One silicone iron anode is suspended from the roof of the well.

4.5 TEST POINTS:

Test points are installed on cathodically protected structures to enable testing to ensure full protection of the pumps and pipes. On these pumps and pipes test points have been brought out to the cathodic protection switchboard.

4.6 ASSOCIATED DRAWINGS:

Standard Rectifier Wiring Diagram 486/5/25-S101

4.7 ASSOCIATED STANDARDS:

AS/NZS 3000:2000 Electrical Installations

AS/NZS 2832.1:1998 Cathodic Protection of Metals-Pipes and Cables

4.8 GOVERNMENT REGULATIONS:

Queensland Electricity Safety Rules and Regulations 2002

5.0 PERFORMED TESTING.

- (1) Natural Potential Survey.
- (2) Testing of Insulated Flanges, Joints.
- (3) Current Drain Survey.
- (4) Rectifier Loop Resistance.
- (5) Foreign Structure Interference Survey and Mitigation.
- (6) Final Potential Survey and Commissioning.

Note: Attached copies of above testing can be found in Appendix A.

6.0 CONCLUSION.

Full Cathodic protection has been achieved on these pumps and pipes.

7.0 MAINTENANCE.

The cathodic protection system shall be maintained on a regular basis after commissioning. The maintenance schedule recommended in AS2832.1 is as set out below.

- (a) Bi-monthly.
- (b) Six monthly.
- (c) Five yearly.

8.0 POTENTIAL COMMISSIONING DATA.

Date: 04/08/2005.

Unit set at 2.6 volts 0.7amps.

Potentials to copper sulphate reference cell.

Potentials	Natural	On	Off
Pipe 1	-378mV	-1098mV	-910mV
Pipe 2	-377mV	-1070mV	-907mV
Ladder	-377mV	-1170mV	-1007mV

Interference Testing.

	On	Off	Swing
Fence	-625mV	-625mV	0mV

Insulated Joints.

The two insulated joints were tested.

Pipe 1 Bolt to flange greater than 40 Megohms. Flange to flange 15 Megohms.

Pipe 2 Bolt to flange greater than 37 Megohms. Flange to flange 15 Megohms

Pipe 1 8 x ¾ x 4 inch insulated bolts

Pipe 2 8 x ¾ x 4 inch insulated bolts

Tested by J. Taylor.

Brisbane Water Engineering Services

CP Form No. 37

Page of

Electrical Engineering Unit

Cathodic Protection Six Monthly Maintenance Check Form

Installation. Trade Coast Lytton P. str CPS No. 219 SWB No.Unit Reading before test 2.6 Volts. 0.069 Amps. Date. 13-7-05

Unit Reading after test _____ Volts. _____ Amps.

Check List

Loop Resistance	
Voltage	Current
<u>0.7</u>	<u>17 ma</u>
<u>2.6</u>	<u>69 ma</u>
<u>4.5</u>	<u>163 ma</u>

- (A) Check Switchboard for damage. ()
 (B) Clean Switchboard Exterior. ()
 (C) Zero Voltmeter and Ammeter. ()
 (D) Check there are two spare fuses of each type in switchboard. ()
 (E) Check Test Point Identification. ()
 (F) Check Individual Anode String. (✓)
 (G) Check Individual Anode Current. (1)

(2)
(3)

Test Point No.	Potentials As Found		Potentials After Maint.	
	On	Off	On	Off
Pipe 1	-1098	-910		Natural -378
zn	-1115	-1007		
zn P	+	+189		
Pipe 2	-1070	-907		Natural -377
zn	-1062	-1033		
zn P	+84	+128		
Ladder	-1170	-1007		Natural -377
zn	-1068	-1177		
zn Lad.	+59	+209		

COMMENTS:

69 ma. @ switch ON.Instrument No. 1N11Tested By. J Taylor

Revision 27/06/2005

Brisbane Water Engineering Services

Electrical Engineering Unit

Cathodic Protection System Loop Resistance Lytton Rd.SP298 Rectifier CPS 219

Date: 04th August 2005
Cathodic Protection System: Lytton Road Submersible Pump Station
System Operating Volts: 2.6 System Operating amps 70.0ma

Test Voltage:		Test Current:	
(volts)		(amps)	
0.7		0.017	
2.6		0.07	
4.5		0.163	

Loop Resistance (ohms)
27.607362

Loop Resistance




Image 100_0472.jpg




Image 100_0474.jpg



Image 100_0476.jpg




Image 100_0498.jpg





Image 100_0477.jpg





Image 100_0479.jpg











				MANAGER		DIRECTOR OF PLANNING & DESIGN		DESIGN	J.S.	16.12.93	PROJECT <i>SP298 LYTTON RD P/STN</i>		 BRISBANE CITY COUNCIL DEPARTMENT OF WATER SUPPLY AND SEWERAGE MECHANICAL & ELECTRICAL SERVICES	
				DATE:		DATE:		DRAWN	R.LISTON	16.12.93	OXLEY ARCHERFIELD CATHODIC PROTECTION			
				DIRECTOR OF CONSTRUCTION		DIRECTOR OF M & E SERVICES		CHECKED	<i>fl</i>	17.6.94	TITLE			
								ENGINEER IN CHARGE			SUBMERSIBLE PUMP STATION GENERAL LAYOUT		SCALE: NTS	No. 1 OF 1 SHEETS.
0	16.12.93	ISSUED FOR CONSTRUCTION	R.L.					SUPERVISING ENGINEER <i>M. Lukes</i>			CADD FILE No. 77C2188-		DRAWING No.	AMEND.
No	DATE	AMENDMENT	BY	DATE:		DATE:		DATE:					486/7/7-PE1C2188E	0

HTMS1048

Active in 1994

Page 412 of 417



No.	DATE	AMEND.	INITIALS
APPROVED			
FOR BRISBANE WATER			DATE
FOR URBAN MANAGEMENT			DATE
No. OF SHEETS			




TITLE
STANDARD 0-54 kw A/T
SEWAGE PUMP STATION
CATHODIC PROTN. UNIT




DRAWING No.	486/5/25-S101	AMEND.
		0

DRAFT

Sheet 14

22/10/2014
21/10/2014
20/10/2014

Page 416 of 417



ITEM	QTY	DESCRIPTION	RS	= RS COMPONENTS PART NUMBER
BD1	1	DIODE BRIDGE SINGLE PHASE 25A 200V ISOLATED METAL BASE	RS264888	
D1	1	DIMMER 240V 250VA		
F1	1	DC OUTPUT FUSE - PANEL MTG 5x20 FUSE HOLDER 6/4 5A FUSE		
H1	1	POWER ON INDICATOR 240VAC NEON RED		
H2	1	INTERUPT INDICATOR 240VAC NEON RED		
H3	1	FAULT INDICATOR		
K1	1	REMOTE INTERUPT - RELAY 240V2A 2POLE CHANGEDOVER - FW BASE		
M1	1	VOLTMETER 0-30 V 69x53 RS259577		
M2	1	AMMETER 0-5 A 69x53 RS259511		
S1	1	LOCAL INTERUPT - MOMENTARY PUSH BUTTON SWITCH 240V2A CHANGEDOVER		
S2	1	FAULT RESET - MOMENTARY PUSH BUTTON SWITCH 240V2A CHANGEDOVER		
TDR1	1	TRANSUDER - 0-10mV/1-20mA CLASS 1.0 24VAC POWERED		
T1	1	TRANSFORMER - 240V/24V 4.16A RS805316 - SHROUDS RS805732		
VR1	1	VARISTOR - SURGE SUPPRESSOR RS649150 1CLAMP 76V10Apl (31VDC CONTINUOUS)		
-	14	TERMINALS 4.0mm RAIL MTG - END COVERS & STOPS		

DRAFT

Sheet 14

NOTE: THIS DRAWING CONTAINS BRISBANE CITY COUNCIL'S MINIMUM REQUIREMENTS AND IS TO BE USED AS A REFERENCE FOR PRODUCING THE DETAILED CONSTRUCTION DESIGN. THIS DRAWING IS NOT TO BE USED FOR CONSTRUCTION.

No.	DATE	APPROV.	INITIALS

APPROVED

FOR BRISBANE WATER

FOR URBAN MANAGEMENT

No. OF SHEETS



CADD FILE: 0-15 STANDARDS/DRAWINGS/05 STANDARDS/1525110105

TITLE

STANDARD 0-54 kW A/T
SEWAGE PUMP STATION
CATHODIC PROT. UNIT

DRAWING No.	486/5/25-5101	APPROV.	0
-------------	---------------	---------	---