

AUSTRALIAN MADE
ESSELTE DYMO
ROCKHAMPTON RD
ENGINE/ELECTRIC
GEN CONTROL



ROGHAN ROAD GAS EXTRACTION ENGINE START UP AND SHUT DOWN PROCEDURE

PETER TRANTER
29/07/92

START UP

1. Follow Roghan Road Gas Extraction Plant start up and shut down procedure up to the step prior to plant start up.
2. Open coalescing Filter supply. V3
3. Open coalescing Filter delivery. V25
4. Drain and close coalescing Filter valves. V26, V27
5. Open engine fuel supply in line valve. V28
6. Open methane separator supply valve. V29
7. Open engine fuel supply valve. V30
8. Open engine oil make up valve. V31
9. Check engine oil (dip stick) level.
10. Observe gas engine alternator alarm panel and reset if required.
11. Switch radiator 3 phase isolator to ON.
12. Switch Gas Engine Alternator (GEA) control panel engine selector to ON.
13. Complete Roghan Road Extraction plant start up and shut down procedure.
14. Ensure Blower bypass selector is OFF.
15. Engine should automatically start 5 minutes after the blower starts up.
16. Complete engine check list and log.

SHUTDOWN

- Complete system:
1. Follow shut down procedure of Roghan Road Extraction plant start up and shut down procedure.
 2. Reverse engine start up procedure.

- Engine only:
1. Switch engine selector to OFF
NOTE: Emergency stop should only be used for emergency stop of engine.
 2. Reverse start up procedure.

ROGHAN ROAD GAS ENGINE ALTERNATOR SET OPERATIONAL PARAMETERS & SUPPLIERS

GEA CONTROL PANEL:

Phase failure/rotation/imbalance relay EMAIL 2P740 sensitivity 10%.

SUPPLIER: BCC STOCK

Genaust AVR 380 series

SUPPLIER: Genaust Power P/L

Overload >55 amps <80 amps
Underspeed 48HZ
Volts 240 volts AC
Stability Maximum

6 La Salle St
DUDLEY PARK SA 5008
(08) 269 7000

Alternator
Thermocouple relay SHIMADEN SR41
Thermocouple type "K"
Temperature alarm 70°C

SUPPLIER: Control Equipment
Commercial Rd
FORTITUDE VALLEY 4006
852 1936

High speed fan Thermal overload 5 amps
Low speed fan Thermal overload 2.2 amps

SUPPLIER: Klockner-Moeller
Eagle Farm

Woodward 2301A speed controller

SUPPLIER: Dynamic (Governors)
Turbo Charger Services
32 Raynham St
SALISBURY
275 1499

Start fuel limit 3
Actuator compensation 0
Reset Rate 10
Gain 0
Ramp time 0
Low idle 3
Rated speed 1000 RPM

Delta Electronics Speed Sensor Mode DE097

SUPPLIER: AS ABOVE OR
Delta Electronics
Cnr Cavan &
Grand Junct Rds
GEPPS CROSS SA 5084
(08) 260 2522

No. of teeth (actual 190) 192
Starter cut out 200
Underspeed 950
Overspeed 1100

Gas Engine Waukesha F817G

KIM Hot start lube oil heater OL61523
Power rating 150W

Danfoss KPS 79-060 L 3-121
Temperature controller
Temperature setting 70°C

SUPPLIER: Danfoss P/L
1/32 Billabong St
STAFFORD 4053
356 7911

Danfoss RT107 temperature switches 2 metre capillary

Lube oil temperature alarm 95°C
Water temperature alert 95°C
Water temperature alarm 100°C

SUPPLIER: AS ABOVE

ROGHAN ROAD GAS ENGINE ALTERNATOR SET
OPERATIONAL PARAMETERS & SUPPLIERS

Danfoss RT103 pressure switches

SUPPLIER: Danfoss P/L
 1/32 Billabong St
 STAFFORD 4053
 356 7911

Low fuel pressure 3Kpa
 High fuel pressure 10Kpa

Murphy safety vibration switch Model V8-2 2g

Engine fuel pressure pre start up requirement

Throttled flare delivery valve back pressure 0Kpa

Battery charger Delta Electronics DE001

SUPPLIER: Delta Electronics
 Cnr Cavan &
 Grand Junct Rd
 GEPPS CJROSS SA 5084
 (08) 260 2522

Type	Cyclic Lead-Acid
Cyclic Voltage cut in	26 volts
Cyclic Voltage cut out	28.5 volts
Constant potential	27.6 volts
Cyclic charger current	6-7 amps
Under voltage inhibit	18 volts
Under voltage alarm	24 volts
Over voltage alarm	29 volts
Extra low voltage	21 volts

Remote Radiator

Thermo switch (for low speed fan start) 93°C

ROGHAN RD REFUSE TIP GAS ENGINE CHECK LIST/LOG

P. TRANIER 29-6-92

DATE:.....				
SEQEB HOURS RUN				
ALTERNATOR HOURS RUN				
ALT. THERMOCOUPLE TEMP C				
ENGINE FUEL PRESSURE KPA				
ENGINE REG. FUEL PRESS INS WG				
COOLING WATER TEMP. C				
LUBE OIL TEMP C				
LUBE OIL PRESS KPA				
OILCOOLER OUTLET WATER TEMP C				
ENGINE TACHOMETER RPM				
ENGINE EXHAUST TEMP CYL 1 C				
ENGINE EXHAUST TEMP CYL 2 C				
ENGINE EXHAUST TEMP CYL 3 C				
ENGINE EXHAUST TEMP CYL 4 C				
ENGINE EXHAUST TEMP CYL 5 C				
ENGINE EXHAUST TEMP CYL 6 C				
CYCLIC BATTERY VOLTS				
BATTERY CURRENT AMPS				
SLOW FLOW OIL MAKE UP METER L				
SEPERATER WATER LEVEL %				
MAKE UP OIL LEVEL %				
RADIATOR MAKE UP WATER LEVEL L				
RADIATOR WORKING LEVEL %				
TOTAL SITE CURRENT AMPS				
CHECK LIST				
FORCED AIR FAN				
OIL LEAKS				
UNUSUAL ENGINE NOISES				
UNUSUAL ALTERNATOR NOISES				
UNUSUAL RADIATOR FAN NOISES				
SHUT DOWN/ ALTERNATOR HEATER				
SHUT DOWN/ LUBE OIL HEATER				
COMMENT:.....				
SIGNED.....				

BRISBANE CITY COUNCIL

MEMORANDUM

To	Ref. No.
From	Date
Subject	

Waukesha Engine

~~AETCO 02-6844666~~~~Maurice Duffield~~~~Alternator~~~~KATO Reliance~~~~A 23008 0000~~~~50KW 62.5KVA~~~~90044-13~~

Gear Teeth = 190 on Ring gear

1000 RPM

12 Pole Alternator

Governor is EG3P


Woodward Hydraulic/Electric

200 mA = full throttle

BOSCH Magnetic Pick ups

CC132S (m) (J1 4/86)


Service Co. Gas Drive Systems. (02) 748 7100
 Albert Stevens (Sydney)



REV.	DESCRIPTION	ORG.	DATE	ASSEMBLY GROUP REF DRG No.	SHEET	ITEM	TITLE
B	45kW UPGRADE. & TITLE CHANGE	P.T.	06/88	45755-E2GA-041	1	A, B	45755 - E2GA-067
							45kW GEA ENGINE INSTRUMENT PANEL GENERAL ARRANGEMENT

WOODWARD

2301A SPEED CONTROL



Installation, Operation, and Troubleshooting

WOODWARD GOVERNOR COMPANY

MANUAL 82020A

WARNING

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.



CAUTION

CONTENTS SUBJECT TO DAMAGE BY

STATIC ELECTRICITY

DO NOT OPEN

EXCEPT AT APPROVED
STATIC-FREE WORK STATION

CAUTION

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- *Discharge body static before handling the control (contact a grounded surface and maintain contact while handling the control).*
- *Avoid all plastic, vinyl, and styrofoam (except antistatic plastics) around printed circuit boards (PCBs) or modules (modular PCBs).*
- *Do not touch a PCB with your hands or with conductive devices. Do not touch any part of a module except the faceplate handle.*

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Woodward Governor Company reserves the right to update any portion of this publication at any time. Information provided by Woodward Governor Company is believed to be correct and reliable. However, no responsibility is assumed by Woodward Governor Company for its use unless otherwise expressly undertaken.

© Woodward Governor Company, 1989
All Rights Reserved

Table of Contents

CHAPTER 1	
GENERAL INFORMATION	1
Introduction	1
Description	1
Applications	2
Reverse Acting	2
References	3
 CHAPTER 2	
ELECTROSTATIC DISCHARGE AWARENESS	4
 CHAPTER 3	
INSTALLATION	5
Introduction	5
Unpacking	5
Selection of Speed Range	5
Power Requirements	5
Location Considerations	6
Electrical Connections	6
Shielded Wiring	6
External Adjustments	8
Speed Trim	8
Droop Potentiometers	8
Switch Options	8
Minimum Fuel Contact	8
Failed Speed Signal Override	9
Idles/Rated Ramp Contact	9
Actuator Output	9
External Speed Trim	10
Speed and Phase Matching with an SPM-A Synchronizer	10
Auxiliary Input	10
Speed Sensor	10
Installation Check-Out Procedure	11

WOODWARD
Manual 82020

CHAPTER 4	
OPERATION AND ADJUSTMENT	15
Introduction	15
Initial Pre-Start Settings	15
Start-Up Adjustments	16
Adjust for Stable Operation	17
Speed Setting Adjustment	18
Dynamic Adjustment	18
Actuator Compensation Adjustment	19
Low-Idle Speed Adjustment	19
Ramp Time Adjustment	21
Start Fuel Limit Adjustment	21
Speed Sensor Check	22
Droop Adjustment	22
CHAPTER 5	
DESCRIPTION OF OPERATION	25
Speed Control	25
Auxiliary Inputs	26
Failed Speed Signal Circuit	26
Reverse Acting Controls	28
CHAPTER 6	
TROUBLESHOOTING	29
CHAPTER 7	
REPAIR AND REPLACEMENT PROCEDURES	39
Instructions for Returning Equipment for Repair	39
Replacement Parts Information	39

Illustrations

Figure 1-1 2301A Speed Control	1
Figure 3-1 Speed Range Switch	5
Figure 3-2 Preparation of Shielded Cable	7
Figure 3-3 Outline Drawing of 2301A Speed Control	12
Figure 3-4 High Voltage Plant Wiring Diagram	13
Figure 3-5 Low Voltage Plant Wiring Diagram	13
Figure 4-1 Diesel Engine Performance Curve	20
Figure 4-2 Droop Adjustment	23
Figure 4-3 Droop Base Load with 5% Droop	23
Figure 5-1 Speed Control System	25
Figure 5-2 Speed Control Adjustments	27
Figure 5-3 Reverse Acting System	28

NOTES

WOODWARD
 Manual 82020

Supply Voltage	Actuator Current	PART NUMBER	
		Forward	Reverse
88-131 ac or 90-150 dc	0-200 mA (tandem)		9905-138
10 to 40 dc	0-200 mA (tandem)		9905-137
88-132 ac or 90-150 dc	0-200 mA (tandem)	9905-136	
10 to 40 dc	0-200 mA (tandem)	9905-135	
88-132 ac or 90 to 150 dc	0-200 mA		9905-134
10 to 40 dc	0-200 mA		9905-133
88-132 ac or 90 to 150 dc	0-200 mA		9905-132
10 to 40 dc	0-200 mA	9905-131	

Chapter 1 General Information

INTRODUCTION

The manual has seven chapters: General Information; Static Discharge Awareness, Installation, Operation and Adjustment, Description of Operation, Troubleshooting, and Repair and Replacement Procedures.

DESCRIPTION

The 2301A Speed Control controls the speed or load of diesel or gas engines, or steam or gas turbines. These power sources are referred to as "prime movers" throughout this manual.

The control is housed in a sheet-metal chassis and consists of a single printed circuit board. All potentiometers are accessible from the front of the chassis.

The 2301A Speed Control provides control in the isochronous mode with droop available through an externally wired potentiometer.

The isochronous mode is used for constant speed of the controlled prime mover as long as it is able to provide the load. Isochronous is also used when load sharing with a Woodward load sensor.




Figure 1-1. 2301A Speed Control

82000-A-24

WOODWARD Manual 82020

External droop is used for speed control as a function of load when a prime mover is operating on an infinite bus or when two or more prime movers are in parallel operation.

The 2301A system for a prime-mover includes:

- A 2301A electronic speed control,
- An external power source,
- A speed-sensing device (MPU), and
- A proportional actuator to position the fuel- or steam-metering device.

APPLICATIONS

2301A Speed Controls are available for forward- or reverse-acting applications for use with single or tandem actuators. High voltage models accept 88 to 132 Vac or 90 to 150 Vdc. Low voltage models accept 10 to 40 Vdc supply.

A listing of 2301A Speed Controls and applications is provided on page iv of this manual.

Speed range is set on an internal dip switch, available inside the steel cover of the control. Speeds are set according to the sensor output frequency. The relationship between prime-mover speed and sensor-output frequency is expressed in the formula: Sensor Frequency in Hz equals the number of teeth on the speed-sensing gear times the revolutions per minute of the sensing gear, times the ratio of the engine speed to the sensing gear speed, divided by 60.

$$\begin{aligned} &192 \\ &\times 1000 \times 1 \\ &= 60 \\ &= 3200 \text{ Hz} \end{aligned}$$

Reverse Acting

Most reverse acting 2301A Speed Controls will operate Woodward EGB governor/actuators. In reverse-acting systems, the actuator calls for more fuel when the actuator current decreases. Complete loss of signal to the actuator will drive the actuator to full fuel. This allows a backup mechanical ballhead governor to take control rather than shut down the prime mover as would a direct-acting system.

External wiring connections for reverse-acting controls are identical to those for direct-acting controls. However, changes must be made to the printed circuit board should a control need to operate the opposite type of actuator. Contact Woodward should it be necessary to change the type of 2301A Speed Control. Changing the supply voltage rating requires exchanging the unit for the properly rated control.

REFERENCES

The following Woodward publications contain additional product or installation information on speed controls and related components. Publication ordering information is provided on the back cover of this manual.

Manual Title

25070 Electric Governor
Installation

82510 Magnetic Pickups
Governors

82514 Speed Setting
Potentiometers

82343 Digital Reference Unit

Product Specification

82516 EG-3P Actuators

82575 EGB-2P Governor/Actuator

Woodward Governor Company Application Engineers will assist you in the selection of the correct control and answer questions.

Chapter 2

Electrostatic Discharge Awareness

All electronic equipment is static-sensitive, some components more than others. To protect these components from static damage, you must take special precautions to minimize or eliminate electrostatic discharges.

1. Before performing maintenance on the electronic control, discharge the static electricity on your body to ground.
 - Discharge body static by touching and holding a grounded metal object (pipes, cabinets, equipment, etc.).
 - Avoid the built-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these fabrics resist static electric charges more than synthetics.
2. Do not remove the cover from the printed circuit board except as absolutely necessary. If it is necessary to handle the printed circuit board follow these instructions:
 - Touch only the edges of the board.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a board keep the new board in the antistatic protective plastic bag it comes in until you are ready to install it. After installing the new board, place the old board in the antistatic protective bag for storage or for return to Woodward Governor Co.
3. Keep all plastic, vinyl, and styrofoam away from the control, the board, and the work area. These materials tend to generate and store static electric charges.
 - These materials include plastic or styrofoam cups, cellophane packaging material, vinyl books or folders, and plastic ash trays, tape dispensers, or calendar holders.

Chapter 3 Installation

INTRODUCTION

This section contains general installation instructions for the 2301A Speed Control. Power requirements, environmental precautions, and location considerations are included to determine the best location for the control. Additional information includes unpacking instructions, electrical connections, and an installation check-out procedure.

UNPACKING

Before handling the control, read Chapter 2, "Electrostatic Discharge Awareness". Be careful when unpacking the electronic control. Check the control for signs of damage such as bent or dented panels, scratches, and loose or broken parts. Notify the shipper of any damage.

SELECTION OF SPEED RANGE




Figure 3-1. Speed Range Switch

A 4-pole mini-switch is located on the lower left-hand quarter of the printed circuit board. This switch sets the controlling speed range as sensed by the MPU. The speeds are related to the MPU frequency, which is proportional to engine RPM. The control is shipped with Switch 3 on for 2000 to 6000

Hz. Switch 1 provides 500 to 1500 Hz, Switch 2 provides 1000 to 3000 Hz, and Switch 4 provides 4000 to 12000 Hz. Select only one switch on to match the control to the MPU frequency.

POWER REQUIREMENTS

High and low voltage models of 2301A Speed Controls are available.

Low voltage models require a supply of 10 to 40 Vdc, 12 watts.

High Voltage models require a supply of 88 to 120 Vac or 90 to 150 Vdc, 12 watts. AC supply may be 50 to 400 hz.

WOODWARD
Manual 82020

If a battery is used for operating power, an alternator or other battery charging device is necessary to maintain a stable supply voltage.

CAUTION

To prevent damage to the control, make sure that the alternator or other battery-charging device is not connected to the control when the battery is disconnected from the control.

LOCATION CONSIDERATIONS

Consider these requirements when selecting the mounting location:

- Adequate ventilation for cooling
- Space for servicing and repair
- Protection from direct exposure to water or to a condensation-prone environment.
- Protection from high-voltage or high-current devices, or devices which produce electromagnetic interference.
- Protection from excessive vibration.
- An ambient operating temperature range of -40 degrees C (-40 degrees F) to +85 degrees C (+185 degrees F).

Do not mount the control on the engine.

ELECTRICAL CONNECTIONS

External wiring connections and shielding requirements for a typical control installation are shown in the Plant Wiring Diagram, Figure 3-2. These wiring connections and shielding requirements are explained in the balance of this section.

SHIELDED WIRING

All shielded cable must be twisted conductor pairs. Do not attempt to tin the braided shield. All signal lines should be shielded to prevent picking up stray signals from adjacent equipment. Connect the shields to the grounding lug on the chassis plate below Terminal 9. Keep grounding connections under 6 inches



(15 centimeters) length. A solid ground connection must be made from "earth" or ground to the grounding lug to provide proper chassis grounding. Refer to local wiring codes for proper grounding methods. *

Wire exposed beyond the shield should be as short as possible, not exceeding 6 inches. The other end of the shields must be left open and insulated from any other conductor. Do not run shielded signal wires with other wires carrying large currents. See Application Note 50532 "EMI Control for Electronic Governing Systems" for more information.

Where shielded cable is required, cut the cable to the desired length and prepare the cable as instructed below and shown in Figure 3-1.

1. Strip outer insulation from both ends, exposing the braided or spiral wrapped shield. Do not cut the shield on the control end. Cut off the shield on the end away from the 2301A control.
2. Use a sharp, pointed tool to carefully spread the strands of the shield.
3. Pull the inner conductors out of the shield. Twist braided shields to prevent fraying.
4. Connect lugs to the shield and to the control wires. Number 6 slotted or round crimp-on terminals are used for most installations. Connect the wires to the appropriate terminals on the control and the shield to the grounding lug below terminal 9.




Fig. 3-2. Preparation of Shielded Cables

Installations with severe electromagnetic interference (EMI) may require shielded wire run in conduit, double shielded wire, or other precautions. Contact Woodward Governor Company for additional information.

EXTERNAL ADJUSTMENTS

SPEED TRIM

A speed trim potentiometer or digital reference unit is connected to terminals 11 and 12. Use a high quality 100 ohm, 10-turn potentiometer (Woodward part 1657-537 or equivalent) to provide about ± 5 percent speed adjustment. Terminals 11 and 12 must be jumpered if the speed trim potentiometer or digital reference unit is not used. The 2301A Speed Control will have a jumper installed in the factory and this must be removed if a speed-trim device is used.

DROOP POTENTIOMETER

A 2K potentiometer may be connected to provide a maximum of about 8 percent droop. Connect the potentiometer (ccw) to terminal 15, (cw) to terminal 14, and wiper to terminal 13. If droop is not desired make no connections to terminals 13 and 14.

SWITCH OPTIONS

MINIMUM FUEL CONTACT

The minimum-fuel contact between terminals 2 and 3 on the low-power models and 3 and 6 on the high-power models is intended as an optional means for a normal shutdown of the prime mover. The contact is connected as shown on the plant wiring diagram for the particular control. If a minimum fuel contact is not used, the terminals must be permanently jumpered.

WARNING

Do NOT use the minimum-fuel contact as a part of any emergency stop sequence. The emergency may be caused by a governor malfunction which would also cause a malfunction of the minimum-fuel feature. Use of the minimum-fuel contact for an emergency stop sequence could cause overspeed of the prime mover and mechanical damage and personal injury, including death.

FAILED SPEED SIGNAL OVERRIDE

Circuits in the 2301A Speed Control constantly monitor the signal from the MPU. Should this signal be below a minimum threshold the control sends a minimum fuel signal to the actuator (maximum fuel signal on a reverse acting control).

Before start-up of the prime mover, the speed signal is nonexistent, activating the failed speed signal circuit. On units with cranking motors, the cranking speed is usually sufficient to provide a speed signal, so an override contact is not needed for starting. On some steam turbine systems, the Close for Override of Failed Speed Signal contact must be closed to allow the actuator to open and provide steam for starting.

The failed speed-signal override switch should be a momentary switch so the failed-speed-sensor circuit will be enabled after start up.

IDLE/RATED RAMP CONTACT

Close for rated OPEN for IDLE

Connect a single-pole, single throw switch to terminal 5 as shown on the appropriate plant-wiring diagram. Close the contact for rated, open for idle. Oil pressure is often used to close this contact. When closed, 10 to 40 Vdc is applied to terminal 5, and the prime mover can be operated at a speed higher than idle. When the contact is open, the voltage is removed from terminal 5, and the prime mover's speed decelerates to idle. The ramp rate applies only to the acceleration mode. When the ramp time potentiometer is full CW the ramp time from idle to rated is 22 +/-4 seconds. When the ramp time potentiometer is fully CCW the ramp rate is less than 1 second from idle to rated.

The ramp time from rated to idle is always less than 1 second, regardless of the setting of the ramp-time potentiometer.

ACTUATOR OUTPUT

The actuator wires connect to terminals 9 (+) and 10 (-). Use shielded wires with the shield connected to the grounded post on the panel. Do not connect the shield to the actuator or to any other point. The shield must have continuity the entire distance to the actuator and must be insulated from all other conductors.

Some 2301As may be used to operate prime movers in tandem by wiring the two actuators in series as shown in detail A of the wiring diagram. Tandem operation with a single 2301A control requires that the two engines provide identical power response to identical current signals to each of the actuators.

WOODWARD
Manual 82020**NOTE**

Electro-Magnetic Interference (EMI) can be an intermittent condition. Improperly shielded installations can provide good control for a while and then cause problems. For this reason it is important to be sure all shields are properly installed.

EXTERNAL SPEED TRIM

A jumper must be connected between terminals 11 and 12 unless an optional remote Speed Trim potentiometer is used. If a Speed Trim potentiometer is used, connect it as shown in the Plant Wiring Diagram, using shielded wire. A 100 ohm multiturn potentiometer will provide ± 5 percent speed adjustment. Potentiometers of smaller values may be used if less adjustment is desired.

SPEED AND PHASE MATCHING WITH AN SPM-A SYNCHRONIZER

Connect the SPM-A (optional equipment) wires to terminals 15 (+/-) and 16 (com). Use shielded wire and connect the shield to the ground.

AUXILIARY INPUT

Terminals 17 (-) and 15 (+) are used for auxiliary input from a load sensor. Use of the load sensor and parallel lines allow the 2301A Speed Control to be used in isochronous load-sharing circuits. If the load sensor is not used, droop must be used to share load. (An exception is a multiple engine installation in which one engine is operated isochronously and all other engines are operated in droop.)

SPEED SENSOR

Connect a speed-sensing device (a magnetic pickup (MPU) is normally used) to terminals 8 and 7. No polarity is observed. Use shielded wire and connect the shield only at the 2301A control. The shield must have continuity the entire distance to the MPU. The shield is to be insulated from all other conductors and from the MPU.

Installation Check-Out Procedure

When the installation is completed perform the following check-out procedure before beginning the start-up adjustments in Chapter 4.

1. Visual Inspection:
 - a. Check the linkage between the actuator and the prime mover for looseness or binding. Refer to the appropriate actuator manual, and Manual 25070 "Electric Governor Installation Guide" for additional information on linkage.

WARNING



The actuator lever should be near, but not at, the minimum position when the fuel or steam rack is at the minimum position. This could avoid a dangerous condition caused by an engine which will not shut down.

- b. Check for correct wiring according the plant wiring diagram.
 - c. Check for broken terminals and loose terminal screws. Make sure all terminal lugs are carefully and correctly installed. (Incorrectly installed crimp-on terminals can cause governor failure.)
 - d. Check the speed sensor (MPU) for visible damage. Check the clearance between the gear and the sensor, and adjust if necessary. See Manual 82510 "MPUs for Electric Governors."
2. Check for Grounds.

With the power off, check for grounds by measuring the resistance between each terminal and the grounding bolt located below terminal 9. Terminals 1 and 2 are power-input terminals. Either of these terminals may be grounded in accordance with local codes or through other equipment powered from the same supply. If either is grounded, a high resistance to ground will be evident at terminals 1 through 5 on low voltage models and terminals 1 through 4 on high voltage models. grounds present on these terminals will not normally affect operation, unless they interfere with the input power or switching logic. Grounds on terminals 7 through 17, detected by readings other than infinity, should be located and removed.

WOODWARD
Manual 82020

LOW VOLTAGE MODEL



82000-A-26
89-7-21 GA

Figure 3-3. Outline Drawing of 2301A Speed Control

Heat in the circuit will open a circuit breaker in the 2301A. Circuit beaker will automatically reset after a cooldown.





Figure 3-4. Low Voltage Plant Wiring Diagram

NOTES:

- 1 SHIELDED WIRES TO BE TWISTED PAIRS OR TRIPLETS WITH SHIELD GROUNDING AT CONTROL END ONLY.
- 2 GROUND SHIELDS AT GROUNDING LUG ON THE CHASSIS PLATE BELOW TERMINAL. KEEP GROUNDING CONNECTIONS UNDER 6 INCHES (15 CENTIMETERS) LENGTH.
- 3 REMOVE JUMPER BETWEEN TERMINALS 11 & 12. IF SPEED TRIM POTENTIOMETER OR DIGITAL REFERENCE UNIT IS USED. IF SPEED TRIM POTENTIOMETER IS USED, A HIGH QUALITY 100 OHM, 10 TURN, POTENTIOMETER SIMILAR TO THAT SHOWN TOWARD P/N 1657-537 IS RECOMMENDED. 100 OHMS WILL GIVE APPROXIMATELY $\pm 5\%$ SPEED ADJUSTMENT.
- 4 FOR SERIES OR TANDEM OPERATION. SEE DETAIL "A".



DETAIL "A"
CONNECTION FOR SERIES
OR TANDEM OPERATION

- 5 WARNING: DO NOT USE FOR EMERGENCY SHUTDOWN.**
- THE PRIME MOVER SHOULD BE EQUIPPED WITH A SEPARATE OVERSPED, OVERTEMPATURE OR OVERPRESSURE SHUT-DOWN DEVICE(S), TO PROTECT AGAINST RUNAWAY OR DAMAGE TO THE PRIME MOVER WITH POSSIBLE PERSONAL INJURY, OR LOSS OF LIFE.
- 6 REMOVE JUMPER IF MINIMUM FUEL SWITCH IS USED.**
- 7 USE A 2K POTENTIOMETER FOR UP TO 7.5% DROOP WHEN USING 2/3 ACTUATOR TRAVEL FOR 0 TO 100% LOAD. MAKE NO CONNECTION TO TERMINALS 13 AND 14 IF DROOP IS NOT REQUIRED.**
- 8 GROUND AS REQUIRED BY LOCAL WIRING CODE.**
- 9 A SOLID GROUND CONNECTION MUST BE MADE FROM "EARTH" OR "GROUND" TO THE GROUNDING LUG ON THE CHASSIS PLATE BELOW TO MINIMIZE ELECTRICAL NOISE FROM CHASSIS GROUNDING. REFER TO LOCAL WIRING CODE FOR PROPER GROUNDING METHODS.**




Figure 3-5. High Voltage Plant Wiring Diagram

WOODWARD
Manual 82020

Notes

Chapter 4

Operation and Adjustment

INTRODUCTION

This chapter contains information on control calibration. It includes initial prestart-up and start-up settings and adjustments.

WARNING

Overspeed with resultant equipment damage, personal injury, or death is possible when setting up a control system. Read this entire procedure before starting the prime mover for the first time.

INITIAL PRE-START SETTINGS

1. RATED SPEED
 - a. Set the RATED SPEED potentiometer to minimum (fully counterclockwise).
 - b. Set the external SPEED TRIM, if used, to mid-position.
2. RESET--Set at mid-position.
3. GAIN--Set at mid-position.
4. RAMP TIME--Set at minimum (fully counterclockwise).
5. LOW IDLE SPEED--Set at maximum (fully clockwise).
6. DROOP--Set optional external droop (if used) at minimum (fully counterclockwise).
7. ACTUATOR COMPENSATION
 - a. DIESEL, GAS TURBINE, FUEL-INJECTED GASOLINE PRIME MOVERS: Set the ACTUATOR COMPENSATION potentiometer at 2 on the 0 to 10 scale.

WOODWARD
Manual 82020

- b. CARBURETED GAS OR GASOLINE or STEAM TURBINE PRIME MOVERS: Set the ACTUATOR COMPENSATION potentiometer at 6 on the 0 to 10 scale. ✓
9. START FUEL LIMIT--Set at maximum (fully clockwise).
10. Be sure the actuator is connected to terminals 9 (+) and 10 (-).

START-UP ADJUSTMENTS

1. Complete the installation checkout procedure in Section 3, and the initial prestart settings above.
2. Close the Close for Rated contact. If the external droop feature is being used it should already be set at isochronous, fully ccw.

NOTE

This is for initial prime mover start-up only. For normal start-up, the Close for Rated contact should be open if the prime mover is to start at idle.

3. Apply input power to the control.
4. Preset rated speed.

If a signal generator is not used, set the RATED SPEED potentiometer at minimum (fully counterclockwise).

If a signal generator is used set the signal for the frequency of the speed sensor at rated speed, and connect it to terminals 28 and 29. (The rated speed frequency in Hz equals the rated engine speed in RPM times the number of teeth on the speed sensing gear, times the ratio of engine speed to speed-sensing-gear speed, divided by 60.) Put the Close For Rated contact in rated (closed) position. Set the speed trim potentiometer (if used) to mid-position. Connect a dc analog voltmeter to terminals 9 (+) and 10 (-) to read actuator voltage.

If the actuator voltage is at minimum (about 0 volts) slowly turn the RATED SPEED potentiometer clockwise (counterclockwise for reverse acting controls) until the voltage just begins to move toward maximum.

as per pre-start settings

sig generator only

*Signal
Generator
only*

If the actuator voltage is at maximum, slowly turn the **RATED SPEED** potentiometer counterclockwise (clockwise for reverse-acting controls) until the voltage just begins to move toward minimum.

Continue to very slowly adjust the **RATED SPEED** potentiometer in the appropriate direction, trying to stop the actuator voltage between the minimum and maximum voltages. Because it is not possible to stop the motion, cease adjusting when the voltage changes very slowly. The **RATED SPEED** potentiometer is now set very close to the desired speed. A slight adjustment when the engine is running will achieve the exact speed.

5. Check the speed sensor.

Minimum voltage required from the speed sensor to operate the electronic control is 1.0 volts RMS, measured at cranking speed or the lowest controlling speed. For this test, measure the voltage while cranking, with the speed sensor connected to the control. Before cranking, be sure to prevent the prime mover from starting. At 5 percent of the lower value of the control's speed range, the failed speed sensing circuit is cleared. For example 100 Hz is required on the 2000 to 6000 Hz speed range ($2000 \text{ Hz} \times .05 = 100 \text{ Hz}$).

WARNING

TO PROTECT AGAINST POSSIBLE PERSONAL INJURY, LOSS OF LIFE, and/or PROPERTY DAMAGE WHEN STARTING the engine, turbine, or other type of prime mover, BE PREPARED TO MAKE AN EMERGENCY SHUTDOWN to protect against runaway or overspeed should the mechanical-hydraulic governor(s), or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the control devices fail.

ADJUST FOR STABLE OPERATION

If prime-mover operation is stable, go to the "speed setting adjustment" procedure.

If the prime mover is hunting at a rapid rate, slowly decrease the gain (turn the potentiometer counterclockwise) until performance is stable. Adjusting the gain may cause a momentary speed change which can be minimized by turning the gain potentiometer slowly.

*FOUND 10.85
= 550 HZ
ON CRANK**START
ENGINE*

WOODWARD Manual 82020

If the prime mover is hunting at a slow rate, increase the RESET setting (turn the potentiometer clockwise) until the prime mover stabilizes. If increasing the RESET potentiometer setting does not stabilize the prime mover, it also may be necessary to either:

- Slowly decrease the GAIN (turn the potentiometer counterclockwise) or
- Slowly decrease the GAIN and increase the ACTUATOR COMPENSATION.

SPEED SETTING ADJUSTMENT

With the prime mover operating stably, and the external speed trim potentiometer (if used) set at mid-position, adjust the RATED SPEED potentiometer to bring the prime mover to the desired operating speed:

1000 RPM

DYNAMIC ADJUSTMENT

The object of the GAIN AND RESET potentiometer adjustments is to obtain the optimum, or desired, stable prime-mover-speed response.

NOTE

Adjusting the GAIN may cause momentary changes in speed which can be minimized by turning the GAIN potentiometer slowly.

Increasing the setting of the GAIN potentiometer provides faster transient response (decreases the magnitude of the speed change from a sudden change in load). To achieve optimum response, slowly increase the GAIN (turn the potentiometer clockwise) until the actuator becomes slightly unstable, then slowly turn the GAIN back counterclockwise as necessary to stabilize the actuator. Step load the generator, or bump the actuator terminal shaft, to make sure that the prime mover returns to the proper speed with little overshoot or undershoot of the speed setting. To reduce overshoot, increase the RESET setting (turn the potentiometer clockwise).

When the RESET potentiometer is in the lower part of its adjustment (0 to 3 on the scale), increasing the RESET clockwise may require decreasing the GAIN (turning the GAIN potentiometer counterclockwise) to maintain stable operation.

If the prime mover is slow in returning to the proper speed, decrease the RESET by turning the potentiometer counterclockwise.

Figure 4-1 illustrates prime mover starts with the RAMP TIME potentiometer fully counterclockwise (no ramp), step loadings at four different RESET potentiometer settings, and stable, steady-state running conditions. These are typical performance curves on a naturally aspirated (nonturbocharged) diesel engine.

NOTE

Optimum performance is not necessarily obtained with the GAIN potentiometer at the maximum stable clockwise position. In some cases, the gain must be reduced slightly to ensure stability under widely varying conditions.

ACTUATOR COMPENSATION ADJUSTMENT

If the ACTUATOR COMPENSATION is set as described under INITIAL PRESTART SETTINGS, no further adjustment is normally required. If a slow, periodic instability remains, slightly increase the ACTUATOR COMPENSATION (turn the potentiometer clockwise) and repeat the GAIN and RESET adjustments. Continue to increase the ACTUATOR COMPENSATION and readjust the GAIN and RESET until stability is achieved.

If a fast instability or extremely active actuator is evident, slightly decrease the ACTUATOR COMPENSATION (turn the potentiometer counterclockwise). If necessary, the ACTUATOR COMPENSATION may be set fully counterclockwise. This may be required when engine torsionals cause excessive fuel-linkage movement.

LOW IDLE SPEED ADJUSTMENT





1. The prime mover should be at rated speed with the LOW IDLE SPEED potentiometer set at maximum (fully clockwise). Open the external CLOSE FOR RATED contact.
2. Decrease the LOW IDLE SPEED (turn the potentiometer counterclockwise) until the recommended idle speed is reached.

If the RATED SPEED setting is changed, LOW IDLE SPEED will also be changed and may require readjustment. Changing the LOW IDLE SPEED does not change the RATED SPEED setting.

900 RPM = 45 Hz

NOTE

Make certain that the prime-mover speed is controlled by the LOW IDLE SPEED potentiometer in a range above the minimum-fuel position (mechanical stop) of the actuator or prime-mover fuel rack.



82500-A-303

Figure 4-1. Diesel Engine Performance Curve

RAMP TIME ADJUSTMENT

Adjust the RAMP TIME potentiometer to achieve satisfactory prime mover acceleration to rated speed with minimum overshoot. First start at the fully clockwise (maximum ramp time) position and work back in the counterclockwise direction until the unit ramps as rapidly as desired. (Ramp time will be adjustable from 1 to 22 seconds from idle to rated.

START FUEL LIMIT ADJUSTMENT

NOTE

N/A
Start-fuel limit is not recommended for use with reverse-acting controls. With loss of speed signal, the reverse acting control will position the actuator at the start-fuel level if the failed-speed-signal override is activated. Reverse-acting systems normally require the control to demand full fuel on loss of speed signal to allow the mechanical backup governor to control the system. The Start Fuel Limit can be deactivated by turning the potentiometer fully clockwise.

$$V = 1.50 \text{ mV}$$

$$a. 30 \text{ mA}$$

$$\text{Start Calc} = 1.50 + 30\%$$

$$= 1.95 \text{ V}$$

$$a. 43 \text{ mA}$$

With the prime mover [✓]operating at rated speed and no load, ¹record the voltage across the actuator terminals 9 (+) and 10 (-). ²Shut down the prime mover and activate the Failed Speed Signal Override by closing the override contact. The voltage to the actuator should now be adjustable by the START FUEL LIMIT potentiometer. Set the actuator voltage about 30 percent higher than the voltage obtained at rated speed for forward-acting controls and 30 percent lower than rated speed voltage for reverse-acting controls. Remove the Failed Speed Signal Override contact if not required to start the prime mover.

Start the prime mover and observe the start time, overshoot of speed setting, and exhaust smoke obtained. If the prime mover does not start, turn the START FUEL LIMIT potentiometer slightly clockwise until the prime mover starts. The START FUEL LIMIT may be adjusted as required to optimize the prime-mover starting characteristics. The fuel-limiting function is turned off automatically when the speed control takes over.

NOTE

ie controller calls for less than start fuel value set.
For prime movers not requiring start-fuel limiting, the START FUEL LIMIT function can be deactivated by turning the potentiometer fully clockwise.

Refer page 27

SPEED SENSOR CHECK

If the sensor is a magnetic pickup, measure the voltage across terminals 7 and 8 to be sure there is a minimum of 1.0 volts at cranking speed, and a maximum of 30 volts RMS at rated speed. If the voltage exceeds 30 volts, increase the gap of the speed sensor, and be sure that there is still a minimum of 1.0 volts at cranking speed.

N/A DROOP ADJUSTMENT

The amount of droop is not critical in many installations. If the engine needs to run in droop but the amount is not critical set the droop potentiometer in mid-position, then adjust load with the speed-setting potentiometer.

When paralleled with an infinite bus, the generator frequency cannot change, and unless a load-sensing module is being used, the control must be in droop to maintain stable operation. With the droop potentiometer at mid-position, parallel the generator, then increase the Rated Speed potentiometer until the desired amount of load on the engine is achieved.

Too much droop will cause the engine to overspeed should the load be suddenly lost. Excessive droop will also cause the engine to be sluggish in response to load changes.

Too little droop will cause instability, similar to that experienced with improperly adjusted GAIN and RESET.

Units running against an isolated bus often need droop set to a particular level, to prevent excessive off speed when load changes. Droop is usually expressed as a percentage and calculated by the following formula:

$$\% \text{ Droop} = \frac{\text{No Load Speed} - \text{Full Load Speed}}{\text{No Load Speed}} \times 100$$

To set a specified amount of droop using an isolated bus for the load:

1. Set the droop potentiometer to mid-position. (Use a 2K potentiometer, connected to terminal 14 (cw), 13 (wiper) and 15 (ccw)).
2. Start the prime mover and adjust the RATED SPEED potentiometer for rated speed with no load.
3. Apply full load.*
4. Adjust the droop potentiometers to give desired speed.

5. Remove the load and repeat Steps 2 through 4 until engine speed returns to 60 Hz when the load is removed.

Example: Operating at 60 Hz, 57 Hz at full load indicates 5 percent droop.




Figure 4-2. Droop Adjustment

* If only 50 percent loading is possible, 58.5 Hz would indicate 5 percent droop. See Figure 4-3.

To set a specified amount of droop on an infinite bus load:




Figure 4-3. Droop Base Load with 5% Droop.

1. With the generator not paralleled, adjust the **RATED SPEED** (or speed trim) potentiometer to give a speed setting above 60 Hz by the percent of droop required.

Example: Droop of 5 percent would require raising the speed to 63 Hz.

2. Mark the potentiometer position and re-adjust the **RATED SPEED** (or speed trim) potentiometer for 60 Hz.
3. Turn the external droop potentiometer full CW for maximum droop.
4. Synchronize the generator with the bus and close the tie-breaker.
5. Return the **RATED SPEED** potentiometer to the mark made in Step 2.
6. Load the generator by turning the droop potentiometer counterclockwise until full load is achieved.

WOODWARD
Manual 82020

7. Unload the generator by turning the **RATED SPEED** (or **Speed Trim**) potentiometer ccw until no load is achieved.
8. Open the tie-breaker and repeat steps 1 through 6 until no further adjustment of the external droop is required in Step 6.

NOTE

Droop is 10 percent per volt.

Auxiliary is 3 percent per volt.

Synchronizer Input is 0.667 of 1 percent per volt.

Speed Trim is 10 percent per volt.

Chapter 5


Description of Operation

The 2301A Speed Control monitors prime-mover speed and maintains it at the correct operating level. With the addition of a load sensor the system will share the load with other generators when two or more systems are running in parallel.

SPEED CONTROL

The system, as shown in Figure 5-1, consists of:

1. A magnetic pickup (MPU), to sense the speed of the prime mover.
2. A frequency to voltage converter, to convert MPU frequency to a voltage for use in the 2301A internal circuits.
3. A speed reference to which the prime mover speed is compared. (Idle and Rated speed references are provided by the 2301A Speed Control. The speed reference being used is selected by the operator with an external switch.)
4. A speed summer/amplifier with an output proportional to the amount of fuel or steam required to maintain the reference speed at any given load.
5. An actuator to position the fuel or steam mechanism (injector rack or steam valve) of the prime mover.



82300-A-57

Figure 5-1. Speed Control System

The MPU generates an ac signal with a frequency proportional to prime-mover speed.

The frequency-to-voltage converter receives the MPU frequency signal and changes it to a proportional dc voltage.

The speed-reference circuit generates a dc reference voltage to which the speed signal voltage is compared.

The speed-signal voltage is compared to the reference voltage at the summing point. If the speed-signal voltage is lower or higher than the reference voltage, a signal is sent by the control amplifier calling for an increase or decrease in speed. The actuator is controlled by this signal, repositioning the fuel valve or rack until the speed-signal voltage and the reference voltage are equal.

AUXILIARY INPUTS

Terminals 11 through 17 are used for auxiliary inputs which change the reference voltage and thus the output of the speed control. These inputs include speed trim, droop, SPM synchronizer, and the auxiliary input, (usually from a load sensor and parallel lines).

Failed Speed Signal Circuit

A failed-speed-signal circuit monitors the speed-signal input. When no signal is detected, it calls for minimum fuel. The minimum-fuel signal is sufficient to cause the actuator to go to the minimum position. Incorrect linkage adjustments or other restrictions in the external system may prevent prime-mover shutdown.

For controls with actuator current of 20 to 160 mA, minimum fuel is defined as:

- Actuator current of less than 10 mA for forward-acting controls.
- Actuator current greater than 180 mA for reverse-acting controls.

For controls with actuator current of 40 to 320 mA, minimum fuel is defined as:

- Actuator current of less than 20 mA for forward acting controls.
- Actuator current of more than 360 mA for reverse-acting controls.

✓ 200 mA

A contact to override the failed-speed-signal circuit can be connected in series with terminal 4 and low voltage dc power. (This power is available on terminal 2 for units supplied with 10 to 40 Vdc power and from terminal 6 on those units supplied with about 120 V ac or dc power.) Temporarily closing the contact overrides the failed-speed-signal circuit as required for start-up.

The control must be tuned to each system for optimum performance. The potentiometers for setting and adjusting these circuits are located in the upper right corner of the control as shown in Figure 5-2. They include:




Figure 5-2. Speed Control Adjustments.

- The **RATED SPEED** potentiometer, adjusted so the converter-speed voltage and the reference-speed voltage are equal at the desired operating speed.
- The **LOW IDLE** potentiometer, adjusted so the reference voltage is correct for the desired idle speed.
- The **START FUEL LIMIT** potentiometer to provide a means of limiting the fuel-rack position when starting diesel engines. Adjustment of the potentiometer sets the maximum actuator position from no speed until the speed control calls for a fuel setting lower than the setting of the start-fuel limit. The limit is automatically placed in the circuit whenever the speed monitor input declines below the Failed Speed Signal level. Setting the Start Fuel Limit potentiometer full CW will raise the limit above the maximum fuel position, making the limit non-effective.
- **RESET, GAIN, and ACTUATOR COMPENSATION** potentiometers adjust the control amplifier to accommodate various types of prime-movers. Reset adjustment affects reaction time when recovering after a sudden load change. The magnitude of the speed change resulting from a sudden change in load is controlled by adjusting the Gain potentiometer. Actuator Compensation compensates for the time the actuator and prime-mover system take to react to signals from the control.
- The **RAMP TIME** potentiometer sets the time required for the prime mover to accelerate from idle to rated speed.

NOTE

Droop and Speed Trim settings change at 10 percent of the existing reference per volt. The Auxiliary input causes a 3 percent speed change per volt. The Synchronizer input causes a 0.666 percent change of reference speed per volt.

ACTUATOR CIRCUIT PROTECTION

The speed control is protected from shorts or overloads in the actuator circuit at terminals 9 and 10 by an automatic circuit breaker. The circuit breaker will reset automatically after the short or overload is corrected and the control has a few minutes to cool down.

REVERSE ACTING CONTROLS

The reverse-acting 2301A Speed Control and its actuator are designed so that zero voltage to the actuator corresponds to maximum fuel to the prime mover. The actuator usually used with a reverse-acting control has a mechanical governing mechanism included (see Figure 5-3). The speed setting of this mechanical governor is slightly higher than the speed setting of the 2301A. Should the electronics fail, the actuator will try to go to maximum fuel but will be stopped when it gets to the speed setting of the mechanical governor, providing continued operation of the prime mover, although at a speed which is slightly higher than the electronic control speed reference.




Figure 5-3. Reverse Acting System

Chapter 6

Troubleshooting

The following trouble-shooting guide is an aid in isolating trouble to the control box, actuator, plant wiring, or elsewhere. The guide assumes that the system wiring, soldering connections, switch and relay contacts, and input and output connections are correct and in good working order. Make the checks in the order indicated.

NOTE

The wrong voltage can damage the control. When replacing a control, check the power supply, battery, etc., for the correct voltage as indicated on the name tag on the control. Both high-voltage and low-voltage models of 2301A speed controls are available. The low-voltage model will be damaged if connected to a high-voltage supply. The high-voltage model will not operate with a low-voltage supply.

SYMPTOM	CAUSE	REMEDY
Prime mover will not start. Actuator not moving to start-fuel position.	DC supply voltage polarity reversed, no supply voltage, or supply voltage is low.	Check for supply voltage within limits indicated on control name tag. Reverse leads if dc polarity is incorrect.
	Actuator not responding to input signal from control. NOTE: Hydraulic actuators must have oil pressure and either gear rotation or oil motor rotation to operate.	If there is a voltage output at terminals 9 and 10, but the actuator does not move, the wiring to the actuator should be checked for opens or shorts. With the EG3P actuator, remember that terminals C and D of the mating plug must be jumpered. Coil resistance in a Woodward actuator with terminals 9 and 10 disconnected, is about 35 ohms.

WOODWARD
Manual 82020

SYMPTOM	CAUSE	REMEDY
Prime mover will not start. Actuator not moving to start-fuel position.	Start fuel limit set too low.	Turn start fuel limit cw until prime mover starts.
		Check actuator and linkage for proper installation and operation. Problems may be oil supply, direction of rotation, insufficient drainage, linkage, worn actuator components, or improper adjustment.
	No actuator voltage at terminals 9 and 10 while cranking.	<p>Stop cranking. Check for shorted or grounded actuator leads by removing wires to terminals 9 and 10. Close terminal 4, short terminal 11 to 12. Check for 18 to 22 volts at terminals 9 and 10 for forward acting controls and 0 to 1 volts for reverse acting controls.</p> <p>While cranking, check for at least 1 V RMS at terminals 7 and 8, and at least 30 to 80 Hz.</p> <p>If these readings are not available close terminal 4 to override failed-speed signal while cranking.</p> <p>MPU sensor spaced too far from gear. Make sure there are no metal chips on end of pickup. Check MPU wiring and shields.</p>

SYMPTOM	CAUSE	REMEDY
Prime mover will not start. Actuator not moving to start-fuel position.		Speed setting too low on initial start. Control may be set for the wrong speed range. Check speed sensor frequency versus control part number. Speed setting may be lower than cranking speed. Control should be set for rated speed. Increase RATED SPEED setting clockwise (cw). Be sure and return rated speed setting full ccw if adjusting cw does not produce the correct output.
	LOW IDLE SPEED setting may be too low.	Adjust LOW IDLE SPEED potentiometer cw.
	Minimum Fuel contact open. See "MINIMUM FUEL CONTACT" in Chapter 3. If voltage exceeds 3 volts, the switch or wiring is faulty.	Check switch at terminal 3. Minimum-fuel contact must be closed for normal operation. Check for 0 to 3 Vdc from terminal 2 (+) to 3 (-) on low-voltage controls. (Between terminals 6 (+) and 3 (-) on high-voltage controls.
	MPU not supplying signal to control.	Check MPU wiring for proper connection, check shields for proper installation. Magnetic pickup may be open-circuited or shorted. Check resistance with the leads disconnected from the control. Resistance should be about 100 to 300 ohms.

WOODWARD
Manual 82020

SYMPTOM	CAUSE	REMEDY
Prime mover will not start. Actuator not moving to start-fuel position.	Terminals 11 and 12 are open.	Verify that terminals 11 and 12 are jumpered if optional external speed trim is not used. Check the voltage from terminal 11 (+) to 12 (-). It should be less than 2 volts.
	Faulty speed trim potentiometer.	With power OFF, check speed-trim potentiometer with an ohmmeter.
	Faulty 2301A Speed Control.	Replace unit.
Prime mover overspeeds only on starts.	Ramp adjustment.	Increase RAMP TIME (cw). This decreases acceleration rate (from low idle to rated.)
	RATED SPEED setting too high.	Set RATED SPEED as described in Chapter 4.
	Amplifier adjustment.	2301A may be adjusted for sluggish operation, causing overspeed on start. Slowly adjust GAIN for fastest stable response. RESET may be adjusted too low. Increase RESET setting.

SYMPTOM	CAUSE	REMEDY
Prime mover overspeeds only on starts.	Engine is malfunctioning.	<p>Verify that the fuel rack is not binding and the linkage is properly adjusted. Determine if the fuel rack is quickly following the actuator input voltage.</p> <p>Verify proper operation of overspeed protection devices to determine if a shutdown is occurring without an overspeed condition.</p>
	2301A Speed Control.	If the control does not cut back the actuator voltage when the speed setting is completely ccw the 2301A control may be faulty, or may have the wrong speed range. If the voltage is cut back, (increased on reverse acting controls) look for a problem in the linkage or actuator.
Prime mover overspeeds after operating at rated speed for some time.	Prime mover.	Check for proper operation of prime-mover fuel system. If actuator moves toward minimum fuel during overspeed, problem is in fuel system.
	MPU and 2301A control.	Check MPU voltage at speeds above idle (at least 1.0 V rms). If MPU fails and the switch at terminal 4 is closed, the 2301A will call for maximum fuel.

WOODWARD
Manual 82020

SYMPTOM	CAUSE	REMEDY
Prime mover overspeeds after operating at rated speed for some time.	2301A dynamics adjustment.	Control the prime mover manually at rated speed and adjust the RATED SPEED setting fully ccw. If the output voltage is not zero, replace the control. (Voltage should be about 7 volts for 0-200 mA reverse acting controls or maximum current time actuator resistance for controls of other ratings.)
Prime mover has momentary speed change when adjusting GAIN.	GAIN adjustment made too quickly.	Make GAIN adjustment slowly. Momentary speed change when adjusting GAIN is normal.
Low speed is not regulated by LOW IDLE SPEED potentiometer.	<p>NOTE</p> <p><i>On carbureted prime movers, the minimum fuel stop rpm setting will vary with prime mover temperature. An improper cold setting may interfere with the Low Idle Speed Setting when the prime mover is hot.</i></p>	The Low Idle Speed setting may be below the min-fuel position of the actuator or prime-mover fuel stop. In this case, the output voltage to the actuator will be zero (maximum for reverse acting controls). The engine will be maintained at the min-fuel position by the actuator or the prime mover min-fuel stop. The conditions indicate that the min-fuel position should be decreased by linkage adjustment (diesel) or low-idle set screw (gas engine), or the LOW IDLE SPEED setting should be raised. If this does not correct the problem, the 2301A control may be faulty.

SYMPTOM	CAUSE	REMEDY
Low speed is not regulated by Low Idle Speed potentiometer.	LOW IDLE SPEED potentiometer.	If adjustment of the LOW IDLE SPEED potentiometer causes erratic behavior, replace the control.
Prime mover does not decelerate when Close for Rated contact is open.	Faulty Close for Rated contact or wiring.	The voltage from terminal 5 (-) to 2 (+) on low voltage controls or 5 (-) to 6 (+) on high voltage controls must be less than 2 volts. Replace the contact or wiring as necessary.
	LOW IDLE SPEED set fully cw.	Turn LOW IDLE SPEED setting ccw with terminal 5 open.
	2301A ramp circuitry. CAUTION The speed-setting controls have sufficient range to override the ramp and bring the prime-mover speed up to rated while still in the low-idle mode (because of control or switching defect. A Close for Rated contact that is intermittent may cause the prime mover to overspeed if the RATED SPEED setting is adjusted for rated speed with terminal 5 open.	A faulty Close for Rated contact may remain in the accelerate position with the contact open. If the Close for Rated contact is operative, loss of idle control may be due to a faulty circuit. In general, adjustment of LOW IDLE SPEED will vary the speed of the prime mover with the Close for Rated contact in the decelerate (open) position. Adjustment of LOW IDLE SPEED should not affect prime mover speed when the Close of Rated contact is closed.

WOODWARD
Manual 82020

SYMPTOM	CAUSE	REMEDY
Prime mover will not stabilize at rated no-load speed. The instability may occur at no load or it may vary with load. Control may be erratic.	2301A Speed Control.	Adjust GAIN, RESET, and ACTUATOR COMPENSATION as described in "Adjust for Stable Operation" and "Dynamic Adjustment" in Chapter 4.
	Speed setting controls.	If adjustment of external speed trim causes instability, check potentiometer with ohmmeter for erratic behavior. (Turn power off). Use nonlubricating electrical cleaner if necessary. If internal potentiometer is faulty, replace control.
	Improper linkage adjustment.	Make sure the actuator moves about 2/3 of its travel from no load to full load. Be sure linkage provides a proportional change in power for every change in actuator terminal-shaft position. Refer to the actuator manual for more detailed linkage instructions.
	Necessary wires not properly shielded.	Electrical noise, caused by wiring carrying an ac voltage or stray magnetic fields, can be picked up by improperly shielded wire. Noise will cause instability. See "Shielding" in the installation chapter.

SYMPTOM	CAUSE	REMEDY
Prime Mover will not stabilize.	Prime mover not receiving fuel as called for by the actuator.	Check actuator linkage to fuel-controlling mechanism for lost motion, binding, or excessive loading. Check for a steady fuel pressure of proper value.
	Prime mover not operating properly.	Prime mover may be causing speed variations. Control engine manually to determine if instability is in prime mover or governor/actuator control.
	Input voltage low.	Check voltage supply.
Prime mover unstable or will not accept full load.	EGB governor/actuator.	Verify that mechanical speed setting of EGB governor/actuator is above the set electronic speed reference at full load. Mechanical droop can cause speed setting of ballhead governor to be below electronic speed setting at full load.

Chapter 7

Repair and Replacement Procedures

INSTRUCTIONS FOR RETURNING EQUIPMENT FOR REPAIR

If any part of the electronic control is to be returned to Woodward Governor Company for repair, attach a tag to the part with the following information:

- Name and location where the control is installed.
- Complete Woodward Governor Company part number(s) and serial number(s).
- Description of the problem.
- Instructions describing the desired type of repair.

NOTE

Before handling any electronic component, read Manual 82715, "Guide for Handling and Protection of Electronic Controls."

Use the following materials when returning a complete control:

- Antistatic packing materials that will not damage the surface of the unit.
- At least four inches of tightly packed, industry-approved packing material.
- A packing carton with double walls.
- A strong tape around the outside of the carton for increased strength.

REPLACEMENT PARTS INFORMATION

When ordering replacement parts for electronic controls, include the following information:

- The part number (9905-XXX) from the enclosure nameplate.
- The unit serial number, which is also on the nameplate.

For more information on replacement parts, contact Woodward Governor Company, Engine and Turbine Controls Division, PO 390x 1519, Fort Collins, Colorado 80522, USA. Telephone (303)-482-5811, or contact your nearest Woodward Governor Company service facility.

ORDERING MANUALS

TO ORDER MANUALS, WRITE TO:

Woodward Governor Company
Attention: Technical Services
P.O. Box 1519
Fort Collins
Colorado 80522-1519

PLEASE INCLUDE THE FOLLOWING INFORMATION:

- Your name
- The name and address of your company
(write on letterhead or include business card if available)
- The address where you want the manuals sent (if different from above)
- The quantity wanted of each manual
- The manual number(s) of the manual(s) you are ordering

— OR —

The part number and serial number from the nameplate on your Woodward Equipment

THERE IS NO CHARGE FOR MANUALS ORDERED IN SMALL QUANTITIES.

WOODWARD GOVERNOR COMPANY



CORPORATE HEADQUARTERS • AIRCRAFT CONTROLS DIVISION • 5001 North Second St. • P.O. Box 7001 • Rockford IL 61125-7001, U.S.A.
• Phone: (815) 877-7441 • Telex: 25-7410

ENGINE & TURBINE CONTROLS DIVISION • 1000 East Drake Rd. • P.O. Box 1519 • Fort Collins, CO 80522-1519, U.S.A.
• Phone: (303) 482-5811 • Telex: 4-5691

INTERNATIONAL OPERATIONS DIVISION • 1000 East Drake Rd. • P.O. Box 1519 • Fort Collins, CO 80522-1519, U.S.A.
• Phone: (303) 482-5811 • Telex: 4-5691

INTERNATIONAL DIVISIONS

Woodward Governor (U.K.) Ltd. • P.O. Box 15 • 664 Ajax Ave. • Slough, SL1 4DD, England • Phone: 44-753-26835 • Telex: 848181

Woodward Governor Nederland B.V. • P.O. Box 34, 2130 AA Hoofddorp • Hoofdweg 601, 2131 BA Hoofddorp, The Netherlands
• Phone: 31-2503-13241 • Telex: 74508

Woodward Governor (Japan) Ltd. • Tomisato P.O. Box 1 • Inba-gun, Chiba-ken, 286-02, Japan • Phone: 81-476-93-4661 • Telex: 3762-164


Woodward Governor Company • Kobe Service Station • 86-1, Edayoshi 4-chome • Nishi-ku, Kobe-shi • Hyogo-ken, 673, Japan
• Phone: 81-78-928-8321

Woodward Governor Company • P.O. Box 319 • Unit 1-1 Wirega Ave. • Kingsgrove, N.S.W. 2208, Australia
• Phone: 61-2-758-2322 • Telex: 24175

Woodward Governor Company (Reguladores) Ltda. • Caixa Postal 1785 • Rua Fernao Pompeo De Camargo, 1306 • 13100 Campinas, S.P., Brazil
• Phone: 55 (192) 31-4977 • Telex: 191844

HYDRAULIC TURBINE CONTROLS DIVISION • 2301 Country Club Drive • P.O. Box 287 • Stevens Point, WI 54481-0287, U.S.A.
• Phone: (715) 344-2350 • Telex: 671-4868

89/10/F



DE-097 SPEED SENSOR

INTRODUCTION

The Delta DE-097 Speed Sensor is a solid state speed detection module designed for use with constant speed diesel engines. In operation, three relays within the Sensor switch at factory preset speeds providing functions normally related to starter motor cut-out (SCO), engine underspeed (US), and engine overspeed (OS). Signal source for the Speed Sensor may be either an electromagnetic pickup on the engine flywheel ring gear, or the Delta DE-064 tacho generator.

SPECIFICATIONS

Operating Voltage:	12 to 24 volts D.C.
Supply Current:	175mA with all relays energised.
Starter Cut-out Setting:	Factory preset to 0-30% of nominal running speed. Typical setting 20%, i.e. 300 R.P.M. for a 1500 RPM system. Relay state is preset to be either:— (A) energised with engine stationary and power on, de-energised on rising speed, or— (B) de-energised at rest, operating at set-point.
Underspeed Setting:	70-100% of nominal running speed. Typical setting—90%.
Overspeed Setting:	100-130% of nominal speed. Typical setting—110%. The overspeed relay may be either locking or non-locking.
Switch Repeatability:	± 2% of nominal speed.
Relay Contacts:	Single changeover for SCO and US.
Contact Rating:	Single make contact for OS. 5 Amps resistive. Inductive loads must have diode suppression for good contact life. SCO relay should interrupt circuit to pilot solenoid only.
Operating Temperature:	0-70°C Ambient.
Finish:	Front panel—Anodized aluminium. Black legends. Case—Delta grey hammertone stove enamel.
Weight:	0.9kg.
Dimensions:	152mm L x 125mm W x 65mm D.
Insulation:	10 M above case.

OPERATION

Non-latched OS condition—

On rising speed the relays operate at their preset points, the SCO makes or breaks according to type; the US and OS relays make if speeds are attained. On falling speed the relays will return to their initial state.

Latched OS condition—

Similar to above but if overspeed occurs all relays remain latched. Reset is achieved by removing the D.C. power supply.

ORDERING INFORMATION

Input from:	a) Electromagnetic Pickup.
No. of teeth on ring gear:	b) Delta DE-064 Tacho-generator.
Nominal speed:	RPM
Starter cut-out:	RPM
SCO type:	A or B
Underspeed Setting:	RPM
Overspeed Setting:	RPM
OS type:	Latching or Non-Latching

NUMBER OF TEETH — 192


STARTER CUT OUT — 200

UNDER SPEED — 950

O/SPEED — 1100

Delta Electronics
Head office & plant:


Corner Cavan & Grand Junction Roads
Gepps Cross
South Australia 5084
Telephone (08) 260 2522 Teléx AA82427



DELTA ELECTRONICS

Automatic Battery Chargers

DE001
for Lead-acid batteries
DE009
for Nickel-cadmium batteries



The DE001 and DE009 Automatic Static Battery Chargers are compact, robust units which, although similar in function and appearance, are intended for different applications. The DE001 provides charging characteristics to suit lead-acid accumulators while the DE009 provides the characteristics required by nickel-cadmium cells.

Both units provide similar controls and features, deliver 10 amps of current and incorporate generous protection features. They offer fully automatic operation; regulating their charging voltage and current to maintain battery capacity. They are identical in size and are intended for panel mounting inside electrical switchboard cubicles.

The DE001 and DE009 are designed and manufactured to withstand the rigours of heavy industrial use in harsh environments where less sturdy equipment may not provide the same long-term reliability. They feature heavy-duty construction, use conservatively rated components throughout and their printed circuit board assemblies are protected with a heavy conformal coating to offer lasting protection against the effects of vibration and extremes of temperature and humidity.

These many reasons make them an ideal choice in all industrial applications where the need for high operational reliability (at reasonable cost) is paramount: for power generation control supplies; for stand-by batteries supplying emergency lighting, fire, burglar alarm and communication systems; for emergency engine starting and many other similar applications.

The DE001 is normally supplied with a "Cyclic" charging characteristic which is particularly suitable for use with stand-by batteries in which sulphating may occur during long periods of inactivity. The output cycles on and off, supplying periodic bursts of current at the charger's full output capacity. The battery voltage thus cycles between upper and lower limits which may be independently adjusted. Models with conventional "Constant Potential" charging are also available.

The DE001 provides a "Boost" mode which allows charging to continue above the normal voltage setting. Occasional periods of Boost will ensure that the battery is always at full charge.


The DE001 also features a temperature compensation circuit which reduces its output voltage at high temperatures in order to match the temperature characteristic of lead-acid cells.

The DE009 uses a Constant Potential characteristic to provide the "Float" and "Boost" charging usually required by nickel-cadmium cells. Boost mode allows the voltage to be raised to an adjustable higher level.



DELTA
ELECTRONICS

MANUFACTURERS AND SUPPLIERS OF
ELECTRONIC CONTROL, MONITORING,
ALARM AND PROTECTION EQUIPMENT.



DE-010 TRANSFORMER MODULE

DESCRIPTION

The DE010 Transformer Module is a voltage matching unit, containing two transformers, used for interfacing Australian Standard to American Standard Voltages. Suitable for 415 to 208 Volts, 3 phase conversion for inputs to Woodward and Barber Colman load sharers, also 240 to 120 volts conversion to match input to synchronisers.


SPECIFICATIONS

Peak voltage rating: 500 Volts A.C. 50/60Hz. Terminals 3 to 5.
Power: 30 Watts per transformer, maximum.
Finish: Gray hammer tone stoved enamel.
Approx. Dimensions:

L x B x H
155mm (6") x 128mm (5") x 105mm 4 1/8"

Weight: 5 lb./2.25 kg.

Ambient Operating Temperature Range: 0°C—70°C.



(Specifications subject to change without notice)


Delta Electronics
Head office & plant:

Corner Cavan & Grand Junction Roads,

Gepps Cross,
South Australia 5084.

Q-Pulse 100MS051SS
Tel: (08) 922 0500 Telex: A68142

Active 29/01/2011



DELTA ELECTRONICS

DE001/DE009

Automatic Battery Chargers

FEATURES

- 10 amps continuous charging current
- A Boost charging facility
- *Charger On* indicator output
- Available with 12 or 24 volt output
- Current smoothing choke helps extend battery plate life
- Generous overload protection — a current limiting circuit backed up by an internal fuse and the choke
- *Undervoltage Inhibit* circuit turns off charger if output is short circuited or when an engine's starter motor is operating
- Temperature compensated output voltage on the DE001
- DE001 models available with Cyclic or Constant Potential output
- Cyclic charging mode is ideal for stand-by applications
- Adjustable Boost voltage on the DE009 caters for the exacting requirements of nickel-cadmium cells
- Wide operating temperature range with no current derating
- Heavy-duty construction on sturdy steel chassis
- Conformal coating on control circuit enhances reliability in harsh environments
- Robust *Voltage Adjust* control with locking facility
- Remote voltage sensing facility on DE001 units
- Adjusted at the factory to suit common batteries
- Full 12-month warranty
- Designed, manufactured and supported in Australia

SPECIFICATIONS*


- Supply voltages: 208, 240 or 254 VAC, $\pm 10\%$; 48 to 62 Hz.
- Charging current: Normally 9 A; 10 A maximum (adjustable).
- DE001 output voltage: 24 volt models — cut-in at 26 V, cut-out at 28.5 V. 12 volt models — cut-in at 13 V, cut-out at 14.3 V (both levels are adjustable).
- DE001 output voltage: Normally 27.6 V for 24 volt models, (Constant Potential) 13.8 V for 12 volt models (adjustable).
- DE001 Boost level: Approximately 30 V for 24 volt models, 15 V for 12 volt models.
- DE009 output voltage: 9 cells — 13.05 V, 10 cells — 14.50 V, 18 cells — 26.10 V, 19 cells — 27.55 V, 20 cells — 29.00 V (adjustable).
- DE009 Boost level: Normally 0.1 V per cell increase over the above voltages (adjustable).
- Charge On indication: Approximately 23 VAC on 24 volt units and 11 VAC on 12 volt units. Maximum load is 200 mA. Indication is lost if the internal fuse fails.
- Remote voltage sensing: Sense terminals are provided for use on Cyclic models, and are usually linked on the charger for Constant Potential models.
- DE001 units only)
- Controls: *Voltage Adjust*, *Current Limit*, *Undervoltage Inhibit*, *Differential* (DE001 models only), *Boost Level* (DE009 models only).
- Ambient temperature: Range 0 to 70°C.
- Terminations: 12 screw terminals which accept 3.5 mm fork or ring lugs.
- Dimensions (L x B x D): 320 x 205 x 120 mm maximum.
- Weight: 8.3 kg (shipping weight 9 kg).
- Finish: Grey hammerstone stoved enamel with white silk-screened labelling.

Note: output voltages are quoted for an ambient temperature of 20°C.


INSTALLATION DETAILS*

CAUTION


These units must be installed and wired in accordance with Handbook DE000124 in order to ensure reliable operation.



LEAD-ACID BATTERY CHARGER, TYPE DE001



NICKEL-CADMIUM BATTERY CHARGER, TYPE DE009




ORDERING INFORMATION

To order a new DE001 or DE009 Battery Charger quote the appropriate Model/Part number:

Part No.	Description
DE00100201	Lead-acid charger, 12 volts, Cyclic
DE00100202	Lead-acid charger, 24 volts, Cyclic†
DE00100203	Lead-acid charger, 12 volts, Constant Potential
DE00100204	Lead-acid charger, 24 volts, Constant Potential
DE00900201	Nickel-cadmium charger, 12 volts, Constant Potential
DE00900202	Nickel-cadmium charger, 24 volts, Constant Potential†

Units can be burned in for either 100 or 200 hours at 50°C for use in high-reliability applications specify when ordering. (A nominal charge applies.)

†These models will be supplied if an incomplete part number or specification is quoted.



DELTA ELECTRONICS

A DIVISION OF BOWATER TUTT INDUSTRIES PTY. LTD. (Incorporated in Victoria)

*ABRIDGED INFORMATION ONLY. For design purposes refer to Handbook DE000124 for complete specifications and application information.

BROCHURE No. DE000134A, October '87.

© COPYRIGHT 1987 BY DELTA ELECTRONICS.

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.


CORNER OF CAVAN AND GRAND JUNCTION ROADS,
GEPPS CROSS, SOUTH AUSTRALIA, 5094

POSTAL ADDRESS:

P.O. BOX 308, BLAIR ATHOL, S.A., 5084

TELEPHONE: (08) 260 2522

FACSIMILE: (08) 349 4142



DE-008 CRANK CYCLE TIMER

PHYSICAL DESCRIPTION

The Crank Cycle timer is a small unit intended for use as a starter motor cranking timer in auto start standby alternators. It is housed in an impact resistant polystyrene case with connections brought out as an 11 pin base to plug into a conventional relay socket. On application of a 24 volts D.C. signal, an internal relay will function for a preset time, then release. Up to four cycles may be programmed. A "failed to start" signal will be activated if the input voltage is not removed before the end of the last crank cycle. The unit must be de-energised externally when the engine comes up to speed.

SPECIFICATIONS


Timer: Adjustable 4 to 20 seconds.
 Number of cycles: 1, 2, 3 or 4 externally programmable.
 On/Off Ratio: Fixed at 1:1.
 Supply Voltage: 24 volts D.C.
 Relay Contacts: One changeover on crank relay. One changeover on failed to start.
 Contact Rating: 24 Volts 4 Amp. D.C. resistive load.
 Programming: Terminals 5, 6 and 7 allow selection of number of start attempts.
 1 Cycle: No linking required.
 2 Cycle: Link T5 to T7.
 3 Cycle: Link T6 to T7.
 4 Cycle: Link T6 to T6 and T7.

12 Volts D.C. operation is possible when used in conjunction with DE-042 Auxiliary Power Supply.

Approx. dimensions: 83 mm x 74 mm x 27 mm.
 Weight: 50g.

Ambient Operating Temperature Range: 0°C--70°C.

(Specifications subject to change without notice).



Warning: Do not megger internal circuits as damage to semiconductors may result.

Delta Electronics
 Head office & plant:


Corner Cavan & Grand Junction Roads,
 Gepps Cross,
 South Australia 5094

Active 29/01/2014

Page 57 of 109.



DELTA ELECTRONICS



DE 023 BATTERY VOLTAGE SENSING RELAY

PHYSICAL DESCRIPTION

The Battery Voltage Sensing Relay is used as an alarm module to detect deviation of the battery voltage beyond presettable limits. Two alarm levels are incorporated in the Relay Module. Typical utilization is in monitoring the battery voltage of standby diesel generators or fire pumps, giving indication of undervoltage or overvoltage. An input signal during engine cranking disables the undervoltage alarm preventing nuisance tripping.

The Relay is housed in a polystyrene case with connections brought out to an 11 pin base for mating to a standard relay socket. Sensing Relays are available for 12 and 24 volt systems. Alarm settings are adjustable.

SPECIFICATIONS:


	12 Volts D.C.	24 Volts D.C.
Undervoltage Range	8-16 volts	12-28 volts
Undervoltage Factory Setting:	11.5 volts	23 volts
Overvoltage Range:	12-17 volts	24-34 volts
Overvoltage Factory Setting:	16 volts	32 volts
Undervoltage inhibit pin 1	Greater than 5 volts	
Relay Contacts:	1 c/o undervoltage 1 c/o overvoltage	
Contact Rating:	4 amp D.C. resistive load.	

Approx. dimensions: 93 mm x 74 mm x 27 mm.
Weight: 50g.
Ambient Operating Temperature Range: 0°C—70°C.

Warning: Do not megger internal circuits as damage to semiconductors may result.

(Specifications subject to change without notice)

TRUTH TABLE	Undervoltage contacts	Overvoltage contacts
Below undervoltage setting		
Normal voltage		
Above overvoltage		



Delta Electronics
Head office & plant:

Corner Cavan & Grand Junction Roads,
Gepps Cross,
South Australia 5084.

Active 29/01/2014

Page 58 of 109

DELTA ELECTRONICS

DETROIT ENGINE AND TURBINE CO.
569, GRAND JUNCTION RD.
GEPPS CROSS. SA 5084
PO BOX 188, BLAIR ATHOL, 5084.
TEL. 81-8-260-2299.
FAX. 81-8-349-4151.
ACN. 004 322 123.


FACSIMILE MESSAGE

TO: PETER TRANTER FROM: BRIAN KING
COMPANY: BRISBANE CITY COUNCIL LOCATION: ELECTRONIC
SERVICE DEPT.
FAX: 07-2680847 REF: BK010
CC: DATE: 9/7/92
SUBJECT: DE001 BATTERY CHARGER PAGE 1 OF 5

PETER,


AS REQUESTED , HERE IS THE INFO ON OUR DE001 BATTERY CHARGER
I HAVE ALSO INCLUDED INFO ON THE RELAY MODULES THAT I THINK YOU
MAY HAVE .

REGARDS



Automatic Battery Chargers

DE001
for Lead-acid batteries
DE009
for Nickel-cadmium batteries



07-26809A7

The DE001 and DE009 Automatic Static Battery Chargers are compact, robust units which, although similar in function and appearance, are intended for different applications. The DE001 provides charging characteristics to suit lead-acid accumulators while the DE009 provides the characteristics required by nickel-cadmium cells.

Both units provide similar controls and features, deliver 10 amps of current and incorporate generous protection features. They offer fully automatic operation, regulating their charging voltage and current to maintain battery capacity. They are identical in size and are intended for panel mounting inside electrical switchboard cubicles.

The DE001 and DE009 are designed and manufactured to withstand the rigours of heavy industrial use in harsh environments where less sturdy equipment may not provide the same long-term reliability. They feature heavy-duty construction, use conservatively rated components throughout and their printed circuit board assemblies are protected with a heavy conformal coating to offer lasting protection against the effects of vibration and extremes of temperature and humidity.

These many reasons make them an ideal choice in all industrial applications where the need for high operational reliability (at reasonable cost) is paramount: for power generation control supplies; for stand-by batteries supplying emergency lighting, fire, burglar alarm and communication systems; for emergency engine starting and many other similar applications.

The DE001 is normally supplied with a "Cyclic" charging characteristic which is particularly suitable for use with stand-by batteries in which sulphating may occur during long periods of inactivity. The output cycles on and off, supplying periodic bursts of current at the charger's full output capacity. The battery voltage thus cycles between upper and lower limits which may be independently adjusted. Models with conventional "Constant Potential" charging are also available.


The DE001 provides a "Boost" mode which allows charging to continue above the normal voltage setting. Occasional periods of Boost will ensure that the battery is always at full charge.

The DE001 also features a temperature compensation circuit which reduces its output voltage at high temperatures in order to match the temperature characteristic of lead-acid cells.

The DE009 uses a Constant Potential characteristic to provide the "Float" and "Boost" charging usually required by nickel-cadmium cells. Boost mode allows the voltage to be raised to an adjustable higher level.



DELTA
ELECTRONICS



DE-010 TRANSFORMER MODULE

DESCRIPTION

The DE010 Transformer Module is a voltage matching unit, containing two transformers, used for: interfacing Australian Standard to American Standard Voltages. Suitable for 415 to 208 Volts, 3 phase conversion for inputs to Woodward and Barber Colman load sharers, also 240 to 120 volts conversion to match input to synchronisers.


SPECIFICATIONS

Peak voltage rating: 500 Volts A.C. 50/60Hz. Terminals 3 to 5.
Power: 30 Watts per transformer, maximum.
Finish: Gray hammer tone stoved enamel.
Approx. Dimensions:

L x B x H
155mm (6") x 128mm (5") x 105mm (4 1/8")

Weight: 5 lb./2.25 kg.

Ambient Operating Temperature Range: 0°C—70°C.



(Specifications subject to change without notice)

Delta Electronics
Head office & plant:


Corner Cavan & Grand Junction Roads,

Gepps Cross,
South Australia 5084.

Q-Pulse 09 MS0315

Active 29/01/2014

Page 41 of 109



DELTA ELECTRONICS

DE001/DE009 Automatic Battery Chargers

FEATURES


- 10 amps continuous charging current
- A Boost charging facility
- *Charger On* indicator output
- Available with 12 or 24 volt output
- Current smoothing choke helps extend battery plate life
- Generous overload protection — a current limiting circuit backed up by an internal fuse and the choke
- *Undervoltage Inhibit* circuit turns off charger if output is short circuited or when an engine's starter motor is operating
- Temperature compensated output voltage on the DE001
- DE001 models available with Cyclic or Constant Potential output
- Cyclic charging mode is ideal for stand-by applications
- Adjustable Boost voltage on the DE009 caters for the exacting requirements of nickel-cadmium cells
- Wide operating temperature range with no current derating
- Heavy-duty construction on sturdy steel chassis
- Conformal coating on control circuit enhances reliability in harsh environments
- Robust *Voltage Adjust* control with locking facility
- Remote voltage sensing facility on DE001 units
- Adjusted at the factory to suit common batteries
- Full 12-month warranty
- Designed, manufactured and supported in Australia

SPECIFICATIONS*

Supply voltages:	208, 240 or 254 VAC, $\pm 10\%$; 48 to 62 Hz.
Charging current:	Normally 9 A; 10 A maximum (adjustable).
DE001 output voltage:	24 volt models — cut-in at 26 V, cut-out at 28.5 V. 12 volt models — cut-in at 13 V, cut-out at 14.3 V (both levels are adjustable).
(Cyclic)	Normally 27.6 V for 24 volt models, 13.8 V for 12 volt models (adjustable).
DE001 output voltage:	Approximately 30 V for 24 volt models, 15 V for 12 volt models.
(Constant Potential)	
DE001 Boost level:	9 cells — 13.05 V, 10 cells — 14.50 V, 18 cells — 26.10 V, 19 cells — 27.55 V, 20 cells — 29.00 V (adjustable).
DE009 output voltage:	Normally 0.1 V per cell increase over the above voltages (adjustable).
DE009 Boost level:	Approximately 23 VAC on 24 volt units and 11 VAC on 12 volt units. Maximum load is 200 mA. Indication is lost if the internal fuse fails.
Charge On indication:	Sense terminals are provided for use on Cyclic models, and are usually linked on the charger for Constant Potential models.
Remote voltage sensing:	<i>Voltage Adjust</i> , <i>Current Limit</i> , <i>Undervoltage Inhibit</i> , <i>Differential</i> (DE001 models only), <i>Boost Level</i> (DE009 models only).
(DE001 units only)	Range 0 to 70°C.
Controls:	12 screw terminals which accept 3.5 mm fork or ring lugs.
Ambient temperature:	12 screw terminals which accept 3.5 mm fork or ring lugs.
Terminations:	Dimensions (L x B x D): 320 x 205 x 120 mm maximum.
	Weight: 8.3 kg (shipping weight 9 kg).
	Finish: Gray hammertone stoved enamel with white silk-screened labelling.

Note: output voltages are quoted for an ambient temperature of 20°C.

INSTALLATION DETAILS*



ORDERING INFORMATION

To order a new DE001 or DE009 Battery Charger quote the appropriate Model/Part number:

Part No.	Description
DE00100201	Lead-acid charger, 12, volts, Cyclic
DE00100202	Lead-acid charger, 24 volts, Cyclic
DE00100203	Lead-acid charger, 12 volts, Constant Potential
DE00100204	Lead-acid charger, 24 volts, Constant Potential
DE00900201	Nickel-cadmium charger, 12 volts, Constant Potential
DE00900202	Nickel-cadmium charger, 24 volts, Constant Potential

Units can be burned in for either 100 or 200 hours at 50°C for use in high-reliability applications specify when ordering. (A nominal charge applies.)

*These models will be supplied if an incomplete part number or specification is quoted.



A DIVISION OF BOWATER TUTT INDUSTRIES PTY. LTD. (Incorporated in Victoria)

*ABRIDGED INFORMATION ONLY. For design purposes refer to Handbook DE000124 for complete specifications and application information.

BROCHURE No. DE000134A, October '87.

© Copyright 1987 BY DELTA ELECTRONICS.

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

CORNER OF CAVAN AND GRAND JUNCTION ROADS,
GEPPE CROSS, SOUTH AUSTRALIA, 5094


POSTAL ADDRESS:

P.O. BOX 308, BLAIR ATHOL, S.A., 5084

TELEPHONE: (08) 260 2522

TELEX: 260 2522

TELE: AA8242Z, DETCO



DE-008 CRANK CYCLE TIMER


PHYSICAL DESCRIPTION

The Crank Cycle timer is a small unit intended for use as a starter motor cranking timer in auto start standby alternators. It is housed in an impact resistant polystyrene case with connections brought out as an 11 pin base to plug into a conventional relay socket. On application of a 24 volts D.C. signal, an internal relay will function for a preset time, then release. Up to four cycles may be programmed. A "failed to start" signal will be activated if the input voltage is not removed before the end of the last crank cycle. The unit must be de-energised externally when the engine comes up to speed.

SPECIFICATIONS

Timer: Adjustable 4 to 20 seconds.
Number of cycles: 1, 2, 3 or 4 externally programmable.
On/Off Ratio: Fixed at 1:1.
Supply Voltage: 24 volts D.C.
Relay Contacts: One changeover on crank relay. One changeover on failed to start.
Contact Rating: 24 Volts 4 Amp. D.C. resistive load.
Programming: Terminals 5, 6 and 7 allow selection of number of start attempts:
1 Cycle: No linking required.
2 Cycle: Link T5 to T7.
3 Cycle: Link T6 to T7.
4 Cycle: Link T5 to T6 and T7.
12 Volts D.C. operation is possible when used in conjunction with DE-042 Auxiliary Power Supply.
Approx. dimensions: 83 mm x 74 mm x 27 mm.
Weight: 50g.
Ambient Operating Temperature Range: 0°C--70°C.

(Specifications subject to change without notice)



Warning: Do not migger internal circuits as damage to semiconductors may result.


Delta Electronics
Head office & plant:

Corner Cavan & Grand Junction Roads,
Glen Cross,
South Australia 5084

Active 29/01/2014

Page 63 of 109





DE 023 BATTERY VOLTAGE SENSING RELAY

PHYSICAL DESCRIPTION

The Battery Voltage Sensing Relay is used as an alarm module to detect deviation of the battery voltage beyond presettable limits. Two alarm levels are incorporated in the Relay Module. Typical utilization is in monitoring the battery voltage of standby diesel generators or fire pumps, giving indication of undervoltage or overvoltage. An input signal during engine cranking disables the undervoltage alarm, preventing nuisance tripping.

The Relay is housed in a polystyrene case with connections brought out to an 11 pin base for mating to a standard relay socket. Sensing Relays are available for 12 and 24 volt systems. Alarm settings are adjustable.

SPECIFICATIONS:


	12 Volts D.C.	24 Volts D.C.
Undervoltage Range	8-16 volts	12-28 volts
Undervoltage Factory Setting	11.5 volts	23 volts
Overvoltage Range	12-17 volts	24-34 volts
Overvoltage Factory Setting	16 volts	32 volts
Undervoltage inhibit pin 1	Greater than 5 volts	
Relay Contacts	1 c/o undervoltage 1 c/o overvoltage	
Contact Rating	4 amp D.C. resistive load.	

Approx. dimensions: 93 mm x 74 mm x 27 mm.
Weight: 50g.
Ambient Operating Temperature Range: 0°C—70°C.

Warning: Do not megger internal circuits as damage to semiconductors may result.

(Specifications subject to change without notice)

TRUTH TABLE	Undervoltage contacts	Overvoltage contacts
Below undervoltage setting		
Normal voltage		
Above overvoltage		



DETROIT ENGINE AND TURBINE CO.
569, GRAND JUNCTION RD.
GEPPS CROSS. SA 5084
PO BOX 188, BLAIR ATHOL, 5084.
TEL. 81-8-260-2299.
FAX. 81-8-349-4151.
ACN. 004 322 123.


FACSIMILE MESSAGE

TO: PETER TRANTER FROM: BRIAN KING
COMPANY: BRISBANE CITY COUNCIL LOCATION: ELECTRONIC
SERVICE DEPT.
FAX: 07-2680847 REF: BK010
CC: DATE: 8/7/92
SUBJECT: DE001 BATTERY CHARGER PAGE 1 OF 5

PETER,

AS REQUESTED , HERE IS THE INFO ON OUR DE001 BATTERY CHARGER
I HAVE ALSO INCLUDED INFO ON THE RELAY MODULES THAT I THINK YOU
MAY HAVE

REGARDS



Telephone: 268 6733
Fax: 268 6097

ACTION AUTO ELECTRICS PTY LTD

A.C.N. 010 009 462

156 LAVARACK AVE., EAGLE FARM 4009
P.O. BOX 1015, EAGLE FARM

Queensland Distributors -
Ingersoll-Rand Air Starters
Prestolite-Leece-Neville
Load Handler Trek Star
R.C.P. Automotive Products

INVOICE TO:

BRISBANE CITY
COUNCIL
G.P.O. BOX 1434
BRISBANE Q.
4001

DELIVER TO:

INVOICE No.: 10FFX

Date: 13/07/92

DELIVERY DOCKET

CUSTOMER No.	ORDER No.	SALES TAX No.	DELIVERY DETAILS				
78	529816	EXEMPT	PICK-UP				
PRODUCT CODE	DESCRIPTION	Quantity Supplied	Quantity B/O	LIST PRICE	NETT PRICE	Tax Code	TOTAL
N150	BATTERY 12V 23P	2	0	151.20	302.40	C	302.40
<p>THIS INVOICE IS DUE FOR PAYMENT BY 30TH AUGUST 1992 ***</p> <p><i>Beeco</i> <i>12V 23 N150</i> <i>850 Amps</i> <i>Rating I</i></p> <p><i>45/106/304</i> <i>400/90/304</i></p>							
TERMS OF SALE 1. NETT 30 DAYS.— PLEASE PAY ON INVOICE 2. All claims for credit must be made within 7 days after Receipt of goods. 3. Invoice No. must be quoted on all claims paper work. 4. Bought in or special purchase components will not be subject to credit returns. 5. A handling charge will be made on credit returns. 14 days — Nil, 15-30 days — 10%, 30 days & over — 15%. 6. Goods are subject to prices and conditions ruling at the time of delivery.							SALES TAX CODES Q = A = B 20% = C 30% = D Exempt = E
SUB TOTAL SALES TAX FREIGHT TOTAL							302.40 0.00 0.00 302.40

The list price set out or referred to herein is a recommended price only and there is no obligation to comply with the recommendations

Danfoss

INSTRUCTIONS

PRESSURE

RT 113

Range

0-30 KPA

RT









Fig. 1

RT113



A = Områdeindstilling/Range setting/Bereichseinstellung/Réglage de la plage/Ajuste de gama/Instelling regelbereik/Alueasettelu

B = Opnået differens/Differential obtained/Erreichte Differenz/Différentiel obtenu/Diferencial obtenida/Verkregen differentie/Saavutettu eropaine

C = Differensindstilling/Differential setting/Differenzeinstellung/Réglage du différentiel/Ajuste diferencial/Instelling differentie/Eroasettelu




Fig. 3




Fig. 4

Hoide fra beholderstuds til pressostat
Height from tank connection to pressure controller
Höhe vom Behälterstutzen zum Pressostat
Hauteur du raccord du réservoir au pressostat
Altura desde la conexión del depósito al pressostat
Vertikale afstand van de tankaansluiting naar de pressostat
Korkeus säiliöliitoksesta pressostaattiin





Fig. 5

Mindste vandrette rørlængde
Minimum horizontal tube length
Mindestlänge der waagerechten Rohrstrecke
Longueur minimale du tuyau horizontal
Longitud minima del tubo horizontal
Minimum horizontale lengte van de leiding
Lyhyin vaakasuora putkipituus

Danfoss




INSTRUCTIONS

KPS 76-83






060R9301


060R9301





	T ₂ max. (°C)	T ₁ min. (°C)	T ₁ max. (°C)
KPS 76	80	-40	70
KPS 77	130		
KPS 79	200		
KPS 80	220		
KPS 81	250		
KPS 83	300		











L (mm)	Ms	St. 18/8
75	060L3326	060L3328
110	060L3330	060L3331
160	060L3327	060L3329



10 (6) A, 440 V ~ L.R. 50 A
220 V, 12 W ~ PILOT



	Diff. (°C)
KPS 79 (060L3141)	9
KPS 83 (060L3139, 060L3140)	18




Danfoss

INSTRUCTIONS

TEMPERATURE

RT 107, 108, 120, 123, 124

Range
70-150 °C



017R932

017R9321




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5

	RT 107	RT 108	RT 120	RT 123	RT 124
L	110	410	86	110	110
Ø	9.5	9.5	9.5	9.5	11

1	AC 1 10A	2	DC 11
μ	AC 3 4A	2	12W
AC 11	3A	400V	220V
017-4030			

1	AC 1 10A	2	DC 11
μ	AC 3 4A	2	12W
AC 11	3A	400V	220V
017-4240			

1	AC 1 10A	2	DC 11
μ	AC 3 3A	2	12W
AC 11	2A	400V	220V
017-4034			

1	AC 1 10A	2	DC 11
μ	AC 3 3A	2	12W
AC 11	2A	400V	220V
017-4036			

1	2	μ	017-0181
24V	25VA	a.c. = d.c.	

Fig. 6




Fig. 7

- A. Områdeindstilling/Range setting/Bereichseinstellung/Réglage de la plage/
Настройка диапазона
- B. Opnået differens/Differential obtained/
Erreichte Differenz/Differential obtenu/
Полученный дифференциал
- C. Differenzindstilling/Differential setting/
Differenzeinstellung/Réglage du différentiel/
Настройка дифференциала




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7

- A. Områdeindstilling/Range setting/Bereichseinstellung/Réglage de la plage/
Настройка диапазона
- B. Opnået differens/Differential obtained/
Erreichte Differenz/Différentiel obtenu/
Полученный дифференциал
- C. Differensindstilling/Differential setting/
Differenzeinstellung/Réglage du différentiel/
Настройка дифференциала

DANSK

RT 107, 108, 120, 123, 124

Tekniske data

Kontaktbelastning: kontaktsystem 17-4030 se fig. 6.

Tæthed: IP 66 i henhold til IEC 144 og DIN 40050. For udførelser med max. eller min. reset IP 54.

Tilladelig omgivelsestemperatur: -50°C til +70°C.

Montage

RT-apparaterne kan monteres vilkårligt med hensyn til position. Korrekt montage af føler i følerlomme se fig. 1.

Ved udendørsmontage, bør apparatet beskyttes mod direkte nedbør. Dette kan fx ske ved anbringelse under halvtag.

Indstilling

Indstil termostaten (se fig. 5) til den funktion – slutte eller bryde – som ønskes ved faldende temperatur. Aflæs indstilling på hovedskala (se fig. 5).

Eksempel

Temperaturen i en tørreovn ønskes reguleret af en RT 123. Max. temperatur 188°C. Min. temperatur 180°C. Differens $188 - 180 = 8^\circ\text{C}$.

1. Tilslut varmelegemet til termostatsens klemmer 2-1.
2. Indstil termostaten på 180°C med håndknappen (se fig. 5).
3. Indstil differensrullen (fig. 5) på tallet 3 som fremkommer ved aflæsning af nomogrammet for RT 123 i fig. 7.

ENGLISH

RT 107, 108, 120, 123, 124

Technical data

Contact load: switch 17-4030 see fig. 6.

Enclosure: IP 66 to IEC 144 and DIN 40050.

For versions with max. or min. reset, IP 54.

Permissible ambient temperature: -50°C to +70°C.

Installation

RT units can be fitted in any position. For correct fitting of bulbs in bulb pockets, see fig. 1. With outdoor installation, the unit should be protected against direct rainfall. It could, for example, be placed under a lean-to roof.

Setting

Set the thermostat (fig. 5) to the function required (make or break) on falling temperature. Read off the setting on the main scale (fig. 5).

Example

An RT 123 is required to regulate the temperature in a drying oven. Max. temperature 188°C. Min. temperature 180°C. Differential $188 - 180 = 8^\circ\text{C}$.

1. Connect the heating element to thermostat terminals 2-1.
2. Set the thermostat on 180°C with the knob (fig. 5).
3. Set the differential adjusting nut (fig. 5) on number 3 which can be found by reading off the nomogram for the RT 123 in fig. 7.

DEUTSCH

RT 107, 108, 120, 123, 124

Technische Daten

Kontaktbelastung: Kontaktsystem 17-4030 siehe Fig. 6.

Schutzart: IP 66 gem. IEC 144 und DIN 40050. Für Ausführungen mit max. oder min. Wiedereinschaltung IP 54.

Zulässige Umgebungstemperatur: -50°C bis +70°C.

Montage

Die RT-Geräte können in beliebiger Stellung montiert werden. Die korrekte Montage des Fühlers in die Fühlerhülse ist für Geräte ohne Kapillarrohrbewehrung in Fig. 1.

Bei Montage im Freien sollte das Gerät gegen Niederschläge geschützt werden, z.B. durch Anbringen unter einem Dachvorsprung.

Einstellung

Der Thermostat (siehe Fig. 5) ist auf die Funktion – Ein oder Aus – einzustellen, die bei abfallender Temperatur gewünscht wird. Die Einstellung ist an der Hauptskala (siehe Fig. 5) abzulesen.

Beispiel

Die Temperatur in einem Trockenofen soll von einem RT 123 geregelt werden. Max. Temperatur 188°C. Min. Temperatur 180°C. Differenz $188 - 180 = 8^\circ\text{C}$.

1. Der Heizkörper ist an die Klemmen 2-1 des Thermostats anzuschließen.
2. Der Thermostat ist mit dem Einstellknopf (siehe Fig. 5) auf 180°C einzustellen.
3. Die Differenzrolle (Fig. 5) ist auf die Zahl 3 einzustellen, die auf dem Nomogramm für RT 123 in Fig. 7 abzulesen ist.

FRANCAIS

RT 107, 108, 120, 123, 124

Caractéristiques techniques

Charge des contacts: système de contact 17-4030. Voir fig. 6.

Étanchéité: IP 66 selon IEC 144 et DIN 40050. Pour modèles avec réarmement max. ou min.: IP 54.

Température ambiante admissible: -50°C à +70°C.

Montage

Les appareils RT peuvent être montés dans n'importe quelle position.

Pour montage correct de l'élément sensible dans la poche: voir figure 1.

En cas de montage à l'extérieur, l'appareil doit être abrité contre les chutes directes de pluie et de neige, ce qui peut être réalisé, par exemple, en le plaçant sous un auvent.

Réglage

Régler le thermostat (voir fig. 5) pour la fonction désirée – fermeture ou ouverture du circuit – à température décroissante. Relever le réglage sur l'échelle principale (voir figure 5).

Exemple

On désire régler, à l'aide d'un thermostat RT 123, la température d'un four à sécher. Température maximale: 188°C. Température minimale: 180°C. Différentiel: $188 - 180 = 8^\circ\text{C}$.

1. Connecter le corps de chauffe aux bornes 2-1 du thermostat.
2. Régler le thermostat sur 180°C au moyen du bouton (voir figure 5).
3. Régler le rouleau de différentiel (figure 5) sur le chiffre 3 relevé sur le nomogramme du RT 123 de la figure 7.

ESPAÑOL

RT 107, 108, 120, 123, 124

Características técnicas

Carga de los contactos: conmutador 17-4030 véase figura 6.

Caja de protección: IP 66 según IEC 144 y DIN 40050. Para versiones con rearme máx. o mín., IP 54.

Temperatura ambiente máxima admisible: -50°C a +70°C.

Instalación

Las unidades RT pueden montarse en cualquier posición. Para el montaje correcto de los bulbos situados en protectores, véase figura 1.

En el caso de instalación al exterior, será preciso proteger la unidad contra la acción directa de la lluvia. Por ejemplo, podría situarse debajo de una cubierta.

Ajuste

Ajustar el termostato (figura 5) para la función deseada (cierre o apertura) cuando la apertura disminuye. La lectura del punto de ajuste se efectúa en la escala principal (figura 5).

Ejemplo

Se desea regular con un RT 123 la temperatura de un horno de secado. La temperatura máxima es de 188°C. El diferencial es de $188 - 180 = 8^\circ\text{C}$.

1. Conectar el elemento de calentamiento con los terminales 2-1 del termostato.
2. Ajustar el termostato en 180°C por medio del botón (figura 5).
3. Fijar el diferencial ajustando la tuerca (figura 5) sobre el número 3 que puede encontrarse en el nomograma del RT 123 de la figura 7.

NEDERLANDS

RT 107, 108, 120, 123, 124

Technische gegevens

Contactbelasting: kontaktsysteem 17-4030 zie fig. 6.

Dichtheidsklasse: IP 66 volgens IEC 144 en DIN 40050. Voor uitvoeringen met max. of min. reset: IP 54.

Max. toelaatbare omgevingstemperatuur: -50°C tot +70°C.

Installatie

De RT thermostaten kunnen in elke positie worden gemonteerd.

Voor de juiste montage van voelers in dompelbuizen, zie fig. 1.

Bij installatie in de buitenlucht, dient de thermostaat te worden beschermd tegen directe regenval door deze bijv. onder een afdak aan te brengen.

Instelling

De thermostaat (fig. 5) moet worden ingesteld op de gewenste functie (maken of breken) bij temperatuurdaling.

Op de hoofdschaal (fig. 5) kan de instelling worden afgelezen.

Voorbeeld

Voor het regelen van de temperatuur in een droogoven wordt een RT 123 toegepast.

Max. temperatuur 188°C.

Min. temperatuur 180°C.

Differentie: $188 - 180 = 8^\circ\text{C}$.

- 1) Verwarmingselement aansluiten op de thermostaatklemmen 2-1.
- 2) Thermostaat d.m.v. knop op 180°C instellen (fig. 5).
- 3) Differentie-instelschijf (fig. 5) afstellen op het getal 3 dat kan worden gevonden in het nomogram voor RT 123 in fig. 7.

RT 107, 108, 120, 123 ja 124

Tekniset tiedot

Koskettimien kuormitettavuus: kosketinlaite 17-4030 (kuva 6).

Tiiviys: IP 66, IEC 144 ja DIN 40050 mukaan. Maksimi ja minimi palautuspainikkeilla malleilla IP 54.

Ympäristön sallittu lämpötila $-50^{\circ}\text{C} \dots +70^{\circ}\text{C}$.

Asennus

RT-laitteet voidaan asentaa vapaasti joihinkin asentoon. Tuntoelimen asennus upotusputkeen (kuva 1).

Asennettaessa termostaatti ulos, olisi se suojattava sateelta.

Asettelu

Aseta termostaatti lämpötilalle, jossa toiminta (kytkentä/katkaisu) halutaan laskevalla lämpötilalla. Lämpötila luetaan asteikosta, (kuva 5).

Esim

Kuivausuunin lämpötilaa säädetään RT 123 termostaatilla. Maks. lämpötila 188°C ja minimi 180°C .

Erutus $188 - 180 = 8^{\circ}\text{C}$.

1. Liitä lämmitysvastus koskettimien 2-1 väliin.

2. Asettele termostaatti 180°C asettelunäppäimellä, (kuva 5).

Asettele erotusrulla, (kuva 5) asentoon 3, joka saadaan nomokrammista RT 123 (kuva 7).

RT 107, 108, 120, 123, 124

Техническая характеристика

Контактная нагрузка: контактная система 17-4030, см. рис. 6.

Плотность: IP 66 согласно IEC 144 и DIN 40050. Для выполнения с макс. или мин. возвратом IP 54.

Допустимая температура окружающей среды: -50°C до $+70^{\circ}\text{C}$.

Монтаж:

Приборы-RT можно монтировать произвольно в отношении позиции. Правильный монтаж датчика в кармане датчика показан на рис. 1.

При монтаже под открытым небом следует защищать прибор от прямых осадков. Это может осуществляться, например, помещением прибора навесом.

Настройка

Настраивать термостат (см. рис. 5) на функцию – включать или выключать – желаемую при падающей температуре. Снимать показания главной шкалы (см. рис. 5).

Пример:

Желательно урегулировать температуру в сушилке прибором RT 123. Макс. температура 188°C . Мин. температура 180°C . Разница $188 - 180 = 8^{\circ}\text{C}$.


1. Присоединить термозлемент к зажимам термостата 2-1.

2. Настроить термостат на 180°C нажимной кнопкой (см. рис. 5).







3. Настроить дифференциальный регулировочный ролик (рис. 5) на цифру 3, получаемую при считывании номограммы для RT 123 на рис. 7.



KPS Pressure Controls/Thermostats



Thermostats type KPS


	Setting range	Adjustable differential, fixed differential	Max. sensor temp.	Insert length of suitable pocket (see also table below)	Cap. tube length	Code numbers			Type
	°C	°C	°C	mm	m				
	-10 → 30	3 → 10	80	65, 75, 110, 160	2		060L3112	060L3113	KPS 76
	20 → 60	3 → 14	130	- 75 - -	-	060L3118			KPS 77
	20 → 60	3 → 14	130	- - 110 -	-	060L3100			KPS 77
	20 → 60	3 → 14	130	- - - 160	-	060L3138			KPS 77
	20 → 60	3 → 14	130	65, 75, 110, 160	2		060L3101	060L3102	KPS 77
	20 → 60	3 → 14	130	- - 110, 160	5		060L3119	060L3120	KPS 77
	50 → 100	4 → 16	200	- 75 - -	-	060L3121			KPS 79
	50 → 100	4 → 16	200	- - 110 -	-	060L3103			KPS 79
	50 → 100	4 → 16	200	- - - 160	-	060L3137			KPS 79
	50 → 100	4 → 16	200	65, 75, 110, 160	2		060L3104	060L3105	KPS 79
	50 → 100	4 → 16	200	- - 110, 160	5		060L3122	060L3123	KPS 79
	50 → 100	4 → 16	200	- - 110, 160	8		060L3124	060L3125	KPS 79
	50 → 100	4 → 16	200	- 75, 110, 160	3		060L3143		KPS 79
	50 → 100	9	200	- 75 - -	-	060L3141)			KPS 79
	70 → 120	4.5 → 18	220	- 75 - -	-	060L3126			KPS 80
	70 → 120	4.5 → 18	220	- - 110 -	-	060L3127			KPS 80
	70 → 120	4.5 → 18	220	- - - 160	-	060L3138			KPS 80
	70 → 120	4.5 → 18	220	65, 75, 110, 160	2		060L3128	060L3129	KPS 80
	70 → 120	4.5 → 18	220	- - 110, 160	5		060L3130	060L3131	KPS 80
	70 → 120	4.5 → 18	220	- - 110, 160	8		060L3132	060L3133	KPS 80
	70 → 120	4.5 → 18	220	- 75, 110, 160	3		060L3158		KPS 80
	80 → 150	5 → 25	250	65, 75, 110, 160	2		060L3108	060L3107	KPS 81
	80 → 150	5 → 25	250	- - 110, 160	5		060L3134	060L3135	KPS 81
	100 → 200	6.5 → 30	300	65, 75, 110, 160	2		060L3108	060L3109	KPS 83
	100 → 200	18	300	65, 75, 110, 160	2		060L3139)	060L3140)	KPS 83

) Thermostat with max. reset.


Sensor pockets for KPS thermostats

Insert length mm	Material	Connection		Code no.	Insert length mm	Material	Connection	Code no.
		NP1	RSP				RSP	
65	Brass	1/8"	1/8"	060L3265	110	Brass	1/2"	060L3271
70	Brass	1/8"	1/8"	060L3266	110	Stainless 18/8	1/2"	060L3268
75	Brass	1/8"	1/8"	060L3264	100	Brass	1/8"	060L3263
75	Brass	1/8"	1/8"	060L3262	160	Stainless 18/8	1/2"	060L3269
75	Stainless 18/8	1/8"	1/8"	060L3267	Cap. tube gland	Brass	1/4"	003N0155


KPS 77	060L3100	226.00	1.00	4	range 20→60°C rod-type for sensor pocket 110 mm
KPS 77	060L3118	226.00	1.00	4	range 20→60°C rod-type for sensor pocket 75 mm
KPS 77	060L3136	226.00	1.00	4	range 20→60°C rod-type for sensor pocket 160 mm




KPS 77	060L3101	268.00	1.40	4	range 20→60°C 2m armoured cap. tube
KPS 77	060L3119	365.00	2.00	4	range 20→60°C 5m armoured cap. tube




KPS 77	060L3102	237.00	1.20	4	range 20→60°C 2m cap. tube
KPS 77	060L3120	272.00	1.50	4	range 20→60°C 5m cap. tube




KPS 79	060L3103	226.00	1.00	4	range 50→100°C rod-type for sensor pocket 110 mm
KPS 79	060L3121	226.00	1.00	4	range 50→100°C rod-type for sensor pocket 75 mm
KPS 79	060L3137	226.00	1.00	4	range 50→100°C rod-type for sensor pocket 160 mm
KPS 79	060L3144	226.00	1.00	4	range 50→100°C rod-type for sensor pocket 200 mm
KPS 79	060L3141	323.00	1.00	4	range 50→100°C with max reset rod-type for sensor pocket 75 mm




KPS 79	060L3104	266.00	1.45	4	range 50→100°C 2m armoured cap. tube
KPS 79	060L3143	306.00	1.50	4	range 50→100°C 3m armoured cap. tube
KPS 79	060L3122	365.00	2.00	4	range 50→100°C 5m armoured cap. tube
KPS 79	060L3124	465.00	2.50	4	range 50→100°C 8m armoured cap. tube




KPS 79	060L3105	237.00	1.20	4	range 50→100°C 2m cap. tube
KPS 79	060L3123	272.00	1.50	4	range 50→100°C 5m cap. tube
KPS 79	060L3125	306.00	1.80	4	range 50→100°C 8m cap. tube



KPS 80	060L3126	226.00	1.00	4	range 70→120°C rod-type for sensor pocket 75 mm
KPS 80	060L3127	226.00	1.00	4	range 70→120°C rod-type for sensor pocket 110 mm
KPS 80	060L3138	226.00	1.00	4	range 70→120°C rod-type for sensor pocket 160 mm
KPS 80	060L3157	226.00	1.00	4	range 70→120°C rod-type for sensor pocket 200 mm



KPS 83	060L3109	237.00	1.20	4	range 100-200°C 2m cap. tube
KPS 83	060L3140	342.00	1.20	4	range 100-200°C 2m cap. tube with max reset




SENSOR POCKETS FOR KPS THERMOSTATS

Symbol

Type	Code no.	Price \$ A	Weight kilos	Content of multipack	Description
------	----------	---------------	-----------------	----------------------------	-------------

Sensor pocket of brass without gland

060L3265	38.00	0.09	10	65 mm 1/2" NPT
060L3264	38.00	0.08	10	75 mm 1/2" NPT
* 060L3262	38.00	0.08	10	75 mm 1/2" BSP
060L3266	57.00	0.15	10	75 mm 3/4" BSP
060L3271	41.00	0.09	10	110 mm 1/2" BSP
060L3263	50.00	0.10	10	160 mm 1/2" BSP
060L3206	80.00	0.12	10	200 mm 1/2" BSP



Sensor pocket of stainless steel without gland

060L3267	87.00	0.08	10	75 mm 1/2" BSP
060L3268	87.00	0.09	10	110 mm 1/2" BSP
060L3270	87.00	0.08	10	110 mm 1/2" NPT
060L3269	100.00	0.10	10	160 mm 1/2" BSP




Packingland for sensor pocket

* 060L3273	13.00	0.02	10	Stuffing box
------------	-------	------	----	--------------

PRESSURE CONTROLS

Type	Code no.	P	Weight kilos	Content of multipack	Description
------	----------	---	-----------------	----------------------------	-------------



Symbol



Series SR40 MICROPROCESSOR-BASED PID CONTROLLERS

OPERATING INSTRUCTIONS

CONTENTS

1. Specifications	2
2. Codes for Ordering & Codes for Selectable Measuring Ranges	3
3. Installation	4
(1) External Dimensions	4
(2) Panel Cutout	4
(3) Installation Area	4
(4) Wiring	4
(5) Terminal Arrangement	4
4. Names and Functions	5
(1) Front Panel Information	5
(2) Positions of Internal Switches	5
(3) Selection by Internal Switches	6
5. Operation and Setting of Front Panel Keys	8
(1) Procedure of Parameter Calling, Value Change and Registration	8
(2) Parameter Block Diagram	9
(3) Parameters	10
Parameters in the Operation Block	10
• Setting of Set Value (SV)	10
Parameters in the  (Up) Key Block	10
• Auto Tuning (AT)	10
• Alarm (ALM) Setting	10
• Setting of Heater Break Alarm (HB)	10
Parameters in the  (Down) Key Block	11
• Setting of Proportional Band (P)	11
• Setting of Integral Time (I)	11
• Setting of Derivative Time (D)	11
• Setting of Sensor Compensation (SC)	11
• Setting of Hysteresis (DF)	11
• Setting of Set Value Bias (SB)	11
• Key Lock (LOC)	11
6. Operation	12
(1) Setting of Set Value (SV)	12
(2) Setting of Alarm (ALM)	12
(3) Setting of Key Lock (LOC)	13
(4) Execution of Auto Tuning (AT)	14
(5) Operation by Set Value Bias (SB)	15
7. Error Display	15
8. Check Items in Troubleshooting	16

1 SPECIFICATIONS

Display

Process Value (PV) and Parameter Type:

Set Value (SV) and Parameter Value:

Display Tolerance:

Display Range:

Display Resolution:

Parameter Displays:

Monitor Lamp Displays:

Digital display 7-segment red LED, 3 digits

LED(SR41, SR42, SR44:10mm high, SR43:14.2mm high)

Digital display 7-segment green LED, 3 digits

LED(SR41, SR42, SR44:8mm high, SR43:10mm high)

$\pm(0.5\% \text{ FS} + 1 \text{ digit})$ at $23^{\circ}\text{C} \pm 5^{\circ}\text{C}$

See "Codes for Selectable Measuring Ranges"

0.1 or 1 (depending on measuring range)

Setting of Set Value (Sv), Auto Tuning (At), Alarm set value (AL),

Heater Break Alarm set value (Hb), Proportional Band (P), Integral Time (I),

Derivative Time (d), Sensor Compensation (SC),

Differential (dF), SV Bias (Sb), Set Value locking (LOC)

Control output (CONT), Auto Tuning mode (AT),

Alarm mode (ALM), Heater Break Alarm mode (HB)

Setting

Setting Method:

Keys for setting:

Setting Selection:

By front key switch

4 keys - \odot (Parameter selection), \odot (Shift), \odot (Down) and \odot (Up)

Set Value setting, Auto Tuning mode, Alarm value, Heater Break Alarm value,

Proportional Band, Integral Time, Derivative Time, Sensor Compensation,

Hysteresis (in ON-OFF operation), SV Bias and Key Lock

Input

Thermocouple (Multi-Input, Multi-Range):

External allowable resistance range:

Input impedance:

Burnout:

Cold junction temperature compensation range:

R.T.D. (Multi-Range):

Amperage:

Lead wire tolerance range:

Voltage (Multi-Range):

Input impedance:

Current (Multi-Range):

Receiving impedance:

Sensor Compensation (PV Bias Range):

Sampling Cycle:

J, K, L (DIN 43710)

100 Ω maximum

500k Ω minimum

Standard feature (Up-scale)

$5^{\circ}\text{C} \sim 45^{\circ}\text{C}$

JIS Pt100/JPt100 internally selectable (JPt100 when shipped)

0.25mA

3 Ω maximum/wire

0 \sim 10mV DC, 0 \sim 10V DC

500k Ω minimum

4 \sim 20mA DC

250 Ω

$-19.9 \sim +19.9^{\circ}\text{C}$ or $^{\circ}\text{F}$ (only in case of thermocouple input and R.T.D. input)

0.5 seconds

Control

Control Method:

Proportional band:

Integral time:

Derivative time:

Proportional Cycle:

Hysteresis:

PID control with Auto Tuning function/ON-OFF control.

(by internal switch. PID control when shipped)

0.1 \sim 99.9% FS

1 \sim 999 seconds

0 \sim 999 seconds (PI control at 0 setting)

Contact output: 20 seconds, SSR voltage output: 2 seconds fixed

0.2 \sim 10.0% FS (in ON-OFF mode)

Control Output

Contact:

Contact configuration:

SSR Voltage Output:

Isolation:

DA/RA Mode:

240V AC 2.5A (resistive load), 1A (inductive load)

SR41: 1a contact, SR42, 43 & 44: 1c contact

15V DC \pm 3V (when resistive load is 1.5k Ω), 30mA maximum

Between input and output

Internally selectable (RA mode when shipped)

Alarm Output (Option)

Alarm Setting Method:

Alarm Action:

Alarm Sensitivity Adjustment:

Alarm Output:

Inhibit/Non-inhibit:

Alarm Mode Display:

By front panel key

ON-OFF

0.3% FS fixed

Contact 240V 2.5A (resistive load), 1a

Internally selectable (Non-inhibit when shipped)

ALM lamp lit

Heater Break Alarm (Option)

Alarm Action:

Heater Amperage Setting Range:

Setting Resolution:

Setting Tolerance:

Alarm Mode Display:

Break Alarm Output:

Heater amperage detection by external CT, Alarm output ON upon detection of break (CT attached)

1.5A \sim 30.0A

(In "OFF" setting, Alarm mode will not operate. OFF when shipped)

0.1A

$\pm 5\% \text{ FS} + 1 \text{ digit}$

HB lamp lit

Contact 240V AC 2.5A (resistive load) 1a

(In SR41 and 42, common output with Alarm output. However, if SV Bias function is selected in SR41, this function cannot be selected.)

Set Value Bias (Option)

Mode Input:

Setting Range:

Setting Resolution:

Non-voltage contact (Closed input/Bias mode)

± 999 or ± 99.9 (0 when shipped)

1 or 0.1 (depending on measuring range)

(If SR41 is added with Heater Break Alarm function, this function cannot be selected.)

Others

Memory Protection:

Operating Ambient Temperature:

Operating Ambient Humidity:

Power Supply:

Consumption:

Insulation Resistance:

Dielectric Strength:

Material:

External Dimensions:

Mounting:

Thickness of Panel:

Cutting:

Weight:

Non-volatile memory

$-10^{\circ}\text{C} \sim 50^{\circ}\text{C}$

90% RH maximum (non-condensing)

90 \sim 264V AC, 50/60Hz

Approximately 4VA

20M Ω minimum at 500V DC megger between input/output terminals and power supply terminal

1 minute at 1000V AC between input terminal and power supply terminal

1 minute at 1000V AC between input terminal and output terminal

Resin molding

SR41: H48 \times W48 \times D109mm, SR42: H72 \times W72 \times D102mm

SR43: H96 \times W96 \times D72mm, SR44: H96 \times W48 \times D112mm

Push in panel (no mounting hardware necessary)

SR41: SR44: 1.0 \sim 3.5mm, SR42: SR43: 1.0 \sim 4.0mm

SR41: 45 \times 45mm, SR42: 68 \times 68mm, SR43: 92 \times 92mm, SR44: 92 \times 45mm

SR41: approx. 150g, SR42: approx. 230g, SR43: approx. 270g,

SR44: approx. 240g

2 CODES FOR ORDERING & CODES FOR SELECTABLE MEASURING RANGES

Codes for Ordering

ITEM	CODE	SPECIFICATIONS
SERIES	SR41- <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	MPU-Based PID Auto-Tuning Controller, DIN 48 x 48
	SR42-	MPU-Based PID Auto-Tuning Controller, DIN 72 x 72
	SR43-	MPU-Based PID Auto-Tuning Controller, DIN 96 x 96
	SR44-	MPU-Based PID Auto-Tuning Controller, DIN 48 x 96
INPUT	1	Thermocouples: J, K, L (DIN43710) Input impedance: 500k Ω min., Multi-input, Multi-range
	2	R.T.D. Pt100/JPt100, Amperage: 0.25mA
	3	DC Voltage 0 ~ 10mV, Input impedance: 500k Ω min.
	4	DC Current 4 ~ 20mA, Receiving impedance: 250 Ω
	6	DC Voltage 0 ~ 10V, Input impedance: 500k Ω min.
	9	Others (Please consult before ordering.)
CONTROL OUTPUT	Y- <input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	Contact, 240V AC 2.5A (resistive load), 1A (inductive load)
	P-	SSR voltage, 15V DC \pm 3V (under 1.5k Ω load) 30mA maximum
	X-	Others (Please consult before ordering.)
ALARM (OPTION)	00	None
	02	Higher limit absolute value
	21	Lower limit deviation value
	22	Higher limit deviation value
	23	Higher & lower deviation values
	29	Within higher & lower deviation limits value
HEATER BREAK ALARM & SV BIAS FUNCTION (OPTION)	0	None
	1	Heater Break Alarm: Heater current value setting range 1.5 ~ 30.0A Alarm output/contact 240V AC 2.5A (resistive load)
	2	Set Value Bias function: \pm 999 or \pm 99.9 (depending on setting range)
	3	Heater Break Alarm + SV Bias function (Note: Not available for SR41)
	9	Others (Please consult before ordering.)
LEGEND	N	None
	C	Temperature in degrees Centigrade °C
	F	Temperature in degrees Fahrenheit °F
	H	Relative Humidity %RH
	X	Others (Please consult before ordering.)
REMARKS	0	Without
	9	With (Please consult before ordering.)

Codes for Selectable Measuring Ranges


ITEM	CODE	STANDARD						
TYPE OF STANDARD	J	JIS JPt100 and thermocouples						
	F	JIS '89/IEC Pt100 (new JIS)						
	D	DIN						
	X	Others (Please consult before ordering.)						
		SET NO.	Type of Input	J	F	D	X	°C/°F
INPUT/ MEASURING RANGE	R.T.D. (MULTI-RANGE)	00	Pt100	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		0~99.9°C
		01	Pt100	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		0~200°C
		02	Pt100	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		0~400°C
		03	Pt100	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		-19.9~99.9°C
		04	Pt100	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		-50~50°C
		05	Pt100		<input type="radio"/>	<input type="radio"/>		0~800°F
		06	Pt100		<input type="radio"/>	<input type="radio"/>		-60~130°F
	THERMOCOUPLE (MULTI-RANGE, MULTI-INPUT)	07	K	<input type="radio"/>		<input type="radio"/>		0~400°C
		08	K	<input type="radio"/>		<input type="radio"/>		0~999°C
		09	J	<input type="radio"/>				0~600°C
		10	L (DIN 43710)			<input type="radio"/>		0~600°C
		11	K	<input type="radio"/>		<input type="radio"/>		0~999°F
		12	J	<input type="radio"/>				0~999°F
	VOLTAGE/CURRENT (MULTI-RANGE)	13	mV, V/mA				<input type="radio"/>	0~99.9
		14	mV, V/mA				<input type="radio"/>	0~100
15		mV, V/mA				<input type="radio"/>	0~999	

* The Series SR40 controllers are designed for user-selectable inputs and user-selectable ranges. Their factory-set ranges are as follows.

	TYPE OF INPUT	MEASURING RANGE	SET NO
THERMOCOUPLE	K	0~400 °C/0~999 °F	07 / 11
R.T.D.	JPt100	0~99.9 °C/0~800 °F	00 / 05
VOLTAGE / CURRENT	V, mV/mA	0 ~ 99.9 °C	13

3. INSTALLATION

(1) External Dimensions




SERIES	A	B	C	D	E	F	G
SR41	48	48	100	9	109	44.8	44.8
SR42	72	72	90	12	102	67.5	67.5
SR43	96	96	60	12	72	91.5	91.5
SR44	48	96	100	12	112	44.5	91.5

Unit : mm



CT (Option)



(2) Panel Cutout



When n pieces are installed laterally



When the instruments are installed laterally, use the attachment provided.

SERIES	H	I	J	K	PANEL THICKNESS	REMARKS
SR41	45 $\begin{smallmatrix} +0.6 \\ 0 \end{smallmatrix}$	45 $\begin{smallmatrix} +0.6 \\ 0 \end{smallmatrix}$	—	60 min.	1.0~3.5mm	Can be installed laterally by means of the attachment provided.
SR42	68 $\begin{smallmatrix} +0.7 \\ 0 \end{smallmatrix}$	68 $\begin{smallmatrix} +0.7 \\ 0 \end{smallmatrix}$	110 min.	100 min.	1.0~4.0mm	—
SR43	92 $\begin{smallmatrix} +0.8 \\ 0 \end{smallmatrix}$	92 $\begin{smallmatrix} +0.8 \\ 0 \end{smallmatrix}$	130 min.	130 min.	1.0~4.0mm	—
SR44	45 $\begin{smallmatrix} +0.6 \\ 0 \end{smallmatrix}$	92 $\begin{smallmatrix} +0.8 \\ 0 \end{smallmatrix}$	—	110 min.	1.0~3.5mm	Can be installed laterally by means of the attachment provided.


Unit : mm

(3) Installation Area

- The installation area should:
- be free from corrosive gases, soot and dust
 - have an ambient temperature of -10° to 50°C
 - have a relative humidity of under 90%
 - be free from strong impacts or vibration
 - be away from heavy electric circuits and electric fields
 - be away from direct sunlight and water vapor.

(4) Wiring

- In the case of thermocouple input, use the specified compensating lead.
- In the case of R.T.D. input, use the lead wire where resistance is low and no resistance difference is found between the three wires.
- For connection to the power source, use wire or cable which is equal to or better than 600V vinyl insulated wire (JIS C3307). Use a noise filter in the power source if needed.
- To prevent a noise effect on the input signal line, lay it away from a strong circuit line such as a motor circuit. Do not pass them together through the same conduit or duct. If this cannot be avoided, make sure to use shielded cable.
- For connecting wire to a terminal, the use of a solderless terminal attached with a sleeve (for the 3.5mm terminal screw) is recommended.




Max. 7.0 mm

(5) Terminal Arrangement (Those enclosed in dotted lines are terminals to be used when an optional function is added.)

Control Output	SR41	SR42	SR43 & 44
Contact Output Type (Y)			
SSR Voltage Type (P)			

4 NAMES AND FUNCTIONS

(1) Front Panel Information



■ Displays

1. Control lamp: Lit while control output is ON.
2. Auto Tuning lamp: Lit while Auto-Tuning is executed.
3. Alarm lamp: Lit while Alarm output is ON.
4. Heater Break Alarm lamp: Lit while Heater Break Alarm output is ON.
5. PV Parameter Display: Displays the measured temperature. In the SV or parameter setting, types of selectable parameters are displayed.
6. SV Parameter Display: Displays the set temperature. In parameter setting, the value of the parameter is displayed.
7. Unregistration Indicator / SV Bias Mode Indicator: The point flashes when a parameter value is being changed by means of the up key or the down key (before the value is registered), or while the SV Bias input terminal is ON.


■ Keypad

8. Parameter key: Used to switch a parameter intended to be set or changed and to register a parameter value. Used together with the up key and the down key to select a parameter block.
9. Shift key (for shifting the place of a figure): In setting a parameter value, this moves the place of the figure to be changed.
10. Up key: Increases the value in the SV display. If this key is pressed simultaneously with the parameter key, you can move out from the operation block to the up key block.
11. Down key: Decreases the value in the SV display. If this key is pressed simultaneously with the parameter key, you can move out from the operation block to the down key block.


(2) Positions of Internal Switches

The inner unit and the case are connected through a connector. The inner unit can be drawn out while pressing the lock spring under the front panel. To encase the inner unit, push it in slowly until the inner unit and the case are locked together.

Note: Be sure to turn supply to the instrument OFF before drawing out the inner unit. If this is not done, it may cause a problem.



Draw the inner unit out while pressing the lock spring located under the front panel.



Items selectable by SW1 (for setting position, see page 6.)


- Input selection for thermocouple input and range selection in case of thermocouple, R.T.D., voltage and current

Items selectable by SW2 (for setting position, see page 7.)

- Selection of output characteristics (RA/DA), R.T.D. input standard (JPt100/Pt100 IEC), Alarm (non-inhibit/inhibit) and control method (PID/ON-OFF)

(3) Selection by Internal Switches

Selection of input type/measuring range by SW1

SR4 Δ \square Δ Δ Δ Δ 


Input Type	Measuring Range	SW1 Setting Position		Initial Message	
		OFF	ON	Set No. Control Output Legend	Lower Limit of Range, Higher Limit of Range
Thermocouple	K 0 ~ 400 °C *			07 P C	0 400
	K 0 ~ 999 °C			08 P C	0 999
	J 0 ~ 600 °C			09 P C	0 600
	L 0 ~ 600 °C			10 P C	0 600
	K 0 ~ 999 °F			11 P F	0 999
	J 0 ~ 999 °F			12 P F	0 999
R.T.D. Pt100/JPt100	0 ~ 99.9 °C *			00 P C	0 99.9
	0 ~ 200 °C			01 P C	0 200
	0 ~ 400 °C			02 P C	0 400
	-19.9 ~ 99.9 °C			03 P C	-19.9 99.9
	-50 ~ 50 °C			04 P C	-50 50
	0 ~ 800 °F			05 P F	0 800
	-60 ~ 130 °F			06 P F	-60 130
Voltage	0 ~ 99.9 *			13 P	0 99.9
Current	0 ~ 100			14 P	0 100
Voltage	0 ~ 999			15 P	0 999

Note: The instrument is normally supplied with the * marked range setting. Other ranges may be specified when ordering.


INITIAL MESSAGE

Confirm that the range selected in the initial message which is displayed upon applying power is the intended one.

Initial Message (Upper line: PV display, Lower line: SV display)



Mode Selection by SW2



Item Selection	Output Characteristics	Input Standard	Alarm Mode	Control Method
OFF 	RA (Reverse action)	JPt 100 (Old JIS)	Non-inhibit	PID
ON 	DA (Direct action)	Pt100/IEC JIS Pt100 (DIN Pt100)	Inhibit	ON-OFF

* All switches are set at "OFF" position when shipped.

OUTPUT CHARACTERISTICS

RA (reverse action): As the Process Value (PV) rises higher above the Set Value (SV), output becomes smaller. In the case of temperature, this is used for the control of heating.

DA (direct action): As the Process Value (PV) rises higher above the Set Value (SV), output becomes larger. In the case of temperature, this is used for the control of cooling.

INPUT STANDARD

This selection is necessary in the case of R.T.D. input.

JPt100 (old JIS): JIS C1604 1981 Standard

PT100/IEC: JIS C1604 1989 (JIS-89Pt100) Standard

JIS Pt100


(DIN Pt100)

IEC (International Electric Standard) is equivalent to JIS, DIN and ANSI.


INHIBIT MODE

In the inhibit mode, if the Process Value (PV) is within the alarm output range upon applying power, alarm output is inhibited and alarm is output if it enters the alarm range again after getting out of the range once.

Drawing for output in inhibit mode



Drawing for output in non-inhibit mode



The example shows the lower limit deviation value alarm action.

CONTROL METHOD


PID: Control is carried out jointly by P (proportional band), I (integral time) and D (derivative time).

ON-OFF: On/Off control

5 Operation and Setting of Front Panel Keys


Follow the procedure of parameter calling, referring to the parameter block diagram and the description of each parameter.

(1) Procedure of Parameter Calling, Value Change and Registration




When power is applied, the initial message will be displayed (about 8 seconds), and then PV and SV will be displayed.

(While the initial message is displayed, the operation of the front panel keys is ineffective.)




Operate the front panel key while confirming the types of parameters shown in the PV display and numerical data shown in the SV display.



PROCEDURE FOR CALLING A PARAMETER

There are three ways of calling a parameter.

1. Press only the (parameter) key.
2. Press the (parameter) key while pressing the (up) key.
3. Press the (parameter) key while pressing the (down) key.




PROCEDURE FOR CHANGING A VALUE

Call up the type of desired parameter in the PV display, and set the desired value of SV displayed value by pressing the (up) key or (down) key.

Pressing the (shift) key moves the place of the figure to be changed.

(When the (up) key, (down) key or (shift) key is pressed, the point beside the figure in the SV display flashes to indicate that the figure can be changed.)



PROCEDURE FOR REGISTERING A VALUE


Confirm that the desired value is displayed and press the (parameter) key to register that value. Upon pressing the (parameter) key, the point beside the value in the SV display goes out to indicate that the desired value has been registered.

If the (parameter) key is not pressed within 30 seconds, it returns to the value before setting and PV/SV displays are restored.

TWO FUNCTIONS OF THE (PARAMETER) KEY

Besides the function to switch types of parameters, the (parameter) key is used for data registration.


(When the (up) key, (down) key or (shift) key is pressed for a change of data, the (parameter) key functions as the data registration key, i.e., by pressing (up) + (parameter), (down) + (parameter) or (shift) + (parameter).)




Note: Use only your fingers to operate the front panel keys.

Using something hard, such as a screwdriver or a pen, may break a key and put the instrument out of order.

It is not possible to change a setting when Key Lock has been selected or Auto Tuning is being executed.

(2) Parameter Block Diagram

- Parameters in the Operation Block



- Setting of Set Value (SV)
 - Initial value: 0 or 0.0 (depending on measuring range)
 - Setting range: Within measuring range

- Parameters in the \odot (Up) Key Block

```

graph TD
    A["OFF  
AL"] --> B["AL  
OFF"]
    B --> C["AL  
OFF"]
    C --> D["Hb  
OFF"]
    D --> A
  
```

This is displayed when PID control is selected.

Execution of Auto Tuning: **On** Stop or termination of Auto Tuning: **Off**

This is displayed when the instrument is equipped with the alarm function (option)

Type of Alarm	Parameter Display and Initial Value	Setting Range (differs depending on measuring range)	Alarm Action △ : SV (main setting) ▲ : ALM (alarm setting)
Higher limit deviation alarm	AL1 99.9 or 999	0.0 ~ 99.9 or 0 ~ 999	
Lower limit deviation alarm *	AL2 (-)99.9 or (-)999	0.0 ~ -99.9 or 0 ~ -999	
Higher / lower limit deviation alarm	AL3 50.0 or 500	0.1 ~ 50.0 or 1 ~ 500	
Alarm within higher lower limits of deviation	AL4 0.1 or 1	0.1 ~ 50.0 or 1 ~ 500	
Higher limit absolute value alarm	AL5 Higher limit value of measuring range	Within measuring range	

S (Alarm hysteresis): 0.3% fixed

A type of alarm (AL1 ~ AL5) should be designated when ordering.

Note * : The minus code (-) is not shown in numerical data in the SV display

The ALM lamp is lit while the Alarm mode is ON (ALM closed) and goes out when it is turned OFF (ALM open).


This is displayed when the instrument is equipped with the Heater Break Alarm function (option).

Stop of Heater Break Alarm action: OFF Setting range of heater current: 1.5A ~ 30.0A

When the heater is broken and the load current falls below the Set Value of the heater current, the HB terminal is short circuited and the HB lamp lights.


Once a Heater Break Alarm is output, it is maintained as long as the power is ON. To release it, the power should be turned OFF or the Set Value of heater current should be either changed or turned to OFF.

To instrument CT connection terminal
(no polarity)



- Use the CT (current trans) provided.
- Lay the CT cable away from the power supply and load cable.
- Heater power line must be wired through the CT as illustrated on the left.

Parameters in the (Down) Key Block



In the PV/SV display, press the (Down) key while pressing the (Up) key. Thereafter, the parameter changes every time the (Down) key is pressed.

Setting of Proportional Band (P)

Initial value: 3.0% FS

This is displayed when PID control is selected.
Setting range: 0.1 ~ 99.9% FS

Setting of Integral Time (I)

Initial value: 120 sec.

This is displayed when PID control is selected.
Setting range: 1 ~ 999 sec. (0 sec. cannot be set.)

Setting of Derivative Time (D)

Initial value: 0 sec.

This is displayed when PID control is selected.
Setting range: 0 ~ 999 sec. (PI control is carried out when this is set at 0 sec.)

Setting of Sensor Compensation (SC)

Initial Value: 0.0°C (°F)

This is displayed in the case of thermocouple/R.T.D. input.
Setting range: -19.9 ~ 19.9°C (°F)
Examples: If the sensor compensation is set at 5.0°C, PV value becomes input value + 5.0°C.
If the sensor compensation is set at -5.0°C, PV value becomes input value - 5.0°C.

Setting of Differential Gap (DF)

Initial value: 0.2% FS

This is displayed when ON-OFF control is selected.
Setting range: 0.2 ~ 10.0% FS
Note: DF means the difference between the positions of the ON and OFF actions. If this is too narrow, the frequency of ON-OFF switching increases and, particularly in contact output, shortens the life of the relay.

Setting of Set Value Bias (SB)




Initial value: 0.0 or 0

This is displayed when the instrument is equipped with the SV Bias function (option).
Setting range: -99.9 ~ 99.9 or -999 ~ 999 (depending on measuring range)
Examples: If the SV Bias is set at 5.0°C, SV value becomes SV + 5.0°C while the SV Bias is functioning.
If the SV Bias is set at -5.0°C, SV value becomes SV - 5.0°C while the SV Bias is functioning.
(When a minus figure is set, the minus code is shown on the PV display.)

EXAMPLE OF TEMPERATURE SWITCH BETWEEN DAY AND NIGHT

The Set Value is set at 80.0°C and the SV Bias at -10.0°C.

Set Value of temperature: SV				
Set Value of bias: SV - SB				
Signal for SB (bias) action : ON				
(Timer output) : OFF				
	Day	Night	Day	Night
	⏏	⏏	⏏	⏏



- Note:
- The SV Bias is put to function when the SB terminal is turned ON (short circuit).
 - While the SV Bias is functioning, and the PV/SV display is ON, the point on the lower right side of the SV display flashes.
 - When the value added to (subtracted from) the SV Bias gets out of the measuring range, the 100% FS (0% FS) thus limited serves as the Set Value.
 - The alarm function continues to be workable even when the SV Bias is functioning.


Setting of Key Lock (LOC)

Initial value: 0


When Key Lock is set at LOC 1, no parameter data can be changed.
When Key Lock is set at LOC 2, no parameter data except Set Value (SV) can be changed.
Key Lock is released by setting at LOC 0.

6 Operation


(1) Setting of Set Value (SV)



- Apply power and confirm that the PV/SV displays are on.




- Press the \odot key and change the PV display to the SV setting parameter.




- In the SV display, you can change to the desired value by means of the \wedge or \vee key. When the \odot key is pressed, the place of the figure to be changed is moved.

(When the \odot key is pressed, the point in the place of the figure that can be changed flashes in the SV display.)




- The example shows that the Set Value (SV) is set at 50.0°C.



- When the figure in the SV display has been changed to the desired value, register the value by pressing the \odot key.


(The point stops flashing and operation is started with the registered value.)

(2) Setting of Alarm (ALM)




- In the PV/SV display, press the \odot key while pressing the \wedge key to change it to an alarm setting parameter in the up key block.


The example shows the setting of higher limit deviation alarm. (A different parameter code is displayed according to the alarm specifications.)






- In the SV display, change the figure to the desired value and register the value by pressing the \odot key.

The example shows that the higher limit deviation alarm value is set at 20.0°C. If the Set Value (SV) is 50.0°C, the alarm output level is $50.0^\circ\text{C} + 20.0^\circ\text{C} = 70.0^\circ\text{C}$. Therefore, when a Process Value (PV) exceeds 70.0°C, an alarm is output (ALM closed).








To return to the PV/SV display, press the  key while watching the parameter codes. (The parameter code changes every time the  key is pressed.)





The PV/SV display is restored automatically if none of the front panel keys is pressed within 30 seconds.


(3) Setting of Key Lock




This is set after all the parameters have been set. In the PV/SV display, press the  key while pressing the  key, to bring the Key Lock parameter in the down key block onto display.





Select a desired Key Lock condition (see page.11) while watching the value in the SV display. When the  key is pressed, the Key Lock condition is set.



The example shows that Key Lock 1 is set.




To release the Key Lock condition, call up the Key Lock parameter display, change the figure on the SV display to 0 and press the  key.




The example shows that Key Lock condition 1 is released. (The same procedure is applicable to Key Lock condition 2.)

(4) Execution of Auto Tuning


This instrument is built with a microprocessor and has the Auto Tuning function to automatically compute optimum PID values and register them.




This is carried out after completing the setting of all the parameters except PID values and Key Lock.




In the PV/SV display, press the \odot key while pressing the \wedge key to bring the Auto Tuning parameter onto display.



"OFF" is shown in the SV display. Change the "OFF" code in the SV display to "ON" by pressing the \wedge or \vee key. Then press the \odot key to execute Auto Tuning.




When the \odot key is pressed with "ON" on display, the point on the lower right side in the SV display goes out and Auto Tuning starts. The AT lamp is lit to indicate that Auto Tuning is being executed.



The ON-OFF control functions and when it completes a limit cycle, the AT lamp goes out and Auto Tuning terminates. The PID values computed during Auto Tuning are automatically registered with the respective PID.

AT:PID AUTO TUNING FUNCTION

PID Auto Tuning shows the following characteristics.



In the operation of Auto Tuning, the limit cycle method is used. When Auto Tuning is executed, after the operation is carried out by repeating the ON-OFF action in two cycles if PV/SV during the execution and 1.5 cycles if PV/SV to take data in, PID values are automatically computed. The Auto Tuning time is decided by the time constant of the process.


If overshoot and undershoot are not allowed, terminate Auto Tuning earlier, or set the PID constant value manually.

PID values computed during Auto Tuning are optimum values, or common measures as it were. For some types of processes, better results may be obtained when PID values computed during Auto Tuning are amended manually before their use.

Note: 1. If power failure or overrange occurs during the execution of Auto Tuning, Auto Tuning will be released.

2. If output is at 0% or 100% continuously for more than 2 hours during the execution of Auto Tuning, Auto Tuning will be released automatically and the PID values will return to the previous ones.


3. When ON-OFF control has been selected, operation of Auto Tuning Parameter is not displayed.



4. While Auto Tuning is functioning, no setting other than its execution and stop can be changed.
5. To release Auto Tuning during operation, select OFF of the Auto Tuning parameter in the SV display and press the  key. Auto Tuning is released (the AT lamp goes off) and the PID values return to the previous ones.
6. If AT is executed again while Auto Tuning is functioning, AT is not restarted but just continues.
7. When power is turned ON again, operation is resumed with the parameters of the preceding operation with the assistance of the non-volatile memory.


(5) Operation by Set Value Bias


This feature provides the user with the ability to bias the set point figure by plus or minus 'x' amount. This is made operative by closing an external contact.

This feature is useful where two different set points are required and are frequently changed.






- In the PV/SV display, press the  key while pressing the  key to bring the SV-Bias parameter in the down key block onto display.



- In the SV display, set the desired value and register it by pressing the  key.

The example shows that SV Bias is set at 5.0 °C. If the Set Value (SV) is 80.0 °C, the Set Value while SV Bias is functioning (SB closed) will become 80.0 °C + 5.0 °C = 85.0 °C.







- While the SV Bias is functioning, the point on the lower right side in the SV display flashes to indicate that SV Bias is functioning.

The SV Bias function becomes ineffective during the execution of Auto Tuning.

7 Error Display

When the PV (Process Value) exceeds the measuring range, the following will be displayed.

Process Value (PV)	PV Display	Applicable Range
$-5\%FS \geq PV$		All ranges
$-5\%FS < PV < 0\%FS$		- 19.9 ~ 99.9
	PV value on display	All ranges except - 19.9 ~ 99.9
$-100\%FS < PV < 105\%FS$		0 ~ 99.9 / - 19.9 ~ 99.9 / 0 ~ 999
	PV value on display	All ranges except 0 ~ 99.9 / - 19.9 ~ 99.9 / 0 ~ 999
$PV \geq 105\%FS$		All ranges

Note: When **LL-** or **HH-** is displayed, control output becomes 0% regardless of the characteristics (RA/DA) and the alarm (option) is output. If Auto Tuning is executed at the time, Auto Tuning will be released.

8 Check Items in Troubleshooting

When something is found to be malfunctioning, check the input and output connections and wiring for a possible error, and check that no terminal is loosened. Then, go through the contents of the settings concerned. If the problem cannot be identified, turn the power OFF and apply power again to make sure.

MALFUNCTION	ITEMS TO BE CHECKED	REFERENCE PAGE
Error is found in PV.	<ul style="list-style-type: none"> Check type & standard of input. Check Sensor Compensation value. 	<p>P. 7</p> <p>P. 11</p>
Output does not change or is in wrong direction.	<ul style="list-style-type: none"> Check output characteristics (RA / DA). 	P. 7
SV cannot be changed.	<ul style="list-style-type: none"> Is procedure in order? Is Key Lock in effect? Is Auto Tuning in operation? 	<p>P. 8, P. 12 & P. 13</p> <p>P. 11, P. 12 & P. 13</p> <p>P. 14</p>
Alarm is not output.	<ul style="list-style-type: none"> Check inhibit / non-inhibit. Check alarm Set Value. 	<p>P. 7</p> <p>P. 10</p>
No operation	<ul style="list-style-type: none"> Check power source. Is inner unit encased properly? 	<p>P. 4</p> <p>P. 5</p>
Part of display (segment) is missing.	<ul style="list-style-type: none"> Instrument should be either repaired or replaced. 	

Temperature and Humidity Control Specialists

SHIMADEN CO., LTD.

Head Office: 2-30-10 Kitamachi, Nerima-ku, Tokyo 179 Japan
 Phone: (03) 3931-9111 Fax: (03) 3937-1240 Telex: 02722778 SDCL J

USED IN A LABORATORY

Type K Thermocouples Continued

Temperature in Degrees Celsius (IPTS 1968)

EMF in Absolute Millivolts																								Reference Junctions at 0°C											
DEG C	0	1	2	3	4	5	6	7	8	9	10	DEG C	0	1	2	3	4	5	6	7	8	9	10	DEG C											
350	14.292	14.334	14.376	14.418	14.460	14.502	14.544	14.586	14.628	14.670	14.712	350	14.292	14.334	14.376	14.418	14.460	14.502	14.544	14.586	14.628	14.670	14.712	350											
360	14.712	14.754	14.796	14.838	14.880	14.922	14.964	15.006	15.048	15.090	15.132	360	14.712	14.754	14.796	14.838	14.880	14.922	14.964	15.006	15.048	15.090	15.132	360											
370	15.132	15.174	15.216	15.258	15.300	15.342	15.384	15.426	15.468	15.510	15.552	370	15.132	15.174	15.216	15.258	15.300	15.342	15.384	15.426	15.468	15.510	15.552	370											
380	15.552	15.594	15.636	15.678	15.720	15.762	15.804	15.846	15.888	15.930	15.972	380	15.552	15.594	15.636	15.678	15.720	15.762	15.804	15.846	15.888	15.930	15.972	380											
390	15.972	16.014	16.056	16.100	16.142	16.184	16.227	16.269	16.311	16.353	16.395	390	15.972	16.014	16.056	16.100	16.142	16.184	16.227	16.269	16.311	16.353	16.395	390											
400	16.395	16.438	16.480	16.522	16.564	16.607	16.649	16.691	16.733	16.776	16.818	400	16.395	16.438	16.480	16.522	16.564	16.607	16.649	16.691	16.733	16.776	16.818	400											
410	16.818	16.860	16.902	16.945	16.987	17.029	17.072	17.114	17.156	17.199	17.241	410	16.818	16.860	16.902	16.945	16.987	17.029	17.072	17.114	17.156	17.199	17.241	410											
420	17.241	17.283	17.326	17.368	17.410	17.453	17.495	17.537	17.580	17.622	17.664	420	17.241	17.283	17.326	17.368	17.410	17.453	17.495	17.537	17.580	17.622	17.664	420											
430	17.664	17.707	17.749	17.792	17.834	17.876	17.919	17.961	18.004	18.046	18.088	430	17.664	17.707	17.749	17.792	17.834	17.876	17.919	17.961	18.004	18.046	18.088	430											
440	18.088	18.131	18.173	18.216	18.258	18.301	18.343	18.385	18.428	18.470	18.513	440	18.088	18.131	18.173	18.216	18.258	18.301	18.343	18.385	18.428	18.470	18.513	440											
450	18.513	18.555	18.598	18.640	18.683	18.725	18.768	18.810	18.853	18.895	18.938	450	18.513	18.555	18.598	18.640	18.683	18.725	18.768	18.810	18.853	18.895	18.938	450											
460	18.938	18.980	19.023	19.065	19.108	19.150	19.193	19.235	19.278	19.320	19.363	460	18.938	18.980	19.023	19.065	19.108	19.150	19.193	19.235	19.278	19.320	19.363	460											
470	19.363	19.405	19.448	19.490	19.533	19.576	19.618	19.661	19.703	19.746	19.788	470	19.363	19.405	19.448	19.490	19.533	19.576	19.618	19.661	19.703	19.746	19.788	470											
480	19.788	19.831	19.873	19.916	19.959	20.001	20.044	20.086	20.129	20.172	20.214	480	19.788	19.831	19.873	19.916	19.959	20.001	20.044	20.086	20.129	20.172	20.214	480											
490	20.214	20.257	20.299	20.342	20.385	20.427	20.470	20.512	20.555	20.598	20.640	490	20.214	20.257	20.299	20.342	20.385	20.427	20.470	20.512	20.555	20.598	20.640	490											
500	20.640	20.683	20.725	20.768	20.811	20.853	20.896	20.938	20.981	21.024	21.066	500	20.640	20.683	20.725	20.768	20.811	20.853	20.896	20.938	20.981	21.024	21.066	500											
510	21.066	21.109	21.152	21.194	21.237	21.280	21.322	21.365	21.407	21.450	21.493	510	21.066	21.109	21.152	21.194	21.237	21.280	21.322	21.365	21.407	21.450	21.493	510											
520	21.493	21.535	21.578	21.621	21.663	21.706	21.749	21.791	21.834	21.876	21.919	520	21.493	21.535	21.578	21.621	21.663	21.706	21.749	21.791	21.834	21.876	21.919	520											
530	21.919	21.962	22.004	22.047	22.090	22.133	22.175	22.218	22.261	22.303	22.346	530	21.919	21.962	22.004	22.047	22.090	22.133	22.175	22.218	22.261	22.303	22.346	530											
540	22.346	22.388	22.431	22.473	22.516	22.559	22.601	22.644	22.687	22.729	22.772	540	22.346	22.388	22.431	22.473	22.516	22.559	22.601	22.644	22.687	22.729	22.772	540											
550	22.772	22.815	22.857	22.900	22.942	22.985	23.028	23.070	23.113	23.156	23.198	550	22.772	22.815	22.857	22.900	22.942	22.985	23.028	23.070	23.113	23.156	23.198	550											
560	23.198	23.241	23.284	23.326	23.369	23.411	23.454	23.497	23.539	23.582	23.624	560	23.198	23.241	23.284	23.326	23.369	23.411	23.454	23.497	23.539	23.582	23.624	560											
570	23.624	23.667	23.710	23.752	23.795	23.837	23.880	23.923	23.965	24.008	24.050	570	23.624	23.667	23.710	23.752	23.795	23.837	23.880	23.923	23.965	24.008	24.050	570											
580	24.050	24.093	24.136	24.178	24.221	24.263	24.306	24.348	24.391	24.434	24.476	580	24.050	24.093	24.136	24.178	24.221	24.263	24.306	24.348	24.391	24.434	24.476	580											
590	24.476	24.519	24.561	24.604	24.646	24.689	24.731	24.774	24.817	24.859	24.902	590	24.476	24.519	24.561	24.604	24.646	24.689	24.731	24.774	24.817	24.859	24.902	590											
600	24.902	24.944	24.987	25.029	25.072	25.114	25.157	25.199	25.242	25.284	25.327	600	24.902	24.944	24.987	25.029	25.072	25.114	25.157	25.199	25.242	25.284	25.327	600											
610	25.327	25.369	25.412	25.454	25.497	25.539	25.582	25.624	25.666	25.709	25.751	610	25.327	25.369	25.412	25.454	25.497	25.539	25.582	25.624	25.666	25.709	25.751	610											
620	25.751	25.794	25.836	25.879	25.921	25.964	26.006	26.048	26.091	26.133	26.176	620	25.751	25.794	25.836	25.879	25.921	25.964	26.006	26.048	26.091	26.133	26.176	620											
630	26.176	26.218	26.260	26.303	26.345	26.387	26.430	26.472	26.515	26.557	26.599	630	26.176	26.218	26.260	26.303	26.345	26.387	26.430	26.472	26.515	26.557	26.599	630											
640	26.599	26.642	26.684	26.726	26.769	26.811	26.853	26.896	26.938	26.980	27.022	640	26.599	26.642	26.684	26.726	26.769	26.811	26.853	26.896	26.938	26.980	27.022	640											
650	27.022	27.065	27.107	27.149	27.192	27.234	27.276	27.318	27.361	27.403	27.445	650	27.022	27.065	27.107	27.149	27.192	27.234	27.276	27.318	27.361	27.403	27.445	650											
660	27.445	27.487	27.529	27.572	27.614	27.656	27.698	27.741	27.783	27.825	27.867	660	27.445	27.487	27.529	27.572	27.614	27.656	27.698	27.741	27.783	27.825	27.867	660											
670	27.867	27.909	27.951	27.993	28.035	28.078	28.120	28.162	28.204	28.246	28.288	670	27.867	27.909	27.951	27.993	28.035	28.078	28.120	28.162	28.204	28.246	28.288	670											
680	28.288	28.330	28.372	28.414	28.456	28.498	28.540	28.583	28.625	28.667	28.709	680	28.288	28.330	28.372	28.414	28.456	28.498	28.540	28.583	28.625	28.667	28.709	680											
690	28.709	28.751	28.793	28.835	28.877	28.919	28.961	29.002	29.044	29.086	29.128	690	28.709	28.751	28.793	28.835	28.877	28.919	29.002	29.044	29.086	29.128	29.170	690											
700	29.128	29.170	29.212	29.254	29.296	29.338	29.380	29.422	29.464	29.505	29.547	700	29.128	29.170	29.212	29.254	29.296	29.338	29.380	29.422	29.464	29.505	29.547	700											
710	29.547	29.589	29.631	29.673	29.715	29.756	29.798	29.840	29.882	29.924	29.965	710	29.547	29.589	29.631	29.673	29.715	29.756	29.798	29.840	29.882	29.924	29.965	710											
720	29.965	30.007	30.049	30.091	30.132	30.174	30.216	30.257	30.299	30.341	30.383	720	29.965	30.007	30.049	30.091	30.132	30.174	30.216	30.257	30.299	30.341	30.383	720											
730	30.383	30.424	30.466	30.508	30.549	30.591	30.632	30.674	30.716	30.757	30.799	730	30.383	30.424	30.466	30.508	30.549	30.591	30.632	30.674	30.716	30.757	30.799	730											
740	30.799	30.840	30.882	30.924	30.965	31.007	31.048	31.090	31.131	31.173	31.214	740	30.799	30.840	30.882	30.924	30.965	31.007	31.048	31.090	31.131														

Mat 2777844



GENAUST POWER

A.V.R. 380 SERIES

08-2696976

This unit will replace the following AVR's: Caterpillar, Dunlite, Stamford, Markon-Controlgy, Stone, McColl, Brush, Modra, Arrow, Kato, Artemus, Taiyo, Lister, Newton Derby, Reliance, Marathon, Kubota, Basler and many more.

AVR 380 AUTOMATIC VOLTAGE REGULATOR

1. INTRODUCTION

The AVR 380 is a solid state device, which is designed to give accurate and stable voltage regulation of alternators.

The AVR is suitable for regulating 50 or 60Hz brushless, rotating or stationary field alternators regardless of prime mover type and will replace most electronic regulators with or without separate excitation.

The AVR is suitable for one or three phase alternators and has four selectable voltage sensing ranges available.

i.e. 120, 208, 240 and 415V

The AVR is suitable for parallel operation of alternators with quadrature droop facilities with only an additional standard 5 amp current transformer and resistor being required.

The AVR has several features:-

1. Voltage adjustment $\pm 10\%$ over each range.
2. Overload sensing and shut down, plus opto isolator for remote indication.
3. Wide range of stability.
4. Underspeed adjustment which will provide voltage droop with large motor starting loads, this feature will provide excellent starting characteristics and prevent unnecessary stalling of the prime mover.
5. Remote voltage adjustment available.
6. Optional overvoltage crow bar protection circuit is available which will blow the fuse, further protecting the load. (Order before delivery from factory.)
7. Transformer isolated voltage sensing.

2. OPERATION

The regulator senses the alternator output and derives excitation power from the 3 phase connections to the alternator output.

Regulation and stability is maintained provided the prime mover speed is within governor class A1 to ISO3046, at any machine load or power factor by comparing the sensed voltage with a reference bridge.

The unit constantly adjusts the field excitation level to compensate for voltage difference between the sensed voltage and reference.

Output voltage of the machine will be held to $\pm 1.5\%$ including cold to hot variations in ambient conditions of -10 deg. to $+60$ deg. and engine speed changes of $\pm 4\%$ from preset nominal.

3. CONSTRUCTION

The assembled PCB is solidly mounted in a folded aluminium housing which provides the necessary mechanical protection and is suitable to mount directly in the alternator terminal box or in the separate control cubicle.

All components used are selected for stable operation in ambients ranging from -10 deg. to 70 deg. and severely capacity derated for high reliability.

The printed circuit board is a 1.5mm reinforced fibreglass with double sided tracks and plated through holes.

4. CONTROLS

There are five standard and one optional control on each AVR.

a. Stability I

This potentiometer adjusts the stability and response of the alternator and should initially be set in a counter-clockwise position and rotate clockwise to give optimum stability and response characteristics. Once set, no further adjustment should be necessary.

Full CCW position gives maximum response, minimum stability.

Full CW position gives minimum response, maximum stability.

b. Voltage Adjust

This potentiometer varies the reference voltage and hence the amount of excitation of the alternator which adjusts the output voltage over a range of $\pm 10\%$.

An external 5K potentiometer may be added to terminals P.P. for remote panel voltage adjustment. When this is used the loop on P.P. is removed and the internal pot is turned to maximum.

c. Underspeed

This potentiometer sets the frequency at which voltage drooping with speed will occur.

For example, if set at 48Hz and a large motor is started which temporarily overloads the prime mover on starting, once the speed falls to 48Hz the alternator voltage will decrease and act as an automatic reduced voltage starter and greatly assist in motor starting.

d. Overload

This potentiometer sets the maximum permissible field excitation should the engine speed remain constant whilst the alternator is overloaded. Allowances are made for temporary overload by a non-adjustable built in 15 seconds delay.

Once the overload does trip, the output voltage falls to approximately 50 volts and can only be reset by stopping the engine.

e. Stability II - Located on PBC next to IC.I

This potentiometer widens the range of stability and should always be normally fully anti-clockwise and only adjusted slightly clockwise to counter further stability should 'Stability I' run out of range particularly on single phase machines.

Set stability II fully anti-clockwise for 3 phase or clockwise for 1 phase.

f. Overvoltage (Optional)

5. ADJUSTMENTS

a. Voltage

The AVR sensing voltage must be first selected for the required sensing voltage. Adjacent to the transformer are four pins connected to the relevant pin to match the available sensing output of the alternator. 120, 208, 240 and 415 volts.

NOTE: If replacing other electronic regulators for convenience use the same sensing connections if possible.

b. Stability

Rotate clockwise to increase stability.

To check, if after sudden load change prolonged fluctuation occurs, turn stability slightly clockwise, or if voltage is very slow to recover from load changes then counter clockwise.


c. Underspeed

To adjust the alternator must be running at the correct speed. i.e. 50Hz \pm at no load.

Connect an AC voltmeter across the output of the alternator and slowly turn the underspeed potentiometer clockwise until the voltage just starts to fall, then turn slightly counter-clockwise, approx 30 deg.

To check apply full load if possible and voltage should not droop more than 1%.

Or alternatively lower speed to 48 Hz and voltage should droop.



d. Overload

NOTE: Some alternator manufacturers state maximum field voltage or scoop setting, these will correspond to overload setting.

To adjust correctly connect a 0-50V voltmeter across the field positive and negative.

Run the plant at the correct speed and apply full load, slowly turn the overload potentiometer counter-clockwise until the LED just lights then turn 30 deg. clockwise until LED off.

Apply overload, LED should illuminate for 15-20 seconds before output falls to approximately 50-80 volts AC.


Stopping the plant will automatically reset this function.

If load is not available an alternative test is to connect a 50 ohm rheostat in the field circuit (series) and by increasing the resistance this will cause the field voltage to increase until the desired maximum level is reached. (In the absence of any manufacturers detail a maximum field voltage of 46 - 48V can be used.)

advised Power
\$418.00

6. CONNECTIONS

a. Standard 3 phase 4 wire




Transformer

Tap Selections

- (a) 415/240V - 415 tap
- (b) 208/120V - 208 tap

b. Standard 1 phase 2 wire




Transformer

Tap Selections

- (a) 240V - 240V tap
- (b) 120V - 120V tap

c. Non Standard 3 phase 3 wire

To be used in the event of a machine with field resistance higher than 50 ohms to ensure sufficient field excitation supply voltage is available.



*NOTE! For non standard connection with L1-N and L3 on 415 Volt remove large green 10K resistor, located next to transformer. It may become too hot and damage the PCB. R14

Transformer

Tap Selections

- (a) 415/240V - 415V tap
- (b) 208/120V - 208V tap

7. RADIO INTERFERENCE

Additional RFI suppression can be achieved by connecting a 0.47MFD capacitor, rated at 250 volt AC between terminals N & L3.

8. DROOP FACILITY

The AVR has quadrature droop facilities for parallel operations.


Quadrature droop allows load sharing of reactive load (KVAR) only since KW load is a function of the prime mover.

A current transformer with 5 amp output at 10VA secondary rating and ratio of twice the alternator output is required.

When this is used the loop between D1 and D2 must be removed.

Droop Facility

The current transformer must be connected in the blue phase or L3. It is to be noted that the AVR senses Red L1 and Yellow L2 phase voltage and to achieve quadrature droop, current must be sensed in the blue or L3 phase.



R1 1 ohm 2w

R2 adjustable 30 ohm 2W

- NOTE:
1. R2 must be adjusted on both plants to give same voltage drop (approximately 5V/100%) for equal % of load for correct KVAR load sharing.
 2. If rising voltage with load is detected the current transformer primary current flow direction must be reversed by reversing the transformer body.
i.e. Remove the primary turns and rotate transformer 180 deg. and reconnect secondary.

9. SPECIFICATIONS


Voltage range 120, 208, 240, 415 volts
 Selectable taps $\pm 10\%$ adjustment on each range
 Maximum field current 10 amps
 SCR rated at 50 amps 1600 volts
 Suitable for single and three phase alternators
 Regulation $\pm 1.5\%$ (1% can be attained on some machines)
 Temperature -10 deg. to 60 deg.
 Underspeed adjustment 10Hz - 55Hz
 Time delay 15 - 20 seconds approximately fixed
 Residual voltage required for reliable excitation 3-5 volts
 Minimum field resistance 3-5 ohms
 Field voltage 50% of input sensing voltage

10. REMOTE VOLTAGE CONTROL

The AVR has remote voltage facilities where the voltage range can be varied up to 10%.

Remove bridge from P.P. and fit external 5K linear 2W potentiometer. Turn the pot on the AVR fully clockwise so as to have maximum voltage range.


It is necessary to use screened cable for remote control, connect as Figure 5.



11. REMOTE OVERLOAD INDICATION

O1 and O2 terminals are used for remote indication of overload operation.


The output is an opto coupled NPN transistor, maximum output is 50ma suitable for LED driver, shut down signal or relay.



12. BENCH TEST

The AVR can be bench tested as follows

a. Test Circuit



b. AVR Test Setup

Transformer

Tap Selections

(a) 240V - 240V tap


c. Test equipment required

1. A 240 Volt 40 Watt globe, complete with holder and wire.
2. 3 pin 240 Volts mains plug and lead.
3. Mains supply.

d. Procedure

1. Remove AVR from generator.
2. Connect as above and select transformer tap to 240 Volt position. (Note the original sensing voltage tap position)
3. Mark position of voltage adjusting potentiometer with biro or pencil. (This enables the potentiometer to be returned to its original position.)
4. Turn voltage adjusting potentiometer fully clockwise.
5. Turn on the 240 Volt supply.
6. 240 Volt globe should be illuminated and the overload LED should be on for 15-20 seconds, then go off.
7. Turn 240 volt supply off. (Resets the overload)
8. Turn the voltage potentiometer fully anti-clockwise.
9. Turn 240 volt supply on
10. 240 volts globe should just flash and then remain off immediately.

11. Turn the voltage adjusting potentiometer back to the original position or just passed. If the AVR was set to 240 volts as the mains then the light should again come on for 15-20 seconds and go off.
12. If the AVR operates as the test procedure then the fault may be in the alternator.
13. Reconnect to alternator making sure the T/F sensing tap is returned to it's correct position and try again.



GENAUST POWER PTY. LTD. 1111 Main Street Sydney, N.S.W. 2000 Australia		DATE: 14/07/01 DESIGNED: J.A.A. DRAWN: J.A.A. CHECKED: J.A.A. APPROVED: J.A.A.		SCALE:
		PART NUMBER: 380.S.001		A2 380.S.001
COMPONENT LAYOUT AVR 380		SER NO.		
		TYPE 380.S.001		

CONTROL AND PROTECTION UNITS

GENAUST POWER
A.V.R. 400 SERIES

STAB. 1

STAB. 2

UNDER
SPEED

VOLTS

UNDER
SPEED
L.E.D.

6 LA SALLE STREET DUDLEY PARK, S.A. 5003 PH: (08) 269 7000 FAX: 269 6976


SCALE	GENAUST POWER PTY. LTD.
PART NUMBER	383-S-014
AZ ES-00 54	

MADE IN
AUSTRALIA

○ O/LOAD INDICATION
OVERLOAD UNDER VOLTS STABILITY
ADJUST SPEED ADJUST

GENAUST POWER
A.V.R. 380 SERIES

6 LA SALLE STREET DUDLEY PARK, S.A. 5003 PH: (08) 269 7000 FAX: (08) 269 6976



PTY. LTD.

AVR 380

AUTOMATIC VOLTAGE REGULATOR

A solid state device which is designed to provide stable voltage regulation to a wide range of 3 phase or 1 phase brushless rotating or stationary field alternators regardless of prime mover type.

Provision is made for:


- Remote voltage adjustment
- Remote overload indication
- Quadrature droop input for reactive load sharing.

The regulator has many features which benefit its user.

1. Built-in reliability using underrated components and plated through component PCB holes.
2. Fully repairable.
3. Adjustable volts/hertz characteristics which assists prime mover recovery on application of large step loads.
4. Input transformer isolation for better circuit protection. With input taps for 120, 208, 240 and 415V sensing, 50 or 60Hz.
5. Wide adjustable stability range to eliminate light flicker especially useful on 1 phase machines.
6. Overload field current sensing which provides protection for both the AVR and the alternator.
7. Voltage adjustment of $\pm 10\%$ over each sensing range provides setting accuracy down to $\pm 1\%$ on most machines.
8. 12 months warranty.
9. Comes with detailed operation and connection instructions.

Physical Size:
220mm long
133mm wide
73mm deep
0.71kg weight

Mounting
centres:
95 x 210mm
via 4 x M4
screws.



GENAUST POWER PTY. LTD.

EPU 300

ENGINE PROTECTION UNIT




A unit designed with latest CMOS technology to protect any stationary or mobile diesel engine from damage due to such things as:

- High cooling medium temperature
- Low lubrication oil pressure
- Underspeed
- Loss of coolant liquid
- Water contamination of fuel
- High exhaust temperature
- Overspeed


as well as allowing starter motor cut out on remote start applications.

Just some of the features which benefit the user are:

- 1. Full reliability using undegraded components and protected through conformal coating holes.
- 2. Fully repairable open PCB construction.
- 3. Can be used on 8-48V DC supply.



GENAUST POWER PTY. LTD.		SCALE
PART NUMBER		383-S-014
A2		ES-00 54






- 1. Regulated 5V supply on board.
- 2. Supply to prevent drop out on depressed supply.
- 3. Voltage 5V, selectable N.O. or N.C. inputs for safety sensing switches.
- 4. Speed sensing from any 4 of 4 signal sources and switch selectable.
- 5. Comes with detailed operation and connection instructions.
- 6. 12 month warranty.
- 7. Output terminals for remote fault indication.
- 8. On board potentiometer adjustments for:
 - Crank output speed
 - Overspeed
 - Underspeed
- 9. On board LED indicators for:
 - Crank relay energised
 - Overspeed
 - Underspeed
 - Temperature
 - Pressure
 - Plus 2 spares.
- 10. On board crank and fuel solenoid control relays each with a 10A changeover contact.

Physical Size:

225mm long, 138mm wide, 33mm deep, 0.7kg weight.

Mounting centres:

95 x 215mm via 4 x M4 screws.



GENAUST POWER PTY. LTD.

AVR 400


AUTOMATIC VOLTAGE REGULATOR

Provides most of the facilities on it's bigger brother the AVR 380. Is more compact, extremely good value by comparison, has many of the AVR 380 features:


1. Built in reliability using underrated components and plated through component PCB holes.
2. Fully repairable.
3. Adjustable volts/hertz characteristics which assists prime mover recovery with applications of large step loads.
4. Wide adjustable stability range to eliminate light flicker especially useful on 1 phase machines.
5. Voltage adjustment of $\pm 10\%$ over each sensing range provides setting accuracy down to $\pm 1\%$ on most machines.
6. 12 months warranty.
7. Comes with detailed operation and connection instructions.
8. Switch selectable voltage input sensing.
9. Field current protection fuse.

Physical Size:
145mm long, 120mm wide,
73mm deep, 0.39kg weight.

Mounting centres:
95 x 138mm via 4 x M4 screws.



GENAUST POWER PTY.
AVR 400
GENAUST POWER PTY.
ENSC



Employing the very latest state-of-the-art technology Genaust Power produces a range of products which are fully designed and fully manufactured in Australia.

Our company is proudly owned and managed by Australians. With a high level of industrial expertise and professional attitudes, we have rapidly gained recognition for the quality of our products and we are now positioned at the forefront of the industry.

Without a doubt, when you purchase Genaust Power products, you will be assured of our renowned value-for-money and built-in reliability.

GENAUST POWER
PTY. LTD.
6 La Salle Street,
Dudley Park,
South Australia 5008

Phone: (61+8) 269 7000
(24 hr)
Facsimile (61+8) 269 6976
A.G.N. 008 127 320

Distributed by:

