



JOHN VALVES

The Valve People

Operation and Maintenance Manual.

Client :

Brisbane Water

Contract No. :


**R. 111/96/97
Supply of Sluice Valves
DN450 to DN1200.**

Supplier :

**John Valves Pty Ltd ACN 006 061 674
Creswick Road, Ballarat, Victoria, Australia 3350
Telephone : 03 53330777 Fax : 03 53381771**



Ref. MM452202
Rev. 0
April, 1998



JOHN VALVES

The Valve People

Operation and Maintenance Manual.

Client :

Brisbane Water

Contract No. :

R. 111/96/97

**Supply of Sluice Valves
DN450 to DN1200.**

Supplier :

**John Valves Pty Ltd ACN 006 061 674
Creswick Road, Ballarat, Victoria, Australia 3350
Telephone : 03 53330777 Fax : 03 53381771**

Ref. MM452202
Rev. 0
April, 1998

CONTENTS

| | |
|-------------|---------------------------|
| SECTION 1: | Safety Precautions. |
| SECTION 2: | Technical Data. |
| SECTION 3: | Functional Description. |
| SECTION 4: | Installation. |
| SECTION 5: | Preventative Maintenance. |
| SECTION 6: | Corrective Maintenance. |
| SECTION 7: | Gearbox Details. |
| SECTION 8: | Drawings |
| SECTION 9: | Trouble Shooting. |
| SECTION 10: | Spare Parts. |

Section 1

Safety Precautions

1.1 General

Do not attempt to store, install, operate the valve or operator without reading the instructions included in this manual.

1.2 Valve (Mechanical)

The valve assembly has been supplied in wooden crates or strapped and fastened to wooden pallets.

Ensure that the equipment is properly supported and carefully lifted using properly located slings so as to prevent damage to the equipment.

Once the equipment is uncrated ensure that the valve is lifted so that the total mass is supported by both lifting eyes.

Ensure that all the equipment is stored in such a manner to properly support the complete valve and actuator assembly from distortion or damage.

Ensure that the equipment is protected from the weather conditions and ingress of foreign matter during storage.

1.3 Valve Operator

Ensure that the Gearbox maintenance instructions in Section 7 forming part of this manual are carefully read and fully understood before operating the valve.

Section 2**Technical Data.**

| Nominal Size (mm) | 450 | 600 | 750 | 900 | 900 | 1200 |
|-------------------------------------|-------------------------------------|---------------|---------------|---------------|--------------------|---------------------|
| John Valves Assembly Drawing No | AL421 | AL420 | AL419 | AL418 | AL417 | AL416 |
| John Valves Item No | 69#A0450-S023 | 69#A0600-S020 | 69#A0750-S011 | 69#A0900-S010 | 69#A0900-S009 | 69#A1200-S001 |
| Quantity | 1 | 1 | 1 | 2 | 1 | 1 |
| John Figure No | 694 | 694 | 694 | 694 | 694 | 694 |
| Type | Sluice | Sluice | Sluice | Sluice | Sluice | Sluice |
| Flange Drilling | AS4087 B2 | AS4087 B2 | AS4087 B2 | AS4087 B2 | AS4087 B2 | AS4087 B2 |
| Maximum Differential Pressure (Kpa) | 1400 | 1400 | 1200 | 1200 | 1200 | 1200 |
| Test Presures : Body (Kpa) | 2800 | 2800 | 2400 | 2400 | 2400 | 2400 |
| Seat (Kpa) | 1400 | 1400 | 1200 | 1200 | 1200 | 1200 |
| Operator Type | Spur | Bevel | Bevel | Bevel | Electric | Electric |
| Operator Brand | Hercus | Hercus | Hercus | Hercus | Limitorque | Limitorque |
| Operator Model | SVT10 | BVT35 | BVT35 | BVT55 | L12040252 BVT55RA7 | L12085606 BVT95RA15 |
| Operator Ratio | 3:1 | 4:1 | 4:1 | 4:1 | 16:1 | 16:1 |
| Valve Mass (Kg) | 982 | 1890 | 3540 | 5500 | 5700 | 9600 |
| Coating System | Jotacote 412 Internal and External. | | | | | |

Section 3**FUNCTION DESCRIPTION**

The 'John' Figure No 694 design flanged gate valve is a non rising stem inside screw wedge type gate valve. This design is primarily for isolating duties, The valve is constructed from spheroidal graphite cast iron body, bonnet and wedge with gunmetal wedge nut, "screwed in" type body seat and wedge rings with type 431 stainless steel stem and galvanised carbon steel component bolting, guide liners are fitted to the body and wedge, this allows for horizontal operation of the valve in situ.

The valves are coupled to a Hercus gearbox which includes a glacier thrust bearing arrangement, where applicable the Electric Actuators are close coupled to the gearbox.

The gearbox is grease filled lubricated and sealed for life to provide maintenance-free reliability.

Section 4

INSTALLATION

Leave flange protectors and other protective material in place until the valve is ready for installation.

Ensure conduit entries on operators are kept sealed until connection.

During installation support should be provided for the free ends of the pipes, as unsupported pipes hung from valves can originate high stresses in the valve body causing leaks or possible damage.

Ensure all flanges and the inlet and outlet ports of the valve and mating pipes are clean prior to installation.

Fit gaskets to adjacent pipework, using suitable lifting gear and both eyebolts (on valves with eyebolts) provided, install valve in position on the flanges and fit flange bolts and run up nuts. Tighten nuts working on a diagonally opposite sequence.

Section 5

PREVENTATIVE MAINTENANCE

5.1 Routine

5.1.1 Gland Tightening

Tightening gland nuts evenly after short period of service. **THIS IS MOST IMPORTANT.** Most damage to valve packing's occurs during early life of the packing due to inattention during the first few days of service. Follow this procedure at monthly intervals and after each repacking of stuffing box. **DO NOT OVERTIGHTEN**

5.1.2 Stuffing Box Packing

To prevent leakage, packing should be added when it is necessary to screw gland nuts more than half way. Should leakage persist after topping up stuffing box, all existing packing must be replaced.

5.2 Periodic

5.2.1 General

Visually check for any leakage.

5.2.2 Body / Bonnet Joint.

At yearly intervals the body / bonnet joint and bonnet / yoke joint should be checked for tightness. Joint faces will be ruined if leakage is permitted. Bonnet nuts and yoke nuts should be tightened evenly, the bonnet nuts in cross - over sequence, not in consecutive order. Any leakage persisting should immediately be fitted with new 'O' rings and gaskets.

5.3 Lubrication

Moving internal parts are lubricated by the service fluid and further lubrication is unnecessary.

Refer to the operator maintenance instructions for lubrication details if required.

Section 6

CORRECTIVE MAINTENANCE

Note 1: Ensure the valve is in the closed position or gagged as noted in 6.1 below..

Should leakage be detected, the valve must be dismantled for inspection and this may be carried out with the body remaining in the line. To re-face body seats the valves must be removed from the line.

Method

The following instructions shall be read in conjunction with the relevant Assembly drawing.

6.1 Dismantle

1. Depressurise line or isolate valve and drain, isolate any power supply for safety.
2. The stem should be gagged by clamping two flat bars onto the milled flats positioned on the stem above the gland, provide suitable packing under the bars to hold the stem in position.
3. Loosen grubscrews in the thrust nut locking nut and remove locking nut and thrust nut.
4. Remove the gear operator from the gearbox stand.
5. Remove stand, Note : The 900 & 1200mm valves have an integral stuffing box and gearbox stand.
6. Unscrew gland stud nuts and remove gland.
7. Unscrew stuffing box nuts and remove stuffing box.
8. Remove bonnet bolts, nuts and bonnet.
9. Carefully raise the wedge / stem assembly vertically clear of the valve body.
Note : The wedge can move sideways allowing the wedge to disengage from the stem/wedge nut assembly.
10. Support the wedge and remove the stem/wedge nut assembly.
11. Unscrew wedge nut from stem.
12. Thoroughly clean all parts and inspect for wear or damage.

6.2 Repairing Parts

Damaged parts should be replaced with new ones available from your supplier or from our Spares department. Any series number shown on the valve or part should be quoted when ordering. Certain parts can be reconditioned if plant is available locally, or return to our Reconditioning department for attention. Facilities are available at our Works for reconditioning complete valves or parts.

6.3 Re-facing Body Seat Rings

The body seat rings of bronze are retained in the body by screwed connection into the body. They must be reconditioned in the valve.

Ref. MM452202
Rev 0
April, 1998

Method

If the body seat ring faces can be reconditioned by lapping, a flat lapping plate of suitable size should be used with oil mixed lapping compound, Grade 400. Remove valve from pipeline if faces are damaged sufficiently to need re-machining. If it is necessary to machine more than 0.4mm metal from each seat ring it is preferable that the valve be returned to the manufacturer for fitting new rings and wedge. If circumstances are such that it is not practical to return the valve, it is possible to machine the body seat rings and fit an oversize wedge.

Fitting New Body Seat Rings

This cannot be done satisfactorily on site. Refer to preceding paragraph.

6.4 Re-facing Wedges

Wedge of cast iron, with bronze facing rings, can be reconditioned by machining or grinding an equal amount off each face and finally lapping. Included angle is 10°. If more than 0.4mm material has to be removed from each face a replacement plain wedge or wedge with facing rings is necessary. Bronze wedge facing rings are securely held in place by a dovetail press-in method or screwed onto the wedge on larger sizes and cannot be replaced. If lapping is necessary wedge faces should be lapped on a flat cast iron lapping plate with oil mixed lapping compound, Grade 400, using a planetary motion covering the whole area of the plate.

Fitting New Wedges

Standard replacement wedges with integral faces or facing rings are available and should be fitted by following the re-assembly procedure. Oversize wedges can be obtained to special order.

6.5 Stem And Wedge Nut

Check for wear, scoring and straightness of the stem and any excessive wear on the shoulders of the wedge nut, if these are apparent, then these parts must be repaired or replaced.

6.6 Re-Assembly

To re-assemble the valve follow the reverse procedure to dismantling using new gaskets and packing applying grease lubricant to the stem threads and lightly smear stem plain portion.

The bonnet bolts must be tightened up evenly on a cross-over sequence and the gland stud nuts tightened sufficiently to compress the packing. Ensure liberal amounts of anti-seize is applied to threads.

If the body was removed from the line, new 'O' rings and gaskets must be used when the valve is re-installed.

6.7 Re-Fitting Gear Operator

Ensure the wedge is in the fully closed position and the shoulder on the stem is hard up against the operator nut.

Check that the operator mounting flange sits freely onto the matching piece, if this does not occur, then rotate the stem into the valve until the flange sits freely.

6.8 Repair And Overhauling Manual Operator

Refer to relevant Operating and Maintenance Instructions covering the manual operator.

Gear Operators are grease packed and sealed for life and would only require repacking if the gear operator is dismantled.

6.9 Re Testing

Re-introduce line pressure, inspect all joints and seals are free from leaks, re-check all bolts for tightness and check valve operation.

Section 7**GEARBOX / ELECTRIC ACTUATOR DETAILS**

| Title | Ref No |
|---|---|
| UEC-3 Universal Electronic Controller | Bulletin 440-12000 Rev C Issue5/97 |
| L120 Series Type Instruction & Maintenance Manual | Bulletin 120-11000 Issue 2/97 |
| Maintenance Instructions Hercus SVT Series Valve Operators. | SVT10 Glacier Thrust-Drg 68MA207 |
| Maintenance Instructions Hercus BV Series Valve Operators. | BVT35 Glacier Thrust-Drg 68MA320 |
| Maintenance Instructions Hercus BV Series Valve Operators. | BVT55 Glacier Thrust-Drg 66MA413 |
| Maintenance Instructions Hercus BV Series Valve Operators. | BVT55-GA8D-F14 Glacier Thrust-Drg 66M4A15 |
| Maintenance Instructions Hercus BV Series Valve Operators. | BVT95-GA8D-F16 Glacier Thrust-Drg 66M5A16 |

UEC-3 Universal Electronic Controller

For ROM version 1.41 or higher

Operation Manual

Limitorque®

WARNING

Read this Instruction Manual carefully and completely before attempting to set-up, operate or troubleshoot your Limitorque UEC-3 Controller. Be aware of electrical hazards within the actuator and high pressure hazards of the attached valve or other actuated device when installing or calibrating your UEC-3 Controller.

**UEC-3 Universal Controller
Operation Manual**

© 1996 Copyright Limitorque Corporation, All rights reserved.

Printed in the United States of America.

DISCLAIMER

All rights reserved. No part of this manual shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise without the written permission from Limitorque. While every precaution has been taken in the preparation of the book, the publisher assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

This document is proprietary information of Limitorque Corporation furnished for customer use ONLY. No other uses are authorized without written permission of Limitorque Corporation.

Limitorque Corporation reserves the right to make changes, without notice, to this document and the products it describes. Limitorque Corporation shall not be liable for technical or editorial errors or omissions made herein; nor for incidental or consequential damages resulting from the furnishing, performance or use of this document.

This manual contains information that is correct to the best of Limitorque's knowledge. It is intended to be a guide and should not be considered as a sole source of technical instruction, replacing good technical judgment, since all possible situations cannot be anticipated. If there is any doubt as to exact installation, configuration, and/or use, call Limitorque Corporation, at (804) 528-4400.

The choice of system components is the responsibility of the buyer, and the use to which they are put cannot be the liability of Limitorque Corporation. However, Limitorque's sales team and application engineers are always available to assist you in making your decision.

MS-DOS® and Windows are a registered trademark of Microsoft Corporation
IBM-PC is a registered trademark of International Business Machines Corporation

Contents

| | |
|--|-----------|
| 1. Introduction | 1 |
| 1.1 Limitorque Valve Control | 1 |
| 1.2 Product Description | 1 |
| 1.3 UEC-3 Models | 1 |
| 1.3.1 UEC-3 | 1 |
| 1.3.2 UEC-3-MPC | 1 |
| 1.3.3 UEC-3-DDC | 2 |
| 2. UEC-3 Operational Features | 3 |
| 2.1 Jammed Valve Protection | 3 |
| 2.2 Anti-Torque Switch Hammer Protection | 3 |
| 2.3 Instantaneous Reversal | 3 |
| 2.4 Opto-Isolated Inputs | 4 |
| 2.5 Motor Thermal Protection | 4 |
| 2.6 Emergency Shut-Down (ESD) | 4 |
| 2.7 Monitor Relay | 5 |
| 2.8 Torque or Position Seating | 5 |
| 2.9 Electrical Interlock / Inhibit Circuits | 5 |
| 2.10 Remote Control Supply | 6 |
| 2.11 Remote 2, 3 and 4 Wire Control | 6 |
| 2.11.1 2-Wire Control | 6 |
| 2.11.2 3-Wire Control | 6 |
| 2.11.3 4-Wire Control | 6 |
| 2.12 Clockwise / Counter Clockwise to "Close" Rotation | 7 |
| 2.13 Power Supply | 7 |
| 2.13.1 Auto Phase Correction | 7 |
| 2.13.2 Phase Protection | 7 |
| 2.13.3 Supply Voltage Setting | 7 |
| 2.14 Two-Speed Opening and Closing | 8 |
| 2.15 Local Position / Running Indication | 8 |
| 3. UEC-3-MPC Modulating Position Controller | 9 |
| 4. Options | 11 |
| 4.1 4 - 20 mA Position Transmitter (PT20SD) | 11 |
| 4.2 Potentiometer | 11 |
| 4.3 Diagnostic Tools | 11 |
| 5. UEC-3 Control Module | 13 |
| 5.1 Single Board Computer (SBC) | 13 |
| 5.2 Power Supply Board | 13 |
| 5.3 Termination/Interconnect Board | 13 |

6. UEC-3 Setup - Wiring and Switch Setting 19

| | |
|--|----|
| 6.1 General Set-Up Information | 19 |
| 6.2 Default DIP Switch Settings | 20 |
| 6.3 Wiring and DIP Switch Settings | 20 |
| 6.4 Phase Protection Jumpers | 27 |
| 6.5 Pushbutton Station Jumpers | 27 |

7. UEC-3-MPC Setup 29

| | |
|--|----|
| 7.1 Default Levels | 29 |
| 7.2 Procedure 1: Calibrate Feedback Potentiometer | 31 |
| 7.3 Procedure 2: Calibrate UEC-3-MPC Control Parameters | 31 |
| 7.4 Procedure 3: Setting DIP Switches to Restore UEC-3 Functionality | 39 |

8. Extended Configuration by Personal Computer 41

| | |
|--|----|
| 8.1 Set the OPEN Speed and Set the CLOSE Speed | 41 |
| 8.1.1 Opening and Closing Speed | 41 |
| 8.1.2 Changing the Opening Slow Speed | 42 |
| 8.1.3 Changing the Closing Slow Speed | 43 |
| 8.2 Configure ESD Override | 43 |
| 8.2.1 ESD Override | 43 |
| 8.2.2 Changing the ESD Override Configuration | 43 |
| 8.3 Configure the User Digital Inputs | 44 |
| 8.3.1 Digital Input Mask | 44 |
| 8.3.2 Changing the Sense of the User Digital Inputs | 44 |
| 8.4 Set the Jam Timer Reload Time | 45 |
| 8.4.1 Jam Timer Reload | 45 |
| 8.4.2 Setting the Jam Timer Reload Time | 45 |
| 8.5 Set the Minimum/Maximum Modulation Position (UEC-3-MPC only) | 46 |
| 8.5.1 Minimum/Maximum Modulation Position | 46 |
| 8.5.2 Changing the Minimum/Maximum Modulation Position | 46 |
| 8.6 Configure the Monitor Relay Actuation Conditions | 47 |
| 8.6.1 Monitor Relay Actuation | 47 |
| 8.6.2 Configuring the Monitor Relay Bit Masks | 47 |

9. Actuator Wiring Details 51

| | |
|--------------------------------|----|
| 9.1 L120 Actuator Wiring | 51 |
| 9.2 LY Actuator Wiring | 52 |

10. Troubleshooting 53

| | |
|---|----|
| 10.1 Troubleshooting with the Universal Diagnostic Tool (UDT) | 53 |
| 10.2 Using the Universal Diagnostic Tool (UDT) | 54 |
| 10.3 UEC Troubleshooting - All Models | 56 |
| 10.4 UEC-3-MPC Troubleshooting | 57 |
| 10.5 Two, Three, and Four-Wire Control Troubleshooting | 58 |

| | |
|---------------------------------|-----------|
| 11. Parts | 59 |
| 12. Customer Service | 61 |
| 13. Related Publications | 63 |

Figures

| | |
|---|----|
| Figure 5-1 UEC-3 and UEC-3-MPC Control Module | 14 |
| Figure 5-2 Single Board Computer | 15 |
| Figure 5-3 Power Supply Board | 16 |
| Figure 5-4 Termination/Interconnect Board | 17 |
| Figure 6-1 Model, Option, and Configuration Identification Label | 19 |
| Figure 6-2 Default DIP Switch Settings for the UEC-3 and UEC-3-MPC | 20 |
| Figure 6-3 Functional Key to UEC-3 DIP Switch Settings | 21 |
| Figure 6-4 UEC-3 Two, Three, and Four-Wire Control | 22 |
| Figure 6-5 UEC-3 and UEC-3-MPC Emergency Shutdown | 23 |
| Figure 6-6 UEC-3 and UEC-3-MPC Electrical Interlock/Inhibit | 24 |
| Figure 6-7 UEC and UEC-3-MPC Monitor Relay and Optional Potentiometer | 25 |
| Figure 6-8 UEC-3 and UEC-3-MPC PT20SD (4-20mA) Position Transducer Wiring | 26 |
| Figure 7-1 UEC-3-MPC Control and Actuator Position Input Wiring | 30 |
| Figure 7-2 UEC-3-MPC Calibration Procedure | 36 |
| Figure 7-3 Functional Key to UEC-3-MPC DIP Switch Settings | 40 |
| Figure 9-1 UEC-3 Limit Switch Connections for L120 Series Actuators | 51 |
| Figure 9-2 UEC-3 Limit Switch Connections for LY Series Actuators | 52 |
| Figure 10-1 Universal Diagnostic Tool | 53 |
| Figure 10-2 UEC Troubleshooting Flow Chart - All Models | 56 |
| Figure 10-3 UEC-3-MPC Troubleshooting Flow Chart | 57 |
| Figure 10-4 Two, Three, and Four-Wire Control Troubleshooting Flow Chart | 58 |

Tables

| | |
|--|----|
| Table 7-1 Table of Values for Proportional Band and Deadband | 35 |
| Table 10-1 UDT LED Caption Designations | 55 |

This page is intentionally blank.

1. Introduction

Note

This manual should be read with the 'L120 or LY Series Instruction and Maintenance Manual' available for easy reference.

1.1 Limatorque Valve Control

Limatorque's L120 and LY series of actuators are the most advanced valve controls on the market...the result of many years of development and awareness of our customers' requirements. This manual has been prepared to help you obtain the most benefit from the equipment. It contains instructions on the correct installation of the units and on the proper use of the operating controls.

Limatorque actuators control the opening and closing of the valve and limit the torque and thrust applied to the valve stem. As a result, all valve operating components are protected from overload, improper seating or pipeline obstructions. Limatorque actuators may be mounted on any size of valve in almost any position or location. They are readily adaptable to existing equipment.

1.2 Product Description

The UEC-3 is a microprocessor based controller for the complete range of Limatorque actuators. It provides many protection and control features which are designed to optimize valve control for your facility. The UEC-3 allows each actuator to be individually configured to fit specific customer needs. This configuration may be altered in the field as process requirements change or as the real needs of the actuator are realized.

1.3 UEC-3 Models:

1.3.1 UEC-3 (Universal Electronic Controller)

The basic UEC-3 model provides control, indication, alarm, and protection features as listed in **Section 2** of this manual. It is intended for use with open/close or pushbutton throttling valves.

1.3.2 UEC-3-MPC (Modulating Position Controller)

This model is designed to position valves in accordance with a 4-20mA command signal, thereby controlling level, flow, pressure, etc. All the indication, alarm, and protection features of the UEC-3 are retained in this model.

1.3.3 UEC-3-DDC (Distributed Digital Controller)

Digital control via Limatorque's DDC-100 Network is provided by this model. The communication protocol may be either Modbus or BITBUS, and up to 250 Limatorque actuators may be controlled and monitored in a DDC-100 Network. The extensive features included and available with the UEC-3-DDC (DDC-100 UEC Field Unit) are covered in two separate publications - Bulletin 440-20014 for the Modbus version and Bulletin 440-20013 for the BITBUS version.

2. UEC-3 Operational Features

2.1 Jammed Valve Protection

The jammed valve state occurs when the actuator possesses insufficient torque capacity to move the valve from the closed or open position. If a signal is sent to the actuator to open or close the valve, the position limit switch is monitored to see if it resets (see section on Limit Switch Settings in the L120 or LY Instruction Manual). This can only occur if the actuator has rotated sufficiently in the reverse direction (2°-5°) for the limit switch to trip to its mid-travel state. If no reset is received the unit will automatically initiate the jammed valve sequence.

A signal to reverse the direction is sent for 0.5 second, then a further signal is applied in the initial direction. If the limit switch resets then the valve and the actuator will resume normal operation. If no reset is detected for the second time, the UEC-3 will inhibit any further electrical operation while the signal is maintained and will de-energize the monitor relay to indicate a valve jammed fault.

The jammed valve state can be reset by operating the valve manually with the handwheel. This resets the position limit switch, which is detected by the UEC-3, and normal control is resumed in both 'Remote' and 'Local' modes. It can also be reset by removing the existing signal (if maintained), and then sending another 'Open' or 'Close' command, either in 'Local' or 'Remote' mode. This is not recommended since the valve is already jammed.

2.2 Anti-Torque Switch Hammer Protection

Torque switch hammer may occur when a 'maintained' control signal is present and the gearing in the actuator is non-locking. The torque switch opens, then recloses, and results in rapid, repeated energizing and de-energizing of the actuator.

Torque switch hammer is prevented by monitoring the torque switch in both the open and close directions. Once the torque switch has operated by the valve hitting an obstruction or, if torque seating is selected, by reaching the end of travel, the actuator will inhibit any further operation in the same direction. If an obstruction is met, the actuator will operate only in the reverse direction. This allows the actuator to back out of any obstruction.

2.3 Instantaneous Reversal

To reverse the direction of travel in either the 'Local' or 'Remote' mode it is not necessary to stop the actuator. The unit has a built-in time delay of 0.5 second when the motor is reversed in order to reduce current surges.

2.4 Opto-Isolated Inputs

The use of opto-isolators on all remote control inputs protects the internal control logic circuits from high voltage transients. The current drawn on each externally fed remote signal is 4mA @ 24 Volts DC and will be proportional at other voltages.

2.5 Motor Thermal Protection

All Limitorque motors are fitted with a thermostat embedded in the windings with normally closed contacts. Should the motor overheat, the contacts will open, de-energizing the contactors and inhibiting any further operation until the motor has cooled sufficiently for the thermostat contacts to close again. The operation of the thermostat may be ignored when a maintained remote ESD signal is present by selection of a DIP switch (see **Section 6** for DIP switch settings).

2.6 Emergency Shutdown (ESD) - for ROM versions 1.41 or higher

A remote signal can be applied to User Digital Input 0 which will override any other command signal when the actuator is in the REMOTE mode. (Note: If a maintained ESD signal is applied when the actuator is in the LOCAL mode, the signal will be acted upon immediately when the actuator is switched from LOCAL to REMOTE.) If the field unit is equipped with ROM version 1.41 or higher, it can be configured with ESD Override so that a maintained ESD signal will be active in the LOCAL and OFF selector switch positions as well as the REMOTE position. The procedure for changing the ESD Override configuration is given in **Section 8.2**.

The actuator will act on the ESD signal to close the valve, open the valve, stay-put (stop) or ignore it, depending on the configuration of the unit (See **Section 6** for setup information). An active ESD signal will override inhibit signals, Torque Switch trip, local STOP and subsequent commands.

Motor thermostat protection can be bypassed by DIP switch selection so that it is not active during ESD operations.

If the ESD signal is removed, ESD operation will be terminated by any of the following:

1. Subsequent remote command signal
2. Motor Thermostat trip
3. Torque switch trip
4. Power loss
5. End-of-travel limit switch (if in position seated mode)
6. Switching from REMOTE to LOCAL
7. Pressing the local STOP button when in local or remote mode

Refer to **Section 6** for DIP switch settings and connection details.

2.7 Monitor Relay

The monitor relay provides immediate indication of problems that disable valve operation. The relay has a normally open contact and a normally closed contact (1 single-pole double-throw - SPDT - contact).

The relay is energized when the actuator power supply is present and the circuits being monitored are in a normal/healthy state. The Monitor relay automatically reverts to the energized state when monitored faulty states have been corrected. The relay will de-energize if any of the following states occur:

1. Local / Off / Remote selector switch is NOT in 'Remote' mode.
2. A lost phase has been detected.
3. Loss of internal power supply.
4. Motor thermostat has tripped due to the overheating of the motor.
5. Jammed Valve detected
6. Contactor fails to energize. (This is active only while the command signal is present).
7. Either torque switch tripped.

The conditions that cause the relay to de-energize can be configured (see **Section 8.6**)

2.8 Torque or Position Seating

Either torque or position seating may be selected without any wiring changes by making the appropriate selection on the DIP switches (see **Section 6** for DIP switch settings).

When TORQUE SEATING is selected, the position limit switches must still be set to trip at both ends of travel. This enables the logic controls to differentiate between torque switch operation under normal seating conditions and a mid-travel obstruction. Refer to 'L120 or LY Series Instruction and Maintenance Manual' on Torque Switch setting.

For POSITION SEATING see 'L120 or LY Series Instruction and Maintenance Manual' on Limit Switch Setting.

2.9 Electrical Interlock / Inhibit Circuits

The interlocks inhibit electrical operation in either the open or close direction. With the setup switch set to ON (see **Section 6** for DIP switch settings and connection details), any signal to open or close the valve will be ignored when there is a remote signal to the 'Open Inhibit' terminal for opening the valve or 'Close inhibit' terminal for closing the valve.

This feature can be used to inhibit electrical operation completely (i.e. functional lockout) or inhibit the actuator until another operation has been completed (i.e. interlock on a sequence control system).

Note

This is effective in both the 'local' and 'remote' modes. If an ESD signal is received, the interlocks will be overridden.

2.10 Remote Control Supply

The remote control inputs can be powered by the internal 24 Volt DC supply incorporated in the actuator (maximum external load - 6 Watts). This supply can be used over long distances because the input circuits require a low switching current (max. 4mA), which virtually eliminates problems due to voltage drop and induction. Alternatively, an external control supply in the range of 24 - 125 Volts AC or DC can be used to source the remote inputs.

Note

If an external supply greater than 90 volts is to be used, the link (LK1) on the Termination/Interconnect Board must be removed.

Caution

Never attempt to connect an external supply to the +24 volt DC or 24 volt DC common terminals (TB1-6 or 7 and TB1-13 or 14).

2.11 Remote 2, 3 and 4-Wire Control**2.11.1 2-Wire Control**

Remote control of the actuator is possible by connecting a single contact (e.g., switch, relay etc.) between two terminals. When the contact is closed the actuator will travel in one direction and in the reverse direction when the contact is open. The direction of travel is determined by setting the appropriate DIP switch.

2.11.2 3-Wire Control

3-Wire Control can function in two selectable modes:

In the Maintained Mode, the actuator will accept momentary signals to open and close the valve and will continue until the valve fully opens or closes or a signal to reverse direction is received.

In the Inching Mode, the actuator performs the commanded action only while the signal is present. If the OPEN or CLOSE pushbutton is released, the actuator stops. This permits intermediate valve positions between open and closed.

2.11.3 4-Wire Control

In 4-Wire Control, the actuator responds to OPEN or CLOSE signals in the manner of the Maintained mode explained above. However, in 4-Wire Control a STOP button is added which stops the actuator when pressed. This permits intermediate valve positions between open and closed.

Refer to **Section 6** for DIP switch settings and connections for 2, 3, or 4-Wire Control.

2.12 Clockwise / Counter Clockwise to 'Close' Rotation

This is normally pre-set at the factory in accordance with the customer's requirements. It can be changed on site by DIP switch selection. The factory default setting is **CLOCKWISE** to close if no direction is specified when the order is placed.

2.13 Power Supply

2.13.1 Auto Phase Correction

The UEC-3 monitors the phase rotation of the incoming 3-phase supply and automatically corrects the actuator controls to ensure that the motor always runs in the correct direction. The feature is selectable ON/OFF according to customer preference.

A yellow LED (see **Figure 5-1** for location) illuminates when the phases are correctly connected. This feature enables the user to check that the phase rotation of the supply is correct.

Caution

If the motor is replaced during the life of the actuator, it is important to connect the leads correctly to ensure proper rotation.

2.13.2 Phase Protection

In addition to monitoring phase rotation, the phase discriminator also detects whether all three phases are present. If any phase is lost, then operation of the actuator will be prevented. A red LED on the power supply board illuminates when all three phases are present.

This feature is selectable ON/OFF in later versions of the UEC-3 and UEC-3-MPC. (See **Section 6.4**)

Note

If an ESD signal is received and then one of the phases is lost, the logic controls will ignore the phase protection circuit and attempt to comply with the ESD signal.

2.13.3 Supply Voltage Setting

The transformer voltage setting is factory set for the supply voltage specified at the time of the order and should not require changing.

Transformer Voltage Options:

Type A. Standard transformer

Type B. Optional transformer

| Nominal Tap | | Nominal Tap | |
|-------------|-----|-------------|-----|
| A | 460 | A | 575 |
| B | 415 | B | 525 |
| C | 380 | C | 220 |
| D | 220 | D | 115 |

2.14 Two-Speed Opening and Closing

A 2-speed pulsing timer is a standard feature of the UEC-3 and can be selected to operate in the opening and/or the closing direction. This enables the operating time of the valve to be increased for the prevention of hydraulic shocks, (e.g. water hammer) in the pipeline.

For L120 series actuators, pulsing operation will begin when the contacts of Gear Limit Switch 14 are made, and will be the same for both directions of travel. This switch may be set anywhere in the valve travel. For LY units, switch LS9 is used.

The 'ON' and 'OFF' pulse times are factory-set at default levels of 2.0 second 'ON' and 10.0 seconds 'OFF' but may be configured to different intervals on receipt of specific details from the user, prior to manufacture. The settings may also be reconfigured on site using a Personal Computer and 'Modsim'. Modsim is a Modbus software package provided by Limatorque. This procedure is described in **Section 8.1**.

2.15 Local Position / Running Indication

When the actuator is operating, the LED's on the local pushbutton station will 'flash' to indicate the direction of travel. At the end of travel, one LED will change to 'steady' to indicate the valve position and the other LED will turn off.

On a standard pushbutton station the 'state' of the colored LEDs will indicate the following in local or remote mode:

Red ON / Green OFF = Valve Fully Open
 Red OFF / Green ON = Valve Fully Closed
 Red ON / Green ON = Intermediate Position
 Red ON / Green flashing = Valve Closing
 Red flashing / Green ON = Valve Opening

An alternate configuration can be specified in which:

Red ON / Green Off = Valve Fully Closed
 Red OFF / Green ON = Valve Fully Open
 Red ON / Green ON = Intermediate Position
 Red ON / Green flashing = Valve Opening
 Red flashing / Green ON = Valve Closing

3. UEC-3-MPC Modulating Position Controller

The UEC-3-MPC is a model of the UEC-3 which accepts a 4-20 mA signal from a set point controller or similar device to position the valve in proportion to the current signal. The UEC-3-MPC contains standard UEC-3 hardware, plus the addition of a feedback potentiometer, analog interface board, and an analog to digital (A/D) converter. All necessary software to run the UEC-3-MPC as a modulating position controller is installed in read-only memory.

The UEC-3-MPC retains all the basic UEC-3 features as set by DIP switches S1 and S2 except for 2, 3 and 4-Wire Control. The additional configuration required for modulating position control is programmed through an Extended Configuration feature as explained in **Section 7**. First, this mode is selected by setting three switches on DIP switch S2 to the ON position. Then, other switches on DIP switches S1 and S2 are used to set individual parameters. In this way it is possible to configure the unit step by step, write each selection to memory, and test the response of the actuator to the 4-20 mA analog command signal. When the configuration performs as required, it can be transferred from temporary memory (RAM) to memory which will be retained even with power off (EEPROM). This can be done without the use of any additional equipment, such as setting tool or Personal Computer. The Extended Configuration can also be performed with a Personal Computer and Modsim software.

The following parameters can be configured/calibrated:

| | |
|--|-----------------|
| Set OPEN reference | } ZERO and SPAN |
| Set CLOSE reference | |
| Set PROPORTIONAL BAND from 1% to 50% max. | |
| Set DEADBAND from 1% to 50% | |
| Set ACTION ON LOSS OF COMMAND; either 'OPEN', 'STOP' or 'CLOSE'. | |

Notes

- 1.) Loss of signal is detected if the analog command falls below 50% of the minimum setting, e.g. 2 mA for a 4-20 mA setting range.
- 2.) The UEC-3-MPC is capable of modulating control over 96% of its range. When the input corresponds to the last 2% of the range on either end of travel, the Field Unit will force the actuator to the limit switch. This can be changed (see **Section 8**).

As soon as the configuration is completed, the EXTENDED CONFIGURATION mode is switched 'OFF' and the DIP switches S1 and S2 are returned to their correct positions for the basic UEC-3 features selected. Full setting instructions are included in **Section 7** of this manual.

This page is intentionally blank.

4.Options

4.1 4-20mA Position Transmitter (PT20SD)

The PT20SD is a resistance to current (R/I) signal converter. It utilizes a potentiometer driven from the Mechanical Dial Position Indicator gearing (MDPI) to provide an output of 4-20 mA which is proportional to the output position of the actuator / valve. A D.C. voltage is applied across the potentiometer and a proportion of that voltage is picked off by the wiper. This voltage is proportional to position and is used to drive an operational amplifier. The amplifier circuit has user adjustable controls for setting the 4 mA (zero) and the 20 mA (span) levels at each end of travel. Full calibration instructions are included on **Figure 6-8** of this manual.

4.2 Potentiometer

If a potentiometer is fitted, connect as shown in the connection diagram in **Figure 6-7**.

4.3 Diagnostic Tools

A port is provided as a standard feature for the connection of a Personal Computer (with Modsim software) or the handheld Universal Diagnostic Tool (UDT). The Personal Computer with Modism Software provides an extensive configuration and diagnostic capability for those situations where the use of a Personal Computer is feasible. The UDT provides a compact and easy to use diagnostic capability.

The UDT directly indicates the following states:

Open Torque Switch

The torque switch, in the opening direction, has tripped between position limits.

Close Torque Switch

The torque switch, in the closing direction, has tripped between position limits.

Open Limit Switch

The Open limit switch has tripped.

Close Limit Switch

The Close limit switch has tripped.

Open Inhibit

The Open inhibit signal is present.

Close Inhibit

The Close inhibit signal is present.

Lost Phase

Phase L2 has been lost (If phases L1 or L3 have been lost, the UEC-3 will not be powered).

Reversed Phase

The three phase supply connections are reversed.

Thermostat Tripped

The motor thermostat has tripped due to motor overheating.

ESD Signal Present

An ESD signal is present at the terminals.

Not in Remote Mode

The actuator is in LOCAL or OFF mode.

Close Contactor Failed

The Close contactor failed to operate after being signaled.

Open Contactor Failed

The Open contactor failed to operate after being signaled.

Valve Jammed

The jammed valve sequence has been initiated but has not been successful.

Communication Failure

No communication through the diagnostic port.

5. UEC-3 Control Module

The UEC-3 and UEC-3-MPC Control Module shown in **Figure 5-1** contains a set of circuit boards, a contactor, and a set of interconnecting cables. The standard circuit boards are:

5.1 Single Board Computer (SBC)


This board contains a processor and support circuits to perform all monitoring, control, and operator interaction functions. The SBC is shown in **Figure 5-2**.

5.2 Power Supply Board

The Power Supply Board provides the voltages required by the Single Board Computer and the Input/Output circuits. There are two versions of this board and both are shown in **Figure 5-3**.

5.3 Termination/Interconnect Board


This board contains connectors and terminal strips and serves as the interface between the Control Module and everything outside the Control Module. All user connections are made to this board. The Termination/Interconnect Board is shown in **Figure 5-4**.



Danger!

Hazardous voltage within the control module. Exercise caution while calibrating the UEC-3 with the actuator control compartment open and power on.

Figure 5-1: UEC-3 and UEC-3-MPC Control Module



Note

Reset LED (Red) will be continuously 'ON' when the controller is healthy. A very short 'OFF' pulse, repeated at regular intervals, will indicate a fault within the controller.

Figure 5-2: Single Board Computer



Earlier Version

Primary Fuses

FS1 & FS2 - 250mA for three-phase operation
FS1 & FS2 - 750mA for single-phase operation

Transformer Tapping to
suit Incoming Power Supply.

Voltages shown are typical only.
Available Voltages include:

| Type A | Type B |
|-------------|-------------|
| Standard | Optional |
| Transformer | Transformer |
| 460V | 575V |
| 415V | 525V |
| 380V | 220V |
| 220V | 115V |

Secondary Fuse
FS3 - 1.0A

Yellow LED
(Phases correctly
connected)

Red LED
(all phases
present)

Later Version

Primary Fuses

FS1 & FS2 - 250mA
for three-phase operation

FS1 & FS2 - 750mA
for single-phase operation

Transformer
Tapping to suit Incoming
Power Supply.

Voltages shown are typical only.
Available Voltages include:

| Type A | Type B |
|-------------|-------------|
| Standard | Optional |
| Transformer | Transformer |
| 460V | 575V |
| 415V | 525V |
| 380V | 220V |
| 220V | 115V |

Single
Phase/Three
Phase Jumpers

Secondary Fuse
FS3 - 1.0A

Green LED
(Single phase or phase
detector disabled)

Yellow LED
(Phases correctly
connected)

Red LED
(all phases
present)



Figure 5-3: Power Supply Board

Fused 24V DC Internal Power Supply
FS4-1.0A (Max. 6W Load)

Terminal Blocks for
Customer Connections

Earlier Version

Connector for
Pushbutton
Station
(SW-93)

Monitor Relay

Connector for
Single Board
Computer

Connector for
Gear Limit
Switch and
Torque Switch
Inputs

Link LK1
To be removed for
external control voltages
ABOVE 90V AC or DC.
(MAXIMUM voltage
125V AC or DC.)

Later Version

Fused 24V DC Internal Power Supply
FS4-1.0A (Max. 6W Load)

Terminal Blocks for
Customer Connections

JP2
(see Section 6.5)

Connector for
Pushbutton
Station
(SW-93)

JP1
(see Section 6.5)

Monitor Relay

Link LK1
To be removed for external
control voltages ABOVE
90V AC or DC.
(MAXIMUM voltage
125V AC or DC.)

Connector for
Gear Limit
Switch and
Torque Switch
Inputs

Connector for
Single Board
Computer

Figure 5-4: Termination/Interconnect Boards

This page is intentionally blank.

6. UEC-3 Set Up - Wiring and Switch Settings

6.1 General Set-Up Information

The actuator must first be set up as instructed in the 'LI20 or LY series Instruction and Maintenance Manual' taking note of the Installation Tips.

This unit should have left the factory set for your requirements. If the requirements were not known at the time or a change is required, the following procedure must be performed.

Caution

Ensure actuator is isolated from all incoming power.

Remove front cover by pressing down with both thumbs on top edge of cover in the approximate area indicated in **Figure 5-1** of this manual. Remove the terminal cover by inserting a screwdriver in the gap as shown on the cover and lifting.

Note

Always use a small non-metallic tool to move the DIP switches; **NEVER** use a pencil.

A label is attached to the side of each Control Module. This label (shown in **Figure 6-1**) is stamped at the factory to indicate the model, the options installed, the input voltage setting, and the serial number. The portion of the label showing the settings for S1, S2, S3 (DDC only), and LK1 are available for the user to show the specific configuration information.

| UEC-3 BASIC CONFIGURATION SWITCH POSITIONS | | | | | | | | | |
|--|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|----------------------|
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | |
| S1 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | ON OFF |
| S2 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | ON OFF |
| S3 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | ON OFF (DDC Only) |
| LK1: <input type="checkbox"/> IN <input type="checkbox"/> OUT <input type="checkbox"/> | | | | | | | | | |

| Model | | Options | |
|-------------|--|---------------|--------------------------|
| UEC-3 BASIC | | Potentiometer | <input type="checkbox"/> |
| UEC-3-MPC | | PT20S (R-1) | <input type="checkbox"/> |
| UEC-3-DDC | | Logitorque | <input type="checkbox"/> |

| Transformer Type/Tapping | | | | | |
|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| Type A | | | Type B | | |
| 460V | 415V | 380V | 220V | 575V | 525V |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | | | 220V | 115V | |
| | | | <input type="checkbox"/> | <input type="checkbox"/> | |

Serial No. _____

Figure 6-1: Model, Option, and Configuration Identification Label

6.2 Default DIP Switch Settings

If specific configuration details were not provided with the order, the unit was shipped with the DIP switches set to their default positions. **Figure 6-2** shows the default settings for S1 and S2 of the UEC-3 and the UEC-3-MPC. The settings for these switches for the UEC-3-DDC are discussed in other manuals.




Figure 6-2: Default DIP Switch Settings for UEC-3 and UEC-3-MPC

'ESD' action - 'CLOSE' - S1-1,-2
 Local inching - DISABLED - S1-3
 Modulating mode - DISABLED - S1-4
 Slow speed opening - DISABLED - S1-5
 Closing rotation - CLOCKWISE - S1-6
 Thermostat bypass - DISABLED - S1-7
 Interlock / Inhibit - DISABLED - S1-8

Remote control mode - 4 WIRE - S2-1,-2-3
 Seating method at 'close' - POSITION - S2-4
 Autophase control - ENABLED - S2-5
 Slow speed closing - DISABLED - S2-6

NOTE: FOR A STANDARD UEC-3 ALWAYS SELECT:

EEPROM - DISABLED - S2-7
 Software Control - ENABLED - S2-8

Note

If changes to the DIP switches are made while power is present at the actuator, it is important to power 'off' and then back 'on' again in order to initialize the changes.

6.3 Wiring and DIP Switch Settings

The functions of each of the switch sections of DIP switches S1 and S2 are given in **Figure 6-3** for the UEC-3, and in **Figure 7-3** for the UEC-3-MPC.


Configuring the UEC-3 for Two, Three, and Four Wire control is detailed in **Figure 6-4**.

Figure 6-5 gives wiring and switch setting options for Emergency Shutdown (ESD) for the UEC-3 and the UEC-3-MPC.

Electrical Interlock/Inhibit wiring and switch selectable options for the UEC-3 and the UEC-3-MPC are given in **Figure 6-6**.

Wiring for the Monitor Relay and for the optional Potentiometer are shown in **Figure 6-7** for the UEC-3 and the UEC-3-MPC.

Wiring and calibration for the optional PT20SD Position Transducer are given in **Figure 6-8**.



Caution

The following features should not be used together. Using these features together can result in unpredictable operation of the unit:


- Modulating control and Two-speed operation
- Torque Seating and Two-speed operation
- Modulating control and 2-, 3-, or 4-wire control

Figure 6-3: Functional Key TO UEC-3 DIP Switch Settings

Internal Control Supply

24 Volt DC - Positive switching only

2 WIRE CONTROL*




DIP switches can be set to give:
 EITHER - Contact closed - Valve OPENS
 Contact opened - Valve CLOSES
 OR - Contact closed - Valve CLOSES
 Contact opened - Valve OPENS


Switch Settings



Contact closed - Valve OPENS




Contact closed - Valve CLOSES



External Control Supply


24 - 125 Volts AC or DC

2 WIRE CONTROL*



ALL VOLTAGES OVER 90V A.C./D.C. REMOVE LINK (LK1) ON TERMINATION BOARD

3 WIRE CONTROL*



To initiate action - 'Open' or 'Close':
 Contact to be closed momentarily for MAINTAINED mode or for longer duration (as necessary) in INCHING mode.

3 Wire MAINTAINED control




3 Wire INCHING control




Note: For 'LOCAL' Inching set S1 position 3 to ON - Refer to Fig. 6.3

3 WIRE CONTROL*



ALL VOLTAGES OVER 90V A.C./D.C. REMOVE LINK (LK1) ON TERMINATION BOARD

4 WIRE CONTROL*




To initiate action - 'Open' or 'Close':
 Contact to be closed momentarily.
 'Stop' contact to be opened momentarily.

4 Wire control with STOP



4 WIRE CONTROL*



ALL VOLTAGES OVER 90V A.C./D.C. REMOVE LINK (LK1) ON TERMINATION BOARD


*To configure the user inputs, see Section 8.3.

Figure 6-4: UEC-3 - Two, Three, and Four Wire Control

Internal Control Supply

24 Volt DC - Positive switching only

Emergency Shut-Down (ESD)



Note:

To initiate 'ESD' action contact to be closed and will only be active when actuator is in 'Remote' mode.

See **Section 2.6** for a description of ESD action.

See **Section 8.3** to configure User Inputs.

Switch Settings



CLOSE on ESD signal



OPEN on ESD signal



STAYPUT or STOP on ESD signal



IGNORE ESD signal



External Control Supply

24 - 125 Volts AC or DC

Emergency Shut-Down (ESD)



* ALL VOLTAGES OVER 90V AC/DC
REMOVE LINK (LK1) ON
TERMINATION BOARD


Notes:

- 1) S2 must be set for the appropriate remote control (See **Fig. 6.4**).
- 2) Mixed voltages can NOT be used. ESD supply MUST be the same as remote control supply.
- 3) Same connections and DIP switch settings to be used for UEC-3-MPC.

**Figure 6-5: UEC-3 and UEC-3-MPC -
Emergency Shutdown (ESD)**

Internal Control Supply 24 Volt DC - Positive switching only

Electrical Interlock / Inhibit



Note:

To initiate INTERLOCK INHIBIT, contact to be closed and remain closed for as long as inhibit is required to be active.

Switch Settings



Enable Open & Close Interlock/Inhibit




Disable Open & Close Interlock/Inhibit



External Control Supply 24 - 125 Volts AC or DC

Electrical Interlock / Inhibit



* ALL VOLTAGES OVER 90V AC/DC REMOVE LINK (LK1) ON TERMINATION BOARD

Notes:


- 1) S2 must be set for the appropriate remote control (See **Figure 6.3** or **Figure 7.3**).
- 2) Mixed voltages can NOT be used. Inhibit supply MUST be the same as remote control supply.
- 3) Same connections and DIP switch settings to be used for UEC-3-MPC.
- 4) See **Section 8.3** to configure User Inputs.

**Figure 6-6: UEC-3 and UEC-3-MPC -
Electrical Interlock/Inhibit**

Monitor Relay

Relay is energised in
NORMAL (healthy) state.

Relay is de-energised in
ERROR state.



Maximum rated load: 0.6 A @ 125 VAC : 2 A @ 30 VDC : 0.6 A @ 110 VDC


Notes:

To configure the Monitor Relay
actuation conditions, see **Section
8.6.**

Option

Potentiometer (R1)

Standard Potentiometer
1K ohms



Calibration Procedure:

1. Position the actuator to mid-travel (valve at 50% position).
2. Disconnect the potentiometer wiring harness and measure the resistance from each end connection to the center connection.
3. To set the potentiometer to the correct resistance reading, loosen the set screw that retains the spur gear on the potentiometer shaft and rotate the shaft until a reading of 500 ohms is achieved
4. Tighten the set screw and re-connect the wiring harness

Notes:

1) This option is not available if
4-20MA Transmitter (PT20SD) is
fitted. (See **Figure 6-8**)

2) Same connections to be used
for UEC-3-MPC.

**Figure 6-7: UEC-3 and UEC-3-MPC -
Monitor Relay and Optional Potentiometer**

Calibration procedure

1. Position the actuator to mid-travel (valve at 50% Position).

2. Disconnect the potentiometer wiring harness from the PT20SD board and measure the resistance from each End connection to the center connection on the potentiometer.

3. To set the potentiometer to the correct resistance reading, loosen the set screw that retains the spur gear on the potentiometer shaft and rotate the shaft until a reading of 500(ohms) is achieved.

4. Tighten the set screw and re-connect the wiring harness to the PT20SD.


5. Run the actuator fully CLOSED.

6. Calibrate ZERO position by adjusting the zero potentiometer until a 4mA output signal is read at terminals TB2-1 and TB2-2.

7. Run the actuator fully OPEN.

8. Calibrate SPAN position by adjusting the span potentiometer until a 20mA output signal is read at terminals TB2-1 and TB2-2.

9. Repeat steps 5 to 8 and fine tune as necessary.

PT20SD Position Transmitter 4-20mA**Specification**

| | |
|----------------------|---|
| Output signal: | 4-20mA |
| Input potentiometer: | 1K (ohms) |
| Temperature rating: | -40 to +85°C |
| Linearity error: | ± 1% max. |
| Loop resistance: | 370 (ohms) max. |
| Power: | 18 VAC or 24 VDC ± 10% (LK2 and LK3 must be set appropriately) |

Important:

Analog inputs must not be connected to earth ground on +VE or -VE terminal.

Note:

Same connections to be used for UEC-3-MPC.

Figure 6-8: UEC-3 and UEC-3-MPC - PT20SD (4-20mA) Position Transducer Wiring

6.4 Phase Protection Jumpers

The phase protection feature can be disabled on most versions of the UEC-3 and UEC-3-MPC Field Units. If the Field Unit is equipped with the later version of the Power Supply Board (See **Figure 5-3**), this can be accomplished by changing jumpers. Three jumpers are located in a block just above the 50 pin connector, J2. For a three-phase supply, these jumpers are normally placed in the 3-PHASE positions, and for a single-phase supply, they are placed in the 1-PHASE positions. For three-phase operation without phase protection, the jumpers can be placed in the 1-PHASE positions. This will disable the phase protection feature which will be indicated by the green LED when the unit is powered.

6.5 Pushbutton Station Jumpers

There are two jumpers on the Termination/Interconnect Board which must be changed if the Field Unit is to be operated without a pushbutton station. JP1 and JP2 are located to the left of TB1 on **Figure 5-4** and should be set as shown below:

| JP1 and JP2 Jumper Position | Application |
|--------------------------------|--|
| 1-2 | No pushbutton station |
| 2-3 | Operation with SW-93 Pushbutton Station (Default) |

This page is intentionally blank.

7. UEC-3-MPC Set Up

The actuator must first be set up as instructed in the 'L120 or LY Series Instruction and Maintenance Manual' taking note of the Installation Tips.

Because this unit will require individual calibration on site, the calibration is not performed by the factory. Please follow the calibration instructions below very carefully to ensure that you receive optimum performance from the unit.

Remove the front cover by pressing down with both thumbs on top edge of cover in the approximate area indicated in **Figure 5-1** of this manual. Remove terminal cover by inserting a screwdriver in the gap as shown on the cover and carefully lifting.

Note

Always use a small non-metallic tool to move the DIP switches; NEVER use a pencil.

Caution

To perform this calibration, the power must be 'on' to the unit. Hazardous voltages are present in the unit. Exercise caution to avoid electrical shock.

Calibration of the UEC-3-MPC is accomplished by carefully performing three separate procedures:

1. Calibrating the potentiometer.
2. Calibrating the control parameters of the Position Controller in EXTENDED CONFIGURATION MODE.
3. Setting DIP switches to restore UEC-3 functionality.

7.1 Default Levels


The following default levels are programmed in the Control Module and will provide satisfactory performance in most cases. We recommend not changing these values until the initial calibration has been completed, as below.

PROPORTIONAL BAND $\pm 14.0\%$

DEADBAND $\pm 1.0\%$

These parameters are defined in **Figure 7-1**.

Calibration positions



Definitions

Command Signal -

Input signal provided by user to assign desired valve position.

Deadband -

Adjust the maximum allowable error signal. (Difference between the Position Command Signal and position Feedback Potentiometer Signal).

Proportional Band (see Note) -

Controls the point on the scale of valve travel that the motor begins the pulsing mode. (Decreasing Proportional Band, increase Gain).

Set Point -

Desired stopping position for UEC-3-MPC; determined by the command signal.


Span -

Calibrates the UEC-3-MPC to align the Maximum Command Signal (normally 20mA) with the Position Feedback Potentiometer at the open position.

Zero -

Calibrates the UEC-3-MPC to align the Minimum Command Signal (normally 4mA) with the Position Feedback Potentiometer at the closed position.

Analog Interface



Jumper Settings

- W1 - not used in UEC-3 or UEC-3-MPC (Jumper position not important.)
W2 - Jumper 1-2 for feedback potentiometer.

Important:

Analog inputs must not be connected to earth ground on +VE or -VE terminal.

Note:

Proportional Band is inversely proportional to Gain.

Figure 7-1: UEC-3-MPC Control and Actuator Position Input Wiring

7.2 Procedure 1: Calibrate Feedback Potentiometer

1. Switch the power to the actuator OFF.
2. Position the actuator to mid-travel (valve at 50% position).
3. Disconnect the potentiometer wiring harness and measure the resistance (ohms) from the wiper to either end of the potentiometer.
4. To set the potentiometer to the correct resistance reading, loosen the set screw on its spur gear and rotate its shaft until a reading of 500 ohms is achieved.
5. Tighten the set screw and reconnect the wiring harness.

7.3 Procedure 2: Calibrate UEC-3-MPC Control Parameters

The procedure that is given below is also given in the form of a flow chart in Figure 7-2.


To calibrate the UEC-3-MPC it is necessary to switch the DIP switches to an EXTENDED CONFIGURATION MODE. This mode provides a different set of meanings in software to all the switch positions than those for standard UEC-3 functions.

These switches are used to program the performance of the actuator by resetting some of the parameters which are then transferred (written) into the memory of the controller via EEPROM. These parameters can be changed at any time by following the simple steps detailed below:

Note

BEFORE proceeding further, we recommend recording the current UEC-3 DIP switch configuration for future reference.

6. Ensure that power to the actuator is 'OFF'.



Set S2 as above.

Note

At this point switches S2-4,5,6, and 7 should be in the states which are appropriate for the application (see Figure 7-3) unless the unit has been calibrated and only the proportional Band and/or the Deadband is to be adjusted. In this case, S2-7 should be ON at this point.

Switch power to the actuator, 'ON'.

7. Set in EXTENDED CONFIGURATION MODE.

Wait approx. 15 seconds for the completion of 'POWER On Self Test' - LEDs on the pushbutton station will illuminate.



Set switches as above.

8. Set 'SPAN' Reference (Fully Open) - MUST BE SET FIRST.



Set switches as above. With the pushbutton control station set to 'LOCAL', run the actuator to the fully open position. Apply the analog command signal that applies to this position. i.e. 4mA or 20mA (the choice depends upon the application).

Reverse the position of S2-4 to write this setting to RAM, i.e. reverse position of switch, 'OFF' to 'ON' or 'ON' to 'OFF'. Do NOT change command signal until actuator is fully clockwise.

9. Set 'ZERO' Reference (Fully Closed)



Set switches as above.

Run the actuator to the fully closed position.

NOW apply the analog command signal that applies to this position (i.e. 4mA or 20mA).

Reverse the position of S2-4 to write this setting to RAM.

10. Set ACTION ON LOSS OF SIGNAL




Set switches as above.


Set the positions of S1-1 and S1-2 to suit the action required of the actuator on loss of analog command signal - detected when signal falls below 50% of 'ZERO' value. i.e. 2mA if 'ZERO' value is 4mA.

The options are shown below:


GO TO CLOSE (FULLY CLOCKWISE)



STOP IN LAST POSITION



GO TO OPEN (FULLY COUNTER CLOCKWISE)



Set switches to correspond to your application and then reverse the position of S2-4.

11. Test RESPONSE TO SIGNAL



Set switches as above.

Reverse the position of S2-4. Switch selector on pushbutton station to 'REMOTE'.

Apply the external 4-20mA analog command signal and test the operation of the actuator in response to this variable command.

IF PERFORMANCE IS SATISFACTORY then proceed as follows. IF NOT THEN SKIP TO STEP 14.


12. Transfer CONFIGURATION from RAM to EEPROM.



Set switches as above.

Reverse the position of S2-4 to transfer all the configuration settings from RAM to the non-volatile EEPROM memory.

13. Exit from the EXTENDED CONFIGURATION MODE.



Set switches as above.

Now proceed to set in new parameters on DIP switches S1 and S2 for the basic functioning of the UEC-3. Note that S1-4 MUST be 'ON' to enable MODULATING MODE. All features are available with the exception of 2,3 and 4-wire control.

Skip to **Section 7.4**

IF THE DEFAULT LEVELS FOR PROPORTIONAL BAND AND DEADBAND PROVE TO BE UNSATISFACTORY FOR YOUR APPLICATION THEN PROCEED AS FOLLOWS BEFORE PROCEEDING WITH STEPS 12 AND 13.

14. Set PROPORTIONAL BAND. This is the point on the scale of valve travel, as a percentage of the full signal range, over which the controller will carry out pulse modulation as the actuator approaches the set point. See **Figure 7-1** for a full definition.



Set switches as above.

Now set S1, as shown in **Table 7-1**, to give the desired value.

Note

The default level for PROPORTIONAL BAND was factory set at $\pm 14.0\%$.



Reverse the position of S2-4. Repeat Step 11- Test RESPONSE TO SIGNAL.

If performance is now satisfactory, proceed to steps 12 and 13.

If not, then either repeat step 14 or proceed to step 15.

Table 7-1: Table of Values for Proportional Band and Deadband

| % | DIP S1 12345678 | % | DIP S1 12345678 |
|----|--------------------|----|--------------------|
| 1 | 10000000 | 26 | 01011000 |
| 2 | 01000000 | 27 | 11011000 |
| 3 | 11000000 | 28 | 00111000 |
| 4 | 00100000 | 29 | 10111000 |
| 5 | 10100000 | 30 | 01111000 |
| 6 | 01100000 | 31 | 11111000 |
| 7 | 11100000 | 32 | 00000100 |
| 8 | 00010000 | 33 | 10000100 |
| 9 | 10010000 | 34 | 01000100 |
| 10 | 01010000 | 35 | 11000100 |
| 11 | 11010000 | 36 | 00100100 |
| 12 | 00110000 | 37 | 10100100 |
| 13 | 10110000 | 38 | 01100100 |
| 14 | 01110000 | 39 | 11100100 |
| 15 | 11110000 | 40 | 00010100 |
| 16 | 00001000 | 41 | 10010100 |
| 17 | 10001000 | 42 | 01010100 |
| 18 | 01001000 | 43 | 11010100 |
| 19 | 11001000 | 44 | 00110100 |
| 20 | 00101000 | 45 | 10110100 |
| 21 | 10101000 | 46 | 01110100 |
| 22 | 01101000 | 47 | 11110100 |
| 23 | 11101000 | 48 | 00001100 |
| 24 | 00011000 | 49 | 10001100 |
| 25 | 10011000 | 50 | 01001100 |

15. Set DEADBAND

Set switches as above.

Now set S1, as shown **Table 7-1**, to give desired DEADBAND.

Note: The default level for DEADBAND was factory set at +/- 1.0%.


Reverse the position of S2-4. Repeat Step 11 - Test RESPONSE TO SIGNAL.

If performance is now satisfactory, proceed to Steps 12 and 13.

If not then repeat Step 15.


Note

Before ending this calibration procedure always complete Steps 12 and 13, otherwise all the settings will be lost. Also ensure that power is always 'on' until this has been done.

**Setting Span
and Zero*****Note**

Span and Zero reference must always be changed together.


Figure 7-2: UEC-3-MPC Calibration Procedure (Sheet 1 of 3)

**Test Response
to Signal****Figure 7-2: UEC-3-MPC Calibration Procedure (Sheet 3 of 3)**

7.4 Procedure 3: Setting DIP Switches to Restore UEC-3 Functionality

The UEC-3-MPC, while in the modulating mode, retains all the functionality of the UEC-3, with the exception of 2,3, and 4-wire control.

Now proceed to set DIP switches S1 and S2 to suit your requirements. A full list of all available features is shown in **Figure 7-3**. A typical example of settings that are in common usage is shown below.




ESD action - 'CLOSE' - S1-1,-2
 Local inching - DISABLED - S1-3
 Modulating mode - ENABLED - S1- 4
 Two-speed opening - DISABLED - S1 - 5
 Closing rotation - CLOCKWISE - S1-6
 Thermostat bypass - DISABLED - S1-7
 Interlock / Inhibit - DISABLED - S1-8

Default after EXTENDED CONFIGURATION
 - S2 -1,-2,-3
 Seating method at 'close' - POSITION - S2 - 4
 Autophase control - ENABLED - S2 - 5
 Two-speed closing - DISABLED - S2 - 6
Note: For A Standard UEC-3 Always Select -
 EEPROM - ENABLED - S2-7
 Software control - ENABLED - S2 - 8

16. Switch power to the actuator OFF.
17. Set switches to suit your individual requirements.
18. Switch power to the actuator ON.
19. Check operation of actuator in LOCAL and REMOTE mode to ensure that correct settings have been made.
20. Record these settings on the label (shown in **Figure 6-1**) on the outside of the module.

Note

If changes to the DIP switches are made while power is present at the actuator, it is important to power 'off' and then back 'on' again in order to initialize the changes.



Caution

The following features should not be used together. Using these features together can result in unpredictable operation of the unit:

- Modulating control and Two-speed operation
- Torque Seating and Two-speed operation
- Modulating control and 2-, 3-, or 4-wire control

**Figure 7-3: Functional Key to UEC-3-MPC
DIP Switch Settings**

8. Extended Configuration by Personal Computer

Almost all of the features of the UEC-3 and UEC-3-MPC Field Units can be configured by changes in DIP switch settings. There are, however, several features whose configuration settings can be changed from default values only by using a personal computer connected to the local serial port of the field unit.

In order to change these settings, several pieces of equipment and two manuals are required. These are listed below:

Equipment Requirements for UEC-3 and UEC-3-MPC Extended Configuration:

- IBM compatible personal computer: Laptop recommended for field use
- Serial Cable: Limitorque P/N 61-825-0931-1 for 9-pin PC serial port connectors or Limitorque P/N 61-825-0932-1 for 25-pin PC serial port connectors
- Serial Interface Adapter: Limitorque P/N 61-825-0951-3
- Modsim Manual: Limitorque Bulletin 435-23001
- Modsim Software version 3.11 or greater: Limitorque P/N EEC-MODSIM
- Optional: Calculator for Hexadecimal to Decimal to Binary conversion and calculations (the Microsoft Windows® calculator program will do this in Scientific Mode)

The subsections below contain descriptions of the features, the reasons for changing the settings, and detailed procedures for changing the settings. These subsections apply to both the UEC-3 and the UEC-3-MPC unless noted otherwise.

Please contact your local service center for assistance with or questions about these changes.

Caution

Extreme care should be taken when changing these settings. Undesirable actuator movement can result if settings are changed incorrectly or are changed to inappropriate values.

8.1 Set the OPEN Speed and Set the CLOSE Speed

8.1.1 Opening and Closing Speed

Slow speed or Two-speed operation is often desired to prevent water hammer, cavitation, vibration or other effects of fast valve motion. The UEC-3 implements slow speed operation by jogging the motor (short applications of power to the motor followed by periods of no power to the motor). The default slow speed duty cycle is two seconds of power on followed by 10 seconds of power off. This duty cycle is repeated as long as the OPEN or CLOSE command is

asserted.

Two-speed Opening and Closing can be independently selected. DIP switch S1-5 ON enables slow speed Opening, and DIP switch S2-6 ON enables slow speed Closing. Regardless of whether one or both are selected, two-speed is active when actuator Limit Switch 14 is closed.

The values that control the on and off times are stored in register 225 for two-speed opening and in register 226 for two-speed closing. The value of the opening on-time is stored in the high byte of register 225, and the value of the closing on-time is stored in the high byte of register 226. The value of the opening off-time is stored in the low byte of Register 225, and the value of the closing off-time is stored in the low byte of register 226.

The duty cycle can be changed in 50ms increments by using the 06 Modbus command to write values to registers 225 and 226 in the field unit. Increasing the ratio of on-time to off-time speeds the motor up (decreases total operating time). Conversely, decreasing the ratio of on-time to off-time slows the motor down (increases total operating time).

8.1.2 Changing the Opening Slow Speed

1. For the new opening slow speed on-time, calculate the value for register 225 high byte using equation A below. For the new opening slow speed off time, calculate the value for register 225 low byte using equation B below. Add the values calculated by equations A and B. This will be the new value that will be written into register 225.

Equation A

$$\text{New High Byte Value} = (\text{on-time(sec.)}) \times \frac{1000 \text{ msec.}}{1 \text{ sec.}} \times \frac{1}{50 \text{ msec.}} \times 255$$

Equation B

$$\text{New Low Byte Value} = (\text{off-time(sec.)}) \times \frac{1000 \text{ msec.}}{1 \text{ sec.}} \times \frac{1}{50 \text{ msec.}}$$

Note

The maximum value for on or off time is 255 units or 12.75 seconds (255 X 50 msec.).

2. Connect the cables and adapters to the UEC-3 local serial port and the PC serial port. Run the Modsim program. (Refer to the the Modsim Manual for details if necessary.)

Note

Ensure that the field unit is configured for the application before proceeding. If settings stored in the EEPROM are being used, DIP switch S2-7 must be turned on when the unit is powered up.

3. Using the Modsim Manual Section 3.3.1, select the LOCAL prompt.
4. Using the Modsim Manual Section 3.3.3, establish communication with the field unit.
5. Referring to the Modsim Manual Section 4.6, use the Modbus 06 command to write the combined opening value from Step 1 to Register 225.
6. Transfer the configuration to the EEPROM by writing the value 7168 to Register 1 (Modsim Manual Section 4.6).
7. If the EEPROM is not already enabled, enable the EEPROM on the field unit by turning S2-7 on.
8. Turn the field unit power off, wait 10 seconds then turn the power back on. Wait 15 seconds for the field unit to initialize. Read the value in Register 225. Convert the hexadecimal value displayed to a decimal value and compare to the value obtained in Step 1 above. If the value does not match, repeat the procedure.

8.1.3 Changing the Closing Slow Speed

If a change in the Closing Slow Speed is required, repeat the steps in **Section 8.1.2** above except substitute 226 for the register number. Steps 2 through 4 can be omitted if the field unit is already connected to the Personal Computer and Modsim is already communicating with the field unit.

8.2 Configure ESD Override

8.2.1 ESD Override

The ESD Override feature allows a maintained ESD command to override the LOCAL and OFF positions of the selector switch. This feature is normally disabled. To enable ESD Override, the third bit of the high byte of Register 105 must be set to one. To set this bit, the contents of Register 105 must be read, decimal 1024 added to the contents, then the sum is written back into Register 105.

8.2.2 Changing the ESD Override Configuration

1. Connect the cables and adapters to the UEC-3 local serial port and the PC serial port. Run the Modsim program. (Refer to the the Modsim Manual for details if necessary.)

Note

Ensure that the field unit is configured for the application before proceeding. If settings stored in the EEPROM are being used, DIP switch S2-7 must be turned on when the unit is powered up.

2. Using the Modsim Manual Section 3.3.1, select the LOCAL prompt.
3. Using the Modsim Manual Section 3.3.3, establish communication with the field unit.
4. Using Modsim Manual Section 4.3, READ Register 105 and record the hexadecimal value.
5. Convert the value from hexadecimal to decimal and record.

6. Add 1024 (decimal) to the value found in Step 5 and record.
7. Using Modsim Manual Section 4.6, WRITE to Register 105 the value obtained in Step 6.
8. Transfer the configuration to the EEPROM by writing the value 7168 to Register 1 (Modsim Manual Section 4.6).
9. Enable the EEPROM on the field unit by turning S2-7 on.
10. Turn the field unit power off, wait 10 seconds then turn the power back on. Wait 15 seconds for the field unit to initialize, then READ Register 105 (see Step 4 above). Verify that the correct bit has been set. This can be verified by converting the contents of Register 105 from hexadecimal to binary and checking the third bit from the right. It should be a 1. If the bit has not been set, the procedure should be repeated.
11. Configure the appropriate ESD action for the application, i.e., CLOSE, OPEN etc. Refer to **Figure 6-3 or 7-3** as appropriate. The ESD function of the field unit should now be checked for proper operation.

8.3 Configure the User Digital Inputs

8.3.1 Digital Input Mask

In standard UEC-3 software, all the User Digital Inputs, except the Remote Stop input, expect normally open contacts. This section explains how to convert these inputs to expect normally closed contacts.

The inputs use Digital Input Mask A to determine the "sense" of the input. This mask can be changed to invert the sense of the inputs. The procedure given in this section covers how to do this from the Local Serial Port on the actuator.

8.3.2 Changing the Sense of the User Digital Inputs

1. Connect the cables and adapters to the UEC-3 local serial port and the PC serial port. Run the Modsim program. (Refer to the the Modsim Manual for details if necessary.)

Note

Ensure that the field unit is configured for the application before proceeding. If settings stored in the EEPROM are being used, DIP switch S2-7 must be turned on when the unit is powered up.

2. Using the Modsim Manual Section 3.3.1, select the LOCAL prompt.
3. Using the Modsim Manual Section 3.3.3, establish communication with the field unit.
4. Using Modsim Manual Section 4.3, read the low byte of Register 107 and record the contents.
5. Using the table below, total the decimal value of all the inputs that will use N.C. (normally closed) inputs (include the Remote Stop input, which by default uses an N.C contact).
6. Use this number in Equation C below and perform the calculation.
7. Using Modsim Manual Section 4.6, write the value obtained from the calculation to Register 107.

8. Transfer the configuration to the EEPROM by writing the value 7168 to Register 1 (Modsim Manual Section 4.6).
9. Enable the EEPROM in the field unit by turning S2-7 on.
10. Turn the field unit power off, wait 10 seconds then turn the power back on. Wait 15 seconds for the field unit to initialize, then read Register 107 (see Step 4 above) and compare the low byte to the original value, and the high byte to the value obtained by summing the decimal values from the chart. If both bytes do not match, restore the original configuration and repeat the procedure.

Decimal Value of Digital Input Masks
Add together the decimal value of all inputs
that require a N.C. input.

| UEC-3, UEC-3-MPC | Decimal Value |
|------------------|---------------|
| Local ESD | 1 |
| Open Inhibit | 2 |
| Close Inhibit | 4 |
| Remote Stop | 8* |
| Remote Open | 16 |
| Remote Close | 32 |

*By default, the Remote Stop Input uses a normally closed (N.C.) contact.

Equation C

New Value = (Decimal Sum From Chart) x 256 + Old Low Value

Example: To set the Local ESD, Open Inhibit, and Close Inhibit of a standard UEC-3 to use normally closed (NC) contacts:

New Value = (8 + 4 + 2 + 1) x 256 + 22 = 3862

8.4 Set the Jam Timer Reload Time

8.4.1 Jam Timer Reload

The jammed valve state and the jammed valve sequence are described in **Section 2.1**. The Jam Timer Reload is the number of 50 msec. intervals that the actuator is allowed to move inside the limit switch before the jammed valve sequence is initiated. The Jam Timer Reload value is stored in Register 115. The minimum (and default) value is 100 (corresponds to 5 sec.) and the maximum value is 150 (corresponds to 7.5 sec.).

8.4.2 Setting the Jam Timer Reload Time

1. Connect the cables and adapters to the UEC-3 local serial port and the PC serial port. Run the Modsim program. (Refer to the the Modsim Manual for details if necessary.)

Note

Ensure that the field unit is configured for the application before proceeding. If settings stored in the EEPROM are being used, DIP switch S2-7 must be turned on when the unit is powered up.

2. Using the Modsim Manual Section 3.3.1, select the LOCAL prompt.
3. Using the Modsim Manual Section 3.3.3, establish communication with the field unit.
4. Calculate the desired Jam Timer Reload Value by dividing the desired time (in seconds) by 0.050. This must be a number between 100 and 150.
5. Using Modsim Manual Section 4.6, write the value just calculated to Register 115.
6. Transfer the configuration to the EEPROM by writing the value 7168 to Register 1 (Modsim Manual Section 4.6).
7. If the EEPROM is not already enabled, enable the EEPROM on the field unit by turning S2-7 on.
8. Turn the power to the field unit off, wait 10 seconds then turn the power back on. Wait 15 seconds for the field unit to initialize. Using Modsim Manual Section 4.3, read Register 115. Verify that the correct value is displayed by comparing it to the value calculated in Step 4. If the value is not correct, the procedure should be repeated.

8.5 Set the Minimum/Maximum Modulating Position (UEC-3-MPC only)

8.5.1 Minimum/Maximum Modulating Position

The UEC-3-MPC controller has a minimum and maximum allowable modulating position. The default values are 2% and 98% of actuator travel. This means that a position command that is less than 2% or greater than 98% will send the UEC-3-MPC running at full speed towards the end of travel on the end closest to the command. If the default values need to be changed, they can be changed by writing new values to Register 118. These must be integer values in 1% increments. The high byte is the minimum modulating position, and the low byte is the maximum modulating position. The default value of Register 118 is 610 decimal (262 hexadecimal).

8.5.2 Changing the Minimum/Maximum Modulating Position

1. Connect the cables and adapters to the UEC-3 local serial port and the PC serial port. Run the Modsim program. (Refer to the the Modsim Manual for details if necessary.)

Note

Ensure that the field unit is configured for the application before proceeding. If settings stored in the EEPROM are being used, DIP switch S2-7 must be turned on when the unit is powered up.

2. Using the Modsim Manual Section 3.3.1, select the LOCAL prompt.

3. Using the Modsim Manual Section 3.3.3, establish communication with the field unit.
4. Calculate the new value for Register 118 using Equation D below.
5. Using Modsim Manual Section 4.6, write the value obtained from the calculation to Register 118.
6. Transfer the configuration to the EEPROM by writing the value 7168 to Register 1 (Modsim Manual Section 4.6).
7. If the EEPROM is not already enabled, enable the EEPROM on the field unit by turning S2-7 on.
8. Turn the power to the field unit off, wait 10 seconds then turn the power back on. Wait 15 seconds for the field unit to initialize. Read Register 118. Verify that the correct value is displayed by converting the displayed value from hexadecimal to decimal and compare to the value calculated in Step 4. If the value is not correct, the procedure should be repeated.

Equation D

New Value = (min. mod. position X 256) + max. mod. position

1. **Example:** To eliminate the min and max modulation positions, set the min position at 0% and the maximum to 100%. Using the equation above, you would write a value of 100 to Register 118.

$$\text{New Value} = (\quad 0 \quad \times \quad 256) + \quad 100 \quad = \quad 100 \text{ (64 hex)}$$

8.6 Configure the Monitor Relay Actuation Conditions

8.6.1 Monitor Relay Actuation

The normal state of the Monitor Relay is the energized state when power is applied to the UEC-3 or the UEC-3-MPC. The default list of conditions that will cause the relay to de-energize is given in **Section 2.7** of this manual and in the table below. The bit masks that define the conditions for de-energizing this relay are contained in Registers 116 and 117, and the default values are 62304 (F360 hexadecimal) and 03 (03 hexadecimal) respectively. The bit masks and thus the conditions for de-energizing the Monitor Relay can be changed by reprogramming the contents of Registers 116 and 117. The procedure for calculating the new values and changing the bit masks are given below.

8.6.2 Configuring the Monitor Relay Bit Masks

1. Connect the cables and adapters to the UEC-3 local serial port and the PC serial port. Run the Modsim program. (Refer to the the Modsim Manual for details if necessary.)

Note

Ensure that the field unit is configured for the application before proceeding. If settings stored in the EEPROM are being used, DIP switch S2-7 must be turned on when the unit is powered up.

2. Using the Modsim Manual Section 3.3.1, select the LOCAL prompt.

3. Using the Modsim Manual Section 3.3.3, establish communication with the field unit.
4. Using the Modsim Manual Section 4.3, read Registers 116 and 117 and record the values in case there is a need to return to this configuration later.
5. Using the table below, total the decimal value of all the events in Column A which should trigger the monitor relay (de-energize the relay).
6. Using the Modsim Manual Section 4.6, write this number to Register 116.
7. Using the table below, total the decimal value of all the events in Column B which should trigger the monitor relay (de-energize the relay).
8. Using the Modsim Manual Section 4.6, write this number to Register 117.
9. Transfer the configuration to the EEPROM by writing the value 7168 to Register 1 (Modsim Manual Section 4.6).
10. If the EEPROM is not already enabled, enable the EEPROM on the field unit by turning S2-7 on.
11. Turn the power to the field unit off, wait 10 seconds then turn the power back on. Wait 15 seconds for the field unit to initialize.
12. Read and record the contents of Registers 116 and 117 (Modsim Manual Section 4.3). Verify that the correct values are in the registers by converting the displayed value of Register 116 from hexadecimal to decimal and compare to the value calculated in Step 5. Then convert the displayed value of Register 117 and compare to the value calculated in Step 7. If the values are not correct, the procedure should be repeated.

Decimal Values for Monitor Relay Masks

Add the decimal value of all events that should cause the Monitor Relay to de-energize for each Register.

| Column A | | Column B | |
|-------------------------------|---------------|--|---------------|
| Events from Register 116 | Decimal Value | Events from Register 117 | Decimal Value |
| Opened | 1 | Failure to Energize Open | 1 |
| Closed | 2 | Failure to Energize Close | 2 |
| Stopped | 4 | Failure to De-energize Open | 4 |
| Opening | 8 | Failure to De-energize Close | 8 |
| Closing | 16 | Phase Loss | 16 |
| Valve Jammed | 32 | Phase Reversal | 32 |
| Local Mode | 64 | Manually Moved— Mid-travel to Open | 64 |
| Combined Fault | 128 | Manually Moved— Open to Mid-travel | 128 |
| Thermal OL Tripped | 256 | Manually Moved— Mid-travel to Close | 256 |
| Failure to De-energize | 512 | Manually Moved— Close to Mid-travel | 512 |
| Network A Fault | 1024 | Network ESD Active | 1024 |
| Network B Fault | 2048 | Local ESD Active | 2048 |
| Open Torque Switch | 4096 | Reset Since Last Poll | 4096 |
| Close Torque Switch | 8192 | Wrong Rotation | 8192 |
| Manual Operation | 16384 | Local Opening | 16384 |
| Phase Error | 32768 | Local Closing | 32768 |

Note: Bold indicates the default values.

Example: Calculate the Monitor Relay Masks so that only the following conditions cause the monitor relay to de-energize:

Open torque switch
Close torque switch
Failure to energize open
Failure to energize close
Local ESD active

New Value for Register 116 = 4096 + 8192 = 12296


New Value for Register 117 = 1 + 2 + 2048 = 2051

This page is intentionally blank.

9. Actuator Wiring Details


9.1 L120 Actuator Wiring

Contact Arrangement for Position Limit Switches



Shown with valve in fully OPEN position.

Note: Both illustrations are for a **CLOCKWISE CLOSING** valve.




Shown with valve in fully OPEN position.

Note: Rotors INT. 1 & INT. 2 can be set at valve position **FULL OPEN**, **FULL CLOSED** or any position between.

Gear Limit Switch 14 is used to initiate the pulsing mode for slow speed

Figure 9-1: UEC-3 Limit Switch Connections for L120 Series Actuators

9.2 LY Actuator Wiring



Valve shown in full open position.

| Limit Switch Contact Development | | | | |
|----------------------------------|----------------|------------|--------------|--|
| LIMIT SWITCH CONTACT | Valve position | | FUNCTION | |
| | FULL OPEN | FULL CLOSE | | |
| 2 | ■ | - | OPEN LIMIT | |
| 3 | - | ■ | SPARE | |
| 4 | - | ■ | SPARE | |
| 5 | - | ■ | SPARE | |
| 6 | - | ■ | CLOSED LIMIT | |
| 7 | ■ | - | SPARE | |
| 8 | ■ | - | SPARE | |
| 9 | - | ■ | TIMER | |

NOTES:

1. - - Open contact
2. ■ Close contact
3. All limit switch trip points are fully adjustable
4. Limit Switch LS1 is not fitted to LY units

Figure 9-2: UEC-3 Limit Switch Connections for LY Series Actuators

10. Troubleshooting

10.1 Troubleshooting With The Universal Diagnostic Tool (UDT):

The UDT diagnostic tool is a simple plug-in device which automatically reads the information contained in a register in the Single Board Computer. The UDT is powered from the UEC-3 module and does not require a separate battery. The front of the UDT contains 18 LEDs which, when illuminated, indicate the presence of a control, status indication or fault condition. Each LED is accompanied by a brief caption, the meaning of which is described in Table 10-1.



Figure 10-1: Universal Diagnostic Tool

Warning

If the actuator is installed in a hazardous area and has explosion-proof certification, then it will be necessary to comply with specific site regulations regarding the maintenance of equipment. Always follow applicable regulations and procedures when performing work in restricted environments.

10.2 Using the UDT Diagnostic Tool:

(For detailed instructions on the use of the UDT, see the UEC-3 and DDC-100 Diagnostic Interface Manual, Bulletin 437-10000.)

1. Do not isolate power from the actuator, otherwise some of the information contained in the register (memory location) in the Single Board Computer (SBC) may be lost.
2. Carefully remove the main cover of the UEC-3 control module.
3. Attach the serial interface adapter to the 34-Pin connector on the SBC.
4. Plug-in the UDT to the serial interface adapter, using the lead supplied with the tool.
5. Check that power is present at the actuator. The LED 'POWER' should be illuminated.
6. Check that the UEC-3 is functioning correctly. The LED 'RESET' should not be illuminated. A fault condition will be indicated if the LED blinks repetitively.
7. If any of the other 16 LEDs are illuminated check the meaning against the list below and take the necessary action to isolate and remedy the fault condition, if one exists.

Table 10-1: LED Caption Designations:

| LED Caption | Explanation |
|--------------|---|
| OPEN TS - | Torque switch has tripped between the limits, in the opening direction. |
| CLOSE TS - | Torque switch has tripped between the limits, in the closing direction. |
| OPEN INH - | 'OPEN' inhibit signal is present at terminal TB1-4 |
| CLOSE INH - | 'CLOSE' inhibit signal is present at terminal TB1-5 |
| OPEN LS - | 'OPEN' limit switch has tripped. |
| CLOSE LS - | 'CLOSE' limit switch has tripped. |
| LOST PH - | Phase L2 has been lost (If phases L1 or L3 have been lost, the UEC will not be powered . |
| TH OL - | Motor thermostat has tripped due to motor over heating. |
| ESD - | ESD signal is present at terminal TB1-3 |
| LOCAL - | Actuator is in LOCAL or OFF mode. Not in REMOTE. |
| VALVE JAM - | The jammed valve signal has been initiated but has not been successful. |
| CLOSE CONT - | 'Close' contactor has failed to operate after being signaled. |
| OPEN CONT - | 'Open' contactor has failed to operate after being signaled. |
| REV PH - | The three phase supply connections are reversed. |
| LOCAL COMM - | No communication through the diagnostics port. |
| COMB - | Combination fault- only used on UEC-3-DDC. This LED will always be illuminated on UEC-3 and UEC-3-MPC since a DDC 2- wire network is not present. |

10.3 UEC Troubleshooting - All Models




Figure 10-2: UEC Troubleshooting Flow Chart - All Models

10.4 UEC-3-MPC Troubleshooting




Figure 10-3: UEC-3-MPC Troubleshooting Flow Chart

10.5 Two, Three, and Four-Wire Control Troubleshooting




Figure 10-4: Two, Three, and Four-Wire Control Troubleshooting Flow Chart

11. Parts

X indicates that parts are required.

O indicates that parts are optional.

| Part | Part Number | UEC-3 | MPC-3-MPC |
|---|--------------------|-------|-----------|
| Single Board Computer | 61-825-0996-4 | X | X |
| Termination/Interconnect Board | 61-825-1060-3 | X | X |
| 3 Phase Power Supply Board | 61-825-0997-4 | X | X |
| Single Phase & Special Power Supply Boards | 61-825-0998-4 | O | O |
| Primary Fuses (FS1 & FS2) - Three Phase Operation | EF4-TDC11-250MA | X | X |
| Primary Fuses (FS1 & FS2) - Single Phase Operation | EF2-TDC11-750MA | X | X |
| Control Fuse (FS3) | EF2-5X20MM-1A-250V | X | X |
| 24VDC I/O Power Fuse (FS4) | EF2-5X20MM-1A-250V | X | X |
| PT 20SD | TM74-743-0066 | O | O |
| SBC Analog Board | 61-825-0962-2 | | X |
| SW93 Pushbutton Station | TM74-790-0033 | X | X |
| Customer Service Kit | TM0700504 | O | O |
| Universal Diagnostic Tool | 61-825-0950-3 | O | O |
| UDT Serial Interface Adapter | 61-825-0951-3 | O | O |
| ADC Chip | 61-825-0733-1 | | X |

Part Numbers are subject to change as product improvements are introduced. Consult Limitorque for current part numbers.

This page is intentionally blank.

12. Customer Service

For parts or parts information, call your local Limatorque distributor or the Parts Department in Lynchburg, VA, at 804-528-4400. For fastest response, please have the order number and serial number from the actuator available when contacting Limatorque for parts or parts information. This information can be found on a Limatorque label affixed to the main housing of the actuator.

For service information, call your local Limatorque distributor, Blue Ribbon Service Center or the Service Department in Lynchburg, VA, at 804-845-9366. For fastest service, please have the order number and serial number from the actuator available when contacting Limatorque with service questions. This information can be found on a Limatorque label affixed to the main housing of the actuator.

This page is intentionally blank.

13. Related Publications

1. DDC-100 UEC Field Unit (BITBUS)
Installation and Operation Manual - Bulletin 440-20013
2. DDC-100 UEC Field Unit (Modbus)
Installation and Operation Manual - Bulletin 440-20014
3. Modsim & Modbus Simulation Software
Operation Manual - Bulletin 440-20014
4. UEC-3 and DDC-100 Diagnostic Interface Manual -
Bulletin 437-10000
5. UEC-3 and UEC-3-MPC Installation and Commissioning
Manual - Bulletin 440-12100.

Notes:

Notes:

For further Limitorque service assistance call:

Limitorque Corporation
2600 East Miroloma Way
Anaheim, CA 92806
Phone (714) 630-7800
Fax (714) 630-1691

Limitorque Corporation
8501 W. 191 St.
Bldg. 5
Mokena, IL 60448
Phone (708) 720-0017
Fax (708) 720-9468

Limitorque Corporation
7615 Boeing Drive
Greensboro, NC 27409-8347
Phone (910) 668-0871
Fax (910) 605-5310

Limitorque Corporation
8901 Jameel Road, Suite 180
Houston, TX 77040
Phone (713) 690-1960
Fax (713) 690-1277

This manual contains information that is correct to the best of Limitorque's knowledge. It is intended to be a guide and should not be considered as a sole source of technical instruction, replacing good technical judgment, since all possible situations cannot be anticipated. If there is any doubt as to exact installation, configuration, and/or use, call Limitorque Corporation, at (804) 528-4400.

Limitorque®

Limitorque Corporation
5114 Woodall Road
P.O. Box 11318
Lynchburg, VA 24506-1318
Phone (804) 528-4400
Fax (804) 845-9736

Limitorque International
Bone Lane, Newbury
Berkshire, RG145EH England
Phone 44-635-46999
Fax 44-635-36034
Telex 851-847214 LIMTRK G

Limitorque/Nippon Gear Co. Ltd.
Tennoz Central Tower, 2-2-24
Higashi-Shinagawa-Ku
Tokyo 140, Japan
Phone 03-5460-7511
Fax 03-5460-8396


Limitorque of Canada, Ltd.
2525 Dunwin Drive, Unit 1
Mississauga, Ontario L5L 1R9,
Canada
Phone (905) 820-1013/1014/1026
Fax (905) 820-5096

Limitorque India, Ltd.
E-45/2 Okhla Industrial Area,
Phase-II, New Delhi-110020, India
Phone 91-11-8276835
Fax 91-11-6839329
Telex 953-31-62921 HLID IN

Limitorque Australia Ltd.
Division of Control Engineering
(Aust.) PTY Ltd.
17 Scoresby Road
Bayswater, Victoria 3153, Australia
Phone 613-9729-0555
Fax 613-9729-8225

Limitorque Asia Pte Ltd.
75 Bukit Timah Rd.,
#05-01/02 Boon Siew Building
Singapore 229833
Phone 65-332-9100
Fax 65-332-9112

L120 Series Type 05 thru 40 Instruction and Maintenance Manual



A Product of Limitorque Corporation

 **Warning**

Do not manually operate actuator with devices other than installed Handwheel and Declutch Lever. Using additive force devices (cheater bars, wheel wrenches, pipe wrenches or other devices of this nature) on the actuator Handwheel or Declutch Lever may cause serious personal injury and/or damage to the actuator or valve.

Copyright 1995, by Limitorque® Corporation

All rights reserved. No part of this manual may be reproduced or utilized for information re-sale in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without written permission from Limitorque Corporation.

Limitorque Corporation reserves the right to make changes, without notice, to this document and the products which it describes. Limitorque Corporation shall not be liable for technical or editorial errors or omission made herein; nor for incidental or consequential damages resulting from the furnishing, performance or use of this document.

Limitorque® is a registered trademark of Limitorque Corporation.

LIMITORQUE TYPE L-120 INSTRUCTION & MAINTENANCE MANUAL

Your Limitorque Valve Control...

Limitorque's L-120 series of actuators is the most advanced valve control on the market...the result of many years of development and an awareness of our customers' requirements. This booklet has been prepared to help you obtain the most benefit from the equipment. It contains instructions on the installation and maintenance of the units, plus helpful suggestions to enable you to become thoroughly familiar with the location and proper use of the operating controls.

Please before you attempt to install or operate your Limitorque Actuator — be sure to read this booklet at least once. Always keep it available for quick reference.

Limitorque actuators control the opening and closing of the valve and limit the torque and thrust applied to the valve stem. As a result, all valve operating components are protected from overload, improper seating or pipeline obstructions.

Limitorque controllers may be mounted on any size of valve in almost any position or location. Readily adaptable to existing equipment, Limitorque actuators may be powered by electricity, hydraulic pressure, air or natural gas.

Where to Find Information

| | |
|-------------------------|----|
| PRINCIPLES OF OPERATION | 2 |
| LUBRICATION | 2 |
| INSTALLATION TIPS | 3 |
| TORQUE SWITCH | 4 |
| GEARED LIMIT SWITCH | 5 |
| POSITION INDICATION | 7 |
| DISASSEMBLY PROCEDURE | 8 |
| STEM NUT REPLACEMENT | 11 |
| REASSEMBLY | 11 |
| SIDE MOUNTED HANDWHEEL | 13 |
| ELECTRICAL START-UP | 16 |
| TYPICAL WIRING DIAGRAM | 16 |

To obtain further information or to order parts for your Limitorque Valve control — contact your local representative or write to:

Limitorque Corporation
5114 Woodall Rd.
P.O. Box 11318
Lynchburg, Va. 24506
Attn: Manager Parts Dept.
(804) 528-4400
Fax: 804-845-9736

Note: All inquiries or orders MUST be accompanied by the following information, which can be obtained from the unit nameplate:

Unit size & type
Serial number
Limitorque Corporation order number.

PRINCIPLES OF OPERATION

Description of Motor Operation:

Your Limitorque actuator is always available for motor operation whenever the motor is energized.

DO NOT FORCE THE DECLUTCH LEVER INTO MOTOR OPERATION POSITION — THE LEVER RETURNS TO THIS POSITION AUTOMATICALLY WHEN THE MOTOR IS ENERGIZED.

(Refer to page 8)

In motor operation, the motor gear set (#'s 35 & 38) drives the wormshaft (#15) and worm gear (#21) which in turn rotates the clutch sleeve (#19) by means of driving lugs. The clutch sleeve and worm gear may be assembled to produce either a 'no lost motion' or 'hammerblow' effect. The drive sleeve (#25) is keyed to the clutch sleeve and, hence, rotates producing the required output rotary motion.

Description of Manual Operation:

Counterclockwise rotation of the declutch lever (#9) causes the declutch actuator to lift the clutch sleeve out of engagement with the worm gear. Drive lugs on top of the clutch sleeve engage matching lugs in the handwheel adapter (#26) and, then, lat-

ches engage the clutch sleeve in this position. The actuator is now in the handwheel drive option. Energizing the motor at this point will cause the latches to drop out and the spring loaded clutch sleeve re-engages with the lugs on the worm gear. The actuator is once more in motor operation. PLEASE NOTE THAT THE SHIFT FROM MANUAL TO MOTOR OPERATION IS AUTOMATIC AND DOES NOT REQUIRE EXTERNAL POSITIONING OF THE DECLUTCH SHAFT.

Torque and Travel Limiting:

The geared limit switch is driven by a bevel gear connected to the upper drive lugs of the clutch sleeve. Thus the limit switch is directly connected to the output of the actuator and, once properly set, remains in step with the valve position regardless of electric or manual operation of the Limitorque actuator.

The worm and wormshaft are supported in two rotating spring packs. As torque is generated by the actuator, the worm moves axially against one of the spring packs. Each pack is pre-calibrated and, hence, a finite compression represents a finite torque output. Movement of the worm operates the torque switch which interrupts the power to the motor. The torque switch is adjustable and can be set to operate at pre-determined torque levels.

LUBRICATION

Lubrication Inspection

Note:

Before operating your actuator, inspect it for proper lubrication, (especially if it has been stored for a long period of time).

Limitorque actuators are designed with a totally sealed gear case factory-packed with grease. The gear case can be mounted in any position (all penetrations into it are sealed); however, those mounting positions which would cause vulnerable areas of the operator (e.g., motor, or switch compartment) to be saturated with lubricant should a seal failure occur, should be avoided if possible and are not recommended.

No seal can remain absolutely tight at all times;

therefore, it is not unusual to find a very small amount of weeping around shaft seals — especially during long periods of idleness such as storage. Using grease minimizes this condition as much as possible. If you find a small amount of weeping at start-up, remove it with a clean rag. Once the equipment is operating, the weeping should stop.

Lubrication Frequency

Base the frequency of lubrication inspections on historical data of your installed equipment. Every actuator application has its own effect on lubricants. Pattern lubricant inspections based on the needs of your facility and its applications. The following schedule of lubrication inspection should be followed until operating experience indicates otherwise.

Gear Case: Inspect lubrication every 18 months or 500 cycles – whichever occurs first.

Inspection

The three primary considerations in a lubrication inspection are:

1. **Quantity** - L120 operators are built to operate on the immersion principle. The primary concern in the amount of lubricant is whether the "worm" is totally immersed in grease.
2. **Quality** - If dirt, water or other foreign matter are found during lubrication inspection, the units should be flushed with a commercial degreaser/cleaner such as Exxon Varsol #18 which is not corrosive and does not affect seal materials. Repack unit with fresh lubricant allowing room for grease thermal expansion.
3. **Consistency** - Lubricant should be slightly fluid approximating a standard NLGI-0 grade consistency or less. Thinners such as Amoco WAYTAC #31 oil may be added provided the volume of thinner does not exceed 20% of the total lubricant.

Factory Lubricants

Gear Case:


Nebula EP-0 calcium complex base grease, suitable for temperatures from -20°F (-29°C) to +175°F (+79°C).

L120 with 3600 and 1900 RPM motor is factory lubricated with Exxon Nebula EP-00 calcium complex base grease, suitable for temperatures from -60°F to +250°F.

Geared Limit Switch:

Exxon Beacon 325 (no substitute).

Limitorque Minimum Lubricant Qualities Required



The standard lubricants used by Limitorque have been proven extremely reliable over years of service. We do not recommend a particular lubricant substitute for our standard lubricants, but below is a list of minimum lubricant qualities required by Limitorque:

- 1) Should contain an "EP" additive.
- 2) Must be suitable for the temperature range intended.
- 3) Must be water and heat resistant and non-separating.
- 4) Must not create more than 8% swell in Buna N or Viton.

- 5) Must not contain any grit, abrasive or fillers.
- 6) Must slump—prefer NLGI grade .
- 7) Must not be corrosive to steel gears, ball or roller bearings.
- 8) Dropping point must be above 316°F (158°C) for temperature ranges of -20°F (-29°C) to 150°F (+66°C).

Approximate Lubricant Weights

| Unit Size | lbs. | kg |
|-----------|------|-----|
| L120-05 | 3.3 | 1.5 |
| L120-10 | 3.3 | 1.5 |
| L120-20 | 6.1 | 2.8 |
| L120-40 | 8.1 | 3.7 |

INSTALLATION TIPS

CAUTION: Do not attempt to store, install or operate your Limitorque Valve Control without reading the instructions and cautionary notes below.

CAUTION: Do not remove the unit mounting bolts when the unit is mounted on a rising stem valve unless the valve is in the fully open position, or there is not, nor cannot be, any pressure in the line.

NOTE: Limit switches are not factory set by Limitorque. They must be set when the unit is installed on the valve.

Short Term Storage (less than one year).

Units are not fully weatherproof until properly installed on the valve or prepared for storage.

Units should be stored in a clean, dry, protected warehouse free from excessive vibration and rapid temperature changes. If the units must be stored outside, they must be stored off the ground, high enough to prevent their being immersed in water or buried by snow.

Connect the internal heaters (if supplied) or place desiccant in the switch compartment. Replace all plastic caps or plugs with pipe plugs and ensure that all covers are tight. If the unit is mounted on a valve and the stem protrudes from unit, a suitable stem cover must be provided.

Unit should be stored with the motor and switch compartment horizontal.

FAILURE TO COMPLY WITH THESE RECOMMENDED STORAGE PROCEDURES WILL VOID THE WARRANTY. FOR LONGER TERM STORAGE PLEASE CONSULT LIMITORQUE FOR PROCEDURES AND RECOMMENDATIONS.

DO:

1. Mount motors on a horizontal plane, if possible.
2. Keep the switch compartment clean and dry.
3. Operate the unit by handwheel only, when initially setting the limit switches.
4. Check all unit wiring to ensure that it coincides with the applicable wiring diagram.
5. Carefully check for correct motor rotation direction. If the motor is driving the valve in the wrong direction, interchange any two leads on three phase motors or switch the armature leads on D.C. and single phase motors.
6. Use protective stem cover. Check valve stem travel and clearance before mounting covers on rising stem valves.
7. Replace all molded plastic conduit and top protectors (installed for shipping purposes only) with pipe plugs when installation wiring is complete.
8. Set up periodic operating schedule for infrequently used valves.
9. Keep the valve stem clean and lubricated.
10. Reset the travel limit switches prior to motor operation if the unit has been dismantled or removed from the valve.

CAUTION: Shut off incoming power before opening switch compartment.

DO NOT:

1. **CAUTION:** Do not attempt to work on your Limitorque actuator without first shutting off incoming power.
2. Do not attempt to work on your Limitorque actuator while it is mounted on a torque seated valve.
3. Do not motor operate the valve without first setting or checking the limit switch setting and motor rotation direction.
4. Do not force the declutch lever into motor operation. **LEVER WILL AUTOMATICALLY RETURN TO MOTOR OPERATION WHEN MOTOR IS ENERGIZED.**
5. Do not force the declutch lever into hand operation. If the clutch does not easily engage, rotate handwheel slowly while operating the declutch lever.
6. Do not use a cheater on the handwheel.
7. Do not use abrasive cloth to clean the contacts on the limit and torque switches.
8. Do not torque seat 90° operation valves nor run them against the stops as this may cause damage to the valve.
9. Do not alternately start/stop the motor to open or close a valve which is too tight for normal operation.
10. Do not reset torque switch to a setting higher than the recommend factory maximum.
11. Do not attempt to repair gearing in the limit switch. Replace entire gear frame assembly if necessary.

TORQUE SWITCH

CAUTION

Disconnect all incoming power before opening limit switch compartment or working on the torque switch.

NOTE

If unit has "torqued out", release torque buildup by operating the unit manually.

The torque switch is designed to protect the actuator in open and close directions. The switch was set at the factory according to information regarding necessary torque or thrust output that was provided at the time of order. A torque switch calibration tag was supplied with the unit.

CAUTION

A maximum stop setting plate is provided on most units. Do not remove this plate. Do not exceed the setting indicated by this limiter plate without contacting Limitorque.

Torque Switch Setting Procedure

Before adjusting or installing a torque switch, place the L120 unit in manual mode and release the load on the wormshaft spring pack.

CAUTION

Installing or adjusting the torque switch with the operator in a loaded condition will result in a loss of torque protection.

Should the present switch setting require changing, proceed as follows:

1. For both open or close direction, loosen screw (A) and move pointer (B) to desired position. A higher number indicates a high torque and/or thrust output.
2. Tighten screw (A).
3. Operate the valve electrically to seat valve and to ensure tight shut-off.


Balancing Procedure

If the torque switch has been removed from the unit or if a new torque switch is being installed, the torque switch must be rebalanced using the following procedure:


1. Ensure that the unit is in manual mode and the load is removed from the wormshaft spring pack.
2. Prior to reinstalling the torque switch, note the open and close torque switch settings.
3. Loosen screws (A) and position both pointers (B) at the #1 setting, tighten screw (A). In this position the index marks should be aligned.
4. Loosen balancing screws and install the torque switch. When properly installed, the base of the torque switch is flush against the compartment and the hole for the mounting screw is aligned. Install the mounting screw.
5. Tighten the balancing screws. The switch is now balanced and ready for the pointers to be returned to their original settings.

CAUTION

The balancing screws should not be touched except during the balancing procedure.



600 Volt Torque Switch



Micro-Switch Style Torque Switch

GEARED LIMIT SWITCH

CAUTION

The geared limit switch is not pre-set at the factory and must be adjusted after the actuator has been mounted on its associated equipment.

Disconnect all incoming power to the unit prior to opening the limit switch compartment and adjusting the switch.

Consult the relevant wiring diagram for limit switch contact development. All L120 units are supplied with 16 contact limit switches - 4 switches on each of 4 rotors. Two rotors are used for end of travel indication. The remaining two rotors may be adjusted for any intermediate point of travel.

Limit Switch Setting Procedure

Danger

Potential Explosion Hazard. Do not use a variable speed electric drill for setting the Limit Switch in an explosive environment.

Caution

When setting Limit Switch Rotor Segments (Cams) using a variable speed electric drill, Do Not run drill at speeds higher than 200 RPM. Operating drill at high speeds can cause damage to gearing within the Limit Switch.

Note

The standard 16 contact, 4 gear, Limit Switch is capable of counting up to 740 drive sleeve turns depending on actuator unit size. The Intermediate Shaft (B) may take a considerable number of turns before rotor trip occurs.

1. Open compartment cover (#200).
2. Put the actuator into manual operation and use the handwheel to operate the valve in the "open" direction. While operating the valve, note the direction of the intermediate shaft (B) corresponding to the rotor or rotors to be set.
3. When the valve is fully open, close it one turn of the handwheel to allow for coast of moving parts.
4. Push in setting rod (A) and turn one quarter turn. The rod will latch in this depressed position.
5. Refer to the applicable wiring diagram for contact development. The limit switch contact is closed when the rotor is engaged with the plunger. If the rotor to be set has not turned 90 degrees to operate the plunger, turn the intermediate shaft in the same direction as noted in step "2" until the rotor clearly trips the switches. This rotor is now set correctly.

If the rotor has already tripped, turn intermediate shaft (B) in the direction opposite the that noted in step "2" until the rotor trips. Immediately reverse direction until the rotor clearly trips again. This rotor is now correctly set.

If the intermediate position rotor is also to be set at the end of travel position, repeat the setting operation as above.

6. Before moving the valve, depress and turn the setting rod (A) one quarter turn to the spring released position. Insert a screwdriver into the intermediate shafts to ensure that they will not move.

**CAUTION:**


Do not operate the valve when the setting rod (A) is in fully depressed position, loss of the contact setting will occur and the setting rod will be damaged.

7. Operate the valve by handwheel to the fully "close" position, reverse direction by one turn of the handwheel to allow for coast of moving parts.
8. Set the other rotors by following steps "1" through "6".

The rotor segments can be separated and rotated through 90 degrees to give various combinations of normally open or normally closed contacts for each rotor:

Proceed as follows:

1. Remove nuts (8) and fillet head machine screws (5) (total 2 fasteners on each side of the switch).
2. Complete contact assembly can now be removed from the back plate.
3. Cams can now be rearranged on the camshaft to produce the required combination of contacts.
4. Replace contact assembly on back-plate (ensuring that the registers fit correctly) and secure with machine screw and nuts.



Limit Switch

Parts List

| PC. NO. | QTY. | DESCRIPTION |
|---------|------|------------------------------|
| 1 | 1 | GEAR FRAME ASSEMBLY |
| 2 | 2 | 8 SWITCH CONTACT BLOCK ASSY. |
| 3 | 12 | ROTOR SEGMENTS (SHORT) |
| 4 | 4 | ROTOR SHAFT |
| 5 | 4 | MACHINE SCREW |
| 6 | 4 | FLAT WASHER |
| 7 | 4 | LOCK WASHER |
| 8 | 8 | HEX NUT |
| 9 | 4 | ROTOR SEGMENTS (LONG) |

● POSITION INDICATION

● Local:

1. The local dial position indicator is factory selected to show valve position but can only be adjusted when mounted on the valve.
2. Disconnect all incoming power and remove Switch Compartment Cover, (#200).
3. Place valve in the fully closed position.
4. Loosen the round head machine screw which holds the pointer in place, move the pointer to the "O" position, and retighten the screw. The indicator is now set.

NOTE: 'Flip-flop' type indicators are activated by the end-of-travel rotors of the geared limit switch. This type of indicator will require no further setting after the geared limit switch has been adjusted.


NOTE: For assemblies supplied for remote indication, the Driving Pinion, has been shipped loose in a bag, to protect the potentiometer from being damaged by accidental rotation of the handwheel prior to installation and setting on the valve.


● Remote:

CAUTION: Typical voltmeter remote indicators furnished by Limatorque are built to accept a maximum of 10 volts. It is necessary to adjust using a separate test voltmeter with a scale suitable for the maximum incoming control voltage.

1. Mount the adjustable resistor furnished as near as possible to the voltmeter indicator.

2. WITH POWER OFF, connect all wires as shown below **except** the two on the voltmeter indicator. Connect these two to the test meter.
3. Move the slider of the adjustable resistor to the extreme opposite end of the resistor from the power connection.
4. Disconnect all incoming power and remove Switch Compartment Cover, (#200). Set screw in small gear which drives the transmitter (potentiometer) should already be loose. If it is not, loosen set screw so gear will not drive the transmitter.
5. Place the valve in the fully closed position. While valve is moving toward closed, note which direction the small shaft and gear **would** be driving the wiper arm on the transmitter.
6. When valve is closed, move the wiper arm on the transmitter to the end of the transmitter coil corresponding to the close position, and tighten set screw on gear.
7. Turn power on. The test meter should now read "O" or almost "O".
8. Place the valve in the full open position.
9. Move the adjustable resistor slider toward the power connected end until the test meter reads 10 volts.
10. Turn power off, disconnect the test meter, and connect leads to the voltmeter indicator.
11. Turn power on. Indicator should now read full open.
12. Final adjustment may be necessary. If the indicator reads less than full open, **carefully** move the adjustable resistor slider ahead being careful not to exceed the full open position on the dial. If the indicator reads more than "O" when the valve is closed, repeat the setting procedure starting with Step 6.
13. When the indicator properly shows valve position, lock the adjustable resistor slider in place.





PARTS LIST

| PC. NO. | QTY. | DESCRIPTION |
|---------|------|------------------------|
| 1 | 1 | HOUSING |
| 2 | 1 | MOTOR ADAPTER |
| 3 | 1 | ELECTRICAL COMPARTMENT |
| 4 | 1 | SEAL RETAINER |
| 5 | 1 | WORM SHAFT END CAP |
| 6 | 1** | HSG. COVER SHIM SET |
| 7 | 1 | DECLUTCH SHAFT ASSY. |
| 9 | 1 | DECLUTCH LEVER |
| 10 | 1 | ROLL PIN |
| 11 | 1 | DECLUTCH CAP |
| 15 | 1 | WORM SHAFT ASSEMBLY |
| 30 | 1 | NIPPLE FLANGE |
| 31 | 1 | MOTOR |
| 32 | 4** | DOWELS |
| 35 | 1 | WORM SHAFT GEAR |

| PC. NO. | QTY. | DESCRIPTION |
|---------|------|---------------------|
| 36 | 1 | KEY |
| 37 | 1 | FLEXLOC NUT |
| 38 | 1 | MOTOR PINION |
| 39 | 1 | KEY |
| 40 | 1 | STOP NUT |
| 41 | 1* | WASHER |
| 42 | 1 | SEALS KIT |
| 46 | 1 | O-RING |
| 47 | 1 | O-RING |
| 50 | 1 | HARDWARE KIT |
| 200 | 1 | COMPARTMENT COVER |
| 300 | 1 | TORQUE SWITCH |
| 305 | 1 | GEARED LIMIT SWITCH |

* L120-40 Only

** Not Shown

DISASSEMBLY PROCEDURE

CAUTION: Do not attempt to perform service on the Limatorque actuator unless all power services have been shut off. Minor work, such as replacing geared limit switch, torque switch or motor, may be readily performed while the actuator is still on the valve. For more complex work, it is suggested that the actuator be removed from the valve.

If the actuator is fitted with a thrust base (#100), it is possible to remove the actuator housing while leaving the base on the valve to accept valve thrust. However, it is preferred that the valve be isolated from service and, if it is a rising stem, that the valve be fully open.

To disassemble the L120-05, 10, 20 and 40 units, proceed as follows:

1. Shut off all power to the unit.
2. Remove electrical compartment cover (#200). (note: fastening screws are captive in cover).
3. Disconnect all electrical leads from the torque switch (#300) and geared limit switch (#305). Ensure that all leads and terminals are clearly marked to facilitate re-assembly.
4. Remove two screws holding limit switch and one holding torque switch. Remove both items.
5. Remove four bolts holding motor (#31) and three

bolts holding conduit nipple flange (#30). Remove motor, drawing motor leads through from switch compartment.

6. Motor pinion (#38) may be replaced by removing flex loc nut (#40).
7. Remove worm shaft cap (#5) and draw complete wormshaft assembly from housing. Note: The wormshaft has been assembled at the factory to obtain the correct pre-load on the spring packs. Do not attempt to disassemble further. If the worm is worn or damaged, it is suggested that the complete wormshaft subassembly be replaced.
8. Remove declutch cap (#11).
9. For L120-05 and 10 size, the complete declutch assembly (#7) may now be drawn from housing.

For L120-20 and 40 sizes, remove declutch input pinion (#12) followed by declutch assembly (#7).

10. Remove handwheel and housing cover (#27) and lift complete drive sleeve subassembly from housing.

Drive Sleeve & Housing Cover Disassembly


1. Remove upper bearing (#17), bevel gear (#18), declutch spring (#24), and clutch sleeve (#19).
2. Remove lower bearing (#16).
3. Spirolox retainer (#22) may now be removed by inserting small flat blade screwdriver under the end of the ring and prying the first layer from

the groove. Continue around the ring until it is free from the groove.

4. Remove wormgear (#21) and lug ring (#20).
5. Handwheel adapter (#26) and Seal (#42) can be removed from housing cover (#27) by removing retaining ring (#28).


| PARTS LIST | | |
|------------|------|-------------------------|
| PG. NO. | QTY. | DESCRIPTION |
| 16 | 1 | BALL BEARING |
| 17 | 1 | BALL BEARING |
| 18 | 1 | DRIVE SLEEVE BEVEL GEAR |
| 19 | 1 | HW CLUTCH SLEEVE |
| 20 | 1 | WORM GEAR LUG RING |
| 21 | 1 | WORM GEAR |
| 22 | 1 | RETAINING RING |
| 23 | 1 | KEY |
| 24 | 1 | DECLUTCH SPRING |
| 25 | 1 | DRIVE SLEEVE |
| 26 | 1 | HANDWHEEL ADAPTER |
| 27 | 1 | HOUSING COVER |
| 28 | 1 | RETAINING RING |
| 29 | 1 | HANDWHEEL |
| 33 | 1 | HANDWHEEL COVER PLATE |
| 34 | 1* | HW COVER PLATE GASKET |
| 42 | 1 | SEAL KIT |
| 43 | 1 | QUAD RING |
| 44 | 1 | QUAD RING |
| 50 | A/R | HARDWARE |

* Not shown



Thrust Base Disassembly

1. If thrust base option is present (#100), remove seal retainer (#102) followed by stem nut (#101) and thrust bearings (#'s 103, 104 and 105).
2. Remove four bolts (#110) and lift thrust base from main housing.



PARTS LIST

| PC. NO. | QTY. | DESCRIPTION |
|---------|------|------------------|
| 100 | 1 | BASE HOUSING |
| 101 | 1 | STEM NUT |
| 102 | 1 | SEAL RETAINER |
| 103 | 2 | NEEDLE BEARING |
| 104 | 2 | THRUST WASHER |
| 105 | 2 | THRUST WASHER |
| 106 | 1 | O-RING SEAL |
| 107 | 2 | QUAD RING SEAL |
| 108 | 1 | GASKET |
| 109 | 1 | GREASE FITTING |
| 110 | 4 | HEX HD CAP SCREW |
| 111 | 4 | LOCK WASHER |

Torque Nut Disassembly

The L120 Series actuator can be supplied without the thrust base option for applications requiring torque only. The torque nut is driven by the drive sleeve lugs and held in place by the torque bushing connector.


Standard Drive Sleeve:

To remove the torque nut (#95), remove retaining ring (#183) and drop the torque nut out the bottom of the drive sleeve (#25).

Optional Drive Sleeve:

1. Remove the handwheel (#29), handwheel cover plate (#33) and gasket (#34) to provide access to the elastic stop nut (#99).

2. Remove the elastic stop nut (#99) from the rod (#1). The torque nut (#95) can now be removed from the bottom of the drive sleeve (#25).
3. The torque bushing connector (#96) can be removed from the torque nut by removing the retaining ring (#98).



Standard & Extended Drive Sleeve Assembly (Ref. dwg. 01-602-0382-3-B)

Parts List for Extended & Optional Drive Sleeve

| PC. NO. | QTY. | DESCRIPTION |
|---------|------|---------------------|
| 183 | 1 | RETAINING RING |
| 99 | 1 | ELASTIC STOP NUT |
| 97 | 1 | TORQUE BUSH WASHER |
| 96 | 1 | TORQ. BUSHING CONN. |
| 98 | 1 | RETAINING RING |
| 95 | 1 | TORQUE NUT |
| 25 | 1 | DRIVE SLEEVE |

STEM NUT REPLACEMENT

This section is applicable only to thrust base applications. Occasionally the stem nut of the operator may need replacing if used in a threaded stem application on rising stem valves.

Warning:

Possible Hazardous Voltage. Turn power OFF before disassembling or removing the L120 from the mounting base. This will prevent accidental start-up during service to unit.

Warning:

Potential high pressure vessel. Before removing or disassembling your actuator, insure that the valve or other actuated device is isolated and is not under pressure.

Use the following procedure to replace stem nut:

1. Disconnect all incoming power to the unit.
2. Remove actuator from valve.
3. Remove seal retainer (#102) followed by stem nut, bearings and seals.
4. Check the fit of the new stem nut on the valve stem — ensure that the nut travels freely without binding.
5. Reassemble the thrust base and remount the actuator on the valve.
6. Remount actuator on thrust base.
7. Removing the actuator from the valve will change the limit switch settings. Refer to the Geared Limit Switch section of this manual to reset the limit switches.
8. Reconnect power and test for correct functioning.

REASSEMBLY

(Refer to illustrations on pages 8, 9, and 12)

1. Install lug ring (#20) onto drive sleeve (#25) followed by worm-gear (#21). Ensure that worm-gear lugs engage with recesses on lug ring.
2. Install Spirolox retainer (separate layers of retainer sufficiently to begin threading the retainer into the drive sleeve groove. Continue threading until the retainer is firmly located in the groove).
3. Now install key (#23) and clutch sleeve (#19).
4. Complete the assembly, by adding the declutch spring (#24), bevel gear (#18), upper bearing (#17), and lower bearing (#16).
5. Replace drive sleeve assembly into main housing, secure with the housing cover (#27). Ensure that all seals are in place.
6. Insert wormshaft assembly (#15) into the housing

and locate the bearings in the housing journals. Replace the wormshaft cap (#5).

7. Install the wormshaft gear (#35) and flex loc nut (#37).

Note:

The flexloc nut may be reused a limited number of times. It is recommended that a new nut be used during reassembly.

8. Declutch Assembly:

Size L120-05 and 10:

Install declutch cap (#11) on declutch shaft (#7), ensure that the return spring is located correctly in the endcap. Replace declutch lever (#9) on the shaft with the lever against the stop. While holding the cap steady rotate the declutch shaft against the spring tension until the holes in the shaft and lever align. (Insert roll-pin (#10)).

Replace complete assembly in main housing. Ensure that declutch actuator (#7-1) declutch latches (#7-2 & #7-3) fit into the groove on the declutch sleeve (#19). Secure declutch cap.

Note:

When the declutch lever is disengaged against the declutch stop (motor operation position), the declutch actuator (#7-1) should not be in contact with the groove on the handwheel clutch sleeve (#19) (see illustration on page 9 and 12).

Size L-120-20 and 40:

Install declutch cap (#11) on the declutch pinion shaft (#12), ensuring that the return spring is correctly located in slots. Install declutch lever (#9) on the pinion and against the stop. While holding the cap steady, rotate the pinion shaft (#12) against the spring tension until the holes in the lever (#9) and shaft align. Insert roll pin (#10). Slide declutch shaft (#7) into the housing, ensuring that declutch shaft assembly (#7) fits correctly in the groove in the handwheel clutch sleeve (#19).

Install declutch cap assembly into housing, finding the nearest tooth on the internal spur gear which will allow the cap to be secured without placing tension on the declutch actuator (#7-1) (causing it to rub against the groove in the handwheel declutch sleeve (#19)).

(Continued)

9. Install torque and limit switches into switch compartment housing.

Note:


The limit switch must be reset before the actuator is placed back into service.

10. Install motor pinion (#38) and elastic stop nut (#40) onto motor shaft.

Note:

The elastic stop nut may be reused a limited number of times. It is recommended that a new nut be used during reassembly.

11. Install motor using the following procedure:
Install conduit nipple flange (#30) and seal (#42) onto conduit nipple in the flange and secure motor. Finally, secure the nipple flange.
12. Connect all electrical leads in switch compartment and complete assembly by replacing the compartment cover, handwheel adapter, handwheel and thrust base if applicable.




Parts List

| PC. NO. | QTY. | DESCRIPTION |
|---------|------|-------------------------------|
| 7 | 1 | DECLUTCH SHAFT ASSY. |
| 7-1 | 1 | DECLUTCH ACTUATOR |
| 7-2 | 1 | DECLUTCH LATCH (LEFT & RIGHT) |
| 8 | 1 | DECLUTCH RETURN SPRING |
| 9 | 1 | DECLUTCH LEVER |
| 10 | 1 | ROLL PIN |
| 11 | 1 | DECLUTCH CAP |
| 12 | 1* | DECLUTCH INPUT PINION |
| 42 | 1 | SEAL |

*L120-20/40 ONLY



OPTIONAL SIDE-MOUNTED HANDWHEEL



L120-05 and 10

| | | | |
|---------|-------------|---------|-----------------------|
| 182 | 182-3 | 1 | HEX. JAM NUT |
| | 182-2 | 1 | SOCK. HEAD CAP SCREW |
| | 182-1 | 1 | HANDWHEEL SPINNER |
| | - | 1 | RETAINING WASHER |
| 181 | - | 1 | KEY |
| 180 | - | 1 | LOCKWASHER |
| 179 | - | 1 | HEX. HEAD CAP SCREW |
| 178 | - | 1 | HANDWHEEL |
| 177 | - | 1 | GREASE FITTING |
| 171 | - | 1 | RETAINING RING |
| 169 | - | 1 | SPACER |
| 164 | - | 1 | SEAL INSERT |
| 161 | - | 1 | BALL BEARING |
| 160 | - | 2 | QUAD-RING |
| 158 | 158-4 | 1 | 'O'-RING |
| | 158-3 | 1 | 'O'-RING |
| | 158-2 | 1 | 'O'-RING |
| | 158-1 | 1 | QUAD RING |
| 157 | 157-6 | 2 | LOCKWASHER |
| | 157-5 | 2 | SOCKET HEAD CAP SCREW |
| | 157-4 | 1 | ROLL PIN |
| | 157-3 | 2 | SOC HEAD CAP SCREW |
| | 157-2 | 4 | LOCKWASHER |
| | 157-1 | 4 | HEX HEAD CAP SCREW |
| 154 | - | 1 | BEVEL PINION SHAFT |
| 153 | - | 1 | BEVEL GEAR |
| 152 | - | 1 | BEARING CAP |
| 151 | - | 1 | BEVEL HOUSING ADAPTER |
| 150 | - | 1 | BEVEL HOUSING |
| 45 | - | 1 | PIPE PLUG |
| 44 | - | 1 | QUAD RING |
| 42-11 | - | 1 | 'O'-RING |
| 6 | - | 1 | HOUSING COVER SHIM |
| PC. NO. | SUB PC. NO. | L120-10 | NAME |
| | QTY. | | |

OPTIONAL SIDE-MOUNTED HANDWHEEL




HANDWHEEL RATIO: 5.7: 1


L120-20

| | | | |
|---------|--------------|----------------|-----------------------|
| 182 | 182-3 | 1 | HEX. JAM NUT |
| | 182-2 | 1 | SOCK. HEAD CAP SCREW |
| | 182-1 | 1 | HANDWHEEL SPINNER |
| 181 | - | 1 | RETAINING WASHER |
| 180 | - | 1 | KEY |
| 179 | - | 1 | LOCKWASHER |
| 178 | - | 1 | HEX. HEAD CAP SCREW |
| 177 | - | 1 | HANDWHEEL |
| 171 | - | 1 | GREASE FITTING |
| 169 | - | 1 | RETAINING RING |
| 161 | - | 1 | SEAL INSERT |
| 160 | - | 1 | BALL BEARING |
| 158 | 158-4 | 1 | QUAD-RING |
| | 158-3 | 1 | O-RING |
| | 158-2 | 1 | O-RING |
| | 158-1 | 1 | QUAD RING |
| 157 | 157-6 | 2 | SOCKET HEAD CAP SCREW |
| | 157-5 | 1 | ROLL PIN |
| | 157-4 | 4 | LOCKWASHER |
| | 157-3 | 4 | HEX HEAD CAP SCREW |
| | 157-2 | 4 | LOCKWASHER |
| | 157-1 | 4 | HEX HEAD CAP SCREW |
| 154 | - | 1 | BEVEL PINION SHAFT |
| 153 | - | 1 | BEVEL GEAR |
| 152 | - | 1 | BEARING CAP |
| 151 | - | 1 | BEVEL HOUSING ADAPTER |
| 150 | - | 1 | BEVEL HOUSING |
| 45 | - | 1 | PIPE PLUG |
| 44 | - | 1 | QUAD RING |
| | 42-11 | 1 | O-RING |
| 6 | - | 1 | HOUSING COVER SHIM |
| PC. NO. | SUB. PC. NO. | L 120 -20 QTY. | NAME |

OPTIONAL SIDE-MOUNTED HANDWHEEL



SECT. THRU PINION



HANDWHEEL RATIO: 12:1

L120-40

| | | | |
|---------|-------------|--------------|-----------------------|
| 182-3 | 182-3 | 1 | HEX. JAM NUT |
| 182-2 | 182-2 | 1 | SOCK. HEAD CAP SCREW |
| 182-1 | 182-1 | 1 | HANDWHEEL SPINNER |
| 181 | - | 1 | RETAINING WASHER |
| 180 | - | 1 | KEY |
| 179 | - | 1 | LOCKWASHER |
| 178 | - | 1 | HEX. HEAD CAP SCREW |
| 177 | - | 1 | HANDWHEEL |
| 171 | - | 1 | GREASE FITTING |
| 169 | - | 1 | RETAINING RING |
| 167 | - | 1 | KEY |
| 164 | - | 2 | BALL BEARING |
| 163 | - | 1 | BALL BEARING |
| 161 | - | 1 | SEAL INSERT |
| 160 | - | 1 | BALL BEARING |
| 159 | - | 1 | SPUR GEAR |
| 158 | 158-4 | 1 | QUAD-RING |
| | 158-3 | 1 | GASKET |
| | 158-2 | 1 | O-RING |
| | 158-1 | 1 | QUAD RING |
| 157 | 157-7 | 1 | SOCKET HEAD CAP SCREW |
| | 157-6 | 2 | DOWEL PIN |
| | 157-5 | 8 | SOCKET HEAD CAP SCREW |
| | 157-4 | 4 | LOCKWASHER |
| | 157-3 | 4 | HEX HEAD CAP SCREW |
| | 157-2 | 4 | LOCKWASHER |
| | 157-1 | 4 | HEX HEAD CAP SCREW |
| 156 | - | 1 | BEVEL GEAR ADAPTER |
| 155 | - | 1 | INPUT PINION SHAFT |
| 154 | - | 1 | BEVEL PINION |
| 153 | - | 1 | BEVEL GEAR |
| 152 | - | 1 | SPUR GEAR COVER |
| 151 | - | 1 | BEVEL HOUSING |
| 150 | - | 1 | BEVEL HOUSING COVER |
| 45 | - | 1 | PIPE PLUG |
| 44 | - | 1 | QUAD RING |
| 6 | 42-11 | 1 | O-RING |
| | - | 1 | HOUSING COVER SHIM |
| PC. NO. | SUB PC. NO. | L120-40 QTY. | NAME |

ELECTRICAL START-UP

1. Check that the actuator has been correctly lubricated. This is particularly important if the actuator has been in long-term storage.
2. Ensure that the geared limit switch has been correctly set per instructions in this manual. (see Geared Limit Switch Section).
3. If the valve stem is not visible, remove the stem cover or handwheel cover plate to observe output direction of the drive sleeve.
4. Engage manual operation and hand crank valve well away from end of travel positions.
5. Turn on power supply and push button to "open."
6. Check output rotation — if phase rotation is correct, the valve should begin to open. If valve

begins to close — stop immediately. Incorrect phase rotation will lead to serious damage if the valve seats.


7. Correct the phase rotation by switching any two of the three power leads for three-phase power, or reversing the armature leads for single-phase or D.C. power.
8. The actuator should now operate correctly and will be stopped at the end of travel positions by torque or limit switch functions.

(Premature stopping may be caused by incorrect limit switch or torque switch settings or line obstructions in the valve.)

9. Replace stem cover or cover plate.

TYPICAL WIRING DIAGRAM

The wiring diagram below is a representation of a typical application and may not be applicable to your specific actuator. Please refer to the wiring diagram supplied with your unit to confirm the actual equipment supplied.



Regulatory Information

DECLARATION OF CONFORMITY

Application of Council Directive(s):

89/336/EEC; EMC Directive

89/392/EEC; Machinery Directive

Standard(s) to which Conformity is Declared:

Machinery; EN 60204

EMC; Emmisions; EN 50081-1&2, EN 55011, CFR 47

Immunity; EN 50082-1&2, IEC 801-3 & IEC 801-6

ESD; IEC 801-2

EFT/Bursts; IEC 801-4

Surge Immunity; IEC 801-5, ANSI/IEEE C62.41

Mains (power) Harmonics; MIL-STD-462, Method CS01 & CS02

Manufacturer's Name:

Limatorque Corporation

Manufacturer's Address:

5114 Woodall Road, Lynchburg, VA 24502

Importer's Name:

Limatorque International

Importer's Address:

Bone Lane, Newbury Berkshire, RG14 5EH, England

Type & Description of Equipment:

Valve Actuators

Model Number:

L120 Series

Note: Tested with Limatorque Corp. products only

I, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s) and Standard(s). List as follows:



(Signature)

Thomas Ferdinand Paul May

(Full Name)

Managing Director, Limatorque International

(Title)

Place: Newbury Berkshire, UK

Date: 1/1/97

L2114 1/97

**For further Limitorque
service assistance call:**

Limitorque Corporation
2600 East Miroloma Way
Anaheim, CA 92806
Phone (714) 630-7800
Fax (714) 630-1691

Limitorque Corporation
7615 Boeing Drive
Greensboro, NC 27409-8347
Phone (910) 668-0871
Fax (910) 605-5310

Limitorque Corporation
8901 Jameel Road Suite 180
Houston, TX 77040
Phone (713) 690-1960
Fax (713) 690-1277

*or contact the Limitorque
offices listed below*

Limitorque®

Limitorque Corporation
5114 Woodall Road
P.O. Box 11318
Lynchburg, VA 24506-1318
Phone (804) 528-4400
Fax (804) 845-9736

Limitorque International
Trinity House
Kennet Side
Newbury
Berkshire RG14 5EH England
Phone 44-1-635-46999
Fax 44-1-635-36034

Limitorque/Nippon Gear Co. Ltd.
Tennoz Central Tower 2-2-24,
Higashi-Shinagawa, Shinagawa-Ku,
Tokyo, 140 Japan
Phone 81-3-5460-7516
Fax 81-3-5460-8396

Limitorque India, Ltd.
302/90 Nehru Place
Mansarovar New Delhi 110019
Phone 91-11-643-1748/643-2749
Fax 91-11-683-9329

Limitorque Australia Ltd.
Division of Control Engineering
(Aust.) PTY Ltd.
17 Scoresby Road
Bayswater, Victoria 3153, Australia
Phone 613-9729-0555
Fax 613-9729-8225

Limitorque Asia Pte Ltd.
75 Bukit Timah Rd
#05-01/02 Boon Siew Building
Singapore 229833
Phone 65-332-9100
Fax 65-332-9112

© Copyright 1997 Printed in U.S.A.

18th MARCH 1998**MAINTENANCE INSTRUCTIONS HERCUS SVT SERIES VALVE OPERATORS****UNIT – SVT10 GLACIER THRUST****DRAWING – 68MA207**

These units are supplied grease packed and in many circumstances require no regular maintenance other than greasing of the Thrust Bearings at the two nipples. This should be carried out at regular intervals depending on conditions. For those applications where the frequency of operation or other high risk factors make it prudent to carry out periodic maintenance checks we set out the details below.

- 1) Remove Body Cover (2) (eight screws (4) in cover).

The interior of the Gearbox can now be examined. Shaft (9) with bearing cones & gears may be lifted out as a unit to check the lower gear.



- 2) Before replacing the cover, the unit should be repacked with grease. If final gear (5) has been removed the bearing diameters and thrust faces should be coated with grease before replacing.
- 3) The Thrust Nut (16) and Glacier Thrust Bearings can be examined or removed by dismounting the Gearbox and removing them from the bottom of the gearbox. The Glacier Bearings should be coated with grease as they are replaced.

IMPORTANT

The Glacier Thrust Nut Assembly should have from 0.008" to 0.012" (0.2 to 0.3mm) end play. This end play is set at assembly and need only be checked when renewing Glacier Thrust Washers.

RECOMMENDED GREASE

SHELL ALVANIA E.P. GREASE 1
OR EQUIVALENT PRODUCT



| 29 | P35N0751 | NAME PLATE | 1 | |
|-------------|-----------------|-----------------------|-----|---|
| 28 | AFK2158 | DOWEL | 2 | $\varnothing \frac{3}{8} \times 1 \frac{3}{4}$ H.D. |
| 27 | ABR0214 | OIL NIPPLE | 2 | H29 |
| 26 | AFB2134 | SCREWS FOR COVER TUBE | 4 | $\frac{5}{16}$ W x $\frac{3}{4}$ HEX H55 |
| 25 | 66M0225 | COVER TUBE 3" | 1 | ALUMINIUM |
| 24 | AFL1100 | RETAINING PINS | 6 | $\frac{3}{16} \times \frac{1}{4}$ ROLL PIN |
| 23 | AFG1117 | SCREWS FOR PLATE | 8 | $\frac{1}{4}$ W x 1 SHCS |
| 22 | ABS0261 | O RING | 1 | 114 x 3 |
| 21 | ABS0251 | O RING | 1 | 75 x 5 |
| 20 | 68M0293 | RETAINING PLATE | 1 | 316 STAINLESS |
| 19 | 68M0292 | THRUST WASHER | 2 | GLACIER DU |
| 18 | 68M0291 | FIXED THRUST RING | 2 | 420 STAINLESS |
| 17 | 68M0290 | ROTATING THRUST RING | 2 | 316 STAINLESS |
| 16 | 68M0276 | THRUST NUT - G | 1 | S1115 |
| 15 | ABS0029 | OIL SEAL | 1 | C3560 |
| 14 | ABT0052 | BEARING CUP | 4 | CUP LM29710 |
| 13 | ABT0051 | BEARING CONE | 4 | CONE LM29749 |
| 12 | 68M0264 | INPUT KEY | 1 | EN6A |
| 11 | 68M0266 | INPUT SHAFT 30 SQUARE | 1 | S1045 |
| 10 | 68M0265 | INTERMEDIATE KEY | 1 | EN6A |
| 9 | 68M0255 | INTERMEDIATE SHAFT | 1 | S1045 |
| 8 | 68M0241 | PRIMARY GEAR | 2 | S1045 |
| 7 | 68M0231 | DRIVE PINION 3" | 1 | S1045 |
| 6 | 68M0279 | KEY FOR GEAR | 1 | EN6A |
| 5 | 68M0221 | DRIVE GEAR | 1 | S1045 |
| 4 | AFB2198 | SCREWS FOR COVER | 8 | $\frac{1}{4}$ W x $1 \frac{3}{4}$ HEX.H.S.S. |
| 3 | P68M0220 | GASKET | 1 | PETROL & OIL PROOF GASKET |
| 2 | 68M0217 | COVER OPEN | 1 | CAST IRON GR.14 |
| 1 | 68M0215 | BODY BASE - G | 1 | CAST IRON GR.14 |
| 65103330200 | SV10 3" GLACIER | | | |
| ITEM | PART NO. | NAME | QTY | MATERIAL |

| | | |
|----------|--------|-----------------------------|
| DRAWN | A.S. | P. W. HERCUS PVT. LIMITED |
| SCALE | 1:1 | |
| DATE | 3/3/90 | |
| APPROVED | | SV10 - G SPUR GEAR VALVE OP |
| | | 68MA207 |

18th MARCH 1998**MAINTENANCE INSTRUCTIONS HERCUS BV SERIES VALVE OPERATORS****UNIT – BVT35 GLACIER THRUST****DRAWING – 66MA320**

These units are supplied grease packed and in many circumstances require no regular maintenance other than greasing of the Thrust Bearings at the two nipples. This should be carried out at regular intervals depending on conditions. For those applications where the frequency of operation or other high risk factors make it prudent to carry out periodic maintenance checks we set out the details below.

- 1) Remove Body Cover (2) (eight screws (3) in cover).

The interior of the Gearbox can now be examined. If further dismantling is required then follow the procedure set out below

- 2) Before replacing the cover, the unit should be repacked with grease. When doing this the area of the unit on the Pinion side of the output centre line should be filled
- 3) The Thrust Nut (22) and Glacier Thrust Bearings can be examined or removed by dismantling the Gearbox and removing them from the bottom of the gearbox. The Glacier Bearings should be coated with grease as they are replaced.

DISMANTLING PROCEDURE


- A) To remove bevel pinion shaft assembly remove 4 screws (11) and withdraw assembly from gearcase.
- B) If pinion shaft (12) is to be removed, release retaining screw (16) and withdraw square input shaft (14), key (15), circlip (17) and spacer (18) and then press pinion shaft (12) through bearing cones.
- C) Bevel gear can be removed by lifting it straight out.
- D) When replacing the Bevel Gear (6) ensure that grease is smeared on the backface and the bottom of the Gearcase (1) is filled to the Thrust Pad level.
- E) When reassembling the Taper Roller Bearings on the Bevel Pinion Shaft they must be grease packed. If new Bearings have been fitted, the width of the Spacer (18) may have to be adjusted to obtain the correct Bearing setting. These Bearings should have from 0 to 0.002" or 0. to 0.05mm end play.
- F) Correct alignment of the Bevel Gears may require reshimming of the face between the Input Sleeve (10) and the Body (1)

IMPORTANT

The Glacier Thrust Nut Assembly in the BVT35 should have from 0.008" to 0.012" (0.2 to 0.3mm) end play. This end play is set at assembly and need only be checked when renewing Glacier Thrust Washers.

RECOMMENDED GREASE

SHELL ALVANIA E.P. GREASE 1
OR EQUIVALENT PRODUCT



18th MARCH 1998**MAINTENANCE INSTRUCTIONS HERCUS BV SERIES VALVE OPERATORS****UNIT – BVT55 GLACIER THRUST****DRAWING – 66MA413**

These units are supplied grease packed and in many circumstances require no regular maintenance other than greasing of the Thrust Bearings at the two nipples. This should be carried out at regular intervals depending on conditions. For those applications where the frequency of operation or other high risk factors make it prudent to carry out periodic maintenance checks we set out the details below.

- 1) Remove Body Cover (2) (eight screws (3) in cover).

The interior of the Gearbox can now be examined. If further dismantling is required then follow the procedure set out below

- 2) Before replacing the cover, the unit should be repacked with grease. When doing this the area of the unit on the Pinion side of the output centre line should be filled
- 3) The Thrust Nut (22) and Glacier Thrust Bearings can be examined or removed by dismantling the Gearbox and removing them from the bottom of the gearbox. The Glacier Bearings should be coated with grease as they are replaced.

DISMANTLING PROCEDURE


- A) To remove bevel pinion shaft assembly remove 4 screws (11) and withdraw assembly from gearcase.
- B) If pinion shaft (12) is to be removed, release retaining screw (16) and withdraw square input shaft (14), key (15), circlip (17) and spacer (18) and then press pinion shaft (12) through bearing cones.
- C) Bevel gear can be removed by lifting it straight out.
- D) When replacing the Bevel Gear (6) ensure that grease is smeared on the backface and the bottom of the Gearcase (1) is filled to the Thrust Pad level.
- E) When reassembling the Taper Roller Bearings on the Bevel Pinion Shaft they must be grease packed. If new Bearings have been fitted, the width of the Spacer (18) may have to be adjusted to obtain the correct Bearing setting. These Bearings should have from 0 to 0.002" or 0. to 0.05mm end play.
- F) Correct alignment of the Bevel Gears may require reshimming of the face between the Input Sleeve (10) and the Body (1)

IMPORTANT

The Glacier Thrust Nut Assembly in the BVT55 should have from 0.008" to 0.012" (0.2 to 0.3mm) end play. This end play is set at assembly and need only be checked when renewing Glacier Thrust Washers.

RECOMMENDED GREASE

SHELL ALVANIA E.P. GREASE 1
OR EQUIVALENT PRODUCT



B BASE HOLES - EQUISPACED OFF C.S.
TAPPED M20 THROUGH FLANGE
ON 298 P.C.D.

NOTE - HOLE IS NOT SHOWN IN TRUE POSITION.

RATIO 4:1

SHEET 2 OF 2

| PART N° | PART NAME | QTY | MATERIAL |
|---------|---------------------------------|-----|-----------------------------------|
| 1 | 66M0415 GEAR CASE 4:1 | 1 | C.I. GRADE 14 |
| 2 | 66M0422 BODY COVER - OPEN | 1 | C.I. GRADE 10 |
| 3 | AFB2196 SCREWS FOR COVER | 8 | 1/2" WHIT x 1 1/4" H.S.S. |
| 4 | 66M0427 COVER PLATE | 1 | C.I. GRADE 10 |
| 5 | AFB2195 SCREWS FOR COVER PLATE | 4 | 1/2" WHIT x 1 1/4" H.S.S. |
| 6 | 66M0435 BEVEL GEAR 4:1 | 1 | MILD STEEL |
| 7 | 66M0437 GEAR CENTRE-THRUST | 1 | MILD STEEL |
| 8 | AFC1195 SCREWS FOR GEAR | 6 | 3/4" WHIT x 1 1/2" H.S.S. |
| 9 | AFK2196 DOWELS FOR GEAR | 6 | 1/2" DIA. x 1 1/2" HD. DOWEL |
| 10 | 66M0472 INPUT SLEEVE | 1 | C.I. |
| 11 | AFK2194 SCREWS FOR SLEEVE | 4 | 5/8" WHIT x 1 1/4" H.S.S. |
| 12 | 66M0451 PINION SHAFT | 1 | 8620 |
| 13 | ABD0119 V-65A V-RING | 1 | INSIDE DIA 58 |
| 14 | 66M04591 INPUT SHAFT | 1 | 420 STAINLESS STEEL |
| 15 | 66M0348 KEY | 1 | 1/4" x 3/8" STEEL KEY |
| 16 | AFC1944 SCREW FOR INPUT SHAFT | 1 | M8-90 STAINL STEEL SET SCREW |
| 17 | ABR0418 CIRCLIP FOR INPUT SHAFT | 1 | SIZE CODE 0380 EXTENSIVE CIRCLIP |
| 18 | 66M0463 SPACER FOR INPUT SHAFT | 1 | 31214 |
| 19 | ABT0052 BEARING CUP | 2 | TIMKEN LM29710 |
| 20 | ABT0051 BEARING CONE - INNER | 1 | TIMKEN LM29749 |
| 21 | ABT0243 BEARING CONE - OUTER | 1 | TIMKEN LM29748L (INCL) |
| 22 | 66M0445 THRUST NUT - G | 1 | MILD STEEL |
| 23 | 66M0447 KEY FOR THRUST NUT | 1 | 1/4" x 3/8" H.S.S. |
| 24 | AFL1256 THRUST RING PIN | 4 | 3/16" DIA. x 1" STAINLESS STEEL |
| 25 | AFL1255 GLACIER WASHER PIN | 2 | 3/16" DIA. x 3/8" STAINLESS STEEL |
| 26 | 66M0481 FIXED THRUST RING | 2 | 420 STAINLESS STEEL |
| 27 | 66M0480 ROTATING THRUST RING | 2 | 420 STAINLESS STEEL |
| 28 | 66M0482 THRUST WASHER | 2 | CLARIER DU |
| 29 | 66M0485 RETAINING PLATE | 1 | 420 STAINLESS STEEL |
| 30 | | | |
| 31 | AB50232 OUTER SEAL | 1 | 364 NEOPRENE O-RING |
| 32 | AB50234 SHAFT SEAL | 1 | 354 NEOPRENE O-RING |

| PART NO. | NAME | NO. REQ. | MAT. |
|-----------------------------|------------------------------------|--------------|----------------------------|
| 33 | AFK4137 SCREWS FOR RETAINING PLATE | 8 | 5/16" WHIT x 1 1/4" H.S.S. |
| 34 | ABR0214 GEAR NIPPLE | 2 | 1/4" B.S.P. GEAR NIPPLE |
| F. W. HERCUS PTY. LIMITED | | | |
| BVJG55 BEVEL VALVE OPERATOR | | | |
| DRAWN | AT | SCALE | 66MA413 |
| CHECKED | | DATE 28/2/83 | |

18th MARCH 1998**MAINTENANCE INSTRUCTIONS HERCUS BV SERIES VALVE OPERATORS****UNIT – BVT55-GA8D-F14 GLACIER THRUST****DRAWING – 66M4A15**

These units are supplied grease packed and in many circumstances require no regular maintenance other than greasing of the Thrust Bearings at the two nipples. This should be carried out at regular intervals depending on conditions. For those applications where the frequency of operation or other high risk factors make it prudent to carry out periodic maintenance checks we set out the details below.

- 1) Remove Body Cover (25) (eight screws (45) in cover).

The interior of the Gearbox can now be examined. If further dismantling is required then follow the procedure set out below

- 2) Before replacing the cover, the unit should be repacked with grease. When doing this the area of the unit on the Pinion side of the output centre line should be filled
- 3) The Thrust Nut (29) and Glacier Thrust Bearings can be examined or removed by dismantling the Gearbox and removing them from the bottom of the gearbox. The Glacier Bearings should be coated with grease as they are replaced.

SPUR REDUCTION GEARBOX

Remove Adaptor (9) if fitted, remove cover (2) (4 screws). Tapped holes are provided in the cover to enable these to be used as extractor screws. The interior of the gearbox may now be examined

DISMANTLING PROCEDURES

- A) Remove adaptor & cover from spur reduction box as described above. Remove gears & shaft assemblies and remove screws which attach spur gear casing. Remove gear case (1)
- B) Take out 4 screws & remove bevel pinion shaft assembly sleeve (32) containing the pinion shaft. Remove circlip & press pinion shaft through bearing cones.
- C) Bevel gear can be removed by lifting it straight out.
- D) When replacing the Bevel Gear ensure that grease is smeared on the backface and the bottom of the Gearcase (24) is filled to the Thrust Pad level.
- E) When reassembling the Taper Roller Bearings on the Bevel Pinion Shaft they must be grease packed. If new Bearings have been fitted, the width of the Spacer (31) may have to be adjusted to obtain the correct Bearing setting. These Bearings should have from 0 to 0.002" or 0. to 0.05mm end play.


- F) Correct alignment of the Bevel Gears may require reshimming of the face between the Input Sleeve (32) and the Body (24)
- G) Spur gear box is then replaced in reverse order to taking off. Pack with grease before replacing covers.

IMPORTANT

The Glacier Thrust Nut Assembly in the BVT55 should have from 0.008" to 0.012" (0.2 to 0.3mm) end play. This end play is set at assembly and need only be checked when renewing Glacier Thrust Washers.

RECOMMENDED GREASE

● SHELL ALVANIA E.P. GREASE 1.
OR EQUIVALENT PRODUCT



| PROTECTIVE TREATMENT | | HEAT TREATMENT | MATERIAL | |
|---|--|--|---------------|---------------------------------------|
| | | | | |
| METRIC SIZES ± 0.05mm BORE SIZES + 0.50mm UNLESS OTHERWISE STATED IF IN DOUBT ASK! | | PASSED | DATE 26/2/98 | PART NAME BV55G-GA8D-F14 16:1 SECTION |
| DRAWN AJ | | SCALE 1:2 | PART NUMBER 1 | REV. |
| 66M4A15 | | SHEET 1 OF 2 | | |
| HERCUS | | F.W.HERCUS CAMIRA ST. REGENCY PARK SOUTH AUSTRALIA A.C.N. 074 849 513 | | |
| | | BV SERIES VALVE OP. | | |

| ITEM | PART NUMBER | DESCRIPTION | UNIT QTY | ITEM | PART NUMBER | DESCRIPTION | UNIT QTY |
|------|-------------|--------------------------------------|----------|------|-------------|--|----------|
| 1 | 63M0610 | GEARCASE | 1 | 28 | 66M0437 | GEAR CENTRE | 1 |
| 2 | 63M0621 | COVER | 1 | 29 | 66M0445 | THRUST NUT GLACIER | 1 |
| 3 | 63M0627 | ADAPTOR SLEEVE | 1 | 30 | 66M0447 | KEY FOR THRUST NUT | 1 |
| 4 | 63M0628 | GEAR SPACER | 1 | 31 | 66M0464 | BEARING SPACER | 1 |
| 5 | 63M0629 | BUSH FOR COVER BEARING | 1 | 32 | 66M0471 | SLEEVE | 1 |
| 6 | 63M06321 | GEAR 45T 35mm BORE | 1 | 33 | 66M0480 | ROTATING THRUST RING | 2 |
| 7 | 63M0653 | PINION 20T (RUNS ON GEAR SIDE) | 1 | 34 | 66M0481 | FIXED THRUST RING | 2 |
| 8 | 63M0655 | PINION 30T (RUNS ON INPUT SIDE) | 1 | 35 | 66M0482 | THRUST WASHER | 2 |
| 9 | 63M0662 | F14 ADAPTOR FLANGE | 1 | 36 | 66M0485 | RETAINING PLATE | 1 |
| 10 | 63M0664 | F14 INPUT SHAFT | 1 | 37 | BEAR/5532 | SEAL PR8 170 (35x55x8) (BV SHAFT) | 2 |
| 11 | 63M0677 | KEY FOR PINION - HDN | 2 | 38 | BEAR/5775 | BEARING LM29749 CONE | 1 |
| 12 | 66M0461 | PINION SHAFT 8:1 GA8 | 1 | 39 | BEAR/5776 | BEARING LM29710 CUP | 2 |
| 13 | 66M0462 | KEY FOR PINION SHAFT - HDN | 1 | 40 | BEAR/5958 | BEARING ASSY LM29748L | 1 |
| 14 | 68M0355 | INTERMEDIATE PINION SHAFT 15T | 1 | 41 | BEAR/7135 | SEAL O'RING BS354 (5.1/8"x5.1/2"x3/16") (SHAFT SEAL) | 1 |
| 15 | BEAR/0285 | BEARING 6005 2RS (25x47x12) | 1 | 42 | BEAR/7136 | SEAL O'RING BS364 (6.3/4"x7.1/8"x3/16") (FACE SEAL) | 1 |
| 16 | BEAR/0295 | BEARING 6007 (35x62x4) | 1 | 43 | FAST/C074 | 38mm EXT CIRCLIP | 1 |
| 17 | BEAR/0425 | BEARING 6203 (17x40x12) | 3 | 44 | FAST/C523S | 1/2"BSWX 1" HEX HD SET SCREWS/S | 4 |
| 18 | BEAR/5530 | SEAL PR4536 (25x40x7) (INPUT SHAFT) | 1 | 45 | FAST/C524S | 1/2"BSWX 1 1/4" HEX HD SET SCREWS/S | 8 |
| 19 | BEAR/7090 | SEAL O'RING BS264 (7.5"x7.75"x0.14") | 1 | 46 | FAST/2468S | 5/16"BSWX 1 1/4" SKT HD CAP SCREWS/S | 8 |
| 20 | FAST/0448B | 3/8"BSWX 1 1/2" HEX HD SET SCREW | 4 | 47 | FAST/2525 | 1/2"BSWX 1 1/4" SKT HD CAP SCREW | 4 |
| 21 | FAST/2485 | 3/8"BSWX 1" SKT HD CAP SCREW | 4 | 48 | FAST/2526 | 1/2"BSWX 1 1/2" SKT HD CAP SCREW | 6 |
| 22 | TRAN/0865 | 5/16" X 1" HDN DOWEL | 1 | 49 | FAST/2545 | 5/8"BSWX 2" SKT HD CAP SCREW | 4 |
| 23 | 63M0685 | ADAPTOR PLATE GA8-BV55 | 1 | 50 | FAST/5201S | 3/16" X 3/8" ROLL PIN S/S | 2 |
| 24 | 66M0415 | BODY - GLACIER | 1 | 51 | FAST/5202S | 3/16" X 1/2" ROLL PIN S/S | 4 |
| 25 | 66M0422 | COVER OPEN | 1 | 52 | FITT/0C02 | 1/4"BSPT PLUG | 1 |
| 26 | 66M0427 | COVER PLATE | 1 | 53 | LUBR/0051 | 1/8"BSP GREASE NIPPLE | 2 |
| 27 | 66M0432 | BEVEL GEAR 8:1 | 1 | 54 | TRAN/0906 | 1/2" X 1 1/2" HDN DOWEL | 6 |

| | | | | | |
|---|--|--|-------|---------------------------------------|--------------|
| PROTECTIVE TREATMENT | | HEAT TREATMENT | | MATERIAL | |
| | | | | | |
| METRIC SIZES IN DECIMALS BORE SIZES IN DECIMALS UNLESS OTHERWISE STATED IF IN DOUBT ASK! | | PASSED | DATE | PART NAME BV55G-GA8D-F14 16:1 SECTION | |
| | | 26/2/98 | | | |
| DRAWN | | AJ | SCALE | PART NUMBER | REV. |
| | | | | 66M4A15 | SHEET 2 OF 2 |
| HERCUS | | F.W.HERCUS CAMIRA ST. REGENCY PARK SOUTH AUSTRALIA A.C.N. 974 849 513 | | BV SERIES VALVE OP. | |

18th MARCH 1998**MAINTENANCE INSTRUCTIONS HERCUS BV SERIES VALVE OPERATORS****UNIT – BVT95-GA8D-F16 GLACIER THRUST****DRAWING – 66M5A16**

These units are supplied grease packed and in many circumstances require no regular maintenance other than greasing of the Thrust Bearings at the two nipples. This should be carried out at regular intervals depending on conditions. For those applications where the frequency of operation or other high risk factors make it prudent to carry out periodic maintenance checks we set out the details below.

- 1) Remove Body Cover (25) (eight screws (47) in cover).

The interior of the Gearbox can now be examined. If further dismantling is required then follow the procedure set out below

- 2) Before replacing the cover, the unit should be repacked with grease. When doing this the area of the unit on the Pinion side of the output centre line should be filled
- 3) The Thrust Nut (29) and Glacier Thrust Bearings can be examined or removed by dismounting the Gearbox and removing them from the bottom of the gearbox. The Glacier Bearings should be coated with grease as they are replaced.

SPUR REDUCTION GEARBOX

Remove Adaptor (9) if fitted, remove cover (2) (4 screws). Tapped holes are provided in the cover to enable these to be used as extractor screws. The interior of the gearbox may now be examined

DISMANTLING PROCEDURES

- A) Remove adaptor & cover from spur reduction box as described above. Remove gears & shaft assemblies and remove screws which attach spur gear casing. Remove gear case (1)
- B) Take out 4 screws & remove bevel pinion shaft assembly sleeve (33) containing the pinion shaft. Remove circlip & press pinion shaft through bearing cones.
- C) Bevel gear can be removed by lifting it straight out.
- D) When replacing the Bevel Gear ensure that grease is smeared on the backface and the bottom of the Gearcase (24) is filled to the Thrust Pad level.
- E) When reassembling the Taper Roller Bearings on the Bevel Pinion Shaft they must be grease packed. If new Bearings have been fitted, the width of the Spacer (32) may have to be adjusted to obtain the correct Bearing setting. These Bearings should have from 0 to 0.002" or 0. to 0.05mm end play.
- F) Correct alignment of the Bevel Gears may require reshimming of the face between the Input Sleeve (33) and the Body (24)


G) Spur gear box is then replaced in reverse order to taking off. Pack with grease before replacing covers.

IMPORTANT

The Glacier Thrust Nut Assembly in the BVT55 should have from 0.008" to 0.012" (0.2 to 0.3mm) end play. This end play is set at assembly and need only be checked when renewing Glacier Thrust Washers.

RECOMMENDED GREASE

SHELL ALVANIA E.P. GREASE 1
OR EQUIVALENT PRODUCT



| PROTECTIVE TREATMENT | | HEAT TREATMENT | MATERIAL |
|---|--|--|--|
| METRIC SIZES ±0.25mm BORE SIZES ±0.50mm UNLESS OTHERWISE STATED IF IN DOUBT ASK! | | PASSED DATE DRAWN: AJ DATE: 18/3/98 | PART NAME BV95G-GA8D-F16 16:1 SECTION PART NUMBER 66M5A16 SHEET 1 OF 2 REV. BV SERIES VALVE OP. |
| HERCUS | | F.W.HERCUS CAMIRA ST. REGENCY PARK SOUTH AUSTRALIA A.C.N. 074 849 513 | |

| ITEM | PART NUMBER | DESCRIPTION | UNIT QTY | ITEM | PART NUMBER | DESCRIPTION | UNIT QTY |
|------|-------------|---------------------------------------|----------|------|-------------|---|----------|
| 1 | 63M0612 | GEARCASE BV95 | 1 | 28 | 66M0537 | GEAR CENTRE | 1 |
| 2 | 63M0621 | COVER | 1 | 29 | 66M0545 | THRUST NUT GLACIER | 1 |
| 3 | 63M0627 | ADAPTOR SLEEVE | 1 | 30 | 66M0547 | KEY FOR THRUST NUT | 1 |
| 4 | 63M0628 | GEAR SPACER | 1 | 31 | 66M0562 | PINION SPACER | 1 |
| 5 | 63M0629 | BUSH FOR COVER BEARING | 1 | 32 | 66M0563 | BEARING SPACER | 1 |
| 6 | 63M06321 | GEAR 45T 35mm BORE | 1 | 33 | 66M0571A | SLEEVE - GA8 | 1 |
| 7 | 63M0653 | PINION 20T (RUNS ON GEAR SIDE) | 1 | 34 | 66M0880 | ROTATING THRUST RING | 2 |
| 8 | 63M0655 | PINION 30T (RUNS ON INPUT SIDE) | 1 | 35 | 66M0881 | FIXED THRUST RING | 2 |
| 9 | 63M0663 | F16 ADAPTOR FLANGE | 1 | 36 | 66M0882 | THRUST WASHER | 2 |
| 10 | 63M0664 | F14/F16 INPUT SHAFT | 1 | 37 | 66M0883 | THRUST RING PIN | 4 |
| 11 | 63M0677 | KEY FOR PINION - HDN | 2 | 38 | 66M0885 | RETAINING PLATE | 1 |
| 12 | 63M0695 | SEAL ADAPTOR | 1 | 39 | BEAR/5570 | SEAL C8289 (40x55x8) (BV SHAFT) | 2 |
| 13 | 66M0462 | KEY FOR PINION SHAFT - HDN | 1 | 40 | BEAR/5803 | BEARING 25580 CONE | 2 |
| 14 | 66M0556 | PINION SHAFT 8:1GA8 | 1 | 41 | BEAR/5804 | BEARING 25520 CUP | 2 |
| 15 | 68M0355 | INTERMEDIATE PINION SHAFT 15T | 1 | 42 | BEAR/7127 | SEAL 'O'RING BS339 (3.1/4"x3.5/8"x3/16") (SHAFT SEAL) | 1 |
| 16 | BEAR/0285 | BEARING 6005 2RS (25x47x12) | 1 | 43 | BEAR/7152 | SEAL 'O'RING BS426 (4.5/8"x5.1/8"x1/4") (FACE SEAL) | 1 |
| 17 | BEAR/0295 | BEARING 6007 (35x62x14) | 1 | 44 | BEAR/7155 | SEAL 'O'RING BS445 (8"x8.1/2"x1/4") (OUTER SEAL) | 1 |
| 18 | BEAR/0425 | BEARING 6203 (17x40x12) | 3 | 45 | FAST/0050 | 13/4" EXT CIRCLIP | 1 |
| 19 | BEAR/5530 | SEAL PR4538 (25x40x7) (INPUT SHAFT) | 1 | 46 | FAST/0523S | 1/2"BSWX 1" HEX HD SET SCREWS/S | 4 |
| 20 | BEAR/7090 | SEAL 'O'RING BS264 (7.5"x7.75"x0.14") | 1 | 47 | FAST/0564S | 5/8"BSWX 1.1/2" HEX HD SET SCREWS/S | 8 |
| 21 | FAST/0448B | 3/8"BSWX 1.1/2" HEX HD SET SCREW | 4 | 48 | FAST/2486S | 3/8"BSWX 1.1/4" SKT HD CAP SCREWS/S | 8 |
| 22 | FAST/2485 | 3/8"BSWX 1" SKT HD CAP SCREW | 4 | 49 | FAST/2526 | 1/2"BSWX 1.1/2" SKT HD CAP SCREW | 8 |
| 23 | TRAN/0865 | 5/16" X 1" HDN DOWEL | 1 | 50 | FAST/2530 | 1/2"BSWX 2.1/2" SKT HD CAP SCREW | 1 |
| | | | | 51 | FAST/2565 | 3/4"BSWX 2.1/4" SKT HD CAP SCREW | 1 |
| 24 | 66M0515 | BODY - GLACIER | 1 | 52 | FAST/2568 | 3/4"BSWX 3" SKT HD CAP SCREW | 2 |
| 25 | 66M0522 | COVER OPEN | 1 | 53 | FITT/0002 | 1/4"BSPT PLUG | 1 |
| 26 | 66M0427 | COVER PLATE | 1 | 54 | LUBR/0051 | 1/8"BSP GREASE NIPPLE | 2 |
| 27 | 66M0532 | BEVEL GEAR 8:1 | 1 | 55 | TRAN/0906 | 1/2" X 1.1/2" HDN DOWEL | 8 |

| | | | | | |
|---|--|--|---------|---------------------------------------|--------------|
| PROTECTIVE TREATMENT | | HEAT TREATMENT | | MATERIAL | |
| METRIC SIZES & DIMENSIONS BORE SIZES - 2.50mm UNLESS OTHERWISE STATED IF IN DOUBT ASK! | | DATE | 18/3/98 | PART NAME BV95G-GA8D-F16 16:1 SECTION | |
| DRAWN AJ | | SCALE | | PART NUMBER | REV. |
| HERCULUS | | F.W.HERCUS CAMIRA ST. REGENCY PARK SOUTH AUSTRALIA A.C.N. 074 849 513 | | 66M5A16 | SHEET 2 OF 2 |
| BV SERIES VALVE OP. | | | | | |


Section 8**DRAWINGS**

| Drawing No | John Valve Item No | Test Cert No |
|-------------------|---------------------------|---------------------|
| AL421 | 694A0450-S023 | 6241 |
| AL420 | 694A0600-S020 | 6240 |
| AL419 | 694A0750-S011 | 6239 |
| AL418 | 694A0900-S010 | 6238 |
| AL417 | 694A0900-S009 | 6238 |
| AL416 | 694A1200-S001 | 6269 |

THIRD ANGLE PROJECTION

| CLIENT | ORDER No. | QTY | REMARKS |
|-----------------------|-------------------------|-----|---|
| BRISBANE CITY COUNCIL | CONTRACT No. R111/96/97 | 1 | FLANGES DRILLED AS4087 F16.B2 MAX. WORKING PRESSURE -1400 KPa TESTING: BODY -2000 KPa SEAT -1400 KPa COATING: INT & EXT JOTACOTE 412 MIN. DFT 500 MICRON |


AL421




| | | | | | |
|-----|----|--|------------------|----------------|----------------|
| 29. | 14 | SCREW, PATCH | A.B. | AS1567-636 | 4759 |
| 28. | 2 | LINER, BONNET | G.M. | AS1565 CB3600 | |
| 27. | 2 | LINER, BODY | G.M. | AS1565 CB3600 | |
| 26. | 1 | PLUG -1/2"BSPT | G.W.I. | | |
| 25. | 2 | SCREW, GRUB -M6 X 16 LG. | A.S. | | |
| 24. | 1 | NUT, THRUST | C.S. | AS1443-CS1020 | 980720 |
| 23. | 1 | GEARBOX -HERCUS SVT10 SPUR (3:1 RATIO) | | | 246728 |
| 22. | 4 | WASHER, SPRING-Ø20 | C.S. | | |
| 21. | 4 | NUT -M20 | C.S. | GALVANISED | |
| 20. | 4 | STUD -M20 X 70 LG. | C.S. | GALVANISED | |
| 19. | 4 | SCREW, DRIVE -No. 4 X 6 LG. | S.S. | | |
| 18. | 2 | BOLT -7/8"BSW X 120 LG. | S.S. | AS2837 Gr. 316 | |
| 17. | 1 | STAND, GEARBOX | C.I. | AS1830 T220 | 70492A |
| 16. | 2 | EYEBOLT -M20 | H.T.S. | GALVANISED | |
| 15. | 1 | O-RING -BS438 | NITRILE | | |
| 14. | 1 | GASKET - BODY/BONNET -3mm TK. | RUBBER INSERTION | | 450-5550-14 |
| 13. | 1 | KEY -14 X 9 X 135 LG. | KEY STEEL | | |
| 12. | 8 | BOLT -M20 X 100 LG. | C.S. | GALVANISED | |
| 11. | 1 | PACKING (SUPPLIED BY OTHERS) | | | |
| 10. | 18 | BOLT -M24 X 140 LG. | C.S. | GALVANISED | |
| 9. | 1 | STEM -A.C. | S.S. | AS2837-431 | 59451A |
| 8. | 1 | NUT, WEDGE -A.C. | G.M. | AS1565 CB3600 | 500-5550-13/RH |
| 7. | 1 | PLATE, IDENTIFICATION | BRASS | 97C56A | |
| 6. | 2 | RING, BODY | G.M. | AS1565 CB3600 | F/0448/C |
| 5. | 1 | WEDGE | G.M. | AS1565 CB3600 | 56108A |
| 4. | 1 | GLAND | G.M. | AS1565 CB3600 | 500-5550-6 |
| 3. | 1 | STUFFINGBOX | C.I. | AS1830 T220 | 500-5550-5 |
| 2. | 1 | BONNET | C.I. | AS1830 T220 | C5214A |
| 1. | 1 | BODY | GGI | AS1831 400-12 | 03714B |

450MM FIG 694A SLUICE VALVE WITH
HERCUS SVT10 SPUR GEAR OPERATORA 23-9-97
INPUT SHAFT CAS
30 A/F SQ.© COPYRIGHT
This drawing is the subject
of copyright and is not to be
used or reproduced without
prior consent of JOHN VAUGHANLOGAN CITY TRUNK MAIN
AMPLIFICATION SCHEME
CONTRACT No: R.111/96/97

| DATE | DESIGN | DATE | DATE | DATE | DATE |
|----------------------------------|---------|---|------|-------------------|------|
| PF 17-9-97 | MM 9-97 | DATE | DATE | DATE | DATE |
| JOHN VAUGHAN The Valve People | | Greenside Road Ballarat 3350 Victoria Australia ACN 005 051 674 | | DRS. No. AL421 | |







THIRD ANGLE PROJECTION

| CLIENT | ORDER No. | QTY | REMARKS |
|-----------------------|-------------------------|-----|--|
| BRISBANE CITY COUNCIL | CONTRACT No. R111/96/97 | 2 | FLANGES DRILLED AS4087 FIG. B2 MAX. WORKING PRESSURE 1200 KPa TEST PRESSURES: BODY -2400 KPa SEAT -1200 KPa COATING: INT & EXT JOTACOTE 412 MIN. DFT 500 MICRON |

AL418

INPUT SHAFT ROTATION ANTI-CLOCKWISE TO CLOSE
NO. OF TURNS 225

| ITEM | QTY | DESCRIPTION | MATERIAL | SPECIFICATION | DETAIL |
|------|-----|---|-----------|----------------|------------|
| 32. | 8 | WASHER, SPRING -Ø20 | C.S. | GALVANISED | |
| 31. | 8 | NUT -M20 | C.S. | GALVANISED | |
| 30. | 8 | STUD -M20 X 100 LG. | C.S. | GALVANISED | |
| 29. | 1 | GEARBOX -HERCUS BVT55 BEVEL (RATIO 4:1) | | | 24642B |
| 28. | 2 | BOLT, SQ. HD. -M24 X 140 LG. | S.S. | AS2837 Gr 316 | |
| 27. | 1 | GASKET | AF2100 | PERMANITE | AJ343 *107 |
| 26. | 16 | BOLT, HEX. HD. -M30 X 180 LG. | C.S. | GALVANISED | |
| 25. | 64 | NUT -M36 | C.S. | GALVANISED | |
| 24. | 32 | STUD -M36 X 270 LG. | C.S. | GALVANISED | |
| 23. | 2 | SCREW, GRUB - M8 X 12 LG | STEEL | | |
| 22. | 1 | O-RING -0.139" SECT. | NITRILE | | |
| 21. | 1 | GASKET -BODY/BONNET | AF2100 | PERMANITE | AA550 |
| 20. | 1 | PLUG -1/2" BSPT | G.W.I. | | |
| 19. | 2 | PLUG -2" BSPT | G.W.I. | | |
| 18. | 1 | PLATE, IDENTIFICATION | BRASS | | 97056A |
| 17. | 1 | NUT, THRUST | C.S. | AS 1442-CS1020 | 98121A |
| 16. | 40 | SCREW, PATCH | A.B. | AS1567-686 | 4759 |
| 15. | 2 | LINER, WEDGE | G.M. | AS1565 C83600 | 35008A |
| 14. | 2 | LINER, BODY | G.M. | AS1565 C83600 | 35007A |
| 13. | 1 | KEY -18 X 11 X 150 LG. | KEY STEEL | | |
| 12. | | PACKING (SUPPLIED BY OTHERS) | | | |
| 11. | 2 | EYEBOLT -M36 | H.T.S. | GALVANISED | |
| 10. | 1 | STEM -AC | S.S. | AS2837 Gr 431 | 59409A |
| 9. | 1 | NUT, WEDGE -AC | G.M. | AS1565 C83600 | 98090A |
| 8. | 1 | GLAND | G.M. | AS1565 C83600 | 25057A |
| 7. | | | | | |
| 6. | 2 | RING, WEDGE | G.M. | AS1565 C83600 | H/AF820 |
| 5. | 2 | RING, BODY | G.M. | AS1565 C83600 | G/AF820 |
| 4. | 1 | PIECE, MATCHING | C.I. | AS1830 T220 | 70456A |
| 3. | 1 | WEDGE | C.I. | AS1830 T220 | 66036B |
| 2. | 1 | BONNET | C.I. | AS1830 T220 | 06269A |
| 1. | 1 | BODY | SGC | AS1831 400-12 | 03696A |

900MM FIG. 694A SLUICE VALVE WITH
HERCUS BVT55 BEVEL GEAR OPERATOR


| | | | |
|-----------------------------|---------|-----------------|---------|
| A | 17-9-97 | B | 2-12-97 |
| RELEASED FOR MANUFACTURE | | DIM 760 WAS 623 | |
| PF | PF | | |

© COPYRIGHT
This drawing is the subject
of copyright and is not to be
used or reproduced without
prior consent of JOHN VALVESLOGAN CITY TRUNK MAIN
AMPLIFICATION SCHEME
CONTRACT No: R.111/96/97

| DRWN | CHG'D | APP'D | ISS | SS00 KG | SCALE |
|---------------------------------|---------|-------|---|-------------------|---------------|
| PF 2-9-97 | MM 9-97 | | | | |
| JOHN VALVES The Valve People | | | Greenside Road Ballarat 3350 Victoria Australia ACN 005 061 674 | DRG. No. AL418 | SHEET 5/12 |

69*AO900-5010

THIRD ANGLE PROJECTION



| CLIENT | ORDER No. | QTY | REMARKS |
|-----------------------|-------------------------|-----|--|
| BRISBANE CITY COUNCIL | CONTRACT No. R111/95/97 | 1 | FLANGES DRILLED AS4087 FIG. B2 MAX. WORKING PRESSURE 1200 KPa TEST PRESSURES: BODY -2400 KPa SEAT -1200 KPa COATING: INT & EXT JOTACODE 412 MIN. DFT 500 MICRON |

AL417

| | | | | | |
|------|-----|---|-----------|----------------|------------|
| 32. | 8 | WASHER, SPRING -Ø20 | C.S. | GALVANISED | |
| 31. | 8 | NUT -M20 | C.S. | GALVANISED | |
| 30. | 8 | STUD -M20 X 100 LG. | C.S. | GALVANISED | |
| 29. | 1 | ACTUATOR -LIMITORQUE L120-40-25/2 HERCULES BYT55RA7(16.1) | | | 3708BA |
| 28. | 2 | BOLT, SQ. HD. -M24 X 140 LG. | S.S. | AS2837 Gr 316 | |
| 27. | 1 | GASKET | AF2100 | PERMANITE | AJ343 #107 |
| 26. | 16 | BOLT, HK. HD. -M30 X 180 LG. | C.S. | GALVANISED | |
| 25. | 64 | NUT -M36 | C.S. | GALVANISED | |
| 24. | 32 | STUD -M36 X 270 LG. | C.S. | GALVANISED | |
| 23. | 2 | SCREW, GRUB - M8 X 12 LG | STEEL | | |
| 22. | 1 | O-RING -Ø.139" SECT. | NITRILE | | |
| 21. | 1 | GASKET -BODY/BONNET | AF2100 | PERMANITE | AA550 |
| 20. | 1 | PLUG-1/2" BSPT | G.W.I. | | |
| 19. | 2 | PLUG-2" BSPT | G.W.I. | | |
| 18. | 1 | PLATE, IDENTIFICATION | BRASS | | 97066A |
| 17. | 1 | NUT, THRUST | C.S. | AS 1442-CS1020 | 98121A |
| 16. | 40 | SCREW, PATCH | A.B. | AS1567-686 | 4759 |
| 15. | 2 | LINER, WEDGE | G.M. | AS1565 CB3600 | 35008A |
| 14. | 2 | LINER, BODY | G.M. | AS1565 CB3600 | 35007A |
| 13. | 1 | KEY -18 X 11 X 150 LG. | KEY STEEL | | |
| 12. | | PACKING (SUPPLIED BY OTHERS) | | | |
| 11. | 2 | EYEBOLT -M36 | H.T.S. | GALVANISED | |
| 10. | 1 | STEM -AC | S.S. | AS2837 Gr 431 | 59409A |
| 9. | 1 | NUT, WEDGE -AC | G.M. | AS1565 CB3600 | 98090A |
| 8. | 1 | GLAND | G.M. | AS1565 CB3600 | 25057A |
| 7. | | | | | |
| 6. | 2 | RING, WEDGE | G.M. | AS1565 CB3600 | H/AFB20 |
| 5. | 2 | RING, BODY | G.M. | AS1565 CB3600 | G/AFB20 |
| 4. | 1 | PIECE, MATCHING | C.I. | AS1830 T220 | 70456A |
| 3. | 1 | WEDGE | C.I. | AS1830 T220 | 66036B |
| 2. | 1 | BONNET | C.I. | AS1830 T220 | CS269A |
| 1. | 1 | BODY | SECI | AS1831 400-12 | 03696A |
| ITEM | QTY | DESCRIPTION | MATERIAL | SPECIFICATION | DETAIL |


900MM FIG. 694A SLUICE VALVE WITH
LIMITORQUE L120-40 ELECTRIC ACTUATOR


| | | | | |
|---------------------------------|------------------|--|-------------------|---------------------|
| DRWN PF 2-9-97 | CHG'D MM 9-97 | DATE APP'D | ISS 5600 KG. | SCALE |
| JOHN VALVES The Valve People | | Greenshield Road Belconnen 3350 Victoria Australia ADN 025 051 674 | DRS. No. AL417 | SHEET SIZE A1 |

| | |
|-----------------------------|-----------------|
| A 17-9-97 | B 2-12-97 |
| RELEASED FOR MANUFACTURE | DIM 760 WAS 623 |
| PF | PF |

© COPYRIGHT
This drawing is the subject
of copyright and is not to be
used or reproduced without
prior consent of JOHN VALVES

LOGAN CITY TRUNK MAIN
AMPLIFICATION SCHEME
CONTRACT No: R.111/95/97





JOHN VALVES PTY. LTD
The Valve People

HEAD OFFICE & MANUFACTURING
Creswick Road, Ballarat, Victoria 3350, Australia
P.O. Box 279, Ballarat, Victoria 3350, Australia
Telephone: (03) 5333 0777 Facsimile: (03) 5338 1771
ACN 005 061 674

TEST CERTIFICATE

CERTIFICATE No.
6241

VALVE DETAILS

To: BRISBANE CITY COUNCIL
.....
.....
.....

Date: 13/2/98

Batch: 920756

Customers Order No: R111/96/97

Valve No./Ident. No.:

Dear Sir,

This is to certify that these valves have been subjected to and have passed the following tests.

Type of valve: Sluice valve

Quantity: 1

Size: 450mm

Figure No.: 694

Drawing No.: AL421

DETAILS OF TESTS

| Part Name / Description | Hydrostatic | Air | Duration of Tests | |
|-------------------------|-------------|-----|-------------------|--|
| BODY | 2800 KPa | - | 3 minutes | |
| SEATING | 1400 KPa | - | 3 minutes | |
| | | | | |
| | | | | |

Remarks: Test medium: Water at ambient temperature.

Strength tests and functional tests performed in accordance with contract R111/96/97.

All tests found to comply with specified requirements.

Yours Faithfully
JOHN VALVES Pty. Ltd.



P. MAWBY

Page 128 of 134



JOHN VALVES PTY. LTD
The Valve People

HEAD OFFICE & MANUFACTURING
Creswick Road, Ballarat, Victoria 3350, Australia
P.O. Box 279, Ballarat, Victoria 3350, Australia
Telephone: (03) 5333 0777 Facsimile: (03) 5338 1771
ACN 005 061 674

TEST CERTIFICATE

CERTIFICATE No.
6240

VALVE DETAILS

To: BRISBANE CITY COUNCIL
.....
.....
.....

Date: 13/2/98

Batch: 920756

Customers Order No: R111/96/97

Valve No./Ident. No.:

Dear Sir,

This is to certify that these valves have been subjected to and have passed the following tests.

Type of valve: Sluice valve

Quantity: 1

Size: 600mm

Figure No.: 694

Drawing No.: AL420

DETAILS OF TESTS


| Part Name / Description | Hydrostatic | Air | Duration of Tests | |
|-------------------------|-------------|-----|-------------------|--|
| BODY | 2800 KPa | - | 3 minutes | |
| SEATING | 1400 KPa | - | 3 minutes | |
| | | | | |
| | | | | |

Remarks: Test medium: Water at ambient temperature.
.....
Strength tests and functional tests performed in accordance with contract R111/96/97.
.....
All tests found to comply with specified requirements.
.....

Yours Faithfully
JOHN VALVES Pty. Ltd.



Peter Mawby
P. MAWBY



JOHN VALVES PTY. LTD
The Valve People

HEAD OFFICE & MANUFACTURING
Creswick Road, Ballarat, Victoria 3350, Australia
P.O. Box 279, Ballarat, Victoria 3350, Australia
Telephone: (03) 5333 0777 Facsimile: (03) 5338 1771
ACN 005 061 674

TEST CERTIFICATE

CERTIFICATE No.
6239

VALVE DETAILS

To: BRISBANE CITY COUNCIL
.....
.....
.....

Date: 13/2/98

Batch: 920756

Customers Order No: R111/96/97

Valve No./Ident. No.:

Dear Sir,

This is to certify that these valves have been subjected to and have passed the following tests.

Type of valve: Sluice valve

Quantity: 1

Size: 750mm

Figure No.: 694

Drawing No.: AL419

DETAILS OF TESTS

| Part Name / Description | Hydrostatic | Air | Duration of Tests | |
|-------------------------|-------------|-----|-------------------|--|
| BODY | 2400 KPa | - | 3 minutes | |
| WEDGE STRENGTH | 2400 KPa | - | 3 minutes | |
| SEATING | 1200 KPa | - | 3 minutes | |
| | | | | |

Remarks: Test medium: Water at ambient temperature.
Strength tests and functional tests performed in accordance with contract R111/96/97.
All tests found to comply with specified requirements.

Yours Faithfully
JOHN VALVES Pty. Ltd.



Peter Mawby
P. MAWBY



JOHN VALVES PTY. LTD
The Valve People

HEAD OFFICE & MANUFACTURING
Creswick Road, Ballarat, Victoria 3350, Australia
P.O. Box 279, Ballarat, Victoria 3350, Australia
Telephone: (03) 5333 0777 Facsimile: (03) 5338 1771
ACN 005 061 674

TEST CERTIFICATE

CERTIFICATE No.
6238

VALVE DETAILS

To: BRISBANE CITY COUNCIL
.....
.....
.....

Date: 13/2/98

Batch: 920756

Customers Order No: R111/96/97

Valve No./Ident. No.: Body No. 7363

7364

7365

Dear Sir,

This is to certify that these valves have been subjected to and have passed the following tests.

Type of valve: Sluice valves

Quantity: 3

Size: 900mm

Figure No.: 694

Drawing No.: AL417, AL418

DETAILS OF TESTS

| Part Name / Description | Hydrostatic | Air | Duration of Tests | |
|-------------------------|-------------|-----|-------------------|--|
| BODY | 2400 KPa | - | 3 minutes | |
| SEATING | 1200 KPa | - | 3 minutes | |
| | | | | |
| | | | | |

Remarks: Test medium: Water at ambient temperature.
Strength tests and functional tests performed in accordance with contract R111/96/97.
All tests found to comply with specified requirements.

Yours Faithfully
JOHN VALVES Pty. Ltd.



Peter Mawby
P. MAWBY



JOHN VALVES PTY. LTD
The Valve People

HEAD OFFICE & MANUFACTURING
Creswick Road, Ballarat, Victoria 3350, Australia
P.O. Box 279, Ballarat, Victoria 3350, Australia
Telephone: (03) 5333 0777 Facsimile: (03) 5338 1771
ACN 005 061 674

TEST CERTIFICATE

CERTIFICATE No.
6269

VALVE DETAILS

To: BRISBANE CITY COUNCIL
.....
.....
.....

Date: 5/3/98

Batch: 920756

Customers Order No: R111/96/97

Valve No./Ident. No.: Body No. 7414

Dear Sir,

This is to certify that these valves have been subjected to and have passed the following tests.

Type of valve: Sluice valve

Quantity: 1

Size: 1200mm

Figure No.: 694A

Drawing No.: AL416

DETAILS OF TESTS

| Part Name / Description | Hydrostatic | Air | Duration of Tests | |
|-------------------------|-------------|-----|-------------------|--|
| BODY | 2400 KPa | - | 3 minutes | |
| WEDGE STRENGTH | 2400 KPa | - | 3 minutes | |
| SEATING | 1200 KPa | - | 3 minutes | |
| | | | | |

Remarks: TEST MEDIUM: Water at ambient temperature.
Strength tests and functional tests performed in accordance with contract No. R111/96/97
All Tests found to comply with specified requirements.



Yours Faithfully
JOHN VALVES Pty. Ltd.

P. Mawby
P. MAWBY

Section 9**TROUBLE SHOOTING.**

| Problem | Cause | Solution |
|---|---|---|
| Valve leaks from stem seal | Damaged o'rings Stem scoring | Replace completely with new set. Remove with emery or remove stem and remachine. |
| Valve leaks from body / bonnet gasket joint. | Loose bolts, damaged gasket | Check gasket and tighten bolts |
| Valve leaks from housing / bonnet gasket joint. | Loose bolts and / or damaged gasket. | Check o'ring, replace if necessary. |
| Valve will not open or close | Gearbox damage. Thrust Nut and locknut loose Valve stem jammed. Obstruction across valve seats | Dismantle Gearbox. Retighten Nut and Locknut. Disconnect Operator from stem check operation . Check for bent stem. Inspect valve seats. |
| Valve stem operates, valve closed, | Stem has disengaged for wedge nut | Check stem / wedge nut assembly. |
| Valve leaking. | Wedge not fully seated. Damaged seat faces. | Obstruction in pipeline Check seat faces and rectify |

Section 10**SPARE PARTS INFORMATION**

When ordering spare parts quote all the information stamped on the nameplate including the valve size and relevant John Valves assembly drawing number, item number, component description and quantity required.

All spare parts are available through John Valves head office.

Qld Office 172 Evans Road
Salisbury QLD 4107

Ph 07 3277 8700
Fax 07 3274 0007

Head Office - Creswick Road
BALLARAT. 3350.

Ph: 03 5333 0777
Fax: 03 5338 1771