BRISBANE WATER

PUMPING STATION SP126 BW70103-001 YOUNGS ROAD HEMMANT

ELECTRICAL SWITCHBOARD OPERATION AND MAINTENANCE MANUAL

Developed by:



J & P RICHARDSON INDUSTRIES CAMPBELL AVENUE WACOL QLD 4076

> ABN 23 001 952 325 ACN 001 952 325

Ph. (07) 3271 2911 Fax. (07) 3271 3623

$\underline{CONTENTS}$

- 1.0 TECHNICAL INFORMATION
- 2.0 TEST RESULTS
- 3.0 ELECTRICAL DRAWINGS

J & P Richardson Industries Pty Ltd

1.0 TECHNICAL INFORMATION

File: //Jpr_Server/docs/!sched/Masters.doc Revision 0 Date: 25 May 2001



Contents

Contents

1. How to Read these Operating Instructions	3
Copyright, Limitation of Liability and Revision Rights	3
Approvals	4
Symbols	4
2. Safety	5
General Warning	6
Before Commencing Repair Work	6
Special conditions	6
Avoid unintended Start	7
Safe Stop of the Frequency Converter (optional)	7
IT Mains	8
3. Introduction	11
Type Code String	11
4. Mechanical installation	13
Before starting	13
5. Electrical installation	19
How to connect	19
Mains wiring overview	23
Motor wiring overview	30
DC bus connection	34
Brake Connection Option	35
Relay Connection	36
Electrical Installation and Control Cables	40
How to Test Motor and Direction of Rotation.	42
6. Application Examples	47
Closed Loop Wiring	47
Submersible Pump Application	48
7. How to operate the frequency converter	51
·Ways of Operation	51
How to operate graphical LCP (GLCP)	51
How to operate numeric LCP (NLCP)	56
Tips and tricks	59
8. How to programme the frequency converter	63
How to programme	63
O1 My Personal Menu	64

Page 6 of 333

Contents

Danfoss

VLT® AQUA Drive Operating Instructions

Q2 Quick Setup	64
Q5 Changes Made	67
Q6 Loggings	67
Commonly Used Parameters - Explanations	69
Main Menu	69
Parameter Options	108
Default settings	108
Operation/Display 0-**	109
Load/Motor 1-**	111
Brakes 2-**	112
Reference / Ramps 3-**	113
Limits / Warnings 4-**	114
Digital In/Out 5-**	115
Analog In/Out 6-**	116
Comm. and Options 8-**	117
Profibus 9-**	118
CAN Fieldbus 10-**	119
Smart Logic 13-**	120
Special Functions 14-**	121
FC Information 15-**	122
Data Readouts 16-**	124
Data Readouts 2 18-**	126
FC Closed Loop 20-**	127
Ext. Closed Loop 21-**	128
Application Functions 22-**	130
Timed Actions 23-**	132
Cascade Controller 25-**	133
Analog I/O Option MCB 109 26-**	135
Cascade CTL Option 27-**	136
Water Application Functions 29-**	138
Bypass Option 31-**	139
Troubleshooting	141
Fault messages	143
). Specifications	147
General Specifications	147
Special Conditions	163
dex	169
	10.

VLT® AQUA Drive Operating Instructions



Danfoss 1. How to Read these Operating Instructions

1. How to Read these Operating Instructions

1.1.1. Copyright, Limitation of Liability and Revision Rights

This publication contains information proprietary to Danfoss. By accepting and using this manual the user agrees that the information contained herein will be used solely for operating equipment from Danfoss or equipment from other vendors provided that such equipment is intended for communication with Danfoss equipment over a serial communication link. This publication is protected under the Copyright laws of Denmark and most other countries.

Danfoss does not warrant that a software program produced according to the guidelines provided in this manual will function properly in every physical, hardware or software environment.

Although Danfoss has tested and reviewed the documentation within this manual, Danfoss makes no warranty or representation, neither expressed nor implied, with respect to this documentation, including its quality, performance, or fitness for a particular purpose.

In no event shall Danfoss be liable for direct, indirect, special, incidental, or consequential damages arising out of the use, or the inability to use information contained in this manual, even if advised of the possibility of such damages. In particular, Danfoss is not responsible for any costs, including but not limited to those incurred as a result of lost profits or revenue, loss or damage of equipment, loss of computer programs, loss of data, the costs to substitute these, or any claims by third parties.

Danfoss reserves the right to revise this publication at any time and to make changes to its contents without prior notice or any obligation to notify former or present users of such revisions or changes.

Page 8 of 333

1. How to Read these Operating Instructions Danfoss



These Operating Instructions will introduce all aspects of your VLT AQUA Drive.

Available literature for VLT AQUA Drive:

- Operating Instructions MG.20.MX.YY provide the neccessary information for getting the drive up and running.
- Design Guide MG.20.NX.YY entails technical information about the drive design and customer applications.
- Programming Guide MG.20.OX.YY provides information on how to programme and includes complete parameter descriptions.

X = Revision number

YY = Language code

Danfoss Drives technical literature is also available online at www.danfoss.com/BusinessAreas/DrivesSolutions/Documentations/Technical+Documenta-

1.1.2. Approvals







1.1.3. Symbols

Symbols used in these Operating Instructions.



NB!

Indicates something to be noted by the reader.



Indicates a general warning.



Indicates a high-voltage warning.

Indicates default setting





2.1.1. Safety note



The voltage of the frequency converter is dangerous whenever connected to mains. Incorrect installation of the motor, frequency converter or fieldbus may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

Safety Regulations

- The frequency converter must be disconnected from mains if repair work is to be carried out. Check that the mains supply has been disconnected
 and that the necessary time has passed before removing motor and mains plugs.
- The [STOP/RESET] key on the control panel of the frequency converter does not disconnect the equipment from mains and is thus not to be used as a safety switch.
- Correct protective earthing of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with applicable national and local regulations.
- 4. The earth leakage currents are higher than 3.5 mA.
- 5. Protection against motor overload is set by par. 1-90 *Motor Thermal Protection*. If this function is desired, set par. 1-90 to data value [ETR trip] (default value) or data value [ETR warning]. Note: The function is initialised at 1.16 x rated motor current and rated motor frequency. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.
- 6. Do not remove the plugs for the motor and mains supply while the frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
- Please note that the frequency converter has voltage inputs other than L1, L2 and L3, when load sharing (linking of DC intermediate circuit) and
 external 24 V DC have been installed. Check that all voltage inputs have been disconnected and that the necessary time has passed before
 commencing repair work.

Installation at High Altitudes



By altitudes above 2 km, please contact Danfoss regarding PELV.

Warning against Unintended Start

- 1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the frequency converter is connected to mains. If personal safety considerations make it necessary to ensure that no unintended start occurs, these stop functions are not sufficient.
- 2. While parameters are being changed, the motor may start. Consequently, the stop key [STOP/RESET] must always be activated; following which data can be modified. 3. A motor that has been stopped may start if faults occur in the electronics of the frequency converter, or if a temporary overload or a fault in the supply mains or the motor connection ceases.



Warning

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Also make sure that other voltage inputs have been disconnected, such as external 24 V DC, load sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic back up.



2.1.2. General Warning



Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Also make sure that other voltage inputs have been disconnected, (linkage of DC intermediate circuit), as well as the motor connection for kinetic back-up.

Before touching any potentially live parts of the VLT AQUA Drive FC 200, wait at least as follows:

200 - 240 V, 0.25 - 3.7 kW: wait at least 4 minutes.

200 - 240 V, 5.5 - 45 kW: wait at least 15 minutes.

380 - 480 V, 0.37 - 7.5 kW: wait at least 4 minutes.

380 - 480 V, 11 - 90 kW, wait at least 15 minutes.

525 - 600 V, 1.1 - 7.5 kW, wait at least 4 minutes.

525 - 600 V, 110 - 250 kW, wait at least 20 minutes.

525 - 600 V, 315 - 560 kW, wait at least 30 minutes.

Shorter time is allowed only if indicated on the nameplate for the specific unit.



Leakage Current

The earth leakage current from the VLT AQUA Drive FC 200 exceeds 3.5 mA. According to IEC 61800-5-1 a reinforced Protective Earth connection must be ensured by means of: a min. 10mm² Cu or 16mm² Al PE-wire or an additional PE wire - with the same cable cross section as the Mains wiring - must be terminated separately.

Residual Current Device

This product can cause a D.C. current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. See also RCD Application Note MN.90.GX.02. Protective earthing of the VLT AQUA Drive FC 200 and the use of RCD's must always follow national and local regulations.

2.1.3. Before Commencing Repair Work

- 1. Disconnect the frequency converter from mains
- Disconnect DC bus terminals 88 and 89
- 3. Wait at least the time mentioned in section 2.1.2
- 4. Remove motor cable

2.1.4. Special conditions

Electrical ratings:

The rating indicated on the nameplate of the frequency converter is based on a typical 3-phase mains power supply, within the specified voltage, current and temperature range, which is expected to be used in most applications.

The frequency converters also support other special applications, which affect the electrical ratings of the frequency converter. Special conditions which affect the electrical ratings might be:

- Single phase applications
- High temperature applications which require derating of the electrical ratings
- Marine applications with more severe environmental conditions.

Consult the relevant clauses in these instructions and in the VLTS AQUA Drive Design Guide for information about the electrical ratings.

Installation requirements:

The overall electrical safety of the frequency converter requires special installation considerations regarding:

- Fuses and circuit breakers for over-current and short-circuit protection
- Selection of power cables (mains, motor, brake, loadsharing and relay)
- Grid configuration (IT,TN, grounded leg, etc.)
- Safety of low-voltage ports (PELV conditions).

Consult the relevant clauses in these instructions and in the VLT^b AQUA Drive Design Guide for information about the installation requirements.

6

MG.20.M5.02 - VLT* is a registered Danfoss trademark



2.1.5. Caution



The frequency converter DC link capacitors remain charged after power has been disconnected. To avoid an electrical shock hazard, disconnect the frequency converter from the mains before carrying out maintenance. Wait at least as follows before doing service on the frequency converter:

/oltage			iting Time	
			20 min.	30 min.
200 - 240 V	0.25 - 3.7 kW	5.5 - 45 kW		
		25 (1) (1) (2)		
380 - 480 V	0.37 - 7.5 kW	11 - 90 kW	110 - 250 kW	315 - 450 kW
		The second second second		
525-600 V	0.75 kW - 7.5 kW		110 - 250 kW	315 - 560 kW
			1.00 P. 10 P.	The Appendix of the Control of the C
525-690 V			45 - 400 kW	450 - 630 kW

2.1.6. Avoid unintended Start

While the frequency converter is connected to mains, the motor can be started/stopped using digital commands, bus commands, references or via the Local Control Panel.

- · Disconnect the frequency converter from mains whenever personal safety considerations make it necessary to avoid unintended start.
- To avoid unintended start, always activate the [OFF] key before changing parameters.
- Unless terminal 37 is turned off, an electronic fault, temporary overload, a fault in the mains supply, or lost motor connection may cause a stopped motor to start.


2.1.7. Safe Stop of the Frequency Converter (optional)

For versions fitted with a Safe Stop terminal 37 input, the frequency converter can perform the safety function Safe Torque Off (As defined by draft CD IEC 61800-5-2) or Stop Category 0 (as defined in EN 60204-1).

It is designed and approved suitable for the requirements of Safety Category 3 in EN 954-1. This functionality is called Safe Stop. Prior to integration and use of Safe Stop in an installation, a thorough risk analysis on the installation must be carried out in order to determine whether the Safe Stop functionality and safety category are appropriate and sufficient. In order to install and use the Safe Stop function in accordance with the requirements of Safety Category 3 in EN 954-1, the related information and instructions of the VLT AQUA Drive Design Guide MG.20.NX.YY must be followed! The information and instructions of the Operating Instructions are not sufficient for a correct and safe use of the Safe Stop functionality!

Page 12 of 333





2.1.8. IT Mains




IT Mains

Do not connect 400 V frequency converters with RFI-filters to mains supplies with a voltage between phase and earth of more than 440 V.

For IT mains and delta earth (grounded leg), mains voltage may exceed 440 V between phase and earth.

par. 14-50 RFI Filter can be used to disconnect the internal RFI capacitiors from the RFI filter to ground. If this is done it will reduce the RFI performance to A2 level.

2.1.9. Software Version and Approvals



8

MG.20.M5.02 - VLT* is a registered Danfoss trademark

VLT® AQUA Drive Operating Instructions



2. Safety

2.1.10. Disposal Instruction



Equipment containing electrical components must not be disposed of together with domestic waste. It must be separately collected with electrical and electronic waste according to local and currently valid legislation.

VLT® AQUA Drive Operating Instructions

3. Introduction






3. Introduction

3. Introduction

3.1. Introduction

3.1.1. Type Code String



[Base Carlo	In	
Description	Pos	Possible choice FC 202
Product group & VLT Series	1-6 8-10	
Power rating Number of phases	11"	0.25 - 630 kW Three phases (T)
Number of phases	41" % ***********************************	S2: 220-240 VAC single phase
Mains voltage	11-12	S4: 380-480 VAC single phase T 2: 200-240 VAC T 4: 380-480 VAC T 6: 525-600 VAC T 7: 525-690 VAC
Enclosure	13-15	E20: IP20 E21: IP 21/NEMA Type 1: E55: IP 55/NEMA Type 12 E2M: IP21/NEMA Type 1 w/mains shield E5M: IP 55/NEMA Type 1 w/mains shield E66: IP66 F21: IP21/kit without backplate G21: IP21 kit with backplate P20: IP20/Chassis with backplate P21: IP21/NEMA Type 1 w/backplate P55: IP55/NEMA Type 12 w/backplate
RFI filter	16-17	HX: No RFI filter H1: RFI filter class A1/B H2: RFI filter class A2 H3: RFI filter class A1/B (reduced cable length) H4: RFI filter class A2/A1
Brake	18	X: No brake chopper included B: Brake chopper included T: Safe Stop: U: Safe + brake
Display	19	G: Graphical Local Control Panel (GLCP) N: Numeric Local Control Panel (NLCP) X: No Local Control Panel
Coating PCB	20	X. No coated PCB C: Coated PCB
Mains option	21	D: Loadsharing X: No Mains disconnect switch 1: With Mains disconnect switch 8: Mains Disconnect + Loadsharing
Adaptation		Reserved
Adaptation	23	Reserved
Software release	24-27	Actual software
Software language A options	29-30	AX: No options A0: MCA 101 Profibus DP V1 A4: MCA 104 DeviceNet
B options	31-32	BX: No option BK: MCB 101 General purpose I/O option BP: MCB 105 Relay option BO:MCB 109 Analog I/O option
CO options MCO		CX: No options
C1 options	35	X: No options
C option software	36-37	XX: Standard software
D options	38-39	DX: No option D0: DC back-up
The various options are described further in the N.T. AQU	A Drive Design Guid	1e. 300 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)

Table 3.1: Type code description.

3. Introduction



3.1.2. Frequency Converter Identification

Below is an example of an identification label. This label is situated on the frequency converter and shows the type and options fitted to the unit. See table 2.1 for details of how to read the Type code string (T/C).




Illustration 3.1: This example shows an identification label for VLT AQUA Drive.

Please have T/C (type code) number and serial number ready before contacting Danfoss.

3.1.3. Abbreviations and Standards

Abbreviations:	Terms:	SI-units:	I-P units:
	Acceleration	m/s²	ft/s²
AWG	American wire gauge		
Auto Tune	Automatic Motor Tuning		を答えてもの 副機能は15
℃	Celsius		
	Current	A A A A A A A A A A A A A A A A A A A	Amp
luм	Current limit		
	Energy	J = N•m	ft-lb/Btu
°F	Fahrenheit		
	Frequency Converter		
	Frequency	Hz	Hz
kHz 😪 🗭 💮	Kilohertz	1925 J. P. 1924 J. 20 E.S.	100 kg
LCP	Local Control Panel		
mA ac	Milliampere		
ms	Millisecond		
min 2007 100 100 100 100 100 100 100 100 100	Minute		प्रमा । जुल्लामुख
MCT	Motion Control Tool		
M-TYPE:	Motor Type Dependent		
Nm	Newton Metres		in-lbs
MN VOUS CONTRACTOR	Nominal motor current		
Fm,n	Nominal motor frequency		
PMN	Nominal motor power		3.0
Um,n	Nominal motor voltage		
par	Parameter		S. Santa Professor
PELV	Protective Extra Low Voltage		
	Power	THE PROPERTY OF THE PARTY OF TH	Btu/hr. hp
	Pressure	Pa = N/m²	psi, psf, ft of wat
Inv	Rated Inverter Output Current		are in Suite
RPM	Revolutions Per Minute		
	Size Related	MARINE SERVICE SERVICES	usan maari
	Temperature	C	F
- FES 7 (ASSET)		. Tisang	
Тин	Torque limit		
7Uh		2286 S.C. (5V2 T. 22.2	STATE VERSENBERT VER

Table 3.2: Abbreviation and Standards table .

4. Mechanical installation

4.1. Before starting

4.1.1. Checklist

When unpacking the frequency converter, ensure that the unit is undamaged and complete. Use the following table to identify the packaging:




Table 4.1: Unpacking table

Please note that a selection of screwdrivers (philips or cross-thread screwdriver and torx), a side-cutter, drill and knife is also recommended to have handy for unpacking and mounting the frequency converter. The packaging for these enclosures contains, as shown: Accessories bag(s), documentation and the unit. Depending on options fitted there may be one or two bags and one or more booklets.

4

Page 18 of 333

4.2.1. Mechanical Front Views 14 C2 C3 A2 **A3 A5 B1** В2 В3 В4 C1 Ç4 IP20/21 IP20/21 IP55/66 IP21/55/66 IP21/55/66 IP20 IP20 IP21/55/66 IP21/55/66 IP20 IP20

Accessory bags containing necessary brackets, screws and connectors are included with the drives upon delivery.

Top and bottom mounting holes. (C3+C4 only)

130BA715.10

All measurements in mm. * A5 in IP55/66 only!

130BA648.11

4.2.2. Mechanical Dimensions

·				Mechanical	dimensions								
Frame size (kW):	Α	2	A	3	. A5	B1:	B2	B3	B4	C1	C2	C3	** C4
200-240 V	0.25	-3.0	3.	.7	0.25-3.7	5.5-11	15	5.5-11	15-18.5	18.5-30	37-45	22-30	37-45
380-480 V	0.37	-4.0	5.5	-7.5	0.37-7.5 11-18.5	22-30	11-18.5	22-37	37-55	75-90	45-55	75-90	
525-600 V	-	-	0.75	-7.5	0.75-7.5	11-18.5	22-30	11-18.5	22-37	37-55	75-90	45-55	75-90
IP	20	21	20	21	55/66	21/ 55/66	21/55/66	20	20	21/55/66	21/55/66	20	20
NEMA	Chassis	Type 1	Chassis '	Type 1	Type 12	Type 1/12	Type 1/12	Chassis	Chassis	Type 1/12	Type 1/12	Chassis	Chassis
Height (mm)					·	. 3 20							<u> </u>
Enclosure A**	246	372	246	372	420	480	650	350	460	680	770	490	
with de-coupling plate A2	374	-	374	-	-	-	-	419	595		-	630	800
Back plate A1	268	375	268	375	420	480	650	399	520	680	77.0	550	:660
Distance between mount, holes a	257	350	257	350	402	454	624	380	495	648	739	521	631
Width (mm)													- 140 / CMC
Enclosure B	90	90	130	130	242	242	242	165	231	308	370	308	370
With one C option B	130	130	170	170	242	242	242	205	231	308	370	308	370
Back plate B	90	90	130	130	242	242	242	165	231	308	370	308	370
Distance between mount, holes b	70	70	110	110	215	. 210	210	140	200	272	334	270	330
Depth (mm)					·						decomposit = = = = = = = = = = = = = = = = = = =	7 March 1997 + 10 m 10 M	10.4000 (AV 10.10
Without option A/B C	205	205	205	205	200	260	260	248	242	310	335	333	333
With option A/B C*	220	220	220	220	200	260	260	262	242	310	335	333	333
Screw holes (mm)				fra e		1 12			restanting of the second	1 43	1 45	14554	*****
C	8.0	8.0	8.0	8.0	8.2	12 19	12 19	8 12	-	12 19	12	-	-
Diameter ø d	11	11	11	11		9	9	6.8	8.5	9.0	9.0	8.5	8.5
Diameter ø e	5.5 9	5.5 9	5.5 9	5.5 9	6.5 9	9	9	7.9	15	9.0	9.0	17	17
Manager	9	9	У.	7 T	3	7. 7. 7. Y		(1.7 ₀)					
Max weight (kg)	4.9	5.3	6.6	7.0	14	23	27	12	23.5	45	65	35	50
* Depth of enclosure will vary with diffe ** The free space requirements are abo													

15

4. Mechanical installation




4.2.3. Mechanical mounting

All IP20 enclosure sizes as well as IP21/ IP55 enclosure sizes except A2 and A3 allow side-by-side installation.

If the IP 21 Enclosure kit (130B1122 or 130B1123) is used on enclosure A2 or A3, there must be a clearance between the drives of min. 50 mm.

For optimal cooling conditions allow a free air passage above and below the frequency converter. See table below.



- Drill holes in accordance with the measurements given.
- 2. You must provide screws suitable for the surface on which you want to mount the frequency converter. Retighten all four screws.




Table 4.2: Mounting frame sizes A5, B1, B2, B3, B4, C1, C2, C3 and C4 on a non-solid back wall, the drive must be provided with a back plate A due to insufficient cooling air over the heat sink.




Illustration 4.1: With heavier drives, use a lift. First wall-mount the 2 lower bolts - then lift the drive onto the lower bolts - finally fasten the drive against the wall with the 2 top bolts.

4.2.4. Safety Requirements of Mechanical Installation



Pay attention to the requirements that apply to integration and field mounting kit. Observe the information in the list to avoid serious damage or injury, especially when installing large units.

The frequency converter is cooled by means of air circulation.

To protect the unit from overheating, it must be ensured that the ambient temperature does not exceed the maximum temperature stated for the frequency converter and that the 24-hour average temperature is not exceeded. Locate the maximum temperature and 24-hour average in the paragraph Derating for Ambient Temperature.

If the ambient temperature is in the range of 45 °C - 55 ° C, derating of the frequency converter will become relevant, see *Derating for Ambient Temperature*

The service life of the frequency converter is reduced if derating for ambient temperature is not taken into account.

4.2.5. Field Mounting

For field mounting the IP 21/IP 4X top/TYPE 1 kits or IP 54/55 units are recommended.

4.2.6. Panel Through Mounting

A Panel Through Mount Kit is available for frequency converter series , VLT Aqua Drive and .

In order to increase heatsink cooling and reduce panel depth, the frequency converter may be mounted in a through panel. Furthermore the in-built fan can then be removed.

The kit is available for enclosures AS through C2.



NB!

This kit cannot be used with cast front covers. No cover or imminent plastic cover must be used instead.

4. Mechanical installation VL Operating

VLT® AQUA Drive Operating Instructions

4

Information on ordering numbers is found in the *Design Guide*, section *Ordering Numbers*.

More detailed information is available in the *Panel Through Mount Kit instruction*, *MI.33.H1.YY*, where yy=language code.

5.1. How to connect

5.1.1. Cables General



NB!

Always comply with national and local regulations on cable cross-sections.

Details of terminal tightening torques.

	Power	(kW)				Torque	(Nm)		
Enclosure	200-240 V	380-480 V	525-600 V	Line	Motor	DC connec- tion	Brake	Earth	Relay
A2	0.25 - 3.0	0.37 - 4.0	0.75 - 4.0	1.8	1.8	1.8	1.8	3	0.6
A3	3.7	5.5 - 7.5	5.5 - 7.5	1:8	1.8	1.8	1.8	- 3	0.6
A 5	0.25 - 3.7	0.37 - 7.5	0.75 - 7.5	1.8	1.8	1.8	1.8	3	0.6
B1	5.5 - 11	11 - 18.5		1.8	1.8	1.5	1.5	3	0.6
В2	-	22	-	4.5	4.5	3.7	3.7	3	0.6
BZ	15	30	-	4.5 ²⁾	4.5 ²⁾	3.7	3.7	3	0.6
B3	5.5 - 11	11 - 18.5	11 - 18.5	1.8	1.8	1.8	1.8	3	0.6
B4	11 - 18.5	18.5 - 37	18.5 - 37	4.5	4.5	4.5	4.5	3	0.6
C1	18.5 - 30	37 - 55	-	10	10	10	10	3	0.6
C2	37	75		14	14	14	14	3	0.6
	45	90	-	24	24	14	14	3	0.6
C3	18:5 - 30	37 - 55	37 - 55	10	10	10	10	3	0.6
C4	30 - 45	55 - 90	55 - 90	14/24 ¹	14/24 ¹	14	14	3	0.6

Table 5.1: Tightening of terminals

- 1. For different cable dimensions x/y where x \leq 95 mm² and y \geq 95 mm².
- 2. Cable dimensions above 18.5 kW \geq 35 mm² and below 22 kW \leq 10 mm²

5.1.2. Enclosure Knock-outs




Illustration 5.1: Cable entry holes for enclosure B1. The suggested use of the holes are purely recommendations and other solutions are possible.




Illustration 5.2: Cable entry holes for enclosure 82. The suggested use of the holes are purely recommendations and other solutions are possible.




Illustration 5.3: Cable entry holes for enclosure C1. The suggested use of the holes are purely recommendations and other solutions are possible.




Illustration 5.4: Cable entry holes for enclosure C2. The suggested use of the holes are purely recommendations and other solutions are possible.

5

5.1.3. Fuses

Branch circuit protection:

In order to protect the installation against electrical and fire hazard, all branch circuits in an installation, switch gear, machines etc., must be shortcircuit and overcurrent protected according to the national/international regulations.

Short circuit protection

The frequency converter must be protected against short-circuit to avoid electrical or fire hazard. Danfoss recommends using the fuses mentioned in tables 4.3 and 4.4 to protect service personnel or other equipment in case of an internal failure in the unit. The frequency converter provides full short circuit protection in case of a short-circuit on the motor output.

Over-current protection:

Provide overload protection to avoid fire hazard due to overheating of the cables in the installation. Over current protection must always be carried out according to national regulations. The frequency converter is equipped with an internal over current protection that can be used for upstream overload protection (UL-applications excluded). See par. 4-18. Fuses must be designed for protection in a circuit capable of supplying a maximum of 100,000 A_{rms} (symmetrical), 500 V/600 V maximum.

Non UL compliance

If UL/cUL is not to be complied with, Danfoss recommends using the fuses mentioned in table 4.2, which will ensure compliance with EN50178: In case of malfunction, not following the recommendation may result in unnecessary damage to the frequency converter.

Frequency converter	Max. fuse size	Voltage	Type
200-240 V			
K25-1K1	16A ¹	200-240 V	type gG
1K5	16A ¹	200-240 V	type gG
2K2	25A ¹	200-240 V	type gG
3K0	25A¹	200-240 V	type gG
3K7	35A1	200-240 V	type gG
5K5	50A ¹	200-240 V	type gG
7K5	63A ¹	200-240 V	type gG
11K	63A ¹	200-240 V	type gG
15K	80A ¹	200-240 V	type gG
18K5	125A ¹	200-240 V	type gG
22K	125A ¹	200-240 V	type gG
30K	160A ¹	200-240 V	type gG
37.K	200A ¹	200-240 V	type aR
45K	250A ¹	200-240 V	type aR
380-480 V			
K37-1K5	10A ¹	380-480 V	type gG
2K2-4K0	20A¹	380-480 V	type gG
5K5-7K5	3 <u>2</u> A ¹	380-480 V	type gG:
11K	63A ¹	380-480 V	type gG
15K	63A ¹ .	380-480 V	type gG
18K	63A ¹	380-480 V	type gG
22K	63A ¹	380-480 V	type gG
30K	80A ¹	380-480 V	type gG
37K	100A ¹	380-480 V	type gG
45K	125A¹	380-480 V	type gG
55K	160A ¹	380-480 V	type gG
75K	250A¹	380-480 V	type aR
90K	250A ¹	380-480 V	type aR

Table 5.2: Non UL fuses 200 V to 480 V

1) Max. fuses - see national/international regulations for selecting an applicable fuse size.

VLT® AQUA Drive Operating Instructions



5. Electrical installation

UL Compliance

Frequency converter	Bussmann	Bussmann	Bussmann	SIBA	Littel fuse	Ferraz- Shawmut	Ferraz- Shawmut
200-240 V					Sur Maria		
Туре	Type RK1	Type J	Type T	Type RK1	Type RK1	Type CC	Type RK1
K25-1K1	KTN-R10	JKS-10	JJN-10	5017906-010	KLN-R10	ATM-R10	A2K-10R
1K5	KTN-R15	JKS-15	JJN-15	5017906-015	KLN-R15	ATM-R15	A2K-15R
2K2	KTN-R20	JKS-20	JJN . 20	5012406-020	KLN-R20	ATM-R20	A2K-20R
3K0	KTN-R25	JKS-25	JJN-25	5012406-025	KLN-R25	ATM-R25	A2K-25R
3K7	KTN-R30	JKS-30	JJN-30	5012406-030	KLN-R30	ATM-R30	A2K-30R
5K5	KTN-R50	JKS-50	JJN-50	5012406-050	KLN-R50	-	A2K-50R
7K5	KTN-R50	JKS-60	JJN-60	5012406-050	KĽN-R60	-	A2K-50R
11K	KTN-R60	JKS-60	JJN-60	5014006-063	KLN-R60		A2K-60R
15K	KTN-R80	JKS-80	JJN-80	5014006-080	KLN-R80		A2K-80R
18K5	KTN-R125	JKS-150	JJN-125	2028220-125	KLN-R125		A2K-125R
22K-	KTN-R125	JKS-150	JJN-125	2028220-125	KLN-R125		A2K-125R
30K	FWX-150	-	-	2028220-150	L25S-150		A25X-150
37K	FWX-200	-		2028220-200	:L25S-200		A25X-200
45K	FWX-250	-	-	2028220-250	L25S-250		A25X-250

Table 5.3: UL fuses 200 - 240 V

Frequency converter	Bussmann	Bussmann	Bussmann	SIBA	Littel fuse	Ferraz- Shawmut	Ferraz- Shawmut
380-480 V,	525-600 V						
kW	Type RK1	Type J	Type T	Type RK1	Type RK1	Type CC	Type RK1
K37-1K1	KTS-R6	JKS-6	JJS-6	5017906-006	KLS-R6	ATM-R6	A6K-6R
1K5-2K2	KTS-R10	JKS-10	JJS-10	5017906-010	KLS-R10	ATM-R10	A6K-10R
3K0	KTS-R15	JKS-15	JJS-15	5017906-016	KLS-R16	ATM-R16	A6K-16R
4K0	KTS-R20	JKS-20	JJS-20	5017906-020	KLS-R20	ATM-R20	A6K-20R
5K5	KTS-R25	JKS-25	JJS-25	5017906-025	KLS-R25	ATM-R25	A6K-25R
7K5	KTS-R30	JKS-30	JJS-30	5012406-032	KLS-R30	ATM-R30	A6K-30R
11K	KTS-R40	JKS-40	JJS-40	5014006-040	KLS-R40	-	A6K-40R
15K	KTS-R40	JKS-40	JJS-40	5014006-040	KLS-R40	-	A6K-40R
18K	KTS-R50	JKS-50	33S-50	5014006-050	-KLS-R50		A6K-50R
22K	KTS-R60	JKS-60	JJS-60	5014006-063	KLS-R60	+	A6K-60R
30K	KTS-R80	JKS-80	JJS-80	2028220-100	KLS-R80	-	A6K-80R
37K	KTS-R100	JKS-100	JJS-100	2028220-125	KLS-R100		A6K-100R
45K	KTS-R125	JKS-150	JJS-150	-2028220-125	KLS-R125		A6K-125R
55K	KTS-R150	JKS-150	JJS-150	2028220-160	KLS-R150		A6K-150R
75K	FWH-220		-	2028220-200	L50S-225		A50-P225
90K	FWH-250	-	-	2028220-250	L50S-250		A50-P250

Table 5.4: UL fuses 380 - 600 V

KTS-fuses from Bussmann may substitute KTN for 240 V frequency converters.

FWH-fuses from Bussmann may substitute FWX for 240 V frequency converters.

KLSR fuses from LITTEL FUSE may substitute KLNR fuses for 240 V frequency converters.

L50S fuses from LITTEL FUSE may substitute L50S fuses for 240 V frequency converters.

A6KR fuses from FERRAZ SHAWMUT may substitute A2KR for 240 V frequency converters.

A50X fuses from FERRAZ SHAWMUT may substitute A25X for 240 V frequency converters.

5.1.4. Earthing and IT mains



The earth connection cable cross section must be at least 10 mm² or 2 rated mains wires terminated separately according to *EN 50178* or *IEC 61800-5-1* unless national regulations specify differently. Always comply with national and local regulations on cable cross-sections.

The mains is connected to the main disconnect switch if this is included.



NB!

Check that mains voltage corresponds to the mains voltage of the frequency converter name plate.



VLT® AQUA Drive Operating Instructions




Illustration 5.5: Terminals for mains and earthing.



IT Mains

Do not connect 400 V frequency converters with RFI-filters to mains supplies with a voltage between phase and earth of more than 440 V.

For IT mains and delta earth (grounded leg), mains voltage may exceed 440 V between phase and earth.

22

MG.20.M5.02 - $\text{VLT}^{\&}$ is a registered Danfoss trademark

Active 10/12/2014 Page 27 of 333

Enclosure:	A2 (IP 20/IP 21)	A3 (IP 20/IP 21)	A5 (IP 55/IP 66)	B1 (IP 21/IP 55/IP 66)	B2 (IP 21/IP 55/IP 66)	B3 (IP 20)	B4 (IP 20)	C1 (IP 21/IP 55/66)	C2 (IP 21/IP 55/66)	C3 (IP 20)	C4 (IP20)
	1 May rain in	Single-year i de	and the same of th								
Motor size (kW	'):				, !		-1				
200-240 V	0.25-3.0	3.7	1.1-3.7	5.5-11	15	5.5-11	15-18.5	18.5-30	37-45	22-30	37-45
380-480 V	0.37-4.0	5.5-7.5	1.1-7.5	11-18.5	22-30	11-18.5	22-37	37-55	75-90	45-55	75-90
525-600 V	,	1.1-7.5	1.1-7.5	11-18.5	22-30	11-18.5	22-37	37-55	75-90	45-55	75-90
Goto:	5.	1.6	5.1.7		5.1.8		5.1.9			5.1.10	

Table 5.5: Mains wiring table.





5.1.6. Mains connection for A2 and A3




Illustration 5.6: First mount the two screws on the mounting plate, slide it into place and tighten fully.




Illustration 5.7: When mounting cables, first mount and tighten earth cable.



The earth connection cable cross section must be at least 10 mm² or 2 rated mains wires terminated separately according to EN 50178/IEC 61800-5-1.




Illustration 5.8: Then mount mains plug and tighten wires.




Illustration 5.9: Finally tighten support bracket on mains wires.

Danfoss

5.1.7. Mains connection for A5




Illustration 5.10: How to connect to mains and earthing without mains disconnect switch. Note that a cable clamp is used.




Illustration 5.11: How to connect to mains and earthing with mains disconnect switch.

5.1.8. Mains connection for B1, B2 and B3




Illustration 5.12: How to connect to mains and earthing for B1 and B2




Illustration 5.13: How to connect to mains and earthing for 83 without RFI.




Illustration 5.14: How to connect to mains and earthing for B3 with RFI.

9

NB!

For correct cable dimensions please see the section General Specifications at the back of this manual.

Danfoss

5.1.9. Mains connection for B4, C1 and C2




Illustration 5.15: How to connect to mains and earthing for 84.




Illustration 5.16: How to connect to mains and earthing for C1 and C2.

5.1.10. Mains connection for C3 and C4




Illustration 5.17: How to connect C3 to mains and earthing.




Illustration 5.18: How to connect C4 to mains and earthing.

5.1.11. How to connect motor - foreword

See section General Specifications for correct dimensioning of motor cable cross-section and length.

- Use a screened/armoured motor cable to comply with EMC emission specifications (or install the cable in metal conduit).
- Keep the motor cable as short as possible to reduce the noise level and leakage currents.
- Connect the motor cable screen/armour to both the decoupling plate of the frequency converter and to the metal of the motor. (Same applies to both ends of metal conduit if used instead of screen.)
- Make the screen connections with the largest possible surface area (cable clamp or by using an EMC cable gland). This is done by using the supplied installation devices in the frequency converter.
- Avoid terminating the screen by twisting the ends (pigtails), as this will spoil high frequency screening effects.
- If it is necessary to break the continuity of the screen to install a motor isolator or motor relay, the continuity must be maintained with the lowest possible HF impedance.

Cable length and cross-section

The frequency converter has been tested with a given length of cable and a given cross-section of that cable. If the cross-section is increased, the cable capacitance - and thus the leakage current - may increase, and the cable length must be reduced correspondingly.

28

MG.20.M5.02 - $\text{VLT}^{\&}$ is a registered Danfoss trademark



Switching frequency

When frequency converters are used together with sine wave filters to reduce the acoustic noise from a motor, the switching frequency must be set according to the sine wave filter instruction in par. 14-01 Switching *Frequency*.

Precautions while using Aluminium conductors

Aluminium conductors are not recommended for cable cross sections below 35 mm². Terminals can accept aluminium conductors but the conductor surface has to be clean and the oxidation must be removed and sealed by neutral acid free Vaseline grease before the conductor is connected. Furthermore, the terminal screw must be retightened after two days due to the softness of the aluminium. It is crucial to ensure the connection makes a gas tight joint, otherwise the aluminium surface will oxidize again.

All types of three-phase asynchronous standard motors can be connected to the frequency converter. Normally, small motors are star-connected (230/400 V, D/Y). Large motors are delta-connected (400/690 V, D/Y). Refer to the motor name plate for correct connection mode and voltage.




Illustration 5.19: Terminals for motor connection

9

NB!

In motors without phase insulation paper or other insulation reinforcement suitable for operation with voltage supply (such as a frequency converter), fit a sine-wave filter on the output of the frequency converter. (Motors that comply with IEC 60034-17 do not require an Sine-wave filter).

No.	96	97	98	Motor voltage 0-100% of mains voltage.
	Ü	ν	W	3 cables out of motor
	U1	V1	W1	6 cables out of motor, Delta-connected
	W2	U2	V2	Cables out of filotor, Delta-conflected
	U1	V1		6 cables out of motor, Star-connected
				U2, V2, W2 to be interconnected separately
				(optional terminal block)
No.	99			Earth connection
	PE			

Table 5.6: 3 and 6 cable motor connection.

ы З



5.1.12. Motor wiring overview

Enclosure:	A2	A3	A5	B1	B2	В3	B4	C1	C2	С3	C4
	(IP 20/JP 21)	(IP 20/IP 21)	(IP 55/IP 66)	(IP 21/IP 55/ IP 66)	(IP 21/IP 55/ IP 66)	(IP 20)	(IP 20)	(IP 21/IP 55/66)	(JP 21/IP 55/66)	(IP 20)	(IP20)
	1300.34410	(Section 1)									
Motor size (kW):							<u> </u>	V 40 0		مخصدة
200-240 V	0.25-3.0	3.7	1.1-3.7	5.5-11	15	5.5-11	15-18.5	18.5-30	37-45	22-30	37-45
380-480 V	0.37-4.0	5.5-7.5	1.1-7.5	11-18.5	22-30	11-18.5	22-37	37-55	75-90	45-55	75-90
525-600 V		1.1-7.5	1.1-7.5	11-18.5	22-30	11-18.5	22-37	37-55	75-90	45-55	75-90
Goto:	5.1.13		5.1.14	5.1.15		5.1.16		5.1.17		5.1.18	

Table 5.7: Motor wiring table.



5.1.13. Motor connection for A2 and A3

Follow these drawings step by step for connecting the motor to the frequency converter.




Illustration 5.20: First terminate the motor earth, then place motor U, V and W wires in plug and tighten.




Illustration 5.21: Mount cable clamp to ensure 360 degree connection between chassis and screen, note the outer insulation of the motor cable is removed under the clamp.

5.1.14. Motor connection for A5




Illustration 5.22: First terminate the motor earth, then place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.

5.1.15. Motor connection for B1 and B2




Illustration 5.23: First terminate the motor earth, then Place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.

32

MG.20.M5.02 - $\text{VLT}^{\&}$ is a registered Danfoss trademark

5.1.16. Motor connection for B3 and B4




Illustration 5.24: First terminate the motor earth, then Place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.




Illustration 5.25: First terminate the motor earth, then Place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.

5.1.17. Motor connection for C1 and C2




Illustration 5.26: First terminate the motor earth, then Place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.

5.1.18. Motor connection for C3 and C4




Illustration 5.27: First terminate the motor earth, then Place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.




Illustration 5.28: First terminate the motor earth, then Place motor U, V and W wires in terminal and tighten. Please ensure that the outer insulation of the motor cable is removed under the EMC clamp.

5.1.19. DC bus connection

The DC bus terminal is used for DC back-up, with the intermediate circuit being supplied from an external source.

Terminal numbers used: 88, 89




Illustration 5.29: DC bus connections for enclosure B3.




Illustration 5.30: DC bus connections for enclosure B4.




Illustration 5.31: DC bus connections for enclosure C3.




Illustration 5.32: DC bus connections for enclosure enclosure C4.

Please contact Danfoss if you require further information.

5.1.20. Brake Connection Option

The connection cable to the brake resistor must be screened/armoured.

Enclosure	A+B+C+D+F	A+B+C+D+F
Brake resistor	81	82
Terminals	R-	R+



NB!

Dynamic brake calls for extra equipment and safety considerations. For further information, please contact Danfoss.

- 1. Use cable clamps to connect the screen to the metal cabinet of the frequency converter and to the decoupling plate of the brake resistor.
- 2. Dimension the cross-section of the brake cable to match the brake current.



NR

Voltages up to 975 V DC (@ 600 V AC) may occur between the terminals.




Illustration 5.33: Brake connection terminal for B3.




Illustration 5.34: Brake connection terminal for B4.

5. Electrical installation

Danfoss




Illustration 5.35: Brake connection terminal for C3.

Illustration 5.36: Brake connection terminal for C4.




NB!

If a short circuit in the brake IGBT occurs, prevent power dissipation in the brake resistor by using a mains switch or contactor to disconnect the mains for the frequency converter. Only the frequency converter shall control the contactor.

5.1.21. Relay Connection

To set relay output, see par. group 5-4* Relays.

No.	01 - 02	make (normally open)	
2.5	01 - 03	break (normally closed)	
	04 - 05	make (normally open)	
	04 - 06	break (normally closed)	






Illustration 5.37: Terminals for relay connection (C1 and C2 enclosures).

The relay connections are shown in the cut-out with relay plugs (from the Accessory Bag) fitted.




Illustration 5.38: Terminals for relay connections for B3. Only one knock-out is fitted from the factory.






Illustration 5.39: Terminals for relay connections for B4.




Illustration 5.40: Terminals for relay connections for C3 and C4. Located in the upper right corner of the frequency converter.

5.1.22. Relay Output

Relay 1

Terminal 01: common

• Terminal 02: normal open 240 V AC

• Terminal 03: normal closed 240 V AC

Relay 2

Terminal 04: common

Terminal 05: normal open 400 V AC


Terminal 06: normal closed 240 V AC

Relay 1 and relay 2 are programmed in par. 5-40 Function *Relay*, par. 5-41 On *Delay*, *Relay*, and par. 5-42 Off *Delay*, *Relay*.

Additional relay outputs by using option module MCB 105.

5.1.23. Wiring Example and Testing

The following section describes how to terminate control wires and how to access them. For an explanation of the function, programming and wiring of the control terminals, please see chapter, *How to programme the frequency converter*.



38

MG.20.M5.02 - VLT* is a registered Danfoss trademark

5.1.24. Access to Control Terminals

All terminals to the control cables are located underneath the terminal cover on the front of the frequency converter. Remove the terminal cover with a screwdriver.




Illustration 5.41: Access to control terminals for A2, A3, B3, B4, C3 and C4 enclosures

Remove front-cover to access control terminals. When replacing the front-cover, please ensure proper fastening by applying a torque of 2 Nm.




Illustration 5.42: Access to control terminals for A5, B1, B2, C1 and C2 enclosures $\,$



5.1.25. Control Terminals

Drawing reference numbers:

- 10 pole plug digital I/O.
- 2. 3 pole plug RS-485 Bus.
- 6 pole analog I/O.
- 4. USB connection.




Illustration 5.43: Control terminals (all enclosures)

D_x

5.1.26. Control Cable Clamp

 Use a clamp from the accessory bag to connect screen to frequency converter decoupling plate for control cables.

See section entitled *Earthing of Screened/Armoured Control Cables* for the correct termination of control cables.




Illustration 5.44: Control cable clamp.

5.1.27. Electrical Installation and Control Cables




Illustration 5.45: Diagram showing all electrical terminals. (Terminal 37 present for units with Safe Stop Function only.)

Very long control cables and analog signals may, in rare cases and depending on installation, result in 50/60 Hz earth loops due to noise from mains supply cables.

If this occurs, break the screen or insert a 100 nF capacitor between screen and chassis.



NB!

The common of digital / analog inputs and outputs should be connected to separate common terminals 20, 39, and 55. This will avoid ground current interference among groups. For example, it avoids switching on digital inputs disturbing analog inputs.



NB!

Control cables must be screened/armoured.

Danfoss

5.1.28. How to Test Motor and Direction of Rotation.



Note that unintended motor start can occur, ensure no personnel or equipment is in danger!

Please follow these steps to test the motor connection and direction of rotation. Start with no power to the unit.




Illustration 5.46:

Step 1: First remove the insulation on both ends of a 50 to 70 mm piece of wire.




Illustration 5.47:

Step 2: Insert one end in terminal 27 using a suitable terminal screw-driver. (Note: For units with Safe Stop function, the existing jumper between terminal 12 and 37 should not be removed for the unit to be able to run!)




Illustration 5.48:

Step 3: Insert the other end in terminal 12 or 13. (Note: For units with Safe Stop function, the existing jumper between terminal 12 and 37 should not be removed for the unit to be able to run!)




Illustration 5.49

Step 4: Power-up the unit and press the [Off] button. In this state the motor should not rotate. Press [Off] to stop the motor at any time. Note the LED at the [OFF] button should be lit. If alarms or warnings are flashing, please see chapter 7 regarding these.

VLT® AQUA Drive Operating Instructions






Illustration 5.50:

Step 5: By pressing the [Hand on] button, the LED above the button should be lit and the motor may rotate.




Illustration 5.51:

Step 6: The speed of the motor can be seen in the LCP. It can be adjusted by pushing the up ▲ and down ▼ arrow buttons.




Illustration 5.52:




Illustration 5.53:

Step 8: Press the [Off] button to stop the motor again.




Illustration 5.54:

Step 9: Change two motor wires if the desired rotation of direction is not achieved.



Remove mains power from the frequency converter before changing motor wires.



VLT® AQUA Drive Operating Instructions

5.1.29. Switches S201, S202, and S801

Switches S201 (Al 53) and S202 (Al 54) are used to select a current (0-20 mA) or a voltage (0 to 10 V) configuration of the analog input terminals 53 and 54 respectively.

Switch S801 (BUS TER.) can be used to enable termination on the RS-485 port (terminals 68 and 69).

Please note that the switches may be covered by an option, if fitted.

Default setting:

S201 (AI 53) = OFF (voltage input)

S202 (AI 54) = OFF (voltage input)

S801 (Bus termination) = OFF




Illustration 5.55: Switches location.

5.2. Final optimization and test

5.2.1. Final optimization and test

To optimize motor shaft performance and optimize the frequency converter for the connected motor and installation, please follow these steps. Ensure that frequency converter and motor are connected, and power is applied to frequency converter.



NB!

Before power up ensure that connected equipment is ready for use.

Step 1. Locate motor name plate.



NB

The motor is either star- (Y) or delta- connected (Δ). This information is located on the motor name plate data.




Illustration 5.56: Motor name plate example

Step 2. Enter motor name plate data in following parameter list. To access list first press [QUICK MENU] key then select "Q2 Quick Setup".

1.	Motor Power [kW] or Motor Power [HP]	par. 1-20 par. 1-21
2.	Motor Voltage	par. 1-22
3.	Motor Frequency	par. 1-23
4.	Motor Current	par, 1-24
5.	Motor Nominal Speed	par. 1-25

Table 5.8: Motor related parameters

5. Electrical installation



Step 3. Activate Automatic Motor Adaptation (AMA)

Performing AMA ensures best possible performance. AMA automatically takes measurements from the specific motor connected and compensates for installation variances.

- 1. Connect terminal 27 to terminal 12 or use [MAIN MENU] and set Terminal 27 par. 5-12 to No operation (par. 5-12 [0])
- Press (QUICK MENU), select "Q2 Quick Setup", scroll down to AMA par. 1-29.
- 3. Press (OK) to activate the AMA par. 1-29.
- Choose between complete or reduced AMA. If sine wave filter is mounted, run only reduced AMA, or remove sine wave filter during AMA
 procedure.
- 5. Press [OK] key. Display should show "Press [Hand on] to start".
- 6. Press [Hand on] key. A progress bar indicates if AMA is in progress.

5

Stop the AMA during operation

1. Press the [OFF] key - the frequency converter enters into alarm mode and the display shows that the AMA was terminated by the user.

Successful AMA

- 1. The display shows "Press [OK] to finish AMA".
- 2. Press the [OK] key to exit the AMA state.

Unsuccessful AMA

- 1. The frequency converter enters into alarm mode. A description of the alarm can be found in the Troubleshooting section.
- "Report Value" in the [Alarm Log] shows the last measuring sequence carried out by the AMA, before the frequency converter entered alarm
 mode. This number along with the description of the alarm will assist troubleshooting. If contacting Danfoss Service, make sure to mention
 number and alarm description.



NB!

Unsuccessful AMA is often caused by incorrectly entered motor name plate data or too big difference between the motor power size and the frequency converter power size.

Step 4. Set speed limit and ramp time

Set up the desired limits for speed and ramp time.

	1 .
Minimum Reference	par. 3-02
Maximum Reference	par. 3-03

Motor Speed Low Limit	par. 4-11 or 4-12	
Motor Speed High Limit	par. 4-13 or 4-14	_

Ramp 1 Ramp Up Time [s]	par. 3-41
Ramp 1 Ramp Down Time 1 [s]	par. 3-42

6 Application Examples

6.1.1. Start/Stop

Terminal 18 = start/stop par. 5-10 [8] Start

Terminal 27 = No operation par. 5-12 [0] *No operation* (Default *coast inverse*

Par. 5-10 Digital Input, Terminal 18 = Start (default)

Par. 5-12 Digital Input, Terminal 27 = coast inverse (default)




Illustration 6.1: Terminal 37: Available only with Safe Stop Function!

6.1.2. Closed Loop Wiring


Terminal 12 /13: +24V DC

Terminal 18: Start par. 5-18 [8] Start (Default)

Terminal 27: Coast par. 5-12 [2] coast inverse (Default)

Terminal 54: Analog input

L1-L3: Mains terminals
U,V and W: Motor terminals



6.1.3. Submersible Pump Application

The system consists of a submersible pump controlled by a Danfoss VLT AQUA Drive and a pressure transmitter. The transmitter gives a 4-20 mA feedback signal to the VLT AQUA Drive, which keeps a constant pressure by controlling the speed of the pump. To design a drive for a submersible pump application, there are a few important issues to take into consideration. Therefore the drive used must be chosen according to motor current.

- 1. The motor is a so called "Can motor" with a stainless steel can between the rotor and stator. There is a larger and a more magnetic resistant air-gap than on a normal motor hence a weaker field which results in the motors being designed with a higher rated current than a norm motor with similar rated power.
- The pump contains thrust bearings which will be damaged when running below minimum speed which normally will be 30 Hz.
- 3. The motor reactance is nonlinear in submersible pump motors and therefore Automatic Motor Adaption (AMA) may not be possible. However, normally submersible pumps are operated with very long motor cables that might eliminate the nonlinear motor reactance and enable the drive to perform AMA. If AMA fails, the motor data can be set from parameter group 1-3* (see motor datasheet). Be aware that if AMA has succeeded the drive will compensate for voltage drop in the long motor cables, so if the Advanced motor data are set manually, the length of the motor cable must be taken into considerations to optimize system performance.
- 4. It is important that the system is operated with a minimum of wear and tear of the pump and motor. A Danfoss Sine-Wave filter can lower the motor insulation stress and increase lifetime (check actual motor insulation and the frequency converter du/dt specification). It is recommended to use a filter to reduce the need for service.
- 5. EMC performance can be difficult to achieve due to the fact that the special pump cable which is able to withstand the wet conditions in the well normally is unscreened. A solution could be to use a screened cable above the well and fix the screen to the well pipe if it is made of steel (can also be made of plastic). A Sine-Wave filter will also reduce the EMI from unscreened motor cables.

The special "can motor" is used due to the wet installation conditions. The drive needs to be designed for the system according to output current to be able to run the motor at nominal power.

To prevent damage to the thrust bearings of the pump, it is important to ramp the pump from stop to min. speed as quick as possible. Well-known manufacturers of submersible pumps recommend that the pump is ramped to min. speed (30 Hz) in max. 2 -3 seconds. The new VLT© AQUA Drive is designed with initial and final Ramp for these applications. The initial and final ramps are 2 individual ramps, where Initial Ramp, if enabled, will ramp the motor from stop to min. speed and automatically switch to normal ramp, when min. speed is reached. Final ramp will do the opposite from min. speed to stop in a stop situation.

Pipe-Fill mode can be enabled to prevent water hammering. The Danfoss frequency converter is capable of filling vertical pipes using the PID controller to slowly ramp up the pressure with a user specified rate (units/sec). If enabled the drive will, when it reaches min. speed after startup, enter pipe fill mode. The pressure will slowly be ramped up until it reaches a user specified Filled Set Point, where after the drive automatically disables Pipe Fill Mode and continues in normal closed loop operation.

This feature is designed for irrigation applications.


Electrical Wiring

Typical/recommended settings Parameters:	in brackets().
Motor Rated Power	Par. 1-20 / par. 1-21
Motor Rated Voltage	Par. 1-22
Motor Current	Par. 1-24
Motor Rated Speed	Par. 1-28




NB!


Note the analog input 2, (terminal (54) format must be set to mA. (switch 202).






6. Application Examples







7. How to operate the frequency converter Danfoss



7. How to operate the frequency converter

7.1. Ways of Operation

7.1.1. Ways of Operation

The frequency converter can be operated in 3 ways:

- 1. Graphical Local Control Panel (GLCP), see 6.1.2
- 2. Numeric Local Control Panel (NLCP), see 6.1.3
- 3. RS-485 serial communication or USB, both for PC connection, see 6.1.4

If the frequency converter is fitted with fieldbus option, please refer to relevant documentation.

7.1.2. How to operate graphical LCP (GLCP)

The following instructions are valid for the GLCP (LCP 102).

The GLCP is divided into four functional groups:

- 1. Graphical display with Status lines.
- 2. Menu keys and indicator lights (LED's) selecting mode, changing parameters and switching between display functions.
- 3. Navigation keys and indicator lights (LEDs).
- 4. Operation keys and indicator lights (LEDs).

Graphical display:

The LCD-display is back-lit with a total of 6 alpha-numeric lines. All data is displayed on the LCP which can show up to five operating variables while in [Status] mode.


Display lines:

- a. Status line: Status messages displaying icons and graphics.
- b. Line 1-2: Operator data lines displaying data and variables defined or chosen by the user. By pressing the [Status] key, up to one extra line can be added.
- c. Status line: Status messages displaying text.

The display is divided into 3 sections:

Top section (a)

shows the status when in status mode or up to 2 variables when not in status mode and in the case of Alarm/Warning.



7. How to operate the frequency converter



The number of the Active Set-up (selected as the Active Set-up in par. 0-10) is shown. When programming in another Set-up than the Active Set-up, the number of the Set-up being programmed appears to the right in brackets.

Middle section (b)

shows up to 5 variables with related unit, regardless of status. In case of alarm/warning, the warning is shown instead of the variables.

It is possible to toggle between three status read-out displays by pressing the [Status] key. Operating variables with different formatting are shown in each status screen - see below.

Several values or measurements can be linked to each of the displayed operating variables. The values / measurements to be displayed can be defined via par. 0-20, 0-21, 0-22, 0-23, and 0-24, which can be accessed via [QUICK MENU], "Q3 Function Setups", "Q3-1 General Settings", "Q3-11 Display Settings".

Each value / measurement readout parameter selected in par. 0-20 to par. 0-24 has its own scale and number of digits after a possible decimal point. Larger numeric values are displayed with few digits after the decimal point.

Ex.: Current readout


5.25 A; 15.2 A 105 A.

Status display I

This read-out state is standard after start-up or initialization.

Use [INFO] to obtain information about the value/measurement linked to the displayed operating variables $(1.1,\,1.2,\,1.3,\,2,\,and\,3).$

See the operating variables shown in the display in this illustration. 1.1, 1.2 and 1.3 are shown in small size. 2 and 3 are shown in medium size.




Status display II

See the operating variables (1.1, 1.2, 1.3,and 2) shown in the display in this illustration.


In the example, Speed, Motor current, Motor power and Frequency are selected as variables in the first and second lines.

1.1, 1.2 and 1.3 are shown in small size. 2 is shown in large size.



Status display III:

This state displays the event and action of the Smart Logic Control. For further information, see section *Smart Logic Control*.






7. How to operate the frequency converter

Bottom section

always shows the state of the frequency converter in Status mode.



Display Contrast Adjustment


Press [status] and [A] for darker display Press [status] and [▼] for brighter display

Indicator lights (LEDs):

If certain threshold values are exceeded, the alarm and/or warning LED lights up. A status and alarm text appear on the control panel.

The On LED is activated when the frequency converter receives power from mains voltage, a DC bus terminal, or an external 24 V supply. At the same time, the back light is on.

- Green LED/On: Control section is working.
- Yellow LED/Warn.: Indicates a warning.
- Flashing Red LED/Alarm: Indicates an alarm.



GLCP keys

Menu keys

The menu keys are divided into functions. The keys below the display and $% \left(1\right) =\left(1\right) \left(1\right) \left$ indicator lamps are used for parameter set-up, including choice of display indication during normal operation.



[Status]

Indicates the status of the frequency converter and/or the motor. 3 different readouts can be chosen by pressing the [Status] key: 5 line readouts, 4 line readouts or Smart Logic Control.

Use [Status] for selecting the mode of display or for changing back to Display mode from either the Quick Menu mode, the Main Menu mode or Alarm mode. Also use the [Status] key to toggle single or double read-out mode.

[Quick Menu]

Allows quick set-up of the frequency converter. The most common functions can be programmed here.

The [Quick Menu] consists of:

- Q1: My Personal Menu
- Q2: Quick Setup
- Q3: Function Setups
- Q5: Changes Made
- Q6: Loggings

The Function set-up provides quick and easy access to all parameters required for the majority of water and wastewater applications including variable torque, constant torque, pumps, dossing pumps, well pumps, booster pumps, mixer pumps, aeration blowers and other pump and fan applications. Amongst other features it also includes parameters for selecting which variables to display on the LCP, digital preset speeds, scaling of analog references, closed loop single zone and multi-zone applications and specific functions related to water and wastewater applications.

The Quick Menu parameters can be accessed immediately unless a password has been created via par. 0-60, 0-61, 0-65 or 0-66. It is possible to switch directly between Quick Menu mode and Main Menu mode.

7. How to operate the frequency converter



[Main Menu]

is used for programming all parameters.

The Main Menu parameters can be accessed immediately unless a password has been created via par. 0-60, 0-61, 0-65 or 0-66. For the majority of water and wastewater applications it is not necessary to access the Main Menu parameters but instead the Quick Menu, Quick Setup and Function Setups provides the simplest and quickest access to the typical required parameters.

It is possible to switch directly between Main Menu mode and Quick Menu mode.

Parameter shortcut can be carried out by pressing down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

[Alarm Log]

displays an Alarm list of the five latest alarms (numbered A1-A5). To obtain additional details about an alarm, use the arrow keys to manoeuvre to the alarm number and press [OK]. Information is displayed about the condition of the frequency converter before it enters the alarm mode.

[Back]

reverts to the previous step or layer in the navigation structure.

[Cancel]

last change or command will be cancelled as long as the display has not been changed.

[Info]

displays information about a command, parameter, or function in any display window. [Info] provides detailed information when needed. Exit Info mode by pressing either [Info], [Back], or [Cancel].






Navigation Keys

The four navigation arrows are used to navigate between the different choices available in [Quick Menu], [Main Menu] and [Alarm Log]. Use the keys to move the cursor.


[OK]

is used for choosing a parameter marked by the cursor and for enabling the change of a parameter.



Operation Keys

for local control are found at the bottom of the control panel.



[Hand On]

enables control of the frequency converter via the GLCP. [Hand on] also starts the motor, and it is now possible to give the motor speed reference by means of the arrow keys. The key can be *Enabled* [1] or *Disabled* [0] via par. *0-40* [Hand on] Key on LCP.

The following control signals will still be active when [Hand on] is activated:

- [Hand on] [Off] [Auto on]
- Reset
- Coasting stop inverse (motor coasting to stop)

54

MG.20.M5.02 - VLT* is a registered Danfoss trademark



7. How to operate the frequency converter

- Reversing
- Set-up select lsb Set-up select msb
- Stop command from serial communication
- Quick stop
- DC brake



NB!

External stop signals activated by means of control signals or a serial bus will override a "start" command via the LCP.

[Off]

stops the connected motor. The key can be *Enabled* [1] or *Disabled* [0] via par. *O-41 [Off] key on LCP*. If no external stop function is selected and the [Off] key is inactive the motor can only be stopped by disconnecting the mains supply.

[Auto On]

enables the frequency converter to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the frequency converter will start. The key can be *Enabled*[1] or *Disabled*[0] via par. *0-42* [Auto on] key on LCP.



NB!

An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand on] - [Auto on].

7

[Reset]

is used for resetting the frequency converter after an alarm (trip). The key can be Enabled [1] or Disabled [0] via par. 0-43 Reset Keys on LCP.

The parameter shortcut

can be carried out by holding down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

7. How to operate the frequency converter



7.1.3. How to operate numeric LCP (NLCP)

The following instructions are valid for the NLCP (LCP 101).

The control panel is divided into four functional groups:

- Numeric display.
- Menu key and indicator lights (LEDs) changing parameters and switching between display functions.
- Navigation keys and indicator lights (LEDs).
- 4. Operation keys and indicator lights (LEDs).



NB!

Parameter copy is not possible with Numeric Local Control Panel (LCP101).

Select one of the following modes:

Status Mode: Displays the status of the frequency converter or the mo-

If an alarm occurs, the NLCP automatically switches to status mode.

A number of alarms can be displayed.

Quick Setup or Main Menu Mode: Display parameters and parameter settings.




Illustration 7.1: Numerical LCP (NLCP)




Illustration 7.2: Status display example




Illustration 7.3: Alarm display example

.

Indicator lights (LEDs):

- Green LED/On: Indicates if control section is on.
- Yellow LED/Wm.: Indicates a warning.
- Flashing red LED/Alarm: Indicates an alarm.

Menu key

[Menu] Select one of the following modes:

- Status
- Quick Setup
- Main Menu

Main Menu

is used for programming all parameters.

The parameters can be accessed immediately unless a password has been created via par. 0-60 Main Menu Password, par. 0-61 Access to Main Menu w/o Password, par. 0-65 Personal Menu Password or par. 0-66 Access to Personal Menu w/o Password.

Quick Setup is used to set up the frequency converter using only the most essential parameters.

The parameter values can be changed using the up/down arrows when the value is flashing.

Select Main Menu by pressing the [Menu] key a number of times until the Main Menu LED is lit.

Select the parameter group [xx-_] and press [OK]

Select the parameter [__-xx] and press [OK]

If the parameter is an array parameter select the array number and press [OK]

Select the wanted data value and press [OK]



7. How to operate the frequency converter

Navigation Keys

[Back]

for stepping backwards

Arrow [▲] [▼]

keys are used for manoeuvring between parameter groups, parameters and within parameters

[OK]

is used for choosing a parameter marked by the cursor and for enabling the change of a parameter.

Operation Keys

Keys for local control are found at the bottom of the control panel.




Illustration 7.4: Display example




Illustration 7.5: Operation keys of the numerical LCP (NLCP)

[Hand on]

enables control of the frequency converter via the LCP. [Hand on] also starts the motor and it is now possible to enter the motor speed data by means of the arrow keys. The key can be *Enabled* [1] or *Disabled* [0] via par. 0-40 [Hand *on*] *Key on LCP*.

External stop signals activated by means of control signals or a serial bus will override a 'start' command via the LCP.

The following control signals will still be active when [Hand on] is activated:

- [Hand on] [Off] [Auto on]
- Reset
- Coasting stop inverse
- Reversing
- Set-up select Isb Set-up select msb
- Stop command from serial communication
- Quick stop
- DC brake

[Off]

stops the connected motor. The key can be Enabled [1] or Disabled [0] via par. 0-41 [Off] Key on LCP.

If no external stop function is selected and the [Off] key is inactive the motor can be stopped by disconnecting the mains supply.

[Auto on]

enables the frequency converter to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the frequency converter will start. The key can be *Enabled*[1] or *Disabled*[0] via par. 0-42 [Auto *on] Key on LCP*.



NB!

An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand on] [Auto on].

[Reset]

is used for resetting the frequency converter after an alarm (trip). The key can be Enabled [1] or Disabled [0] via par. 0-43 [Reset] Key on LCP.

7.1.4. Changing Data

Press [Quick Menu] or [Main Menu] key.

7. How to operate the frequency converter



- 2. Use [▲] and [▼] keys keys to find parameter group to edit.
- 3. Press [OK] key.
- 4. Use [▲] and [▼] keys to find parameter to edit.
- 5. Press [OK] key.
- 6. Use [▲] and [▼] keys to select correct parameter setting. Or, to move to digits within a number, use keys. Cursor indicates digit selected to change. [▲] key increases the value, [▼] key decreases the value.
- 7. Press [Cancel] key to disregard change, or press [OK] key to accept change and enter new setting.

7.1.5. Changing a Text Value

If the selected parameter is a text value, change the text value by means of the up/down navigation keys.

The up key increases the value, and the down key decreases the value. Place the cursor on the value to be saved and press [OK].




Illustration 7.6: Display example.

7.1.6. Changing a Group of Numeric Data Values

If the chosen parameter represents a numeric data value, change the chosen data value by means of the <> navigation keys as well as the up/down navigation keys. Use the <> navigation keys to move the cursor horizontally.




Illustration 7.7: Display example.

Use the up/down navigation keys to change the data value. The up key` enlarges the data value, and the down key reduces the data value. Place the cursor on the value to be saved and press [OK].




Illustration 7.8: Display example.

7.1.7. Changing of Data Value, Step-by-Step

Certain parameters can be changed step by step or infinitely variably. This applies to par. 1-20 *Motor Power [kW]*, par. 1-22 *Motor Voltage* and par. 1-23 *Motor Frequency*.

The parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.



7. How to operate the frequency converter

7.1.8. Read-out and Programming of Indexed Parameters

Parameters are indexed when placed in a rolling stack.

par. 15-30 Alarm *Log: Error Code* to par. 15-32 Alarm *Log: Time* contain a fault log which can be read out. Choose a parameter, press [OK], and use the up/down navigation keys to scroll through the value log.

Use par. 3-10 Preset Reference as another example:

Choose the parameter, press [OK], and use the up/down navigation keys keys to scroll through the indexed values. To change the parameter value, select the indexed value and press [OK]. Change the value by using the up/down keys. Press [OK] to accept the new setting. Press [Cancel] to abort. Press [Back] to leave the parameter.

7.1.9. Tips and tricks

*	ķ	For the majority of water and wastewater applications the Quick Menu, Quick Setup and Function Setups provides the simplest
		and quickest access to all the typical parameters required.
		Whenever possible, performing an AMA; will ensure best shaft performance
*	ķ	Contrast of the display can be adjusted by pressing (Status) and [▲] for darker display or by pressing (Status) and (▼) for
		brighter dispaly
-1		Under [Quick Menu] and [Changes Made] all parameters that have been changed from factory settings are displayed
*	k	Press and hold [Main Menu] key for 3 seconds for access to any parameter
		For service purposes it is recommended to copy all parameters to the LCP, see par 0-50 for further information

Table 7.1: Tips and tricks

7.1.10. Quick Transfer of Parameter Settings when using GLCP

Once the set-up of a frequency converter is complete, it is recommended to store (backup) the parameter settings in the GLCPkeypad or on a PC via MCT 10 Set-up Software Tool.



NB!

Stop the motor before performing any of these operations.

Data storage in LCP:

- 1. Go to par. 0-50 LCP Copy
- 2. Press the [OK] key
- Select "All to LCP"
- 4. Press the [OK] key

All parameter settings are now stored in the GLCP indicated by the progress bar. When 100% is reached, press [OK].

The GLCP can now be connected to another frequency converter and the parameter settings copied to this frequency converter.

Data transfer from LCP to Frequency converter:

- 1. Go to par. 0-50 LCP Copy
- 2. Press the [OK] key
- 3. Select "All from LCP"
- 4. Press the [OK] key

The parameter settings stored in the GLCP are now transferred to the frequency converter indicated by the progress bar. When 100% is reached, press [OK].

7. How to operate the frequency converter



7.1.11. Initialisation to Default Settings

There are two ways to initialise the frequency converter to default: Recommended initialisation and manual initialisation. Please be aware that they have different impact according to the below description.

Recommended initialisation (via par. 14-22 Operation Mode)

- Select par. 14-22 Operation Mode
- 2. Press [OK]
- 3. Select "Initialisation" (for NLCP select "2")
- 4. Press [OK]
- 5. Remove power to unit and wait for display to turn off.
- Reconnect power and the frequency converter is reset. Note that first start-up takes a few more seconds.
- 7. Press [Reset]

par. 14-50 RFI Filt	er	
par.		*********
par.		
par. 8-32 Baud <i>Ra</i>		
par. 8-35 Minimun	Response Delay	
par. 8-36 Maximur		
par. 8-37 Maximur	n Inter-Char Delay	
par. 15-00 Operati	ng <i>Hours</i> to par. 15-05 Over <i>Volt's</i>	
par. 15-20 Historic	Log: Event to par. 15-22 Historic Log: Time	0
par. 15-30 Alarm a	.og: Error Code to par. 15-32 Alarm Log: Tir	ne



NB!

Parameters selected in par. 0-25 My Personal Menu, will stay present, with default factory setting.

Manual initialisation



NB!

When carrying out manual initialisation, serial communication, RFI filter settings and fault log settings are reset. Removes parameters selected in par. 0-25 My *Personal Menu*.

- 1. Disconnect from mains and wait until the display turns off.
- 2a. Press [Status] [Main Menu] [OK] at the same time while power up for Graphical LCP (GLCP).
- 2b. Press [Menu] while power up for LCP 101, Numerical Display
- 3. Release the keys after 5 s.
- The frequency converter is now programmed according to default settings.

This parameter initialises all except: par. 15:00.0 perating *Hours*par. 15:03 Power *Up's*par. 15:04.0ver *Temp's*par. 15:05 Over *Volt's*

7.1.12. RS-485 Bus Connection

One or more frequency converters can be connected to a controller (or master) using the RS-485 standard interface. Terminal 68 is connected to the P signal (TX+, RX+), while terminal 69 is connected to the N signal (TX-,RX-).

If more than one frequency converter is connected to a master, use parallel connections.




Illustration 7.9: Connection example.

In order to avoid potential equalizing currents in the screen, earth the cable screen via terminal 61, which is connected to the frame via an RC-link.

Bus termination

The RS-485 bus must be terminated by a resistor network at both ends. If the drive is the first or the last device in the RS-485 loop, set the switch S801 on the control card for ON.

For more information, see the paragraph Switches S201, S202, and S801.

60

MG.20.M5.02 - VLT* is a registered Danfoss trademark

7.1.13. How to Connect a PC to the frequency converter

To control or program the frequency converter from a PC, install the PC-based Configuration Tool MCT 10.

The PC is connected via a standard (host/device) USB cable, or via the RS-485 interface as shown in the Design Guide, chapter How to Install > Installation of misc. connections.



NB:

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals. The USB connection is connected to protection earth on the frequency converter. Use only isolated laptop as PC connection to the USB connector on the frequency converter.




Illustration 7.10: For control cable connections, see section on Control Terminals.

7.1.14. PC Software tools

PC-based Configuration Tool MCT 10

All Frequency converters are equipped with a serial communication port. Danfoss provides a PC tool for communication between PC and frequency converter, PC-based Configuration Tool MCT 10. Please check the section on Available Literature for detailed information on this tool.

MCT 10 Set-up Software

MCT 10 has been designed as an easy to use interactive tool for setting parameters in our frequency converters. The software can be downloaded from the Danfoss internet site http://www.Danfoss.com/BusinessAreas/DrivesSolutions/Softwaredownload/DDPC+Software+Program.htm.

The MCT 10 Set-up software will be useful for:

- Planning a communication network off-line. MCT 10 contains a complete frequency converter database
- Commissioning frequency converters on line
- Saving settings for all frequency converters
- Replacing a frequency converter in a network
- Simple and accurate documentation of frequency converter settings after commissioning.
- Expanding an existing network
- Future developed frequency converters will be supported

MCT 10 set-up software supports Profibus DP-V1 via a Master class 2 connection. It makes it possible to on line read/write parameters in a frequency converter via the Profibus network. This will eliminate the need for an extra communication network.

Save Frequency Converter Settings:

 Connect a PC to the unit via USB com port. (Note: Use a PC, which is isolated from the mains, in conjunction with the USB port. Failure to do so may damage equipment.)

7. How to operate the frequency converter Danfoss



- Open MCT 10 Set-up Software
- Choose "Read from drive"
- Choose "Save as"

All parameters are now stored in the PC.

Load Frequency Converter Settings:

- Connect a PC to the frequency converter via USB com port
- Open MCT 10 Set-up software
- Choose "Open"- stored files will be shown
- Open the appropriate file
- Choose "Write to drive"

All parameter settings are now transferred to the frequency converter.

A separate manual forMCT 10 Set-up Software is available: MG.10.Rx.yy.

The MCT 10 Set-up Software Modules

The following modules are included in the software package:



MCT Set-up 10 Software

Setting parameters

Copy to and from frequency converters

Documentation and print out of parameter settings incl. diagrams


Ext. User Interface

Preventive Maintenance Schedule Clock settings Timed Action Programming Smart Logic Controller Set-up

Ordering number:

Please order the CD containing MCT 10 Set-up Software using code number 130B1000.

MCT 10 can also be downloaded from the Danfoss Internet: WWW.DANFOSS.COM, Business Area: Motion Controls.



8. How to programme the frequency converter

8.1. How to programme

8.1.1. Parameter Set-Up

Overview of parameter groups

Group	Title	Function
0-	Operation / Display	Parameters related to the fundamental functions of the frequency converter, function of
4.5		the LCP buttons and configuration of the LCP display.
1-	Load / Motor	Parameter group for motor settings.
2->-	Brakes	Parameter group for setting brake features in the frequency converter.
3-	Reference / Ramps	Parameters for reference handling, definitions of limitations, and configuration of the re
		action of the frequency converter to changes.
4-	<u> Limits / Warnings</u>	Parameter group for configuring limits and warnings.
5-	Digital In/Out	Parameter group for configuring the digital inputs and outputs.
6-	Analog In/Out	Parameter group for configuration of the analog inputs and outputs.
8-	Communication and Options	Parameter group for configuring communications and options.
9-	Profibus	Parameter group for Profibus-specific parameters.
10-	DeviceNet Fieldbus	Parameter group for DeviceNet-specific parameters.
11-	LonWorks	Parameter_group for LonWorks parameters
13-	Smart Logic	Parameter group for Smart Logic Control
14-	Special Functions	Parameter group for configuring special frequency converter functions.
15-	Drive Information	Parameter group containing frequency converter information such as operating data
		hardware configuration and software versions.
16-	Data Readouts	Parameter, group for data read-outs, e.g. actual references, voltages, control, alarm
		warning and status words.
18-	Info and Readouts	This parameter group contains the last 10 Preventive Maintenance logs.
20-	Drive Closed Loop	This parameter group is used for configuring the closed loop PID Controller that control
1.00		the output frequency of the unit.
21-	Extended Closed Loop	Parameters for configuring the three Extended Closed Loop PID Controllers.
22-	Application Functions	These parameters monitor water applications.
23-	Time-based Functions	These parameters are for actions needed to be performed on a daily or weekly basis, e.c
		different references for working hours/non-working hours.
25-	Basic Cascade Controller Functions	
		pumps.
26-	Analog I/O Option MCB 109	Parameters for configuring the Analog I/O Option MCB 109.
27-	Extended Cascade Control	
29-	Water Application Functions	Parameters for setting water specific functions.
31-	Bypass Option	Parameters for configuring the Bypass Option

Table 8.1: Parameter Groups

Parameter descriptions and selections are displayed on the graphic (GLCP) or numeric (NLCP) in the display area. (See Section 5 for details.) Access the parameters by pressing the [Quick Menu] or [Main Menu] key on the control panel. The quick menu is used primarily for commissioning the unit at start-up by providing those parameters necessary to start operation. The main menu provides access to all parameters for detailed application programming.

All digital input/output and analog input/output terminals are multifunctional. All terminals have factory default functions suitable for the majority of water applications but if other special functions are required, they must be programmed in parameter group 5 or 6.

8.1.2. Quick Menu Mode

The GLCP provides access to all parameters listed under the Quick Menus. To set parameters using the [Quick Menu] button:

Pressing [Quick Menu] the list indicates the different areas contained in the Quick menu.

Efficient Parameter Set-up for Water Applications


The parameters can easily be set up for the vast majority of the water and wastewater applications only by using the [Quick Menu].

The optimum way to set parameters through the [Quick Menu] is by following the below steps:

- 1. Press [Quick Setup] for selecting basic motor settings, ramp times, etc.
- Press [Function Setups] for setting up the required functionality of the frequency converter if not already covered by the settings in [Quick Setup].
- Choose between General Settings, Open Loop Settings and Closed Loop Settings.

8. How to programme the frequency converter Danfoss

It is recommended to do the set-up in the order listed.



Par.	Designation	[Units]
0-01	Language	
1-20	Motor Power	[kW]
1-22	Motor Voltage	[V]
1-23	Motor Frequency	[Hz]
1-24	Motor Current	[A] ⁽ ,
1-25	Motor Nominal Speed	[RPM]
3-41	Ramp 1 Ramp up Time	[s]
3-42	Ramp 1 Ramp down Time	[s]
4-11	Motor Speed Low Limit	[RPM]
4-13	Motor Speed High Limit	[RPM]
1-29	Automatic Motor Adaptation (AMA)	

Illustration 8.1: Quick menu view.

Table 8.2: Quick Setup parameters

If No Operation is selected in terminal 27 no connection to +24 V on terminal 27 is necessary to enable start.

If Coast Inverse (factory default value) is selected in Terminal 27, a connection to +24V is necessary to enable start.

NB!

For detailed parameter descriptions, please see the following section on Commonly Used Parameters - Explanations.

8.1.3. Q1 My Personal Menu

Parameters defined by the user can be stored in Q1 My Personal Menu.

Select *My Personal Menu* to display only the parameters, which have been pre-selected and programmed as personal parameters. For example, a pump or equipment OEM may have pre-programmed these to be in My Personal Menu during factory commissioning to make on site commissioning / fine tuning simpler.. These parameters are selected in par. 0-25 *My Personal Menu*. Up to 20 different parameters can be defined in this menu.

	Q1 My Personal Menu
20-21 Setpoint 1	
20-93 PID Proport	ional Gain
20-94 PID Integra	Time

8.1.4. Q2 Quick Setup

The parameters in Q2 Quick Setup are the basic parameters which are always needed to set-up the frequency converter to operation.

Q2 Quick Setup							
Parameter number and name	salat, talai terili kalai	Unit	100000000000000000000000000000000000000	BEN IN	STARKET BOX 5	3.445.40	18.00
0-01 Language							
1-20 Motor Power		kW					
1-22 Motor Voltage		٧					
1-23 Motor Frequency	1 X X	Hz			7 1 C 2000 C	27129655	
1-24 Motor Current		Α					
1-25 Motor Nominal Speed		RPM					
3-41 Ramp 1 Ramp Up Time		S					
3-42 Ramp 1 Ramp Down Time		S			4 95	17,200	
4-11 Motor Speed Low Limit		RPM					
4-13 Motor Speed High Limit		RPM		STAGE 1.18		7 77 70 000	100
1-29 Automatic Motor Adaptation (AMA)							

8.1.5. Q3 Function Setups

The Function Setup provides quick and easy access to all parameters required for the majority of water and wastewater applications including variable torque, constant torque, pumps, dossing pumps, well pumps, booster pumps, mixer pumps, aeration blowers and other pump and fan applications. Amongst other features it also includes parameters for selecting which variables to display on the LCP, digital preset speeds, scaling of analog references, closed loop single zone and multi-zone applications and specific functions related to water and wastewater applications.

How to access Function Set-up - example




Illustration 8.2: Step 1: Turn on the frequency converter (On LED lights)




Illustration 8.3: Step 2: Press the [Quick Menus] button (Quick Menus choices appear).




Illustration 8.4: Step 3: Use the up/down navigation keys to scroll down to Function Setups. Press [OK].




Illustration 8.5: Step 4: Function Setups choices appear. Choose 03-1 General Settings. Press [OK].




Illustration 8.6: Step 5: Use the up/down navigation keys to scroll down to i.e. 03-12 *Analog Outputs*. Press [OK].




Illustration 8.7: Step 6: Choose parameter 6-50 *Terminal 42 Output*. Press [OK].




Illustration 8.8: Step 7: Use the up/down navigation keys to select between the different choices. Press [OK].



The Function Setup parameters are grouped in the following way:

Q3-10 Clock Settings	Q3-11 Display Settings	Q3-12 Analog Output	Q3-13 Relays
0-70 Set Date and Time	0-20 Display Line 1.1 Small	6-50 Terminal 42 Output	Relay 1 ⇒ 5-40 Function Relay
0-71 Date Format	0-21 Display Line 1.2 Small	6-51 Terminal 42 Output Min Scale	Relay 2 ⇒ 5-40 Function Relay:
0-72 Time Format	0-22 Display Line 1.3 Small	6-52 Terminal 42 Output Max Scale	Option relay 7 ⇒ 5-40 Function
			Relay
0-74 DST/Summertime	0-23 Display Line 2 Large		Option relay 8 ⇒ 5-40 Function Relay
0-76 DST/Summertime Start	0-24 Display Line 3 Large		Option relay 9 ⇒ 5-40 Function Relay
0-77 DST/Summertime End	0-37 Display Text 1		
	0-38 Display Text 2		
	0-39 Display Text 3		4.0 v

Q3-20 Digital Reference	Q3-21 Analog Reference
3-02 Minimum Reference	3-02 Minimum Reference
3-03 Maximum Reference	3-03 Maximum Reference
3-10 Preset Reference	6-10 Terminal 53 Low Voltage
5-13 Terminal 29 Digital Input	6-11 Terminal 53 High Voltage
5-14 Terminal 32 Digital Input	6-14 Terminal 53 Low Ref/Feedb. Value
5-15 Terminal 33 Digital Input	6-15 Terminal 53 High Ref/Feedb. Value

Q3-30 Feedback Settings	Q3-31 PID Settings
1-00 Configuration Mode	20-81 PID Normal/Inverse Control
20-12 Reference/Feedb Unit	20-82 PID Start Speed [RPM]
3-02 Minimum Reference	20-21 Setpoint 1
3-03 Maximum Reference	20-93 PID Proportional Gain
6-20 Terminal 54 Low Voltage	20-94 PID Integral Time
6-21 Terminal 54 High Voltage	
6-24 Terminal 54 Low Ref/Feedb Value	
6-25 Terminal 54 High Ref/Feedb Value	
6-00 Live Zero Timeout Time	
6-01 Live Zero Timeout Function	

8.1.6. Q5 Changes Made

Q5 Changes Made can be used for fault finding.

Select Changes made to get information about:

- the last 10 changes. Use the up/down navigation keys to scroll between the last 10 changed parameters.
- the changes made since default setting.

Select Loggings to get information about the display line read-outs. The information is shown as graphs.

Only display parameters selected in par. 0-20 and par. 0-24 can be viewed. It is possible to store up to 120 samples in the memory for later reference.

Please notice that the parameters listed in the below tables for Q5 only serve as examples as they will vary depending on the programming of the particular frequency converter.

Q5-1 Last 1	LO Changes
20-94 PID Integral Time	
20-93 PID Proportional Gain	

	Q5-3 Input Assignments
Analog In	ut 53
Analog In	ut 54

8.1.7. Q6 Loggings

Q6 Loggings can be used for fault finding.

Please notice that the parameters listed in the below table for Q6 only serve as examples as they will vary depending on the programming of the particular frequency converter.

	Q6 Loggings	
Reference	person to the second of the se	
Analog Input 53		
Motor Current		
Frequency		
eedback		
Energy Log		
Trending Cont Bin		
Trending Timed Bin Trending Compariso		
Trending Compariso	nt / 一等次經濟學	

R

8.1.8. Main Menu Mode

Both the GLCP and NLCP provide access to the main menu mode. Select the Main Menu mode by pressing the [Main Menu] key. Illustration 6.2 shows the resulting read-out, which appears on the display of the GLCP. Lines 2 through 5 on the display show a list of parameter groups which can be chosen by toggling the up and down buttons.




Illustration 8.9: Display example.

Each parameter has a name and number which remain the same regardless of the programming mode. In the Main Menu mode, the parameters are divided into groups. The first digit of the parameter number (from the left) indicates the parameter group number.

All parameters can be changed in the Main Menu. The configuration of the unit (par. 1-00 *Configuration Mode*) will determine other parameters available for programming. For example, selecting Closed Loop enables additional parameters related to closed loop operation. Option cards added to the unit enable additional parameters associated with the option device.

8.1.9. Parameter Selection

In the Main Menu mode, the parameters are divided into groups. Select a parameter group by means of the navigation keys.

The following parameter groups are accessible:

Croup no	Parameter group
Group no.	Parameter group:
1	Operation/Display
1	Load/Motor
<u>IZSSMESSES</u>	Brakes)
3	References/Ramps
14*****	Limits/Warnings
5	Digital In/Out
6:	Analog In/Out
8	Comm. and Options
9	Profibus
10	CAN Fieldbus
11	LonWorks
13	Smart Logic
14	Special Functions
15	Drive Information
16	Data Readouts
18	Data Readouts 2
20	Drive Closed Loop
21	Ext. Closed Loop
22	Application Functions
23	Time-based Functions
24	Fire Mode
25	Cascade Controller
26	Analog I/O Option MCB 109

Table 8.3: Parameter groups.



After selecting a parameter group, choose a parameter by means of the navigation keys.

The middle section on the GLCP display shows the parameter number and name as well as the selected parameter value.




Illustration 8.10: Display example.

8.2. Commonly Used Parameters - Explanations

8.2.1. Main Menu

The Main Menu includes all available parameters in the VLT® AQUA Drive FC 200 frequency converter. All parameters are grouped in a logic way with a group name indicating the function of the parameter group. All parameters are listed by name and number in the section Parameter Options in these Operating Instructions.

All parameters included in the Quick Menus (Q1, Q2, Q3, Q5 and Q6) can be found in the following.

Some of the most used parameters for VLT® AQUA Drive applications are also explained in the following section.

For a detailed explanation of all parameters, please refer to the VLT® AQUA Drive Programming Guide MG.20.0X.YY which is available on www.danfoss.com or by ordering at the local Danfoss office.

8.2.2. 0-** Operation / Display

Parameters related to the fundamental functions of the frequency converter, function of the LCP buttons and configuration of the LCP display.

O:01 [anguage 🦠	
Option	1	Function:
		Defines the language to be used in the display.
		The frequency converter can be delivered with 4 different language packages. English and German
(01 * 382	C-184	are included in all packages. English cannot be erased or manipulated. Part of Language backages 1 - 4
[0] *	English	
[1]	German	Part of Language packages 1 - 4
[2]	French	Part of Language package 1
[3]	Danish	Part of Language package 1
[4]	Spanish	Part of Language package 1
[5]	Italian	Part of Language package 1
[6]	Swedish	Part of Language package 1
[7]	Dutch	Part of Language package 1
[10]	Chinese	Language package 2
[20]	Finnish	Part of Language package 1
[22]	English US	Part of Language package 4
[27]	Greek	Part of Language package 4
[28]	Portuguese	Part of Language package 4
[36]	Slovenian	Part of Language package 3
[39]	Korean	Part of Language package 2
[40]	Japanese	Part of Language package 2
[41]	Turkish	Part of Language package 4
[42]	Traditional Chinese	Part of Language package 2
[43]	Bulgarian	Part of Language package 3
[44]	Serbian	Part of Language package 3
[45]	Romanian	Part of Language package 3
[46]	Hungarian	Part of Language package 3
[47]	Czech 乊	Part of Language package 3
[48]	Polish	Part of Language package 4
[49]	Russian	Part of Language package 3
[50]	Thai	Part of Language package 2
[51]	Bahasa Indonesian	Part of Language package 2
0±20 D	isplay Line 1-1 Small	
Option		Function:
•		Select a variable for display in line 1, left position.
[0]	None	No display value selected
[37]	Display Text 1	Present control word
[38]	Display Text 2	Enables an individual text string to be written, for display in the LCP or to be read via serial com- munication.
[39]	Display Text 3	Enables an individual text string to be written, for display in the LCP or to be read via serial communication.
[89]	Date and Time Readout	Displays the current date and time.
[953]	Profibus Warning Word	Displays Profibus communication warnings.

70

[1005]

[1006]

[1007]

Readout Receive Error Counter

Readout Bus Off Counter

MG.20.M5.02 - VLT^{dr} is a registered Danfoss trademark

View the number of CAN control receipt errors since the last power-up.

Readout Transmit Error Counter 3 View the number of CAN control transmission errors since the last power-up.

Danfoss 8. How to programme the frequency converter

[1013]	Warning Parameter	View a DeviceNet-specific warning word. One separate bit is assigned to every warning.
[1115]	LON Warning Word	Shows the LON-specific warnings.
[1117]	XIF Revision	Shows the version of the external interface file of the Neuron C chip on the LON option.
[1118]	LON Works Revision	Shows the software version of the application program of the Neuron C chip on the LON option.
[1500]	Operating Hours	View the number of running hours of the frequency converter.
[1501]	Running Hours	View the number of running hours of the motor:
[1502]	kWh Counter	View the mains power consumption in kWh.
[1500]	Gant of World	When the Control Word sent from the frequency converter via the serial communication port in hex
		code the state of
[1601] *	Reference [Unit]	Total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down) in selected
		unit.
[1602]	Reference %	Total reference (sum of digital/analog/preset/bus/freeze ref:/catch-up and slow-down) in percent.
[1603]	Status Word	Present status word
[1605]	Main Actual Value [%]	One or more warnings in a Hex code
[1609]	Custom Readout	View the user-defined readouts as defined in par. 0-30, 0-31 and 0-32.
[1610]	Power [kW]	Actual power consumed by the motor in kW.
[1611]	Power [hp]	Actual power consumed by the motor in HP.
[1612]	Motor Voltage	Voltage supplied to the motor.
[1613]	Motor Frequency	Motor frequency, i.e. the output frequency from the frequency converter in Hz.
[1614]	Motor Current	Phase current of the motor measured as effective value.
[1615]	Frequency [%]	Motor frequency, i.e. the output frequency from the frequency converter in percent.
[1616]	Torque [Nm]	Present motor load as a percentage of the rated motor torque.
[1617]	Speed [RPM]	Speed in RPM (revolutions per minute) i.e. the motor shaft speed in closed loop based on the entered
		motor nameplate data, the output frequency and the load on the frequency converter.
(\$C\$U)-	Marinina S	Thermal load on the motor, calculated by the STR function. See also parameter on a 1-95 Motor. Temperature.
[1622]	Torque [%]	Shows the actual torque produced, in percentage.
[1630]	DC Link Voltage	Intermediate circuit voltage in the frequency converter.
[1632]	BrakeEnergy/s	Present brake power transferred to an external brake resistor.
		Stated as an instantaneous value.
(9[33]	BrakeEriergy/2 min	Brake power transferred to an external brake resister. The mean power is calculated continuously for the most recent (20 seconds:
[1634]	Heatsink Temp.	Present heat sink temperature of the frequency converter. The cut-out limit is 95 ±5 oC; cutting
		back in occurs at 70 ±5° C.
[1635]	Thermal Drive Load	Percentage load of the inverters
[1636]	Inv. Nom. Current	Nominal current of the frequency converter
[1637]	Inv. Max. Current	Maximum current of the frequency converter
[1638]	SL Control State	State of the event executed by the control
[1639]	Control Card Temp.	Temperature of the control card.
[1650]	External Reference	Sum of the external reference as a percentage, i.e. the sum of analog/pulse/bus.
[1652]	Feedback [Unit]	Signal value in units from the programmed digital input(s).
[1653]	Digi Pot Reference	View the contribution of the digital potentiometer to the actual reference Feedback.
[1654]	"Feedback 1 [Unit]	View the value of Feedback 1; See also par. 20-0*.
[1655]	Feedback 2 [Unit]	View the value of Feedback 2. See also par. 20-0*.
[1656]	Feedback 3 [Unit]	View the value of Feedback 3. See also par. 20-0*.
[1660]	Digital Input	Displays the status of the 6 digital input terminals (18, 19, 27, 29, 32 and 33). Input 18 corresponds
		to the bit at the far left. Signal low = 0 ; Signal high = 1
[1661]	Terminal 53 Switch Setting	Setting of input terminal 53. Current = 0; Voltage = 1:

Actual value at input 53 either as a reference or protection value.


[1662]

Analog Input 53

8. How to programme the frequency converter Danfoss

[1663]	Terminal 54 Switch Setting	Setting of input terminal 54. Current = 0; Voltage = 1,
[1664]	Analog Input 54	Actual value at input 54 either as reference or protection value.
[3665]	Analog Output 42 (mA)	Actual value at output 4.7 in mA. Use pair, 6.50 to select the varieties to be represented by codout. 42.
[1666]	Digital Output [bin]	Binary value of all digital outputs.
[1667]	Freq. Input #29 [Hz]	Actual value of the frequency applied at terminal 29 as a pulse input:
[1668]	Freq. Input #33 [Hz]	Actual value of the frequency applied at terminal 33 as a pulse input.
[1669]	Pulse Output #27 [Hz]	Actual value of pulses applied to terminal 27 in digital output mode:
[1670]	Pulse Output #29 [Hz]	Actual value of pulses applied to terminal 29 in digital output mode.
[1671]	Relay Output [bin]	View the setting of all relays.
[1672]	Counter A	View the present value of Counter A.
[1673]	Counter B	View the present value of Counter B.
[1675]	Analog input X30/11	Actual value of the signal on input X30/11 (General Purpose I/O Card. Option)
[1676]	Analog input X30/12	Actual value of the signal on input X30/12 (General Purpose I/O Card. Optional)
[1677]	Analog output X30/8 [mA]	Actual value at output X30/8 (General Purpose I/O Card. Optional) Use Par. 6-60 to select the var-
		iable to be shown.
[1680]	Fieldbus CTW 1	Control word (CTW) received from the Bus Master.
[1682]	Fieldbus REF 1	Main reference value sent with control word via the serial communications network e.g. from the
[1684]	Comm. Option STW	BMS, PLC or other master controller. Extended: fieldbus' communication option status' word:
[1685]	FC Port CTW 1	Control word (CTW) received from the Bus Master.
[1686]	FC Port REF 1	Status word (STW) sent to the Bus Master.
[1690]	Alarm Word	One or more alarms in a Hex code (used for serial communications)
[1691]	Alarm Word 2	One or more alarms in a Hex code (used for serial communications)
	Warning Word	One or more warnings in a Hex code (used for serial communications)
[1692]	Warning Word 2	One or more warnings in a Hex code (used for serial communications)
[1694]	Ext. Status Word	One or more status conditions in a Hex code (used for serial communications)
[1695]	Ext. Status Word 2	One or more status conditions in a Hex code (used for serial communications)
[1696]	Maintenance Word	The bits reflect the status for the programmed Preventive Maintenance Events in parameter group
(-010)	The state of the s	23-1*
[1830]	Analog Input X42/1	Shows the value of the signal applied to terminal X42/1 on the Analog I/O card.
[1831]	Analog Input X42/3	Shows the value of the signal applied to terminal X42/3 on the Analog I/O card.
[1832]	Analog Input X42/5	Shows the value of the signal applied to terminal X42/5 on the Analog I/O card.
[1833]	Analog Out X42/7 [V]	Shows the value of the signal applied to terminal X42/7 on the Analog I/O card.
[1834]	Analog Out X42/9 [V]	Shows the value of the signal applied to terminal X42/9 on the Analog 1/O card.
[1835]	Analog Out X42/11 [V]	Shows the value of the signal applied to terminal X42/11 on the Analog I/O card.
[2117]	Ext. 1 Reference [Unit]	The value of the reference for extended Closed Loop Controller 1
[2118]	Ext. 1 Feedback [Unit]	The value of the feedback signal for extended Closed Loop Controller 1
[2119]	Ext. 1 Output [%]	The value of the output from extended Closed Loop Controller 1
[2137]	Ext. 2 Reference [Unit]	The value of the reference for extended Closed Loop Controller 2
[2138]	Ext. 2 Feedback [Unit]	The value of the feedback signal for extended Closed Loop Controller 2
[2139]	Ext. 2 Output [%]	The value of the output from extended Closed Loop Controller 2
[2157]	Ext. 3 Reference [Unit]	The value of the reference for extended Closed Loop Controller 3
[2158]	Ext. 3 Feedback [Unit]	The value of the feedback signal for extended Closed Loop Controller 3
[2159]	Ext. Output [%]	The value of the output from extended Closed Loop Controller 3
[2230]	No-Flow Power	The calculated No Flow Power for the actual operating speed
[2580]	Cascade Status	Status for the operation of the Cascade Controller

VLT[®] AQUA Drive Operating Instructions



[2581]

Pump Status

Status for the operation of each individual pump controlled by the Cascade Controller



NB!

Please consult the VLT² AQUA Drive Programming Guide, MG.20.0X.YY for detailed information.

Option:	Function:	
	Select a variable for display in line 1, middle position.	
[1662] * : Analog input 53. 🧳	The options are the same as those listed for par 0-20 Display Line 1.1 Small.	
0-22 Display Line 1-3	Small .	
Option:	Function:	
Optioni		
opaon.	Select a variable for display in line 1, right position.	

0-23 Display Line 2 Large

Option:

Function:

Select a variable for display in line 2. The options are the same as those listed for par. 0-20 *Display Line 1.1 Small.*

[1615] * Frequency

0:24 Display Line 3 Large

0 N/A)

Option:

Function:

[1652] * Feedback [Unit]

Select a variable for display in line 2. The options are the same as those listed for par. 0-20 *Display Line 1.1 Small.*

0-37 Display Text 1

Rail	ye.
Service Services	
0 N/A	* (0.
100	
Position	1 Vini 2000

Function:

In this parameter, it is possible to write an individual text string for display in the LCP or to be read, via serial communication. If to be displayed permanently, select Display Text 1 in par :0-20 Display Line 1.1 Small, par :0-21 Display Line 1.2 Small, par :0-22 Display Line 1.3 Small, par :0-23 Display Line 2. Large or par :0-24 Display Line 3 Large. Use the ♣'or ▼ buttons on the LCP to change a character. Use the ♠ and ♣ buttons to move the cursor. When a character is highlighted by the cursor, it can be changed. Use the ♠ or ▼ buttons on the LCP to change a character. A character can be inserted by placing the cursor between two characters and pressing ♠ or ▼

0:38 Display Text 2

Range:	Function:
0 N/A*	In this parameter, it is possible to write an individual text string for display, in the LCP or to be read
	via serial communication. If to be displayed permanently select Display Text 2 in par .0-20 Dis
	play, Line 1.1 Small, par. 0-21 Display Line 1.2 Small, par. 0-22 Display Line 1.3 Small, par
	0-23/Display/ <i>Line 2/Large</i> or par : 0-24/Display/ <i>Line 3 Large</i> Use the ♠ or ▼ buttons on the LCP to
	change a character. Use the ◀ and ► buttons to move the cursor. When a character is highlighted
	by the cursor, this character can be changed. A character can be inserted by placing the cursor
	between two characters and pressing ▲ or ▼
Market and All Washington Control of the World State	"지수는 생물에 되는 사람들이 있다고 있다. 그는 사람들이 그들이 얼마나는 사람들은 사람들은 사람들은 사람들이 사람들이 살아왔다면 하는데 사람들이 없다. 그는 사람들이 되었다면 하다

0-E9 DisplayText8 Range: **Function:** 0 N/A* In this parameter it is possible to write an individual text string for display in the LCP or to be read [0 - 0 N/A] via serial communication. If to be displayed permanently select Display Text 3 in par. 0-20 Display Line 1.1 Small,par. 0-21 Display Line 1.2 Small, par. 0-22 Display Line 1.3 Small, par. 0-23 Display Line 2 Large or par. 0-24 Display Line 3 Large. Use the ▲ or ▼ buttons on the LCP to change a character. Use the ◀ and ▶ buttons to move the cursor. When a character is highlighted by the cursor, this character can be changed. A character can be inserted by placing the cursor between two characters and pressing ▲ or ▼.

0-70 Set Date and Time

Range:

2000-01-01 [2000-01-01 00:00]

00:00 2099-12-01

23:59 *

Sets the date and time of the internal clock. The format to be used is set in par. 0-71 and 0-72.

Function:

This parameter does not display the actual time. This can be read in par. 0-89. The clock will not begin counting until a setting different from default has been

0-71 Date Format Option:	Function:	
[0] * YYYY-MM-DD	Sets the date format to be used in the LCP.	
[1] DD-MM-YYYY	Sets the date format to be used in the LCP.	
[2] MM/DD/YYYY	Sets the date format to be used in the LCP.	
0-72 Time Format		
Option:	Function:	
	Sets the time format to be used in the LCP:	22
[0] * 24 h		
[1] 12 h		\$. 5
0-74 DST/Summe		
Option:	Function:	

Option:	Function:
MATERIAL CONTRACTOR OF THE PROPERTY OF THE PRO	

Manual

0-76 DST/Summertime Start Range: **Function:**

0:N/A* [0 - 0 N/A] Sets the date and time when summertime/DST starts. The date is programmed in the format selected in par. 0-71 Date Format.

0-77 DST/Summertime End

Range:	Function:	
0 N/A* [0 - 0 N/A]	Sets the date and time when sum in par. 0-71 Date <i>Format</i> .	mertime/DST ends. The date is programmed in the format selected

8.2.3. General Settings, 1-0*

Define whether the frequency converter operates in open loop or closed loop.

74



ව <u>ෙ</u> Optio	Configuration Mode on:	Function:
Dis.	Open Lorg	Motor speed is determined by applying a speed reference or by setting desired speed when in Fland, Motor. Open Loop is also used if the frequency converter is part of a closed kep control system based on an external PID controller providing a speed reference signal as output.
[3]	Closed Loop	Motor Speed will be determined by a reference from the built-in PID controller varying the motor speed as part of a closed loop control process (e.g. constant pressure or flow). The PID controller must be configured in par. 20-** or via the Function Setups accessed by pressing the [Quick Menus] button.



NB!

This parameter cannot be changed when motor is running.




NB!

When set for Closed Loop, the commands Reversing and Start Reversing will not reverse the direction of the motor.

Range:	Function:
4.00 KW2: - [0.09=300000 KW]	Laber the number orbit power in switterarding to the motor hame place data. The later in val
	corresponds to the hominal nated output of the unit.
	corresponds to the nominal rated output of the unit. This parameter cannot be adjusted while the more is running. Depending on the choices made
	par. 0-03 Regional Settings, either par. 1-20 Motor Fower (kW) or par. 1-21 Motor Fower (NP)
	made invisible over 1

Range:	Function:
	Enter the nominal motor voltage according to the motor namegiate data. The default value of sponds to the nominal rated output of the unit.
	This parameter cannot be adjusted while the motor is running



1-22 Motor Frequency Range: Function: . Albert the relative the large selection the relative beautiful the collection of the alternative for the Alb ri Vindulus II, ales eko muerapuora lainus Esti Lais nykli etti kirikatsi kiriksi (18.18 Aleen 19.6-etti Helei und variation (CA) (Section (CA) Albania (CA)



NB!

This parameter cannot be adjusted while the motor is running.

1-24 Motor Gurrent Fiunction: Range: Publication: Localed Later Control of the C



NRI

This parameter cannot be adjusted while the motor is running.

1-25 Motor Nominal Speed

Function: Range:

1420 SPM1 (100 - 50000 GPM) Erder ("a februla mixici specificated from the this is complete date. The case signed to care Marsalones associates and



NB!

This parameter cannot be changed while the motor is running.

1+20)	Automatic Motor/Adapt	ation((AMA)
Optio		Function:
		The state of the s
[0] *	Off	No function
	Erallis conquere ama	partorne BMA of the partor resistance Rg. His potential and a security and the standard security and the main reaction of \$1. The ration entage reaction is \$1.00 the main reaction of \$2.00.
[2]	Enable reduced AMA	performs a reduced AMA of the stator resistance R_{ϵ} in the system only. Select this option if an LC

filter is used between the frequency converter and the motor.

Activate the AMA function by pressing [Hand on] after selecting [1] or [2]. See also the section Automatic Motor Adaptation, After a normal sequence, the display will read: "Press [OK] to finish AMA". After pressing the [OK] key the frequency converter is ready for operation.

Note:

- For the best adaptation of the frequency converter, run AMA on a cold motor
- AMA cannot be performed while the motor is running

76

MG.20.M5.02 - VLT^d is a registered Danfoss trademark





It is important to set motor par. 1-2* Motor Data correctly, since these form part of the AMA algorithm. An AMA must be performed to achieve optimum dynamic motor performance. It may take up to 10 min., depending on motor power rating.



NB!

Avoid generating external torque during AMA



If one of the settings in par. 1-2* Motor Data is changed, par. 1-30 Stator Resistance (Rs) to par. 1-39 Motor Poles, the advanced motor parameters, will return to default setting.

This parameter cannot be adjusted while the motor is running



Full AMA should be run without filter only while reduced AMA should be run with filter.

See section Automatic Motor Adaptation - application example.

8.2.4. 3-0* Reference Limits

Parameters for setting the reference unit, limits and ranges.

2-02 Minimum Reference

Function:

backUnit* 10 💫 🔠

0.000 Ref. [-999999.999 par. 3-03 Referent Enter the Minimum Reference. The Minimum Reference is the lowest value obtainable by summing erenceFeed-ceFeedbackUnit] all references. The Minimum Reference value and unit matches the configuration choice made in par. 1-00 Configuration Mode and par. 20-12 Reference/Feedback Unit, respectively. par 1-00 Configuration Mode and par 20-12 Reference/Feedback Unit, respectively.



NB!

This parameter is used in open loop only.

3-03 Maximum Reference

Function:

erenceFeed-ceFeedbackUnit) backUnit*

50,000 Ref. [par. 3-02. 999999,999 Referen- Enter the Maximum Reference. The Maximum Reference is the highest value obtainable by summing all references. The Maximum Reference value and unit matches the configuration choice made in par. 1-00 Configuration Mode and par. 20-12 Reference/Feedback/Unit, respectively.



NB!

This parameter is used in open loop only.

२५० विकल्पस्य विकास


Array [8]

Range:

8

Function:

0.00 %* Enter up to eight different preset references (0-7) in this parameter, using array programming. The [-100.00 - 100.00 %] preset reference is stated as a percentage of the value Reference (par. 3-03 Maximum Reference) or as a percentage of the other external references. If a Refun different from 0 (Par 3-02 Minimum Reference) is programmed, the preset reference is calculated as a percentage of the full reference range; i.e. on the basis of the difference between Remax and Remin. Afterwards, the value is added to Refun. When using preset references, select Preset ref. bit 0 / 1 / 2 [16], [17] or [18] for the corresponding digital inputs in parameter group 5.1* Digital Inputs.



3-41 Ramp1 RampUpTime

Range: **Function:**

•	
10.00 s* [1.00 - 3600.00 s]	
[10.00.5] [1.00 = 3000.00 S]	Enter the ramp-up time, i.e. the acceleration time from 0 RPM to par 1-25. Choose a ramp-up time
●社会のおおおりのでは、これは、これがある。	
	such that the output current does not exceed the current limit in par (4-18 during ramping See
12. は機能を含むし、それなどにはなる。たいではない。	The state of the s
 (1) (2) (2) (2) (3) (3) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	는 사람들은 사람들이 보다는 사람들이 마음 경우를 살아 하는 유명하다는 아니라 모든 사람들이 살아 가장하다.
[1] 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.	ramp-down time in par 3-42 Ramp I Ramp Down Time
N. 120486 T	그는 사람들에 어린다는 여자들은 하는 생활물이 하는 아이들이 모든 사람들은 사람들이 되었다면 하는 것을 되었다.
1. Straight 1983 St. 2007 St. 2006.	$[par, 3-4] = \frac{tacc \times nnorm[par, 1-25]}{(s-1)}[s]$
	- *** - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -
	ref(rpm)
P. T. A. Parking and A. P. C.	
	See drawing above
1 年 日本の登録器であるからはあります。 これを持ちず	yi - California wingwoyd is the William in a stable in a title in the Salina in the Salina in the Salina in the C

3-42 Ramp 1 Ramp Down Time

Range: **Function:**

20.00.5* [1.00 - 3600.00 s] Enter the ramp-down time, i.e. the deceleration time from par: 1-25 Motor Nominal Speed to 0 RPM Choose a ramp-down time such that no over-voltage arises in the inverter due to regenerative operation of the motor, and such that the generated current does not exceed the current limit set in par. 4-18 Current Limit. See ramp-up time in par. 3-41 Ramp 1 Ramp Up Time. par.3 - 42 tdec × nnorm [par.1 - 25][s]

ref [rpm] 👙 🚃


2:84 Initial Ramp Time

Range:

Function:

0 s* $[0 - 60 \, 5]$ Enter the initial ramp up time from zero speed to Motor Speed Low Limit, par. 4-11 or 4-12. Submersible deep well pumps can be damaged by running below minimum speed. A fast ramp time below minimum pump speed is recommended. This parameter may be applied as a fast ramp rate from zero speed to Motor Speed Low Limit.

78




3-85 Check Valve Ramp Time

Range:

0 s* [0 - 60 s]

Function:

In order to protect ball check valves in a stop situation, the check valve ramp can be utilized as a slow ramp rate from par. 4-11 Motor Speed Low Limit [RPM] or par. 4-12 Motor Speed Low Limit [Hz], to Check Valve Ramp End Speed, set by the user in par. 3-86 or par. 3-87. When par. 3-85 is $\label{thm:condition} \mbox{different from 0 seconds, the Check Valve Ramp Time is effectuated and will be used to ramp down$ the speed from Motor Speed Low Limit to the Check Valve End Speed in par. 3-86 or par. 3-87.




3-86 Check Valve Ramp End Speed [RPM]

Range:

Function:

0 [RPM]*

[0 - Motor Speed Low Limit [RPM]] Set the speed in [RPM] below Motor Speed Low Limit where the Check Valve is expected to be closed and the Check Valve no longer shall be active.



3-87 Check Valve Ramp End Speed [Hz]


Range:

Function:

0 [Hz]*

[0 - Motor Speed Low Limit [Hz]]

Set the speed in [Hz] below Motor Speed Low Limit where the Check Valve Ramp will no longer be active



3-88 Final Ramp Time

Range:

Function:


0 [s]*

[0 - 60 [s]]

Enter the Final Ramp Time to be used when ramping down from Motor Speed Low Limit, par. 4-11or 4-12, to zero speed.

MG.20.M5.02 - VLT³ is a registered Danfoss trademark

Submersible deep well pumps can be damaged by running below minimum speed. A fast ramp time below minimum pump speed is recommended. This parameter may be applied as a fast ramp rate



8.2.5. 4-** Limits and Warnings

Parameter group for configuring limits and warnings.

Range: Function: D.REM* [[0 - part 4:13 RPM]] ... Enter the minimum limit for motor speed. The Maker Speed Line (Line can be set to correspond to the manufacturer's recommended minimum motor speed. The Maker Speed Line Line time times and exceed the setting in part 4:13 Motor Speed Line (Line).

4-13 Motor Speed High Limit [RPM]

Range: Function:

1900, RPM* [par. 4-11 - 60000, RPM] Enter the maximum limit for motor speed. The Motor Speed High Limit can be set to correspond to the merufacturer's maximum rated motor. The Motor Speed High Limit must exceed the setting in par. 4-11 Motor Speed Low Limit (No. 1909). Only par. 4-11 Motor Speed Low Limit (No. 1909), or par. 4-12 Motor Speed Low Limit (No. 1909) at the displayed depending on other parameters in the Main Menu.

15 2 and depending on default settings dependant on global location.



NB!

The output frequency value of the frequency converternot exceed a value higher than 1/10 of the switching frequency.



NB!

Any changes in par. 4-13 Motor Speed High Limit [RPM] will reset the value in par. 4-53 Warning Speed High to the same value as set in par. 4-13 Motor Speed High Limit [RPM].



8.2.6. 5-** Digital In/Out

Parameter group for configuring the digital input and output.

5:01	Terminal 2	Mode)
Optio	n:	Function:
[0] *	Input	Defines terminal 27 as a digital input.
[1]	Output	Defines terminal 27 as a digital output.

This parameter cannot be adjusted while the motor is running.

8.2.7. 5-1* Digital Inputs

Parameters for configuring the input functions for the input terminals.

The digital inputs are used for selecting various functions in the frequency converter. All digital inputs can be set to the following functions:

Digital input function	Select	Terminal
No operation	- [0]	All *term 32, 33
Reset	[1]	All
Coast inverse	[2]	All
Coast and reset inverse	[3]	All
DC-brake inverse	[5]	All
Stop inverse	[6]	All
External interlock	[7]	All
Start	[8]	All *term 18
Latched start	[9]	All
Reversing	[10]	All *term 19
Start reversing	[11]	All
Jog	[14]	All *term 29
Preset reference on	[15]	All
Preset ref bit 0	[16]	Ail
Preset ref bit 1	[17]	All
Preset ref bit 2	[18]	Ail
Freeze reference	[19]	All
Freeze output	[20]	All
Speed up	-[21]	All
Speed down	[22]	All
Set-up select bit 0	[23]	All
Set-up select bit 1	[24]	All
Pulse input	[32]	te <u>m 29, 33</u>
Ramp bit 0	[34]	All
Mains failure inverse	[36]	All
Run Permissive	[52]	
Hand start	[53]	
Auto start	[54]	
DigiPot Increase	[55]	All
DigiPot Decrease	[56]	All
DigiPot Clear	[57]	All
Counter A (up)	[60]	29, 33
Counter A (down)	[61]	29, 33
Reset Counter A	[62]	All
Counter B (up)	[63]	29, 33
Counter B (down)	[64]	29, 33
Reset Counter B	[65]	All
Sleep Mode	[66]	
Reset Maintenance Word		
Lead Pump Start	[120]	
Lead Pump Alternation	[121]	
Pump 1 Interlock	[130]	
Pump 3 Interlock	[132]	
	£J	

All = Terminals 18, 19, 27, 29, 32, X30/2, X30/3, X30/4. X30/ are the terminals on MCB 101.

Functions dedicated to only one digital input are stated in the associated parameter.

All digital inputs can be programmed to these functions:

,		
[0]	No operation	No reaction to signals transmitted to terminal.
[1]	Reset	Resets frequency converter after a TRIP/ALARM. Not all alarms can be reset.
[2]	Coast inverse	Leaves motor in free mode. Logic '0' => coasting stop. (Default Digital input 27): Coasting stop, inverted input (NC).
[3]	Coast and reset inverse	Reset and coasting stop Inverted input (NC). Leaves motor in free mode and resets the frequency converter. Logic '0' => coasting stop and reset.
[5]	DC-brake inverse	Inverted input for DC braking (NC). Stops motor by energizing it with a DC current for a certain time period. See par. 2-01 to par. 2-03. The function is only active when the value in par. 2-02 is different from 0. Logic '0' => DC braking.
[6]	Stop inverse	Stop Inverted function. Generates a stop function when the selected terminal goes from logical level '1' to '0'. The stop is performed according to the selected ramp time (par. 3-42, par. 3-52, par. 3-62, par. 3-72).
		When the frequency converter is at the torque limit and has received a stop command, it may not stop by itself. To ensure that the frequency converter stops, configure a digital output to <i>Torque limit & stop</i> [27] and connect this digital output to a digital input that is configured as coast.
[7]	External Interlock	Same function as Coasting stop, inverse, but External Interlock generates the alarm message 'external fault' on the display when the terminal which is programmed for Coast Inverse is logic '0'. The alarm message will also be active via digital outputs and relay outputs, if programmed for External Interlock. The alarm can be reset using a digital input or the [RESET] key if the cause for the External Interlock has been removed. A delay can be programmed in par. 22-00, External Interlock Time. After applying a signal to the input, the reaction described above will be delayed with the time set in par. 22-00.
[8]	Start	Select start for a start/stop command. Logic `1' = start, logic `0' = stop. (Default Digital input 18)
[9]	Latched start	Motor starts, if a pulse is applied for min. 2 ms. Motor stops when Stop inverse is activated
[10]	Reversing	Changes direction of motor shaft rotation. Select Logic '1' to reverse. The reversing signal only
		changes the direction of rotation. It does not activate the start function. Select both directions in
		par. 4-10 Motor Speed Direction.
		(Default Digital input 19).
[11]	Start reversing	Used for start/stop and for reversing on the same wire. Signals on start are not allowed at the same time.
[14]	Jog	Used for activating jog speed. See par. 3-11.
[V2.22.1.3%]		(Default Digital input 29)
[15]	Preset reference on	Used for shifting between external reference and preset reference. It is assumed that External/ preset [1] has been selected in par. 3-04. Logic '0' = external reference active; logic '1' = one of the eight preset references is active.
[16]	Preset ref bit 0	Enables a choice between one of the eight preset references according to the table below.
[17]	Preset ref bit 1	Enables a choice between one of the eight preset references according to the table below.
[18]	Preset ref bit 2	Enables a choice between one of the eight preset references according to the table below.
		Preset ref. bit 2 1 0 Preset ref. 0 0 0 0 Preset ref. 1 0 0 1 Preset ref. 2 0 1 0 Preset ref. 3 0 1 1 Preset ref. 4 1 0 0 Preset ref. 5 1 0 1 Preset ref. 66 1 1 0 Preset ref. 7 1 1 1

82

[19]

Freeze ref

MG.20.M5.02 - $\text{VLT}^{\&}$ is a registered Danfoss trademark

(par. 3-51 and 3-52) in the range 0 - par. 3-03 Maximum Reference.

Freezes actual reference. The frozen reference is now the point of enable/condition for Speed up

and Speed down to be used. If Speed up/down is used, the speed change always follows ramp 2

Danfoss 8. How to programme the frequency converter

[20] Freeze output Freezes actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, the speed change always follows ramp 2 (par. 3-51 and 3-52) in the range 0 - par. 1-23 Motor Frequency.



NB!

When Freeze output is active, the frequency converter cannot be stopped via a

		low 'start [13]' signal. Stop the frequency converter via a terminal programmed for Coasting inverse [2] or Coast and reset, inverse [3].
	- Speed up	For digital control of the apploace speed is desired (motor potentioneter). Activate this function by selecting either France enterance or Franzisch which Speed up is activated for less than 400 mises the resulting reference will be increased by 0.11%. If Speed up is activated for more than 400 mises the resulting reference will ramp according to kamp 1 imper; 3.41.
[22]	Speed down	Same as Speed up [21].
[23]	Set-up select bit 0	Selects one of the four-set-ups. Set par. 0-10 Active Set-up to Multi Set-up.
[24]	Set-up select bit 1	Same as Set-up select bit 0 [23]. (Default Digital input 32)
[[[]]	Publication (1)	Select Pubs input when using a pulse sequence as either reference or feedback. Scaling is done in part group \$-3.5.
[34]	Ramp bit 0	Select which ramp to use. Logic "0" will select ramp 1 while logic "1" will select ramp 2.
[36]	Mains failure Inverse	Activates par: 14-10 Mains Failure. Mains failure inverse is active in the Logic "0" situation.
[52]	Run Permissive	The input terminal, for which the Run permissive has been programmed must be logic "1" before a start command can be accepted. Run permissive has a logic 'AND' function related to the terminal which is programmed for START [8], Jog [14] or Freeze Output [20], which means that in order to start running the motor, both conditions must be fulfilled. If Run Permissive is programmed on multiple terminals, Run permissive needs only be logic '1' on one of the terminals for the function to be carried out. The digital output signal for Run Request (Start [8], Jog [14] or Freeze output [20]) programmed in par. 5-3* Digital outputs, or par. 5-4* Relays, will not be affected by Run Permissive.
		has been pressed and a normal stop command will be described. If disconnecting the agrief the mistor will stop. To make any other start Commands valid, another digital input thest be assign to Auto Start and a signal applied to this. The revolution and Auto Contactions on the LCP has no impact. The Ciffoutton on the LCP will overnote wavefactor and Auto Start Press either the Warra Caror Auto Carbutton to make revolutionard and Auto Start either eights if in signal or neether March Start nor Auto Start, the moster will stop regardless of any normal Start command applied. If signal applied to both Macof Start and Auto Start, the function will be Auto Start. If pressing the Officeton on the LCP, the moster will stop regardless of signals on Month Start and Auto Start.
[54]	Auto start	A signal applied will put the frequency converter into Auto mode as if the LCP button <i>Auto On</i> has been pressed. See also <i>Hand Start</i> [53]
EXIL	(Support Income)	. Oses te a proses in INSO-PASE, sons holt arbigs. Por recommendation is referenced in serior elements. greup 3.95.
[56]	DigiPot Decrease ·	Uses the input as a DECREASE signal to the Digital Potentiometer function described in parameter group 3-9*
[57]	DigiPot Clear	Uses the input to CLEAR the Digital Potentiometer reference described in parameter group 3-9*
[60]	Counter A (up)	(Terminal 29 or 33 only) Input for increment counting in the SLC counter.
[61]	Counter A (down)	(Terminal 29 or 33 only) Input for decrement counting in the SLC counter.
[62]	Reset Counter A	Input for reset of counter A.
-[63]	Counter B (up)	(Terminal 29 and 33 only) Input for increment counting in the SLG counter.
[64]	Counter B (down)	(Terminal 29 and 33 only) Input for decrement counting in the SLC counter.
[65]	Reset Counter B	Input for reset of counter B.
[66]	Sleep Mode	Forces frequency converter into Sleep Mode (see par. 22-4*, Sleep Mode). Reacts on the rising edge of signal applied!
[78]	Reset Preventive Maintenance Wor	Resets all data in par, 16-96, Preventive Maintenance Word, to 0.

The below setting options are all related to the Cascade Controller. Wiring diagrams and settings for parameter, see group 25-** for more details.

[170]	Load Pump Start	Starts/Stops the Lead Pump (controlled by the frequency converter). A start requires that also a System Start agnel has been applied e.g. to one of the digital inputs set for Start [8]):						
[121]	Lead Pump Alternation	must be set to either At Con	Forces alternation of the lead pump in a Cascade Controller. Lead Pump Alternation, par. 25-50 must be set to either At Command [2] or At Staging or At Command [3]. Alternation Event, par 25-51, can be set to any of the four options.					
	30] Pump 1 Indertock Pump 9 (etc.	will also depend on the settin to the pump controlled by ** by the frequency converter or	g in per 125-56, Fleed Lead Pum _{ey} RELAY Letc. If ser to Yes [1], ly (without any of the build envel	must be set to (W [] The function p. if set to Ad [0], then Pumplinete Pumplineters to the journp controll dos involved) and Pumplinete pur annot be intersicked in the basic Ca				
		Service in 1957 5174	, Setting In Part 25-06	Nive:				
	18.00 g	[130] Pump1 Interlock	Controlled by RELAY1 (only if his leed gump)	Frequency, Converter control- led				
		[131] Pump2 Interiors [132] Pump3 Interiors	Controlled by RELAYS Gontrolled by RELAYS	(cannot be interbooked) Controlled by RELAY1 Controlled by RELAY2				
		[133] Pump4 Interiods [134] Pump5 Interiods [135] Pump6 Interiods	Controlled by RELAYS Controlled by RELAYS Controlled by RELAYS	Controlled by RELAY1 Controlled by RELAY1 Controlled by RELAY5				

11000	100000000000000000000000000000000000000	Term			 2.0	W000000000
33 - 46	C 10 100		100	· Y · M · Y	 14.	
20 m	1000		111111111111111111111111111111111111111	* A	 27 4 2	31 7 F G

Function: Option:

[0] *	No Operation	Same options and functions as par. 5-1* Digital Inputs.
5-14	Terminal 32 Digital Inp	uC .
Option) :	Function:
[0] *	No operation	Same options and functions as par. 5-1*, except for <i>Pulse input</i> .
[1]	Reset	
[2]	Coast inverse	
[3]	Coast and reset inv	
[5]	DC-brake inverse	
[6]	Stop inverse	
[7]	External interlock	
[8]	Start	
[9]	Latched start	
[10]	Reversing	
[11]	Start reversing	
[14]	Jog	
[15]	Preset reference on	
[16]	Preset ref bit 0	
[17]	Preset ref bit 1	
[18]	Preset ref bit 2	



	Freeze output
[21]	
	Speed up
[22]	Speed down
[23]	Set-up select bit 0
[24]	Set-up select bit 1
[34]	Ramp bit 0
[36]	Mains failure inverse Fire Mode
[52]	Run permissive
[53]	Hand start
[54]	Auto start
[55]	DigiPot increase
[56]	DigiPot decrease
[57]	DigiPot clear
[62] [65]	Reset Counter B
[66]	Sleep Mode
[78]	Reset Maint. Word
[120]	Lead Pump Start
[121]	Lead Pump Alternation
[130]	Pump 1 Interlock
[131]	Pump 2 Interlock
[132]	Pump 3 Interlock
Roman Administration of the Control	arminal 33 Digital Input
Option:	Function:
[0].*	No operation 🚓 Same options and functions as par. 5-1* Digital Inputs. 🔑
[1]	Reset
[2]/	Coast inverse Coast and reset inv
[5]	DC-brake inverse
[6]	Stop inverse
[7]	External interlock
[8]	Start
E-ii	
0.0000000000000000000000000000000000000	
K	
	Preset-reference on
[16]	Preset ref bit 0
[17]	Preset ref bit 1
[18]	Preset ref bit 2
[19]	
[20]	Freeze output Speed up
[21]	
[8] [9]: [10] [14] [14] [15] [16] [17] [18]	Start Latched start Reversing Start reversing Jog Preset reference on Preset ref bit 0 Preset ref bit 1



[23]	Set-up select bit 0							:_ /	2.00	
[24]	Set-up select bit 1									
[30]	Counter input			(Q.e.s.		Wit.	266			
[32]	Pulse input	, , , , , , , , , , , , , , , , , , , 								
[34]	Ramp bit 0									
[36]	Mains failure invers	е								WV 10.7 ARREST
[37]	Fire Mode									
[52]	Run permissive							· • • • • • • • • • • • • • • • • • • •		
[53]	Hand start	2.20					10 mg.	* * * * * * * * * * * * * * * * * * * *	<u> </u>	1044
[54]	Auto start		~	- xx(\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\			XXV-000007 X			
[55]	DigiPot increase								ă, î,	
[56]	DigiPot decrease	Sessa energy C .c.							17.2.9 98.87	
[57]	DigiPot dear									913 (0)
[60]	Counter A (up)		7 7 7 7 7 7 7 7							
[61]	Counter A (down):	3 S. M								
[62]	Reset Counter A				2	5072000000				300.44
[63]	Counter B (up)							. A		
[64]	Counter B (down)			Park Salah				***		7 3 7 7 3 3 3 3 3 3 3 3 3
[65]	Reset Counter B									
[66]	Sleep Mode				975.5085. 3		7000 CONSTITUTE	. //	- 	72.0
[78]	Reset Maint, Word			11000				107	1.1.7.3.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2	
[120]	Lead Pump Start		90.380.00 X 5 13		20° S.					
[121]	Lead Pump Alternat	ion			7.255		N-51'-		. Jev 38. 1	
[130]	Pump 1 Interlock									
[131]	Pump 2 Interlock			<u>=)</u>						
[132]	Pump 3 Interlock									
5 - 800 TC	rminal 27 Dig	ital Outp	ıΩ.				ä			8
Option:			Funct	ion:	·		····			
[0] *	No operation		Same op	otions and fu	nctions as pa	г. 5-3*.				
[1]	Control ready									
[2]	Drive ready									
[3]	Drive rdy/rem ctrl									
[4]	Standby / no wamii	ng								
[5]	Running									
[6]	Running / no warni	ng								
[8]	Run on ref/no warn	l								
[9]	Alarm									
[10]	Alarm or warning									
[11]	At torque limit									
[12]	Out of current rang	е								
[13]	Below current, low									
[14]	Above current, high	1								
[15]	Out of speed range		2.00		14.					. 3
[16]	Below speed, low					,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				
[17]	Above speed, high									a e i

86

[18]

Out of feedb. range

Danfoss 8. How to programme the frequency converter

[19] Below feedback, low
[20] Above feedback, high
[21] Thermal warning [25] Reverse
[26]: Bus OK.
[27] Torque limit & stop
[28] Brake, no brake war [29] Brake ready, no fault
[29] Brake ready, no fault [30] Brake fault (IGBT)
[35] External Interlock
[40] Out of ref range
[41] Below reference, low [42] Above ref, high
[45] Bus ctrl.
[46] Busictri, 1.if timeout
[47] Bus ctrl, 0 if timeout [55] Pulse output
[60] Comparator 0
[61] Comparator 1:
[62] Comparator 2 [63] Comparator 3
[64] Comparator 4
[65] Comparator 5
[70] Logic rule 0
[71] Logic rule 2
[73] Logic rule 3
[74] Logic rule 4
[75]: Logic rule 5. [80] SL digital output A
[81]. SL digital output B
[82] SL digital output C
[83] SL digital output D [84] SL digital output E
[85] SL digital output F
[160] No alarm
[161] Running reverse
[165] Local ref active [166] Remote ref active
[167] Start command act.
[168] Hand mode
[169] Auto mode [180] Clocki Fault
[181] Prev. Maintenance
[190] No-Flow
[191] Dry Pump [192] End Of Curve

[193]	Sleep Mode
[194]	Broken Belt
[195]	Bypass Valve Control
[196]	Fire Mode _x
[197]	Fire Mode was Act.
[198]	Drive Bypass
[200]	Full capacity
52013	

5-40 Function Relay

[203] Pump 3 running

Pump 2 running

[202]

Array [8] (Relay 1 [0], Relay 2 [1], Relay 7 [6], Relay 8 [7], Relay 9 [8])


Select options to define the function of the relays.

The selection of each mechanical relay is realised in an array parameter.

[0]	No Operation:
[1]	Control Ready
[2]	Drive Ready.
[3]	Drive Ready/Remote
[4]	Stand-by/No Warning
[5] *	Running
[6]	Running/No:Warning
[8]	Run on Ref./No Warning
[9]	Alarm
[10]	Alarm or Warning
[11]	At Torque Limit
[12]	Out of Current Range
[13]	Below Current, low
[14]	Above Current, high
[15]	Out of Speed Range
[16]	Below Speed, low
[17]	Above Speed, high
[18]	Out of Feedb. Range
[19]	Below Feedback, low
[20]	Above Feedback, high
[21]	Thermal Warning
[25]	Reverse
[26]	Bus OK
[27]	Torque Limit & Stop
[28]	Brake; No Warning
[29]	Brake Ready, No Fault
[30]	Brake(Fault (IGBT)
[35]	External Interlock
[36]	Control Word Bit 11
[37]	Control Word Bit 12

88

[40]	Out of Ref- Range
[41]	Below Reference, low
[42]	Above Ref. high
[45]	Bus ctrl
[46]	Bus ctrl, 1 if timeout
[47]	Bus ctrl, 0 if timeout
[60]	Comparator 0
[61]	Comparator 1
[62]	Comparator 2
[63]	Comparator 3
[64]	Comparator 4
[65]	Comparator 5
[70]	Logic Rule 0
[71]	Logic Rule 1
[72]	Logic Rule 2
[73] [74]	Logic Rule 3 Logic Rule 4
[75]	Logic Rule 5
[80]	SL Digital Output A
[81]	SL Digital Output B
[82]	SL Digital Output C
[83]	SL Digital Output D
[84]	SL Digital Output E
[85]	SL Digital Output F
[160]	No Alarm
[161]	Running Reverse
[165]	Local Ref. Active
[166]	Remote Ref. Active
[167]	Start Cmd : Active
[168]	Drive in Hand Mode
[169]	Drive in Auto Mode
[180]	Clock Fault Prev. Maintenance
[181] [190]	No-Flow
[191]	Dry Pump
[192]	End of Curve
[193]	Sleep Mode
[194]	Broken Belt
[195]	Bypass Valve Control
[199]	Pipe Filling
[211]	Cascade Pump1
[212]	Cascade Pump2
[213]	Cascade Pump3
[223]	Alarm, Trip Locked
[224]	Bypass Mode Active



5-53 Term. 29 High Ref./Feedb. Value Range: Function: 100,000 N/ [[-99999] 999 - 999999 999 N/A]. Enter the high reference value (RPM) for the motor shaft speed and the high feedback value (see also par 5:58 Term: 33 High Ref /Feedb. Value

8.2.8. 6-** Analog In/Out

Parameter group for configuration of the analog input and output.

6-00 Live Zero Time Range:	- Function:
	and the state of the control of the
	ation and ingress or assessment with the Arthrodic John State State of the Arthrodic State
	e jage de of Christian III (our restable jage de fi Tagracial III), aus Colony que la gréface que
	And Madelphane part (C.) Commission (A.) and Commission (Commission and Commission (C.) and Andrews (C.). Commission (C.) and
	ing partition and the second come for boundary under the partition of the common for the common for the common
-01 Live Zero Time	out Function *
rtien:	Figure 1
	and the state of t
	and the sea part of the sea of th
	Committee Commit

Committee (Lat. 1. 1. 1.)	#	bi ti	
		A.	
		,,,	ur III.
			1 1 1940 AND STREET


Stop

Jogging

[2]

[3]

Stop and trip [5]



6-10 Terminal 53 Low Voltage

Range:

Function:

(0.07 v^{a.} [0.00 par 6])) V] Enterthe low voltage value. This analog could stain give be excelled correspond to the low reference, a life chart value set in par 6-14 Terminal 53 Cow Rev. /Termin Rev. /Terminal 53 Cow Rev. /Terminal 53 Com Rev. /Terminal 54 Com Rev. /Terminal 54 Com Rev. /Terminal 55 Com Re

6-11 Terminal 53 High Voltage

Range:

Function:

10.00 V* 1. [per 6.10: 10.00 V] Enter the high voltage value. The analog equit is along value strouble correspond to the high reference. The analog equit is along value strouble of 15.7emmin 53 High Ant√Report, Maker.

6-14 Terminal 53 Low Ref./Feedb. Value

Range:

Function:

0.000 N/AP - (1.999991.999 - 9919991.999 N/A) ... Error the analog input scaling value that corresponds to the low voltage/low current set in particular to the low current.

6-10 Ferminal 50 Low voltage and particular ferminal 50 Low current.

6-15 Terminal 53 High Ref./Feedb. Value

Range:

Function:

50,000 N/ [1999999-999-99999999999] Enter the analog inplit scaling value that corresponds to the high voltage/high current value set in part 6-11 Terminal 53 Mg/ Voltage and part 6-13 Terminal 53 Mg/ Current.

6-20 Terminal 54 Low Voltage

Range:

Function:

(0.07 VF [0.00 - par. 6-21 V] Enter the low voltage value. This analog input scaling value should correspond to the low reference,

redback value, set in par. 6:24 (emission Set Com Ref. / Fends. (Setue)

6-21 Terminal 54 High Voltage

Range:

Function:

10:00 V1 (par. 6520 - 10:00 V). The Inter the high voltage value This analog imput scaling value should correspond to the high reference of the high refer

6-24 Terminal 54 Low Ref./Feedb. Value

Range:

Function:

0.000 N/A* [-979999 999 - 999999 999 N/A] Enter the arrang input scaling value that corresponds to the low ochacle to a current value set in par. 6-20 Formius/ 54 Low Rolling and par. 5-22 Termical 5-4 Low Current

6-25 Terminal 54 High Ref./Feedb. Value **Function:** Range: Enter the analog input scaling value that corresponds to the high voltage high current value set in bar: 5-21. Terminar 54 High: Voltage and part 6-23 Terminal, 54 High Correct 6-50 Terminal 42 Output Option: **Function:** Select the function of Terminal 42 as an analog current output [0] *No operation Output freq. 0-100 0 - 100 Hz [100] [101] Reference Min-Max : Minimum reference - Maximum reference [102] Feedback +-200% -200% to +200% of par. 2-14 [103] Motor cur. 0-Imax : 0 - Inverter Max. Current (par. 16-37) [104] Torque 0-Tlim : 0 - Torque limit (par. 4-16) Torque 0-Tnom F1051 : 0 - Motor rated torque [106] Power 0-Pnom : 0 - Motor rated power [107] Speed 0-HighLim : 0 - Speed High Limit (par. 4-13 and par. 4-14) [113] Ext. Closed Loop 1 0 - 100% [114] Ext. Closed Loop 2 0 - 100% [115] Ext. Closed Loop 3 0 - 100% [130] Out frq 0-100 4-20mA :0 - 100 Hz [131] Reference 4-20mA Minimum Reference - Maximum Reference Feedback 4-20mA -200% to +200% of par. 2-14 [132] 0 - Inverter Max, Current (par. 16-37 Inv. Max. Current) [133] Motor cur. 4-20mA [134] Torq.0-lim 4-20 mA :0 - Torque limit (par. 4-16) Torq.0-nom 4-20mA :0 - Motor rated torque [135] [136] Power 4-20mA [137] Speed 4-20mA 0 - Speed High Limit (par. 4-13 and par. 4-14) [139] Bus ctrl. 0 - 100% Bus ctrl. 4-20 mA 0 - 100% [140] 0 - 100% [141] Bus ctrl t.o. [142] Bus ctrl t.o. 4-20mA 0 - 100% [143] Ext. CL 1 4-20mA 0 - 100% [144] Ext. CL 2 4-20mA 0 - 100%


NB!

[145]

Ext. CL 3 4-20mA

Values for setting the Minimum Reference is found in par. 3-02 Minimum Reference and par. 20-13 Minimum Reference/Feedb. - values for Maximum Reference is found in par. 3-03 Maximum Reference and par. 20-14 Maximum Reference/Feedb..

0 - 100%




EXAMPLE 1:

Variable value= OUTPUT FREQUENCY, range = 0-100 Hz

Range needed for output = 0-50 Hz

Output signal 0 or 4 mA is needed at 0 Hz (0% of range) - set par. 6-51 *Terminal 42 Output Min Scale* to 0% Output signal 20 mA is needed at 50 Hz (50% of range) - set par. 6-52 *Terminal 42 Output Max Scale* to 50%




EXAMPLE 2:

Variable≈ FEEDBACK, range= -200% to +200%

Range needed for output= 0-100%

Output signal 0 or 4 mA is needed at 0% (50% of range) - set par. 6-51 *Terminal 42 Output Min Scale* to 50% Output signal 20 mA is needed at 100% (75% of range) - set par. 6-52 *Terminal 42 Output Max Scale* to 75%



EXAMPLE 3:


Variable value= REFERENCE, range= Min ref - Max ref

Range needed for output= Min ref (0%) - Max ref (100%), 0-10 mA

Output signal 0 or 4 mA is needed at Min ref - set par. 6-51 Terminal 42 Output Min Scale to 0%

Output signal 10 mA is needed at Max ref (100% of range) - set par. 6-52 Terminal 42 Output Max Scale to 200%

(20 mA / 10 mA x 100%=200%).



8.2.9. Drive Closed Loop, 20-**

This parameter group is used for configuring the closed loop PID Controller, that controls the output frequency of the frequency converter.

20:12	Referen	oce/Feedback/Unit
Option	1:	Function:
[0]	None	
[1] *	%	是一个人,一个是一个人的大型的一个人。
[5]	PPM	
[10]	1/min	
[11]	RPM	
[12]	Pulse/s	
[20]	l/s	
[21]	l/min	
[22]	l/h	
[23]	m³/s	
[24]	m³/min	
[25]	m³/h	

94

[30]	kg/s
[31]	kg/min ()
[32]	kg/h
[33]	t/min:
[34]	t/h
[40]	m/s
[41]	m/min
[45]	
[60]	°C
[70]	mbar .
[71]	bar
[72]	Pa LOa
[73] [74]	kPa m,WG
[75]	mm Hg
[80]	kW
[120]	GPM
[121]	gal/s
[122]	gal/min
[123]	gal/h
[124]	CFM
[125]	ft ³ /s
[126]	ft ³ /min
[127] -	€3/h
[130]	lb/s
[131]	lb/min b
[132]	lb/h
[140]	ft/s ·
[141]	ft/min
[145]	nt of the second of the secon
[160] [170]	psi
[171]	lb/in ²
[172]	in WG
[173]	ft WG
[174]	in Hg
[180]	HP This parameter determines the unit that is used for the setpoint reference and feedback that the
	PID Controller will use for controlling the output frequency of the frequency converter.
20-21	Setpoint(1
Range	Function:
n na ek	
erafiili. He	exoChildret) converteers PID Controller. See the description of par. 20-20 Feedback Assector.

20-81 PID Normal/Inverse Control Option: **Function:** [0] * Normal Normal [0] causes the frequency converter's output frequency to decrease when the feedback is greater than the setpoint reference. This is common for pressure-controlled supply familing put oppositions (inverse [1] causes, the frequency converter's output frequency, to proceed (inverse [1] causes and inverse [1] causes are selected as a selec

20-82 PID Start Speed [RPM]

Function: Range: When the frequency converter is first started, it initially ramps up to this output speed in Open Loop Mode, following the active Ramp Up Time. Which the cultival speed programmed here is reached, the frequency converter will automatically switch to Closed Loop Mode and the PIC Colomber wil begin to function. This is useful in applications in which the driven load must first quickly accelerate to a minimum speed when it is started. Nat .

20-93 PID Proportional Gain


Range:	Function:
	When the difference between the feedback and the setpoint reference is less than the value of this
	parameter, the frequency converters display will show "Run on Reference". This status can be
	communicated externally by programming the function of a digital outsuffor Aurior Anterexts/No
	್ತು Warning [8] In addition, for serial communications, the On Reference status bit of the frequency
	Contraction's Status Word will be high (L)
	The CN Reference Sandwellins calculated as a percentage of the saftpoint reference

20-94 PID Integral Time

Range:	Function:
P01083 (600):0000	O sije. The pring alto adds over time (integration) the error between the feedback and the sergoint refer-
	ence. This is required to ensure that the error approaches zero. Quick frequency conventor speed adjustment is obtained when this value is small. However, if too small of a value is used, the frequency may become unstable.
	adjustment is obtained when this value is small. However, if too small of a value is used, the fre-
	quency converter's output frequency may become unstable.

8.2.10. 22-** Miscellaneous

This group contains parameters used for monitoring water/ wastewater applications.



Option: Function: When set for Enabled, an auto set up sequence is activated, automatically setting speed to approx. 50 and 85% of rated motor speed (par. 4-13 Motor Speed High Limit [RPM], par. 4-14 Motor Speed High Limit [Hz]). At those two speeds, the power consumption is automatically measured and stored. Before enabling Auto Set Up: 1. Close valve(s) in order to create a no flow condition 2. The frequency converter must be set for Open Loop (par. 1-00 Configuration Mode). Note that it is important also to set par. 1-03 Torque Characteristics. [0] * Off [1] Enabled



NB!

Auto Set Up must be done when the system has reached normal operating temperature!



NB!

It is important that the par. 4-13 Motor Speed High Limit [RPM] or par. 4-14 Motor Speed High Limit [Hz] is set to the max. operational speed of the motor!

It is important to do the Auto Set-up before configuring the integrated PI Contoller as settings will be reset when changing from Closed to Open Loop in par. 1-00 *Configuration Mode*.



NB!

Carry out the tuning with the same settings in par. 1-03 Torque Characteristics, as for operation after the tuning.

22-21	Low Power Detection			
Option:		Function:		
[0] *	Disabled			
[1]	Enabled	If selecting Enabled, the Low Power Detection commissioning must be carried out in order to set the parameters in group 22-3* for proper operation!		
22-22	Low Speed Detection			
Option		Function:		
[0] *	Disabled .			
[1]	Enabled	Select Enabled for detecting when the motor operates with a speed as set in par. 4-11 Motor Speed Low Limit [RPM] or par. 4-12 Motor Speed Low Limit [Hz].		
222-228	No-Flow Function			
Option:		Function:		
		Common actions for Low Power Detection and Low Speed Detection (Individual selections not possible).		
[0] *	Off			
[1]	Sleep Mode			
[2]	Warning	Messages in the Local Control Panel display (if mounted) and/or signal via a relay or a digital output.		
[3]	Alarm	The frequency converter trips and motor stays stopped untilireset.		

Page 102 of 333

22:23	No-Flow Del	57 7
Range:		
10 c*	[1 - 600°c]	

Function: Set the time Low Power/Low Speed must stay detected to activate signal for actions. If detection disappears before run out of the timer, the timer will be reset:

22-26 Div/Pumplametion

Option	n:	Function:
		Low Power Detection must be Enabled (par. 22-21/Low Power Detection) and commissioned (using either par. 22-3*, No Flow Power Tuning, or par. 22-20 Low Power Auto Set-up) in order to use Dry Pump Detection:
[0] *	Off	
[1]	Warning	Messages in the Local Control Panel display (if mounted) and/or signal via a relay or a digital output.
[2]	Alarm	The frequency converter trips and motor stays stopped until reset.

22-27 Dry Rump Delay

Range:	Function:	
10°s* [0 - 600's]	Defines for how long	the Dry Pump condition must be active before activating Warning or Alarm

22-30 No-Flow Power

Range:	Function:
0.00 kW* [0.00 - 0.00 kW]	Read out of calculated No Flow power at actual speed. If power drops to the display value the
	frequency converter will consider the condition as a No Flow situation.

22-31 Power Correction Factor

Range:	Function:
100 %* [1 - 40	00 %] Make corrections to the calculated power at par. 22-30 No-Flow Power.
	If No Flow is detected, when it should not be detected, the setting should be decreased. However,
	if No Flow is not detected, when it should be detected, the setting should be increased to above
	= 100%.

22-32 Low Speed [RPM]

Range:	Function:	
0 RPM* [0 - par. 22-3	5 RPM] To be used if par. 0-02 Motor <i>Speed Unit</i> has been set for R Set used speed for the 50% level: This function is used for storing values needed to tune No	

22-33 Low/Speed [Hz]

Range:	Function:	
0 Hz* [0.0 - p	To be used if par. 0-02 Motor. Speed Unit has been set for Hz (parameter not visible if Set used speed for the 50% level. The function is used for storing values needed to tune No Flow Detection.	RPM selected).

Range:	Function:
0 kW* [0.00 - 0.00 k	To be used if par. 0-03 Regional <i>Settings</i> has been set for International (parameter not visible it
	North America selected).
	Set power consumption at 50% speed level.
	This function is used for storing values needed to tune No Flow Detection.
	mistarcion is used for storing values needed to tune to jow betterion.

98

r	•
ľ	٠

22:35 Low Speed Power [HP]	. · · · · · · · · · · · · · · · · · · ·
Range:	Function:
22-36 High Speed [RPM]	
Range:	Function:
222:37/ High Speed [H2]	
Range:	Function:
	. The section of the Research and section in the medical temperature and the section of the sect
22-38 High Speed Power [kW]	
Flarriger:	Furster:
i marini di	Produce to the contract of the second
	Selection (Company of Strategy of Strategy) Selection (Selection of Strategy) Selection (Company of Selection of Strategy)
22-39 High Speed Power [HP]	
fame:	Function:
22-40 Minimum Run Time	
Europe:	Paractical
	The first of the state of the s
22-41 Minimum Sleep Time Range:	Function:
10's* [0:600's]:	Set the desired minimum time for staying in Sleep Mode. This will override any wake up conditions:
22-42 Wake-up Speed [RPM]	
#22-42% wake-up Speed [RPM]	Function:
	The Control of the Co
	Even who is the com-



22-43 Wake-up Speed [Hz]

Range:

Function:

O Hz* (par 4 12 - par 4 14 Hz) To be used if per C-Oz Motor Speed (AW), has been set for its (parameter not vealue if RPM selected). Only to be used if part 1-00 Configuration Mode; is set for Open Loop and speed reference is applied by an external controller controlling the pressure: Set the reference speed at which the Siero Mode should be a

22-44 Wake-up Ref./FB Difference

Range:

Function:

10%*

[0-100%]

Only to be used if par. 1-00, Configuration Mode, is set for Closed Loop and the integrated PI controller is used for controlling the pressure.

Set the pressure drop allowed in percentage of set point for the pressure (Pset) before cancelling the Sleep Mode.



If used in application where the integrated PI controller is set for inverse control in par. 20-71, PID, Normal/Inverse Control, the value set in par. 22-44 will automatically be added.

22-45 Setpoint Boost

Range:

Function:

14 :[-100 - 100 %] Unity to be used if per: 1-00 Gwelgureton Mode, is set for Closed Loop and the integrated PI conbroiler is used. In systems with e.g. constant pressure control, it is achientageous to increase the system pressure before the motor is stopped. This will extend the time in which the motor is stopped ing bejakawasi faruen stanjen. Set the desired over pressure/temperature in percentage of set point for the pressure (Pset)/tem pereture before entering the Sleep Mode. If setting for 5%, the boost pressure will be Pset 1.05. The negative cooling tower control where a negative change is needed

22-46 Maximum Boost Time

Range:

Function:

60 (* 1.440) (600-1) (**) Only to be used if part 1:00 Cranfouration Models set for Closed Loop and the estegrated PI controller is used for controlling the pressure Set the maximum time for which boost mode will be allowed. If the set time is exceeded, Sleep Made will be entered, not waiting for the set boost pressure to be reached.

22-50 End of Curve Function

Option:

Function:

[0] * Off: End of Curve monitoring not active.	

[1] Warning A warning is issued in the display [W94].

[2] Alarm An alarm is issued and the frequency converter trips. A message [A94] appears in the display.



NB!

Automatic restart will reset the alarm and start the system again.

22-51 End of Curve Delay

Range:

Function:

Which an End of Curve condition is detected, a timer is activated. When the time set in this parameter expires, and the End of Curve condition has been steady in the entire period, the function set in per 22:50 Flat of Core Function will be estimated. If the condition disappears before the time expires, the timer will be resid


100


22-8) Flow Compens	iffon
Optio	n:	Function:
[0] *	Disabled	[0] Disabled: Set-Point compensation not active.
[1]	Enabled	[1] Enabled:Set-Point compensation is active. Enabling this parameter allows Flow Compensated
		Setpoint operation.


9

NB!

Please note: Not visible when running in cascade.







102

VLT[®] AQUA Drive Operating Instructions

22-84 Speed at No:Flow [Hz]	
Range:	Function:
	ANALIS (SERVING 1997)
	rran har flow of the following the management of the flow of the first state of the flow o
*->>o=*G=*********************************	
22-85 Speed at Design Point [RF	(U)
"22-86 Speed at Design Point [Hz	
Range:	Function:
	NET TO THE TOTAL CONTROL TO THE RESERVE OF THE PARTY OF T
	. De la comparte de La comparte de la comparte del la comparte de la comparte del la comparte de la comparte del la comparte della compa
22-87 Pressure at No-Flow Spee Range:	<u>ப</u>
0.000 N/A**, [0.000 - par. 22-88 N/A]	Enter the pressure H _{EDI} corresponding to Speed at No Flow in Reference/Feedback Units
22-88 Pressure at Rated Speed	
Ramani	Function:
	Control Control (Control Control
22-83 Speed at No. Flow [RPM]	
Range:	Function:
	. Britanisti il il 1979 (Atta Curier, Eta Cullisti, Parias, Eta Cullisti, Cullisti, Cullisti, Parias Cullisti
22:90 Flow at Rated Speed	
Range:	Function:
GOODNAT GOOD THEFE SEE WAT	Esting the value complicated by Ester at realist speed, this value can be defined using the purer defined.
	ort 1

8. How to programme the frequency converter Danfoss

8.2.11. Timed Actions, 23-0*

Use Timed Actions for actions needing to be performed on a daily or weekly basis, e.g. different references for working hours / non-working hours. Up to 10 Timed Actions can be programmed in the frequency converter. The Timed Action number is selected from the list when entering parameter group 23-0* from the Local Control Panel. par. 23-00 ON Time – par. 23-04 Occurrence then refer to the selected Timed Action number. Each Timed Action is divided into an ON time and an OFF time, in which two different actions may be performed.



NB!

The clock (parameter group 0-7*) must be correctly programmed for Timed Actions to function correctly.



NB!


When mounting an Analog I/O MCB109 option card, a battery back up of the date and time is included.

23-00 ON Time

Array [10]

Range:

Function:



Arra [10]

[5]

[17]

Option:

Function:

Select the action during ON Time. See par. 13-52 SL Controller Action for descriptions of the options.

- [0] * Disabled
- [1] No action
- [2] Select set-up 1
- [3] Select set-up 2
- [4] Select set-up 3
- [10] Select preset ref 0
- [11] Select preset ref 1

Select set-up 4

- [12] Select preset ref 2
- [13] Select preset ref 3
- [14] Select preset ref 4
- [15] Select preset ref 5
- [16] Select preset ref 6

Select preset ref 7


- [18]
- [19] Select ramp 2

[22] Run

104


MG.20.M5.02 - VLT is a registered Danfoss trademark

VLT® AQUA Drive Operating Instructions



[4]	Select set-up 3
[5]	Select set-up 4
[10]	Select preset ref 0
[11]	Select preset ref 1
[12]	Select preset ref 2
[13]	Select preset ref 3
[14]	Select preset ref 4
[15]	Select preset ref.5
[16]	Select preset ref 6
[17]	Select preset ref 7
[18]	Select ramp 1
[19]	Select ramp 2
[22]	Run
[23]	Run reverse
[24]	Stop
[26]	DC Brake
[27]	Coast
[28]	Freeze output
[29]	Start timer 0
[30]	Start timer 1
[31]	Start timer 2
[32]	Set digital out A low
[33]	Set digital out B low
[34]	Set digital out Crlow
[35]	Set digital out D low
[36]	Set digital out E low
[37]	Set digital out F low
[38]	Set digital out 8 high
[40]	Set digital out B high Set digital out C high
[41]	Set digital out D high
[42]	Set digital out E high:
[43]	Set digital out F high
[60]	Reset Counter A
[61]	Reset Counter B
[70]	Start Timer 3
[71]	Start Timer 4
[72]	Start Timer 5
[73]	Start Timer 6
[74]	Start Timer 7

VLT® AQUA Drive Operating Instructions



Array [10		
Option	n:	Function:
		Select which day(s) the Timed Action applies to Specify working/non-working days in par 0-81 Working <i>Days</i> , par. 0-82 Additional <i>Working Days</i> and par. 0-83 Additional <i>Non-Working Days</i>
[0] *	All days	
[1]	Working days	
[2]	Non-working days	
[3]	Monday	
[4]	Tuesday	
[5]	Wednesday	
[6]	Thursday	
[7]	Friday	
[8]	Saturday	

8.2.12. Water Application Functions, 29-**

The group contains parameters used for monitoring water / wastewater applications.

Option	n: n:	Function:
[0] *	Disabled	Select Enabled to fill pipes at a user specified rate.
[1]	Enabled	Select Enabled to fill pipes with a user specified rate.

29-01 Pipe Fill Speed [RPM]

Range: Function:

Range:

Speed Low [Speed Low Limit - Speed High Lim- Set the filling speed for filling horizontal pipe systems. The speed can be selected in Hz or RPM Limit* depending on the choices made in par. 4-11 / par. 4-13 (RPM) or in par. 4-12 / par. 4-14 (Hz).

29-02 Pipe Fill Speed [Hz]

Range: Function: [Speed Low Limit - Speed High Lim- Set the filling speed for filling horizontal pipe systems. The speed can be selected in Hz or RPM Motor

Speed Lowit] depending on the choices made in par. 4-11 / par. 4-13 (RPM) or in par. 4-12 / par. 4-14 (Hz). Limit*

29-03 Pipe Fill Time **Function:**

0 s* Set the specified time for pipe filling of horizontal pipe systems. [0 - 3600 s]

29-04 Pipe Fill Rate

Range: **Function:**

0.001 units/ [0.001 - 999999.999 units/s] Specifies the filling rate in units/second using the PI controller. Filling rate units are feedback units/ s*

second. This function is used for filling-up vertical pipe systems but will be active when the fillingtime has expired, no matter what , until the pipe fill-set-point set in par. 29-05 is reached.

8. How to programme the frequency converter Danfoss

29:05 Filled Setpoint

Range:

Function:

0 s*

[0 - 999999,999 s]

Specifies the Filled Set-point at which the Pipe Fill Function will be disabled and the PID controller will take control. This function can be used both for horizontal and vertical pipe systems.

8.3. Parameter Options

8.3.1. Default settings

Changes during operation:

"TRUE" means that the parameter can be changed while the frequency converter is in operation and "FALSE" means that the frequency converter must be stopped before a change can be made.

4-Set-up:

'All set-up': the parameter can be set individually in each of the four set-ups, i. e. one single parameter can have four different data values.

'1 set-up': data value will be the same in all set-ups.

SR:

N/A:

Size related

No default value available.

Conversion index:

This number refers to a conversion figure used when writing or reading by means of a frequency converter.

Conv. index	100	67	6	5	4	3	2	1	0	-1	-2	-3	-4	-5	-6
Conv. factor	1	1/60	1000000	100000	10000	1000	100	10	1	0.1	0.01	0.001	0.0001	0.00001	0.000001

Data type	Description	Туре
25 27 7827 1 1 1 1	Integer 8	Int8
3	Integer 16	Int16
4	Integer 32	Int32
5	Unsigned 8	Uint8
6	Unsigned 16	Uint16
7	Unsigned 32	Uint32
9: 5::-	VIsible String	∵ VisStr
33	Normalized value 2 bytes	N2
35	Bit sequence of 16 boolean variables	V2 /
54	Time difference w/o date	TimD

8.3.2.	Operation/Display U-	• * *
	Parameter description	

Par. No. # Parameter description	Default value	4-set-up	FC 302 only	Change during op- eration	Conver- sion index	Туре
0-0* Basic Settings			9.117	CIGUUII		(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)
0-01 Language	[0] English	1 set-up		TRUE	-	Uint8
0-02 Motor Speed Unit	[0] RPM	2 set-ups		FALSE		Uint8
0-03 Regional Settings	[0] International	2 set-ups		FALSE	-	Uint8
	[0] Resume				Call Carlotte And	
0-05 Local Mode Unit	[0] As Motor Speed Unit	2 set-ups		FALSE		Uint8
0-1* Set-up Operations						
0-10 Active Set-up	[1] Set-up 1	1 set-up		TRUE	•	Uint8
	[9] Active Set-up			TRUE	· · ·	Uint8
0-12 This Set-up Linked to	[0] Not linked	All set-ups		FALSE	-	Uint8
0-13 Readout: Linked Set-ups	0.N/A			FALSE!		Uint16
0-14 Readout: Prog. Set-ups / Channel 10-2* LCP Display	0 N/A	All set-ups	and commenters of the	TRUE	0	Int32
	1601		<u> </u>	TRUE		
0-20 Display Line 1.1 Small [0-21 Display Line 1.2 Small		All set-ups All set-ups			- ************************************	Uint16
0-22 Display Line 1.3 Small	1614	All set-ups		TRUE	_	Uint16
		All set-ups			- -	Uint16
0-24 Display Line 3 Large	1652	All set-ups		TRUE		Uint16
0-25 My Personal Menu	ExpressionLimit	All set-up s		TRUE		⊋aUint16
0-3* LCP Custom Readout	to the same present the transfer of the same		17 WOMAN SERVICE ST. 12 (2.5)	COMMENSAGE OF THE CONTRACT OF	·	* (3011R20)
0-30 Custom Readout Unit	[1] %	All set-ups		TRUE	Chi. (53(32) 15/4	Uint8
0-31 Custom Readout Min Value	ExpressionLimit	All set-ups		TRUE	-2	Int32
0-32 Custom Readout Max Value	100.00 CustomReadoutUnit	All set-ups	40.0	TRUE	-2	Int32
0-37 Display Text 1	0 N/A	1 set-up		TRUE	0	VisStr[25]
		1 set-up			0	VisStr[25]
0-39 Display Text 3	0 N/A	1 set-up		TRUE	00	VisStr[25]
0-4* LCP Keypad					53 48 66685335	
0-40 [Hand on] Key on LCP	[1] Enabled	All set-ups		TRUE	-	Uint8
0-41 [Off] Key on LCP		All set-ups	7. V. C. C. A. C. C. T.		<u> </u>	Uint8
0-42 [Auto on] Key on LCP	[1] Enabled	All set-ups		TRUE	-	Uint8
[0-43 [Reset] Key.on:LCP 0-44 [Off/Reset] Key.on.LCP	[1] Enabled	P. Carrier and Co.		TRUE TRUE	- 1,100 - 1,100 -	Uint8
0-44 [Off/Reset] Key on LCP 0-45 [Drive Bypass] Key on LCP	(1) Enabled	All set-ups		TRUE	-	Uint8 Uint8
0-5* Copy/Save	La de La	All Secrops & Secrops	arter a laboration of the color of the color	IRUE(;;;; %)	** * * * * * * * * * * * * * * * * * *	· · · · · · · · · · · · · · · · · · ·
IO-50 LCP Copy	[O] No conv	All set-ups	MINE REPORTED TO	FALSE	5. 1585°23 1860	Uint8
0-51 Set-up Copy	(0) No copy	All set-ups		FALSE	<u></u>	Uint8
0-6* Password		All Set-ups			-	
0-60 Main Menu Password	100 N/A	1 set-up	<u> </u>	TRUE	0	Uint16
	[0] Full access		33.9.5.5.5.7.7.7	TRUE	0	
0-65 Personal Menu Password	200 N/A	1 set-up		TRUÉ	Λ	Uint16
0-66 Access to Personal Menu w/o Password					•	

 $\text{MG.}20.\text{M5.}02 \cdot \text{VLT}^{\oplus}$ is a registered Danfoss trademark

Par. No.	# Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
0-7* Cl	ock Settings		16-17 16-18 (4) (4) (4) (4)	The state of the s		
0-70	Date and Time	ExpressionLimit	All set-ups	TRUE	0	TimeOfDay
0-71	Date Format	[0] YYYY-MM-DD	1 set-up	TRUE	••••••••••••••••••••••••••••••••••••••	Uint8
0-72	Time Format	[0] 24 h	1 set-up	TRUE	-	Uint8
0-74	DST/Summertime	[0] Off	1-set-up	TRUE	Mg (2 -) •	Uint8
0-76	DST/Summertime Start	ExpressionLimit	1 set-up	TRUE	0	TimeOfDay
0-77	DST/Summertime End	ExpressionLimit	1 set-up	TRUE	· · · · 0	TimeOfDay
0-79	Clock Fault	null	1 set-up	TRUE	-	Uint8
0-81	Working Days	null	1 set-up	TRUE	70 - A	UInt8
0-82	Additional Working Days	ExpressionLimit	1 set-up	TRUE	0	TimeOfDay
0-83	Additional Non-Working Days	ExpressionLimit	1 set-up	TRUE	0	TimeOfDay
0-89	Date and Time Readout	0 N/A	All set-ups	TRUE	0	VisStr[25]

	Parameter description	Default value 4-set-up Change during opera- tion	Conver- sion index	Type
	ral Settings			
	Configuration Mode	nuti All set-ups TRUE	_	Uint8
	Motor Control Principle		• •	
	Torque Characteristics	[3] Auto Energy Optim. VT All set-ups TRUE	*	Uint8
	Selection		(IASA II VINE SALAM	
	Motor Construction	[0] Asynchron All set-ups FALSE	estantian (New York Parks)	Uint8
	r Data			
	Motor Power [kW]	ExpressionLimit All set-ups FALSE	1 	Uint32
	Motor Power [HP]	ExpressionLimit Alliset-ups FALSE		
	Motor Voltage	ExpressionLimit All set-ups FALSE	0	Uint16
	Motor Frequency			
	Motor Current	ExpressionLimit All set-ups FALSE	-2	Uint32
THE PERSON NAMED IN COLUMN TWO	Motors Nominal Speed	ExpressionLimit Alliset-ups FALSE	0/	Uint16
	Motor Rotation Check	[0] Off All set-ups FALSE	-	Uint8
	Automatic Motor Adaptation (AMA)	All set-ups FALSE		UING
1-3* Adv. N		ExpressionLimit All/set-ups FALSE	A	Uint32
	Stator Resistance (Rs)			32. VS 2 UIII (2 E E E E
	Rotor Resistance (Rr)	ExpressionLimit All set-ups FALSE ExpressionLimit All set-ups FALSE ExpressionLimit All set-ups FALSE	-4	Uint32
	Main Reactance (Xh) Iron Loss Resistance (Rfe)	ExpressionLimit All set-ups FALSE ExpressionLimit All set-ups FALSE	-3	Uint32
1-20	Motor Poles			
	Indep. Setting	CXVICESIONICHIIII	U session y	yano yan
	Motor Magnetisation at Zero Speed	100% All setturs TRUE	CONST VA	⊈ Uint16 au
	Min Speed Normal Magnetising [RPM]	ExpressionLimit All set-ups TRUE	67	Uint16
	Min Speed Normal Magnetising Hz			
	Depen. Setting	TO SECURE AND ADDRESS OF THE PROPERTY OF THE P		,
11-60	Low Speed Load Compensation	100 % All set ups		Int16
	High Speed Load Compensation	100 % All set-ups TRUE	0	Int16
	Slip Compensation		0.4	
	Slip Compensation Time Constant	ExpressionLimit All set-ups TRUE	-2	Uint16
	Resonance Dampening			
	Resonance Dampening Time Constant	5 ms All set-ups TRUE	-3	Uint8
1-7* Start	Adjustments			
1-71	Start Delay	0.0 s All set-ups TRUE	-1	Uint16
1:73	Flying Stan			Uint8
	Start Speed [RPM]	ExpressionLimit All set-ups TRUE	67	Uint16
1-75	Start Speed [Hz]	ExpressionLimit All:set-ups TRUE	- 1-000 V-K	Uint16
1-76	Start Current	0.00 A All set-ups TRUE	-2	Uint32
1-8*/Stop /	Adjustments			鐵桶空線设计
	Function at Stop	[0] Coast All set-ups TRUE		Uint8
	Min Speed for Function at Stop [RPM]		67	
	Min Speed for Function at Stop [Hz]	ExpressionLimit All set-ups TRUE	-1	Uint16
1-86	Trip Speed Low [RPM]	VAII.SET-UPS	67	
1-87	Trip Speed Low [Hz]		-1	Uint16
				47.65.045.00
	Motor Thermal Protection	[4] ETR trip 1 All set-ups TRUE	•	Uint8
		[0] NO Alliset-ups TRUE		JUINt16
1-93	Thermistor Source	[0] None All set-ups TRUE	-	Uint8

8.3.4. Brakes 2-**

Par. No. i	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
2-0* DC						
2-00	DC Hold/Preheat Current	50 %	All set-ups	TRUE	0	Uint8
2-01	DC Brake Current	50.%	All set-ups	TRUE	0	Uint16
2-02	DC Braking Time	10.0 s	All set-ups	TRUE	-1	Uint16
2-03	DC Brake Cut In Speed [RPM]	<u>ExpressionLimit</u>	All set-ups	TRUE	67	Uint16
2-04	DC Brake Cut In Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
2-1* Bra	ke Energy Funct.					
2-10	Brake Function	[0] Off	All set-ups	TRUE	-	Uint8
2-11	Brake Resistor (ohm)	<u>ExpressionLimit</u>	All set-ups	TRUE	0	Uint16
2-12	Brake Power Limit (kW)	ExpressionLimit	All set-ups	TRUE	0	Uint32
2-13	Brake Power Monitoring	[0] Off	All set-ups	TRUE	-	Uint8
2-15	Brake Check	[0] Off	All set-ups	TRUE	-	Uint8
2-16	AC brake Max. Current	100.0 %	All set-ups	TRUE	-1	Uint32
2-17	Over-voltage Control	[2] Enabled	All set-ups	TRUE	-	Uint8



8.3.5.	Reference	/ Ramps 3-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Type
3-0* Refe	rence Limits					
3-02	Minimum Reference	ExpressionLimit	All set-ups	TRUE	-3	Int32
3-03	Maximum Reference	ExpressionLimit	All set-ups		-3	
3-04	Reference Function	[0] Sum	All set-ups	TRUE	-	Uint8
3-1* Refe	rences		144, 44, 1 779, 18 0, 184, 143	destructions are supplied as a series of the series of	Marie Carlos	1 a 6 6 7 7 7 1
3-10	Preset Reference	0.00 %	All set-ups	TRUE	-2	Int16
	Jog Speed [Hz]		All set-ups		1	
3-13	Reference Site	[0] Linked to Hand / Auto	All set-ups	TRUE	-	Uint8
	Preset Relative Reference				-2	
3-15	Reference 1 Source	[1] Analog input 53	All set-ups	TRUE	-	Uint8
		[0] No function			. 60×5×	Uint8
3-17	Reference 3 Source	[0] No function	All set-ups	TRUE	-	Uint8
	204 0000 [14.00]	ExpressionLimit	All set-ups	TRUE	67	Uint16
3-4* Ram						
h.:	Ramp 1 Ramp Up Time					Uint32
3-42	Ramp 1 Ramp Down Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
	p 2				-	
3-51	Ramp 2 Ramp Up Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
	TRUMP E ROMP BOWN TAME	ExpressionLimit	All set-ups	TRUE (-2	୍ ୟUint32
3-8* Othe			40- 8-8- FARESTON	The state of the s	\$ -2 ·	************
	<u>Jog Ramp Time</u>				<u> </u>	Uint32
3-81	Quick Stop Ramp Time	ExpressionLimit	2 set-ups	TRUE	-2 -2	Uint32
	Initial Ramp Time	0.00 s	All set-ups			Uint16
3-85	Check Valve Ramp Time	0.00 s ExpressionLimit	All set-ups All set-ups	TRUE TRUE	-2 67	Uint16
	Check Valve Ramp End Speed [RPM]			TRUE		Uint16
3-87	Check Valve Ramp End Speed [HZ] Final Ramp Time:	ExpressionLimit 0.00 s	All set-ups		-1 -2	
,		and the control of th		C. TO ASSOCIATE THE PROPERTY OF THE PROPERTY O	-3-199 3 . L.	· · · · · · · · · · · · · · · · · · ·
	al Pot.Meter Step Size	0.10.0/	. (v.)	CHARLEST NO.	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	Uint16: 1
3-90- 3-91	Ramp Time	1.00 s	All set-ups	TRUE	-2	Uint32
	Power Restore				-2 -	
3-93	Maximum Limit	100 %	All set-ups	TRUE	0	Int16
	Minimum Limit					
3-95	Ramp Delay	ExpressionLimit	All set-ups	TRUÉ	-3	TimD
3 73	namp sea,	Expressiones in the second sec	All Set up3	1100		11110



8.3.6. Limits / Warnings 4-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Type
4-1* Moto					1.7	
4-10	Motor Speed Direction	[0] Clockwise	All set-ups	FALSE	_	Uint8
4-11	Motor Speed Low Limit [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
4-12	Motor Speed Low Limit [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
4-13	Motor Speed High Limit [RPM]	ExpressionLimit	All set-ups		67	Uint16
4-14	Motor Speed High Limit [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
4-16	Torque Limit Motor Mode	110.0 %	All set-ups		-1	Uint16
4-17	Torque Limit Generator Mode	100.0 %	All set-ups	TRUE	-1	Uint16
4-18	Current Limit	ExpressionLimit	All set-ups		1	Uint32
4-19	Max Output Frequency	ExpressionLimit	All set-ups	FALSE	-1	Uint16
4-5* Adj. \						
4-50	Warning Current Low	0.00 A	All set-ups	TRUE	-2	Uint32
4-51	Warning Current High	ImaxVLT (P1637)	All set-ups		-2	
4-52	Warning Speed Low	0 RPM	All set-ups	TRUE	67	Uint16
4-53	Warning Speed High	outputSpeedHighLimit (P413)			67	Uint16
4-54	Warning Reference Low	-999999.999 N/A	All set-ups	TRUE	-3	Int32
4-55	Warning Reference High	999999,999 N/A	All set-ups		-3	Int32
4-56	Warning Feedback Low	-999999.999 ReferenceFeedbackUnit	All set-ups	TRUE	-3	Int32
4-57	Warning Feedback High	999999.999 ReferenceFeedbackUnit	All set-ups		-3	Int32
4-58	Missing Motor Phase Function	[1] On	All set-ups	TRUE	-	Uint8
	d Bypass					لــــــــــــــــــــــــــــــــــــــ
4-60	Bypass Speed From [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
4-61	Bypass Speed From [Hz]	ExpressionLimit	All set-ups		<u>-1</u>	Uint16
4-62	Bypass Speed To [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
4-63	Bypass Speed To [Hz]	ExpressionLimit	All set-ups		-1	Uint16
4-64	Semi-Auto Bypass Set-up	[0] Off	All set-ups	FALSE	•	Uint8

8.3.7. Digital In/Out 5-**

Par. No. # Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Type
5-0* Digital/I/O mode		***			
5-00 Digital I/O Mode	[0] PNP - Active at 24V	All set-ups	FALSE	•	Uint8
S-01 Terminal 27 Mode	(O) Input				Uint8
5-02 Terminal 29 Mode 5-1- Digital Inputs	[0] Input	All set-ups	TRUE	-	Uint8
5-10 Terminal 18 Digital Input	[8] Start	All set-ups	TRUE		Uint8
S-10 Terminal 19 Digital Input	[0] Start			-	
5-12 Terminal 19 Digital Input	<u>rojino operacio:</u>	All set-ups	TRUE	-	Uint8
S-13 Terminal 29 Digital Input	[0] No operation	All set-ups		-	
5-14 Terminal 32 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
IS-15 Terminal 33 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-16 Terminal X30/2 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-17 Terminal X30/3 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-18 Terminal X30/4 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-3* Digital Outputs	4 7				
5-30 Terminal 27 Digital Output	[0] No operation	All set-ups	TRUE	-	Uint8
5-31 Terminal 29 Digital Output	[0] No operation	All set-ups	TRUE	- 1	Uint8
5-32 Term X30/6 Digi Out (MCB 101)	[0] No operation	All set-ups	TRUE	-	Uint8
5-33 Term X30/7 Digl Out (MCB 101)	[0] No operation	All set-ups	TRUE		Uint8
5-4* Relays					
5-40 Function Relay	null	All set-ups	TRUE		Uint8
5-41 On Delay, Relay	0.01 s	All set-ups	TRUE	-2	Uint16
S-42 Off Delay, Relay	0:01·s	All set-ups	TRUE	-2	Uint16
5-5* Pulse Input	ACCOM!	70			
5-50 Term, 29 Low Frequency	100 Hz 100 Hz	All set-ups	TRUE TRUE	0	Uint32
5-51 Term. 29 High Frequency 5-52 Term. 29 Low Ref./Feedb. Value	0.000 N/A	All set-ups			Uint32 Int32
5-53 Term. 29 High Ref./Feedb. Value	100.000 N/A	All set-ups All set-ups	TRUE	-3 -3	Int32
5-54 Pulse Filter Time Constant #29	100.000 NyA	All set-ups		-3	
5-55 Term. 33 Low Frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-56 Term. 33 High Frequency	100 Hz	All set-ups			
S-S7 Term, 33 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
5-58 Term. 33 High Ref:/Feedb.:Value	100,000 N/A			-3	
5-59 Pulse Filter Time Constant #33	100 ms	All set-ups	FALSE	-3	Uint16
5-6* Pulse Output					
5-60 Terminal 27 Pulse Output Variable	[0] No operation	All set-ups	TRUE	-	Uint8
5-62 Pulse Output Max Freq #27	5000 Hz	All set-ups	TRUE	0	Uint32
5-63 Terminal 29 Pulse Output Variable	[0] No operation	All set-ups	TRUE	•	Uint8
S-65 Pulse Output Max Freq #29	5000 Hz	All set-ups		0	Uint32
S-66 Terminal X30/6 Pulse Output Variable	[0] No operation	All set-ups	TRUE	-	Uint8
5-68 Pulse Output Max Freq #X30/6	5000 Hz	All set-ups	TRUE	0,	Uint32
5-9* Bus Controlled					
S-90 Digital & Relay Bus Control	O.N/A	All set-ups		U	
5-93 Pulse Out #27 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
S-94 Pulse Out #27 Timeout Preset	0.00 %	1 set-up			
5-95 Pulse Out #29 Bus Control 5-96 Pulse Out #29 Timeout Preset	0.00 %	All set-ups	TRUE	-2	N2
	0.00 %	1 set-up	TRUE	<u>-2</u>	
5-97 Pulse Out #X30/6 Bus Control [5-98 Pulse Out #X30/6 Timeout Preset	0.00 % 0.00 %	All set-ups	TRUE	-2	. N2 Uint16
Fulse: Out: # ADV/O THITIEOUT(Freset	.U:UU 70	1 Set-up	TRUE	-2	UIU(10



8.3.8. Analog In/Out 6-**

r. No. # Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
0* Analog I/O Mode 00 Live Zero Timeout Time	10 s	All set-ups	TRUE	0	Uint8
01 Live Zero Timeout Function	[0] Off	All set-ups		-	
1* Analog Input 53					
10 Terminal 53 Low Voltage	0:07·V	All set-ups	TRUE	-2	Int16
11 Terminal 53 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
12 Terminal 53 Low Current	4.00 mA	All set-ups	TRUE	-5	Int16
13 Terminal 53 High Current	20.00 mA	All set-ups	TRUE	-5	Int16
14 Terminal 53 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
15 Terminal 53 High Ref./Feedb. Value	ExpressionLimit	All set-ups	TRUE	-3	Int32
16 Terminal 53 Filter Time Constant	0.001 s	All set-ups		-3	20 11 1CZ O 11
17 Terminal 53 Live Zero	[1] Enabled	All set-ups	TRUE	-	Uint8
2* Analog Input 54	1 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1				
20 Terminal 54 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
21 Terminal 54 High Voltage	10.00 V	All set-ups			Int16
22 Terminal 54 Low Current	4.00 mA	All set-ups	TRUE	- 5	Int16
23 Terminal 54 High Current 24 Terminal 54 Low Ref./Feedb. Value	20.00 mA 0.000 N/A	All set-ups All set-ups	TRUE TRUE	-5 -3	Int16 Int32
	100.000 N/A	All set-ups		-3 -3	
25 Terminal 54 High Ref./Feedb. Value 26 Terminal 54 Filter Time Constant	0.001 s	All set-ups	TRUE	-3 -3	Uint16
27 Terminal 54 Live Zero	[1] Enabled		TRUE	-5	Uint8
3* Analog Input X30/11	[1] Liabeo	Airsectups	IRUE	-	UIILO
30 Terminal X30/11 Low Voltage	0.07 V	All satures	TRUE	-2	Int16
31 Terminal X30/11 High Voltage	10.00 V	All set-ups	TRUE	- 2	Int16
34 Term. X30/11 Low Ref./Feedb. Value	0:000 N/A	All set-ups		-3	Int32
35 Term. X30/11 High Ref./Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
36 Term, X30/11 Filter Time Constant	0.0015	All set-ups		-3	
37 Term. X30/11 Live Zero	[1] Enabled	All set-ups	TRUE	-	Uint8
4* Analog Input X30/12	5,4				
40 Terminal X30/12 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
41 Terminal X30/12 High Voltage	10.00 V	All set-ups		-2	
14 Term. X30/12 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
Term, X30/12 High Ref./Feedb, Value	100.000 N/A	All set-ups	TRUE	-3	Int32
f6 Term. X30/12 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	Uint16
77 Term. X30/12 Live Zero	[1] Enabled	All set-ups	TRUE		Uint8
5* Analog Output 42					
Terminal 42 Output	[100] Output freq. 0-100	All set-ups		-	
Terminal 42 Output Min Scale	0.00 %	All set-ups	TRUE	-2	Int16
72 Terminal 42 Output Max Scale	100.00 %	All set-ups			Int16
Terminal 42 Output Bus Control	0.00 %	All set-ups	TRUE	-2	N2
54 Terminal 42 Output Timeout Preset	, , , , , , , , , , , , , , , , , , ,	1 set-up	TRUE	-2	Uint16
6* Analog Output X30/8	FOI N				
50 Terminal X30/8 Output	[0] No operation	All set-ups		-	Uint8
Terminal X30/8 Min. Scale	0.00 % 100:00 %	All set-ups	TRUE	-2	Int16
52 Terminal X30/8 Max, Scale			TRUE		Int16
7 Terminal X30/8 Output Bus Control	0.00 %	All set-ups	TRUE	-2	N2
54 Terminal X30/8 Output Timeout Preset	0:00 %	1 Set-up	TRUE	-2	Uint16

8	.3	.9	. '	Co	mm	ì.	and	0	pti	ons	8-**

	Parameter description	Default value	` 4-set-up	Change during opera- tion	Conver- sion index	Туре
	ral Settings	SPEC CONTRACTOR OF THE CONTRAC				
8-01	Control Site	null	All set-ups	TRUE	-	Uint8
		null			,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Uint8
8-03	Control Timeout Time	ExpressionLimit	1 set-up	TRUE	-1	Uint32
	Control Timeout Function				-8994.7	UInt8′ Uint8
8-05	End-of-Timeout Function	[1] Resume set-up	1 set-up	TRUE	-	
		[0] Do not reset			-	
8-07	Diagnosis Trigger	[0] Disable	2 set-ups	TRUE	-	Uint8
	rol Settings	501.50 GU				10-40
8-10	Control Profile	[0] FC profile	All set-ups	TRUE	-	Uint8
		[1] Profile Default			-	
8-14	Configurable Control Word CTW	[1] Profile default	All set-ups	TRUE	•	Uint8
	ort Settings				<u> </u>	115-10
8-30	Protocol	null	1 set-up	TRUE	-	Uint8
	Address	ExpressionLimit			July 19 WOLAN ARCHS	Uint8
8-32	Baud Rate	null	1 set-up	TRUE TRUE	-	Uint8 Uint8
	Parity / Stop Bits	null				
8-35	Minimum Response Delay	ExpressionLimit	1 set-up	TRUE	-3	Uint16
	Max Response Delay: Maximum Inter-Char Delay	ExpressionLimit ExpressionLimit	1 set-up	TRUE	-3 -5	Uint16 Uint16
8-37	C protocol set	ExpressionLimit	1 Set-up			UIILIG
8-40	Telegram Selection	[1] Standard telegram 1	2 set-ups	TRUE	-	Uint8
		[1] Standard telegram 1	z sec-ups			Ollito
8-50	Coasting Select	[3] Logic OR	All set-ups	TRUE	**************************************	Uint8
		[3] Logic OR			7.46-34.55.66	January Uint8
8-53	Start Select	[3] Logic OR	All set-ups	TRUE	-	Uint8
		[3] Edgic OK null			-	
8-55	Set-up Select	[3] Logic OR	All set-ups	TRUE	-	Uint8
		[3] Logic OR			85-75-625-00	Uint8
8-7* BACn				7,,00		
		1 N/A	1 set-up	*TRUE	0	Uint32
8-72	MS/TP Max Masters	127 N/A	1 set-up	TRUE	0	Uint8
	MS/TP Max Info Frames	1.N/A	1 set-up		0	Uint16
8-74	"I-Am" Service	[0] Send at power-up	1 set-up	TRUE	-	Uint8
8-75	Initialisation Password	ExpressionLimit	1 set-up	TRUE	. 0	// VisStr[20]
8-8* FC Pc	ort Diagnostics					
8-80	Bus Message Count	O N/A	All set-ups	TRUE	0	Uint32
8-81	Bus Error Count	0 N/A	All set-ups	TRUE	0	Uint32
	Slave Message Rcvd	0 N/A		TRUE	0	Uint32
8-83	Slave Error Count	0 N/A	All set-ups	TRUE	0	Uint32
8-9* Bus J	og / Feedback				e 27 S. 20 S. 20 S. 3.	
8-90	Bus Jog 1 Speed	100 RPM	All set-ups	TRUE	67	Uint16
	Bus Jog 2 Speed	200 RPM		TRUE	67	
8-94	Bus Feedback 1	. 0 N/A	1 set-up	TRUE	0	N2
	Bus Feedback 2				0.0	
8-96	Bus Feedback 3	0 N/A	1 set-up	TRUE	0	N2

8.3.10. Profibus 9-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
9-00	Setpoint	0 N/A	All set-ups	TRUE	0 - 3	Uint16
9-07	Actual Value	0 N/A	All set-ups	FALSE	0	Uint16
9-15	PCD Write Configuration	ExpressionLimit	2 set-ups		<u> </u>	Uint16
9-16	PCD Read Configuration	ExpressionLimit	2 set-ups	TRUE	-	Uint16
	Node Address	126 N/A		IIIMANIANI III MARKATA A. A. A. A. A. MARKATI III MARKATI III MARKATI II MAR	0	Uint8
9-22	Telegram Selection	[108] PPO 8	1 set-up	TRUE	•	Uint8
9-23	Parameters for Signals		All set-ups	TRUE	74 · 17	Uint16
9-27	Parameter Edit	[1] Enabled	2 set-ups	FALSE	•	Uint16
9-28	Process Control	[1] Enable cyclic master	2 set-ups	FALSE	oggest ≖y disyes	Uint8
9-44	Fault Message Counter	0 N/A	All set-ups	TRUE	0	Uint16
9-45	Fault Code	0 N/A	All set-ups	TRUE	0 7	Uint16
9-47	Fault Number	0 N/A	All set-ups	TRUE	0	Uint16
9-52	Fault Situation Counter	0 N/A	All set-ups	TRUE	0	Uint16
9-53	Profibus Warning Word	0 N/A	All set-ups	TRUE	0	V2
9-63	Actual Baud Rate	[255] No baudrate found	All set-ups	TRUE	-	Uint8
9-64	Device Identification	0 N/A	All set-ups	TRUE	0	Uint16
9-65	Profile Number	0 N/A	All set-ups	TRUE	0 6	OctStr[2]
9-67	Control Word 1	0 N/A	All set-ups	TRUE	0	V2
9-68	Status Word 1	0 N/A	All set-ups	TRUE	0	V2 :::
9-71	Profibus Save Data Values	[0] Off	All set-ups	TRUE	-	Uint8
9-72	ProfibusDriveReset:	[0] No action	1 set-up	FALSE	•	Uint8
9-80	Defined Parameters (1)	0 N/A	All set-ups	FALSE	0	Uint16
9-81	Defined Parameters (2)	0 N/A	All set-ups	FALSE	ુર `.O ેંકે	Uint16
9-82	Defined Parameters (3)	0 N/A	All set-ups	FALSE	0	Uint16
9-83	Defined Parameters (4)	0 N/A	All set-ups	FALSE	0	Uint16
9-84	Defined Parameters (5)	0 N/A	All set-ups	FALSE	0	Uint16
9-90	Changed Parameters (1)	0 N/A	All set-ups		0	Uint16
9-91	Changed Parameters (2)	0 N/A	All set-ups	FALSE	0	Uint16
9-92	Changed Parameters (3)	O N/A		FALSE	0	Uint16
9-93	Changed Parameters (4)	0 N/A	All set-ups	FALSE	0	Uint16
9-94		0.N/A		FALSE	Ď	Uint16

MG.20.M5.02 - VLT* is a registered Danfoss trademark

8.3.11. CAN Fieldbus 10-**

Par. No. #	# Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Type
10-0* Co	ommon Settings					
10-00	CAN Protocol	null	2 set-ups	FALSE	-	Uint8
10-01	Baud Rate Select	null	2 set-ups	TRUE	-	Uint8
10-02	MAC ID	ExpressionLimit	2 set-ups	TRUE	0	Uint8
10-05	Readout Transmit Error Counter	0:N/A	All set-ups	TRUE	0	*Uint8
10-06	Readout Receive Error Counter	0 N/A	All set-ups	TRUE	0	Uint8
	Readout Bus Off Counter	0.N/A	All set-ups	TRUE	0.	Uint8
10-1* D				***************************************		
10-10	Process Data Type Selection		All set-ups	TRUE	-	Uint8
10-11	Process Data Config Write	ExpressionLimit	2 set-ups	TRUE	-	Uint16
	Process Data Config Read	ExpressionLimit	2 set-ups	TRUE	-	Uint16
10-13	Warning Parameter	0 N/A	All set-ups	TRUE	0	Uint16
10-14	Net Reference	[0].Off	2 set-ups	TRUE	-	Uint8
10-15	Net Control	[0] Off	2 set-ups	TRUE	-	Uint8
	OS Filters	0.81/4	AU	ENICE		11: 145
10-20 10-21	COS Filter 1	0 N/A .D.N/A	All set-ups	FALSE	0	Uint16
10-22	COS Filter/2 COS Filter 3		All set-ups		0	Uint16
	COS Filter 4	0 N/A 0 N/A	All set-ups All set-ups	FALSE FALSE	0	Uint16 Uint16
	prameter Access	U.IV/A	All Set-ups	FALSE	· · · · · · · · · · · · · · · · · · ·	UITILIO
10-30	Array-Index	0 N/A	2 set-ups	TRUE	Û	Uint8
10-31	Store Data Values	[0] Off	All set-ups	TRUE	-	Uint8
10-32	Devicenet Revision	ExpressionLimit	All set-ups	TRUE	. 0	Uint16
10-33	Store Always	[0] Off	1 set-up	TRUE	-	Uint8
10-34	DeviceNet Product Code	130 N/A	1 set-up		0	Uint16
10-39	Devicenet F Parameters	0 N/A	All set-ups	TRUE	Ō	Uint32



8.3.12. Smart Logic 13-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
13-0* SL	C Settings					
13-00	SL Controller Mode	null	2 set-ups	TRUE	-	Uint8
13-01	Start Event	null	2 set-ups	TRUE		Uint8
13-02	Stop Event	null	2 set-ups	TRUE	-	Uint8
13-03	Reset SLC	[0] Do not reset SLC	All set-ups	TRUE		Uint8
13-1* Co	omparators					
	Comparator Operand	z null)	2 set-ups	TRUE	-	Uint8
13-11	Comparator Operator	null	2 set-ups	TRUE	-	Uint8
13-12	Comparator_Value	ExpressionLimit	2 set-ups	TRUE	-3	Int32
13-2* Tir						
	SL Controller Timer	ExpressionLimit	1 set-up	TRUE	-3	TimD
	gic Rules					
13-40	Logic Rule Boolean 1	null	2 set-ups	TRUE	-	Uint8
13-41	Logic Rule Operator 1	null	2 set-ups	TRUE	-	Uint8
13-42	Logic Rule Boolean 2	null	2 set-ups	TRUE	-	Uint8
13-43	Logic Rule Operator 2	null	2 set-ups	TRUE	-	Uint8
	Logic Rule Boolean 3	null	2 set-ups	TRUE	-	Uint8
13-5* St						
13-51	SL Controller Event	null	2 set-ups	TRUE	-	Uint8
13-52	SL Controller Action	null	2 set-ups	. TRUE	-	Uint8

8.:	3.1	3.	Spe	ecial	Fun	ctions	14-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
14-0* Inv	erter Switching			CHECK CONTRACTOR	ng gyrasay:	H 2000 - 1
14-00	Switching Pattern	null	All set-ups	TRUE	-	Uint8
14-01	Switching Frequency	n to the first of the control of the	All set-ups		- -	∵ Uint8
14-03	Overmodulation	[1] On	All set-ups	FALSE	•	Uint8
14-04	PWM Random	(0) Off	All set-ups	TRUE	K., 124. April 2	Uint8
14-1* Mai						
14-10	Mains Failure				1,714,714,71	
14-11	Mains Voltage at Mains Fault	ExpressionLimit	All set-ups	TRUE	0	Uint16
		[3] Derate	🗸 🦪 All set-ups 🐃	TRUE		Uint8
	et Functions					
	Reset Mode				2 10 July 2017	∵ Uint8
14-21	Automatic Restart Time	10 s	All set-ups	TRUE	0	Uint16
		[0] Normal operation			14 Big (195	
14-23	Typecode Setting	nui!	2 set∙ups	FALSE	-	Uint8
	Trip Delay at Torque Limit			TRUE	09	
14-26	Trip Delay at Inverter Fault	ExpressionLimit	All set-ups	TRUE	O	Uint8
	Production Settings					
14-29	Service Code	0 N/A	All set-ups	TRUE		Int32
14-37 Cur	rent Limit Ctrl. Current Lim Ctrl, Proportional Gain	100 %	All set-ups	FALSE	0	Uint16
	Current Lim Ctr. Integration Time					
	rgy Optimising	2	A STATE OF THE STA	ALICE TO SEE SEE SEE SEE SEE SEE SEE SEE SEE SE		OBILIO
	VT.Level	56.0	All cet-line	FAI SE	and the second second	Uint8
14-41	AEO Minimum Magnetisation	ExpressionLimit	All set-ups	TRUE	0	Uint8
	Minimum AEO Frequency				race out to	SSEUINT8
14-43	Motor Cosohi	ExpressionLimit	All set-ups	TRUE	-2	Uint16
	ironment					
14-50	RFI Filter	{1] On	i set-up	FALSE	-	Uint8
	Fan Control	COMPACTOR SECURITION AND AUTOMACTOR SECURITION AUTOMACTOR SECURITION AND AUTOMACTOR SECURITION AUTOMACTOR SECURITION AND AUTOMACTOR SECURITION AND AUTOMACTOR SECURITION AUTOMACTOR SECURITION AND AUTOMACTOR SECURITION AUTOMACTO			1,5 H@855 1	Uint8
14-53	Fan Monitor	[1] Warning	All set-ups	TRUE	-	Uint8
14-55	Output Filter	0) No Filter		FALSE	N. Louis - Arguments	
14-59	Actual Number of Inverter Units	ExpressionLimit	1 set-up	FALSE	0	Uint8
14-6* Aut	o Derate					Land Common A.
14-60	Function at Over Temperature	[1] Derate	All set-ups	TRUE	•	Uint8
	Function at Inverter Overload				3 9/43 , 3 90 € 13	Uint8
14-62	Inv. Overload Derate Current	95 %	All set-ups	TRUE	0	Uint16
	ions		A trained of the Parket Control of the Control of t			
14-80	Option Supplied by External 24VDC	[0] No	2 set-ups	FALSE	-	Uint8





8.3.14. FC Information 15-**

Par. No. #	Parameter description		Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
15-0* Op	erating Data		المستعدد والمستعدد والمستعد والمستعدد والمستعد والمستعدد والمستعد		4.34.7.1	Maria de la Carta	
15-00	Operating Hours		0 h	All set-ups	FALSE	74	Uint32
15-01	Running Hours	Charles of the Control of the Contro	2 P. B. J. J. J. L.	All set-ups			Uint32
15-02	kWh Counter		0 kWh	All set-ups	FALSE	75	Uint32
15-03	Power Up's		11 0 N/A				The state of the s
15-04	Over Temp's		0 N/A	All set-ups	FALSE	0	Uint16
15-05	Over Volt's			All set-ups	FALSE	0	Uint16
15-06	Reset kWh Counter		[0] Do not reset	All set-ups	TRUE	-	Uint8
15-07	Reset Running Hours Counter						
15-08	Number of Starts		0 N/A	All set-ups	FALSE	0	Uint32
15-1* Da	ta Log Settings			The state of the s			1.47
15-10	Logging Source		0	2 set-ups	TRUE	-	Uint16
15-11 ·	Logging Interval		ExpressionLimit		TRUE		TimD
15-12	Trigger Event		[0] False	1 set-up	TRUE	-	Uint8
15-13				Sections Added to Asset	TRUE	A	7 7 7
	Logging Mode		[0] Log always		TRUE	C (85) x 10, -1	
15-14	Samples Before Trigger		50 N/A	2 set-ups	TRUE	0	Uint8
	toric Log	NAMES OF A PROPERTY OF A STATE OF A	TOWARD CARRY A COLUMN BASE OF FRANCE	and the second s	A STATE OF THE PARTY OF THE PAR	1.77	النسيبيين
15-20	Historic Log: Event		0 N/A	All set-ups	FALSE	0	Uint8
	Historic Log: Value		V 01- 21 0.N/A		FALSE # # #		Uint32
15-22	Historic Log: Time		0 ms	All set-ups	FALSE	-3	Uint32
15-23	Historic Log: Date and Time		ExpressionLimit	All set-ups	ÇFALSE	0	TimeOfDay
15-3* Ala						<u> </u>	
15-30	Alarm Log: Error Code		O N/A	All set-ups		0	Uint8
15-31	Alarm Log: Value		0 N/A	All set-ups	FALSE	0	Int16
15-32	Alarm Log: Time					0	
15-33	Alarm Log: Date and Time		ExpressionLimit	All set-ups	FALSE	0	TimeOfDay
15-34	· Alarm Log: Setpoint		0.000 ProcessCtrlUnit	· · · · · · · · · · · · · · · · · · ·	FALSE	ું ⊶-3	Int32
15-35	Alarm Log: Feedback		0.000 ProcessCtrlUnit	All set-ups	FALSE	-3	Int32
15-36	Alarm Log: Current Demand			All set-ups		0	
15-37	Alarm Log: Process Ctrl Unit		[0]	All set-ups	FALSE		Uint8
15-4* Dri	ve Identification					arthropia and and	
15-40	FC Type		0 N/A	All set-ups	FALSE	. 0	VisStr[6]
15-41	Power Section		(N/A) () (O N/A	All set-ups	FALSE : 6	0	VisStr[20]
15-42	Voltage		0 N/A	All set-ups	FALSE	0	VisStr[20]
15-43	- Software Version		0 N/A 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4			0	
15-44	Ordered Typecode String		0 N/A	All set-ups	FALSE	0	VisStr[40]
15-45	Actual Typecode String		0 N/A	All set-ups	FALSE	0	VisStr[40]
15-46	Frequency Converter Ordering No		0 N/A	All set-ups	FALSE	0	VisStr[8]
15-47	Power Card Ordering No		0 N/A	All set-ups		0	
15-48	LCP Id No		0 N/A	All set-ups	FALSE	0	VisStr[20]
15-49	SW ID Control Card		O N/A			1860 O - 1891	
15-50	SW ID Power Card		0 N/A	All set-ups	FALSE	0	VisStr[20]
15-51	Frequency Converter Serial Number		0.N/A	All set-ups	FALSE ²	×535 0	VisStr[10]
15-53	Power Card Serial Number		0 N/A	All set-ups	FALSE	0	VisStr[19]
13-33	Fower Card Serial Number		VIVA	All Set ups	· AWE	v	[CIJDCEIV

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
	tion Ident					
15-60	Option Mounted	0 N/A	All set-ups	FALSE	0	VisStr[30]
	Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-62	Option Ordering No	0 N/A	All set-ups	FALSE	0	VisStr[8]
15-63	Option Serial No	O.N/A	All set-ups	FALSE	0	VisStr[18]
15-70	Option in Slot A	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-71	Slot A Option SW Version	0/N/A	All set-ups	FALSE	0	VisStr(20)
15-72	Option in Slot B	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-73	Slot B Option SW Version	0 N/A	All set-ups	FALSE	0 1	VisStr[20]
15-74	Option in Slot C0	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-75	Slot CO Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-76	Option in Slot C1	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-77	Slot G1 Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-9* Par	ameter Info					
15-92	Defined Parameters	, 0 N/A	All set-ups	FALSE	0	Uint16
15-93	Modified Parameters	0 N/A	All set-ups	FALSE	0	Uint16
15-98	Drive Identification	O N/A	All set-ups	FALSE	0 .	VisStr[40]
15-99	Parameter Metadata	O N/A	All set-ups	FALSE	0	Uint16



8.3.15. Data Readouts 16-**

16-0* General Status 16-00 Control Word 0 N/A	All set-ups All set-ups	TRUE		
10-00 Control word			0	V2
16-01 Reference [Unit] 0.000 Reference FeedbackUnit	MII SELTUDS		-3	Int32
16-02 Reference [%] 0.0 %	All set-ups	TRUE	-1	Int16
10-02 Kerterine [70] 16-03 Status Word 0 N/A				
16-05 Main Actual Value [%] 0.00 %	All set-ups	TRUE	-2	N2
16-09 Custom Readout 0.00 CustomReadoutUnit			-2	
16-1* Motor Status			······································	
16:10 Power [kW] 0.00 kW	All set-ups	TRUE	. 1	Int32
16-11 Power [hp] 0.00 hp	All set-ups	TRUE	-2	Int32
	All set-ups	TRUE	-1	Uint16
16-13 Frequency 0.0 Hz	All set-ups	TRUE	-1	Uint16
16-14 Motor Current 0.00 A	All set-ups	TRUE	-2	
16-15 Frequency [%] 0.00 %	All set-ups	TRUE	-2	N2
16-16 Torque [Nm] 0.0 Nm	All set-ups		-1	Int32
16-17 Speed [RPM] 0 RPM	All set-ups	TRUE	67	Int32
16-18 Motor Thermal 0.9%		TRUE		
16-22 Torque [%] 0 %	All set-ups	TRUE	0	Int16
16-3* Drive Status	All - 1	TRUE	Adama de la constanta de la co	
16-30 DC Link Voltage 0 V 16-32 Brake Energy / 5 0.000 kW	All set-ups	TRUE TRUE	0	Uint16
		TRUE	0	UInt32
16-33 Brake Energy /2 min 0.000 kW 16-34 Heatsink Temp. 0.°C	All set-ups All set-ups		100	Uint32 Uint8
16-35 Inverter Thermal 0 %	All set-ups	TRUE	U 100	Uint8
16-36 Inv. Nom. Current Expression Limit	All set-ups		-2	
16-37 Inv. Max. Current ExpressionLimit	All set-ups	TRUE	-2	Uint32
16-38 SL Controller State			Č	Uint8
16-39 Control Card Temp. 0 °C	All set-ups	TRUE	100	Uint8
16-40 Logaing Buffer Full [0] No				
16-5* Ref. & Feedb.				
	All set-ups	TRUE	-1	Int16
16-52 Feedback [Unit] 0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
16-53 Digi Pot Reference		TRUE	-2	
16-54 Feedback 1 [Unit] 0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
16-55 Feedback 2 Unit 0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
16-56 Feedback 3 [Unit] 0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
16-58 PID Output [%] 0.0 %	All set-ups	TRUE	-1	Int16
16-59 Adjusted Setpoint 0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32



Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
	uts & Outputs					
16-60	Digital Input	0 N/A	All set-ups	TRUE	0	Uint16
16-61	Terminal 53 Switch Setting	[0] Current	All set-ups		•	
16-62	Analog Input 53	0.000 N/A	All set-ups	TRUE	-3	Int32
16-63	Terminal 54 Switch Setting	[0] Current	All set-ups	TRUE	**************************************	Uint8
16-64	Analog Input 54	0.000 N/A	All set-ups	TRUE	-3	Int32
16-65	Analog Output 42 [mA]	0.000 N/A		TRUE	-3	Int16
16-66	Digital Output [bin]	0 N/A	All set-ups	TRUE	00	Int16
16-67	Pulse Input #29 [Hz]	0 N/A		TRUE	0	Int32
16-68	Pulse Input #33 [Hz]	0 N/A	All set-ups	TRUE	0	Int32
	Pulse Output #27 [Hz]	0:N/A	All set-ups	TRUE	0	Int32
16-70	_Pulse Output #29 [Hz]	0 N/A	All set-ups	TRUE	0	Int32
16-71	Relay Output [bin]	0 N/A	All set-ups		0	Uint16
16-72	Counter A	0 N/A	All set-ups	TRUE	0	Int32
16-73	Counter B	O:N/A	All set-ups	TRUE	0	Int32
16-75	Analog In X30/11	0.000 N/A	All set-ups	TRUE	-3	Int32
16-76	Analog In X30/12	0.000 N/A		TRUE	-3	Int32
16-77	Analog Out X30/8 [mA]	0.000 N/A	All set-ups	TRUE	-3	Int16
	dbus & FC Port	A PARKET				
16-80	Fieldbus CTW 1	0 N/A	All set-ups	TRUE	0	V2
	Fieldbus REF-1	-0 N/A		TRUE	0	- N2
16-84	Comm. Option STW	0 N/A	All set-ups	TRUE	0	V2
	FC Port CTW 1	0 N/A	All set-ups	TRUE	0	V2
16-86	FC Port REF 1	0 N/A	All set-ups	TRUE	00	N2
	nosis Readouts					
16-90	Alarm Word	0 N/A	All set-ups	TRUE	0	Uint32
16-91	Alarm Word 2	0 N/A	All set-ups		0 11	Uint32
16-92	Warning Word	0 N/A	All set-ups	TRUE	0	Uint32
16-93	Warning Word 2	0 N/A	All set-ups	TRUE	06400000	
16-94	Ext. Status Word	0 N/A	All set-ups	TRUE	0	Uint32
16-95	Ext. Status Word 2	0 N/A			0	Uint32
16-96	Maintenance Word	0 N/A	All set-ups	TRUE	0	Uint32
						

8.3.16. Data Readouts 2 18-**

I8-0* Maintenance Log 0 Maintenance Log: Item 0 N/A All set-ups 18-00 Maintenance Log: Item 0 N/A All set-ups 18-02 Maintenance Log: Time 0 s All set-ups 18-03 Maintenance Log: Date and Time Item (Expression Limit) All set-ups 18-3* Inputs & Outputs 0 cooo N/A All set-ups 18-30 Analog Input X42/1: 0.000 N/A All set-ups		0 0 0	Uint8 Uint8 Uint32
18-00 Maintenance Log: Item 0 N/A All set-ups 18-01 Maintenance Log: Action 0 N/A All set-ups 18-02 Maintenance Log: Time 0 s All set-ups 18-03 Maintenance Log: Date and Time ExpressionLimit All set-ups 18-3* Inputs & Outputs	FALSE	0 0 0	Uint8
18-02 Maintenance Log: Time 0 s All set-ups 18-03 Maintenance Log: Date and Time; 0 s All set-ups 18-3* Inputs & Outputs		0	
18:03 Maintenance Log: Date and Time All set-ups 18:03 Maintenance Log: Date and Time All set-ups 18:03 Maintenance Log: Date and Time All set-ups	FALSE	0	Uint32
18-3* Inputs & Outputs			
18-3* Inputs & Outputs	FALSE	0	TimeOfDay
18-30 Analog Input X42/1 0.000 N/A All set-ups			
	FALSE	-3	Int32
18-31 Analog Input X42/3 0.000 N/A All set-ups	FALSE	-3	Int32
18-32 Analog Input X42/5 0.000 N/A All set-ups	FALSE	-3	Int32
18-33 Analog Out X42/7 [V] 0.000 N/A All set-ups	FALSE	-3	Int16
18-34 Analog Out X42/9 [V] 0.000 N/A All set-ups	FALSE	-3	Int16
18-35 Analog Out X42/11 [V] 0.000 N/A All set-ups	FALSE	-3	Int16

8	.3	.1	7.	FC	CI	<u>osed</u>	Loo	20) - **

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
20-0* Fee 20-00	edback Feedback 1 Source	[2] Analog input 54	All set-ups	TRUE	-	Uint8
	Feedback 1 Conversion	[2] Androg injects			-	Uint8
20-02	Feedback 1 Source Unit	null	All set-ups	TRUE	-	Uint8
20-03	Feedback 2 Source	[0] No function	All set-ups		-	Uint8
20-04	Feedback 2 Conversion	f01 Linear	All set-ups	FALSE	-	Uint8
20-05	Feedback 2 Source Unit	null	All set-ups	TRUE	-	Uint8
20-06	Feedback 3 Source	[0] No function	All set-ups	TRUE	-	Uint8
20-07	Feedback 3 Conversion	[0] Linear	All set-ups	FALSE	-	Uint8
20-08	Feedback 3 Source Unit	null	All set-ups	TRUE	-	Uint8
20-12	Reference/Feedback Unit	null	All set-ups	TRUE	-	Uint8
20-2* Fee	edback/Setpoint					
	Feedback Function	[4] Maximum	: All set-ups	TRUE	-	Uint8
20-21	Setpoint 1	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-22	Setpoint 2	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-23	Setpoint 3	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-7* PID	Autotuning					
20-70	Closed Loop Type	· [0] Auto	2 set-ups	TRUE	•	Uint8
		[0] Normal	2 set-ups			
20-72	PID Output Change	0.10 N/A	2 set-ups	TRUE	-2	Uint16
	Minimum Feedback Level				-3	
20-74	Maximum Feedback Level	999999,000 ProcessCtrlUnit	2 set-ups	TRUE	-3	Int32
		([0] Disabled	All set-ups	TRUE	-	Uint8
) Basic Settings					
	PID Normal/Inverse Control		Marie Committee		-	
20-82	PID Start Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
		ExpressionLimit		TRUE	-1	***************************************
20-84	On Reference Bandwidth	5 %	All set-ups	TRUE	0	Uint8
20-91	PID Anti Windup	[1] On	All set-ups	TRUE	-	Uint8
	PID Proportional Gain	2:00.N/A			-2	Onicad
20-94 20-95	PID Integral Time	8.00 s	All set-ups	TRUE	-2 -2	Uint32
	PID Differentiation Time PID Diff. Gain Limit	00:00;s	······································			<u> </u>
20-96	PID DITT. GAIN LIMIT	5.0 N/A	All set-ups	TRUE	-1	Uint16

œ

8.3.18. Ext. Closed Loop 21-**

ar. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
·	CLAutotuning			TRUE		Uint8
1-00	Closed Loop Type	[0] Auto (0) Norma	2 set-ups		are and reconsiders.	
	PID Performance		2 set-ups	TRUE	-2	Uint16
1-02	PID Output Change	0.10 N/A =999999.000 N/A				
	Minimum/Feedback/Level	999999.000 N/A	2 set-ups	TRUE	-3	Int32
1-04	Maximum Feedback Level	999999.000 N/A (0) Disabled				
	3.3.5.5.5.5.5.5.5.5.5.5.5.5.5.5.5.5.5.5	U UISADIEU	All Secrups	E RUC		www. gunico
	. CL 1 Ref./Fb.		HERBERGER ALL CORNED OF ST	ATRUE	NAMES OF STREET	0441110
	Ext. 1 Ref./Feedback/Unit	0,000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
1-11	Ext. 1 Minimum Reference			TRUE		
	Ext. 1 Maximum Reference	[0] No function	All set-ups	TRUE		Uint8
1-13	Ext. 1 Reference Source	[0] No function		TRUE	- NATIONAL DISCONSTITUTION	
	Ext. 1 Feedback Source	0.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
1-15	Ext. 1 Setpoint	0.000 ExtPID1Unit				
	Ext. 1 Reference [Unit]	0.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
1-18	Ext. 1 Feedback [Unit]	0.000 EXPIDITION		TRUE		
	Ext./1 Output [%]	U 70	All Set-ups	KUE	0, - 3 3	1576 201103
	. CL 1 PID	[O] Normal	All set-ups	TRUE	atour court to subject to	Uint
	Ext: 1. Normal/Inverse Control	0.50 N/A	All set-ups	TRUE	-2	Uint1
1-21	Ext. 1 Proportional Gain		All set-ups			
	Ext. 1 Integral Time	0.00 s	All set-ups	TRUE	-2	Uint1
1-23	Ext. 1 Differentation Time					
	Ext 1 Dif Gain Limit	3.V.N/A	All Settups	IRUL	Selection of Property and	VANA OILLE
	. CL 2 Ref./Fb.	[0]	All estance	TRUE	Sensor and Page	e do Uloti
	Ext. 2 Ref./Feedback/Unit Ext. 2 Minimum Reference	0.000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
1-31		100.000 ExtPID2Unit				
	Ext. 2. Maximum Reference	[0] No function	All set-ups	TRUE		Uint8
1-33	Ext. 2 Reference Source Ext. 2 Feedback Source	[0] No function			rice (Carolina Article)	
	Ext. 2 Setpoint	0,000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
1-35	Ext. 2 Reference (Unit)	0.000 EXP102011R				
1-37 1-38	Ext. 2 Feedback (Unit)	0,000 ExtPID2Unit	All set-ups	TRUE	-3	Int3
	Ext. 2 Peedback (Unit) Ext. 2 Output [%]	0,000 EXPIDED III		TRUE		
	CL 2 PID		Zii 3cc Qh3	COLUMN TO LEGISLATION OF THE PARTY OF THE PA	AND THE REAL PROPERTY OF THE PARTY OF THE PA	
	Ext; 2: Normal/Inverse Control	(O) Normal	Allications	TRUE		Пин
	Ext. 2 Proportional Gain	0.50 N/A	All set-ups	TRUE	-2	Uint1
1-41	Ext. 2 Proportional Gain Ext. 2 Integral Time	20.00 s		TRUE		
		0.00 s	All set-ups	TRUE	-2	Uint1
1-43	Ext. 2 Differentation Time	0.00 s 5:0 N/A	All Secrups	IKUE		Uinti

Page 133 of 333

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
21-5* Fx	t. CL 3 Ref./Fb.			COII	SIGN THUCK	7.4.2.8.2.2.3.3.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1
21-50	Ext. 3 Ref./Feedback Unit	[0]	All set-ups	TRUE	-	Uint8
21-51	Ext. 3 Minimum Reference	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-52	Ext. 3 Maximum Reference	100.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-53	Ext. 3 Reference Source	[0] No function	All set-ups	TRUE	(1) (v. 147649) v 17	CUint8
21-54	Ext. 3 Feedback Source	[0] No function	All set-ups	TRUÉ	-	Uint8
21-55	Ext: 3 Setpoint	0.000 ExtPID3Unit	All set-ups	TRUE	-3/	Int32
21-57	Ext. 3 Reference [Unit]	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-58	Ext, 3 Feedback [Unit]	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-59	Ext. 3 Output [%]	0 %	All set-ups	TRUE	00	Int32
21-6* Ex	t. CL 3 PID					S. 16 May
21-60	Ext. 3 Normal/Inverse Control	[0] Normal	All set-ups	TRUE	-	Uint8
21-61	Ext. 3 Proportional Gain	0.50 N/A	All set-ups	TRUE	-2	Uint16
21-62	Ext. 3 Integral Time	20.00 s	All set-ups	TRUE	-2	Uint32
21-63	Ext. 3 Differentation Time	0.00's	All set-ups	TRUE	-2	≪Uint16
21-64	Ext. 3 Dif. Gain Limit	5.0 N/A	All set-ups	TRUE	-1	Uint16
1						

Page 135 of 333



8.3.19. Application Functions 22-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
	<u> </u>					
22-00	External Interlock Delay	0 s	All set-ups	TRUE	0	Uint16
	Flow Detection					
22-20	Low Power Auto Set-up	[0] Off	All set-ups	FALSE	-	Uint8
22-21	Low Power Detection	[0] Disabled	All set-ups	TRUE	-7	Uint8
22-22	Low Speed Detection	[0] Disabled	All set-ups	TRUE	-	Uint8
22-23	No-Flow Function	[0] Off	All set-ups	TRUE		Uint8
22-24	No-Flow Delay	10 s	All set-ups	TRUE	0	Uint16
22-26	Dry Pump Function	[0] Off	All set-ups	TRUE		Uint8
22-27	Dry Pump Delay	10 s	All set-ups	TRUE	0	Uint16
22-3* No-I	Flow Power Tuning					5.70 1 1 5.93
22-30	No-Flow Power	0.00 kW	All set-ups	TRUE	1	Uint32
22-31	Power Correction Factor	100.%	All set-ups	TRUE	. 0	Uint16
22-32	Low Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
		ExpressionLimit		TRUE	-1	Uint16
22-34	Low Speed Power [kW]	ExpressionLimit	All set-ups	TRUE	1	Uint32
22-35	Low Speed Power [HP]	ExpressionLimit			-2	Uint32
22-36	High Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
	High Speed [Hz]	() (ExpressionLimit	All set-ups		3-1 (C)	Uint16
22-38	High Speed Power [kW]	ExpressionLimit	All set-ups	TRUE	1	Uint32
	High Speed Power [HP]	ExpressionLimit		TRUE	-2	Uint32
22-4* Slee						
	Minimum Run Time	_2340.002	All set-ups	TRUE	(a)((1.50) \ \	Uint16
22-41	Minimum Sleep Time	30 s	All set-ups	TRUE	0	Uint16
22-42	Wake-up Speed [RPM]	ExpressionLimit	All set-ups		67	Uint16
22-43	Wake-up Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-44	Wake-up Ref./FB Difference	10.%	All set-ups		o o	Int8
22-45	Setpoint Boost	0 %	All set-ups	TRUE	0	Int8
	Maximum Boost Time	60 s			<i>a</i> . 0	Uint16
22-5* End						
	End of Curve Function	[0] Off	All set-ups	TRUE	-	Uint8
22-51	End of Curve Delay	10 s	All set-ups	TRUE	0	Uint16
	en Belt Detection	TO A THE STATE OF	** ** PANSET AND SE			011(10
22-60	Broken Belt Function	[0] Off	All set-ups	TRUE	-	Uint8
		10.%		TRUE	- 	Uint8
22-62	Broken Belt Delay	10 s	All set-ups	TRUE	0	Uint16
	t Cycle Protection	1	All Sec-ups			OIIILIO
	Short Cycle Protection	[0] Disabled	All set-ups	TRUE	_	Uint8
	Interval between Starts	start to start min on time (P2277)			0	Uint16
22-77	Minimum Run Time	0 s	All set-ups	TRUE	0	Uint16 Uint16
22 //	THIRIDIN NOT TIME	V 3	All Set-ups	INUL		JIILIO

Par. No. #		Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
22-8* Flo	ow Compensation					
22-80	Flow Compensation	[0] Disabled	All set-ups	TRUE	•	Uint8
22-81	Square-linear Curve Approximation	100 %	All set-ups	TRUE	0	Uint8
22-82	Work Point Calculation	[0] Disabled	All set-ups	TRUE	-	Uint8
22-83	Speed at No-Flow [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
22-84	Speed at No-Flow [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-85	Speed at Design Point [RPM]	ExpressionLimit	All set-ups	TRÚE	67	Uint16
22-86	Speed at Design Point [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-87	Pressure at No-Flow Speed	0.000 N/A	All set-ups	TRÜE	-3	Int32
22-88	Pressure at Rated Speed	999999.999 N/A	All set-ups	TRUE	-3	Int32
22-89	Flow at Design Point	0.000 N/A	All set-ups	TRUE	-3	Int32
22-90	Flow at Rated Speed	0.000 N/A	All set-ups	TRUE	-3	Int32

	Q	9	

Par. No. #	Parameter description	Default value	4-set-up	Change during opera-	Conver-	Туре
				tion	sion index	
23-0-11m	ned Actions					TimeOfDay-
23-00	ON Time	ExpressionLimit	2 set-ups	TRUE	n	WoDate
23-00		[O] Disabled	2 set-ups			Uint8
Expid-	ON ACCION	[9]89-50-53		,,,,,,	*****	TimeOfDay-
23-02	OFF Time	ExpressionLimit	2 set-ups	TRUE	0	WoDate
23-03	OFF Action	[0] Disabled	2 set-ups			Uint8
23-04	Occurrence	[0] All days	2 set-ups	TRUE	-	Uint8
	Intenance					
23-10	Maintenance Item	[1] Motor bearings	1 set-up	TRUE	•	Uint8
23-11	Maintenance Action	[1] Lubricate	1 set-up		•	Uint8
23-12	Maintenance Time Base	[0] Disabled	1 set-up	TRUE	-	Uint8
23-13	Maintenance Time Interval	<u>1 h</u>	1 set-up		····	Uint32
23-14	Maintenance Date and Time	ExpressionLimit	1 set-up	TRUE	0	TimeOfDay
	Intenance Reset	10.5	***			
23-15	Reset Maintenance Word	[0] Do not reset	All set-ups	TRUE	-	Uint8
23-16	Maintenance Text	0.N/A	1 set-up	TRUE	0	VisStr[20]
23-5* Ene		[5] Last 24 Hours		TRUE		Uint8
23-50	Energy_Log_Resolution Period Start	ExpressionLimit	2 set-ups 2 set-ups	TRUE	0	TimeOfDay
23-51	Energy Log	0 N/A	All set-ups	TRUE	0	Uint32
23-54	Reset Energy Log	[0] Do not reset	All set-ups	TRUE	-	Uint8
	ending	[0] DO NOCTOSEC	All Set ups	TIVOE		Oliko
23-60	Trend Variable	[0] Power [kW]	2 set-ups	TRUE	-	Uint8
23-61	Continuous Bin Data	O.N/A	All set-ups	TRUE	0	Uint32
23-62	Timed Bin Data	0 N/A	All set-ups	TRUE	0	Uint32
23-63	Timed Period Start	ExpressionLimit	2 set-ups	TRUE	- 0	TimeOfDay
23-64	Timed Period Stop	ExpressionLimit	2 set-ups	TRUE	0	TimeOfDay
23-65	Minimum Bin Value	ExpressionLimit	2 set-ups	TRUE	0	Uint8
23-66	Reset Continuous Bin Data	[0] Do not reset	All set-ups	TRUE	-	Uint8
	Reset Timed Bin Data	[0] Do not reset	All set-ups	TRUE		Uint8
	yback Counter					
	Power Reference Factor	100 %	**************************************			
23-81	Energy Cost	1.00 N/A	2 set-ups	TRUE	-2	Uint32
23-82	Investment	0.N/A	2 set-ups			
23-83	Energy Savings	0 kWh	All set-ups	TRUE	75	Int32
23-84	Cost Savings	0.N/A	All set-ups	TRUE	0	Int32

8.3.20. <u>Timed Actions 23-**</u>

MG.20.M5.02 - VLT* is a registered Danfoss trademark

8.3.21. Cascade Controller 25-**

Par. No. #	Parameter description		Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
	bern Settings						
25-00	Cascade Controller		null	2 set-ups	FALSE	-	Uint8
	Motor Start		[0] Direct on Line	2 set-ups		200 - 1 200	.: Uint8
25-04	Pump Cycling		null	All set-ups	TRUE	-	Uint8
			null				
25-06	Number of Pumps		2 N/A	2 set-ups	FALSE	0	Uint8
	ndwidth Settings						
25-20	Staging Bandwidth		ExpressionLimit	All set-ups	TRUE	0	Uint8
	Override Bandwidth		100 %				
25-22	Fixed Speed Bandwidth		casco_staging_bandwidth (P2520)	All set-ups	TRUE	0	Uint8
25-23 😓 🚉			6 Land 15 S				*************
25-24	SBW Destaging Delay		15 s	All set-ups	TRUE	0	Uint16
	OBW Time		10 5			0.	
25-26	Destage At No-Flow		[0] Disabled	All set-ups	TRUE	-	Uint8
25-27			null -				Uint8
25-28	Stage Function Time		15 s	All set-ups	TRUE	0	Uint16
	Destage Function		<u>null</u>				
25-30	Destage Function Time		15 s	All set-ups	TRUE	0	Uint16
	ging Settings						
25-40	Ramp Down Delay		10.0 s 2.0 s	All set-ups	TRUE	-1	Uint16
25-41 25-42	Ramp Up Delay					1100-20-00-00-00-00-00-00-00-00-00-00-00-0	
	Staging Threshold	250 72 11 10 10 10 10 10 10 10 10 10 10 10 10	ExpressionLimit	All set-ups	TRUE	0	Uint8
	Destaging Threshold		ExpressionLimit				Uint8
25-44	Staging Speed [RPM]		0 RPM	All set-ups	TRUE	67	Uint16
25-45 25-46	Staging Speed [Hz]		0.0 Hz 0 RPM		TRUE		
	Destaging Speed [RPM] Destaging Speed [Hz]			All set-ups		67	Uint16
	ernation Settings		side of the state	All sectops	SKYZ (SACKIKUE) AWA		- PAY OITITED
			A STATE OF THE STA	All continue to the	TRUE		Uint8
25-50; 25-51	Alternation Event	38 S S S S S S S S S S S S S S S S S S S	[0] External	All set-ups	TRUE		Uint8
	Alternation Time Interval	MAN (All set-ups	TRUE	274 (SV2)	Uint16
25-53	Alternation Timer Value		0 N/A	All set-ups	TRUE	0	VisStr[7]
23-33	Alternation Times value		UNYA	All Set-ups	TRUE	- V	TimeOfDa
25-54	Alternation Predefined Time		ExpressionLimit	All set-ups	TRUE	The County of the	WoDate
25-55	Alternate if Load < 50%		[1] Enabled	All set-ups	TRUE	<u> </u>	Uint8
	Staging Mode at Alternation		[1] Chapled			WAREST IN THE SERVICE	Uint8
25-58	Run Next Pump Delay		0.1 s	All set-ups	TRUE	_1	Uint16
25-59 V.I.:		SENSONE CONSETTS SINCE OF A CONSENSION	0.1 S			-1 \$887 (-1 197)	Uint16
CJ:JY	null on Pidlis Delay of Section 1997	THE RESIDENCE OF THE PROPERTY	San	All Set-ups/ All Set-	U SPACI KUE	th their best T.L. Washers	Unita



8. How to programme the frequency converter **Banfold**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
25-8* Star	tus				37.38.77.4	
25-80	Cascade Status	0 N/A	All set-ups	TRUÉ	0	VisStr[25]
25-81	Pump Status	0 N/A	All set-ups	TRUE	% √·0	VisStr[25]
25-82	Lead Pump	0 N/A	All set-ups	TRUE	0	Uint8
25-83	Relay Status	0 N/ A	All set-ups	TRUE	0	VisStr[4]
25-84	Pump ON Time	0 h	All set-ups	TRUE	74	Uint32
25-85	Relay ON Time	0 h	All set-ups	TRUE	74	Uint32
25-86	Reset Relay Counters	[0] Do not reset	All set-ups	TRUE	-	Uint8
25-9* Sen	vice					
25-90	Pump Interlock	[0] Off	All set-ups	TRUE	-	Uint8
25-91	Manual Alternation	0 N/A	All set-ups	TRUE	0	Uint8

8.3.22. Analog I/O Option MCB 109 26-**

Par. No. # Parameter description	Default value	4-set-up	Change during opera-	Conver-	Type
			tion	sion index	
26-0* Analog I/O Mode		<u></u>			
26-00 Terminal X42/1 Mode	[1] Voltage	All set-ups	TRUE	-	Uint8
	1 Voltage		TRUE	<u> </u>	Uint8
26-02 Terminal X42/5 Mode	[1] Voltage	All set-ups	TRUE		Uint8
	0.07 V		TRUE	-2	Int16
26-10 Terminal X42/1 Low Voltage		All set-ups			
26-11 Terminal X42/1 High Voltage			TRUE	-2 -3	Int32
26-14 Term. X42/1 Low Ref./Feedb. Value	0.000 N/A	All set-ups			
26-15 Term. X42/1 High Ref:/Feedb. Value 26-16 Term, X42/1 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	Uint16
26-16 Term. X42/1 Filter Time Constant [26-17] Term. X42/1 Live Zero	0.001 s				Uint8
26-2* Analog Input X42/3	[1] chabled	All Set-ups	IRUE		CONTROL I
26-20 — Terminal X42/3 Low Voltage	7:007V	All cotains	TDUE	2000 22000 2000	Int16
26-21 Terminal X42/3 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
	0.000 N/A			-3.5	Int32 1
26-25 Term, X42/3 High Ref./Feedb, Value	100.000 N/A	All set-ups	TRUE	-3	Int32
26-26 Term, X42/3 Filter Time.Constant	0.001 s			-3	
26-27 Term, X42/3 Live Zero	[1] Enabled	All set-ups	TRUE	-	Uint8
26-3* Analog Input X42/5		/ III Set Ops		75 C 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	N. 12 (1887)
26-30 Terminal X42/5 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
26-31 Terminal X42/5 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
26-34 Term. X42/5 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
26-35 Term: X42/5 High Ref:/Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
26-36 Term. X42/5 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	Uint16
	[1] Enabled	All set-ups	TRUE		Uint8
26-4* Analog Out X42/7					
26-40 Terminal X42/7 Output					
26-41 Terminal X42/7 Min. Scale	0.00 %	All set-ups	TRUE	-2	Int16
26-42 Terminal X42/7 Max. Scale	100.00 %			-2 -2	
26–43 Terminal X42/7 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
26-44 Terminal X42/7 Timeout Preset	0.00%	1 set-up	TRUE	<u> </u>	Uint16
26-5* Analog Out X42/9		Allecations			SECTION OF THE PROPERTY OF THE
26-50 Terminal X42/9 Output 26-51 Terminal X42/9 Min. Scale	0.00 %	All set-ups	TRUE	-2	Uint8 Int16
26-51 Terminal X42/9 Min. Scale [26-52 Terminal X42/9 Max. Scale			TRUE		
26-53 Terminal X42/9 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
26-54 Terminal X42/9 Timeout Preset	0.00 %				
26-6* Analog Out X42/11	20.00 76	1. Set-up	INUE		Unicio V
	[0].No operation	All set-ups	TRUE		Uint8
26-61 Terminal X42/11 Min. Scale	0.00 %	All set-ups	TRUE	-2	Int16
26-62 Terminal X42/11 Max. Scale		All set-ups		-2	
26-63 Terminal X42/11 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
26-64 Terminal X42/11 Timeout Preset				-2	
			<u> </u>		

8.3.23. Cascade CTL Option 27-**

Par. No. # Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
	501.0				
27-01 Pump Status	[0] Ready	All set-ups	TRUE	· ·	Uint8
27-02 Manual Pump Control	[0] No Operation	2 set-ups	TRUE	74	Uint8
27-03 Current Runtime Hours	0 h	All set-ups	TRUE	74 74	Uint32
27-04 Pump Total Lifetime Hours	<u>0 h</u>	All set-ups	TRUE	/4	Uint32
27-1* Configuration	(0) Disabled	3 1	FALSE		- 10-10 1
27-10 Cascade Controller			FALSE	0	Uint8 Uint8
27-11 Number Of Drives	1 N/A ExpressionLimit	2 set-ups	FALSE	0	Uint8
C. IZ. Munici O' ampo	ExpressionLimit 100 %	2 set-ups	78888888888888888888888888888888888888	0	Uint16
27-14 Pump Capacity	[0] Balanced Priority 1	2 set-ups 2 set-ups	FALSE TRUE	U	Uint8
27-16 Runtime Balancing	[0] Direct Online	2 set-ups	FALSE		Uint8
27-17 Motor Starters		Z set-ups All set-ups	TRUE	- 0	
27-18 Spin Time for Unused Pumps 27-19 Reset Current Runtime Hours	ExpressionLimit (0) Do not reset	All set-ups	TRUE	<u> </u>	Uint16 Uint8
27-19 Reset Current Runtime Hours 27-2* Bandwidth Settings	[U] Do not reset			•	
27-20 Normal Operating Range	ExpressionLimit	All set-ups	TRUE	0	Uint8
27-20 Normal Operating Range	ExpressionLimit 100 %	All set-ups	TRUE	·	Uint8
27-22 Fixed Speed Only Operating Range	ExpressionLimit	All set-ups	TRUE	0	Uint8
27-23 Staging Delay	15.5		TRUE		
27-24 Destaging Delay	15 s	All set-ups	TRUE	0	Uint16
27-25 Override Hold Time	10.5		TRUE	· · · · · · · · · · · · · · · · · · ·	Uint16
27-27 Min Speed Destage Delay	ExpressionLimit	All set-ups	TRUE	0	Uint16
	ExpressionEmit	All Set-ups	TRUL	U	OIIICIO
27-31 Stage On Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
27-32 Stage On Speed [Hz]	ExpressionLimit		TRUE		Uint16
27-33 Stage Off Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint 16
	ExpressionLimit		TRUE		Uint16
27-4* Staging Settings	Expressionaling	rui sec ops	INOL		Onicio /
27-40 Auto Tune Staging Settings	[1] Enabled	All set-ups	TRUE	Students -	Uint8
27-41 Ramp Down Delay	10.0 s	All set-ups	TRUE	-1	Uint16
27-42 Ramp Up Delay	2.0 s	All set-ups		-1	Uint16
27-43 Staging Threshold	ExpressionLimit	All set-ups	TRUE	0	Uint8
27–44 Destaging Threshold	ExpressionUmit	All set-ups		~ 3° 0 37	Uint8
27-45 Staging Speed [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
27-46 Staging Speed [Hz]	0.0 Hz	All set-ups		- 188 V-18V-18V-18V	Uint16
27-47 Destaging Speed [RPM]	0 RPM	All set-ups	TRUE	67	Uint16
27-48 Destaging Speed [Hz]	0.0 Hz	All set-ups		-1	Uint16
27-5* Alternate Settings			1.12 T.		
27-50 Automatic Alternation	[0] Disabled	All set-ups	FALSE	1 S	Uint8
27-51 Alternation Event	null	All set-ups	TRUE	-	Uint8
27-52 Alternation Time Interval	0 min			70	Uint16
27-53 Alternation Timer Value	0 min	All set-ups	TRUE	70	Uint16
	[0] Disabled	All_set-ups		- 1000	Uint8
					TimeOfDayWo-
27-55 Alternation Predefined Time	ExpressionLimit	All set-ups	TRUE	0	Date
27-56 Alternate Capacity is <			TRUE	0	
27-58 Run Next Pump Delay	0.1 s	All set-ups	TRUE	-1	Uint16

Par. No. #		Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
27-6* DI	ital Inputs				C. 40 . 168X	
27-60	Terminal X66/1 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
27-61	Terminal X66/3 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
27-62	Terminal X66/5 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
27-63	Terminal X66/7 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
27-64	Terminal X66/9 Digital Input	[0] No operation	All set-ups	TRUE	•	Uint8
27-65	Terminal X66/11 Digital Input	[0] No operation	All set-ups	TRUE		Uint8
27-66	Terminal X66/13 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
27-7* Co	nnections		-		7	
27-70	Relay	[0] Standard Relay	2 set-ups	FALSE	-	Uint8
27-9* Re	adouts					
27-91	Cascade Reference	0.0.%	All set-ups	TRUE	-1	Int16
27-92	% Of Total Capacity	0%	All set-ups	TRUE	0	Uint16
27-93	Cascade Option Status	[0] Disabled	All set-ups	TRUE	•	Uint8





8.3.24. Water Application Functions 29-**

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
29-0* PI	e Fill					
29-00	Pipe Fill Enable	[0] Disabled	2 set-ups	FALSE	-	Uint8
29-01	Pipe Fill Speed (RPM)	ExpressionLimit	All set-ups	TRUE	67.	Uint16
29-02	Pipe Fill Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
29-03	Pipe Fill Time	0.00 _. s	All set-ups	TRUE	<u></u>	Uint32
29-04	Pipe Fill Rate	0.001 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
29-05	Filled Setpoint	0.000 ProcessCtrlUnit	All_set-ups	TRUE	<u> </u>	Int32

Par. No. #	Parameter description	Default value	4-set-up	Change during opera- tion	Conver- sion index	Туре
31-00	Bypass Mode	[0],Drive	All set-ups	TRUE	-	- Uint8
	Bypass Start Time Delay	30 s	All set-ups	TRUE	0	Uint16
31-02	Bypass Trip Time Delay	0 s	All set-ups	TRUE	0	Uint16
31-03	Test Mode Activation	[0] Disabled	All set-ups	TRUE	-	Uint8
31-10	Bypass: Status: Word	0:N/A	All set-ups	FALSE	0	V2 .
	Bypass Running Hours	0 h	All set-ups	FALSE	74	Uint32
31-19	Remote Bypass Activation	[0] Disabled	2 set-ups	TRUE	-	Uint8

9. Troubleshooting



VLT® AQUA Drive Operating Instructions



9. Troubleshooting

9. Troubleshooting

9.1. Alarms and warnings

A warning or an alarm is signalled by the relevant LED on the front of the frequency converter and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

In the event of an alarm, the frequency converter will have tripped. Alarms must be reset to restart operation once their cause has been rectified.

This may be done in four ways:

- $1. \hspace{0.5cm} \hbox{By using the [RESET] control button on the LCP control panel.} \\$
- Via a digital input with the "Reset" function.
- Via serial communication/optional fieldbus.
- By resetting automatically using the [Auto Reset] function, which is a default setting for VLT AQUA Drive. see par. 14-20 Reset Mode in VLT AQUA Drive Programming Guide



NB!

After a manual reset using the [RESET] button on the LCP, the [AUTO ON] or [HAND ON] button must be pressed to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also table on following page).

Alarms that are trip-locked offer additional protection, means that the mains supply must be switched off before the alarm can be reset. After being switched back on, the frequency converter is no longer blocked and may be reset as described above once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in parameter 14-20 (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in the table on the following page, this means that either a warning occurs before an alarm, or it can be specified whether it is a warning or an alarm that is to be displayed for a given fault.

This is possible, for instance, in parameter 1-90 *Motor Thermal Protection*. After an alarm or trip, the motor carries on coasting, and the alarm and warning flash on the frequency converter. Once the problem has been rectified, only the alarm continues flashing.

a

Danfoss

No.	Description	Warning	Alarm/Trip	Alarm/Trip Lock	Parameter Reference
1	10 Volts low	X 🛇	22	7.3	
	Live zero error	(X)	(X)		6-01
3	No motor	(X)	·	- 1 A 1 A 2	1-80
4	Mains phase loss	(X)	(X)	(X)	14-12
5	DC link voltage high	X	TO STORY OF STREET		
6	DC link voltage low	X			
7	DC over voltage	Χ	X		
8	DC under voltage	X	X		
9	Inverter overloaded	X	······································		
10	Motor ETR over temperature	(X)	(X)		1-90
11	Motor thermistor over temperature	(X)	(X)	V 100 K	1-90
12	Torque limit	X	X		
13	Over Current	X + 7%	1 X	· X	
	Earth fault	X	X	X	
15	Hardware mesh mash		X	X	79.
16	Short Circuit		X	X	
17	Control word timeout	(X)	(<u>X</u>)		8-04
25	Brake resistor short-circuited	X			
26	Brake resistor power limit	(X)	(X)		2-13
27	Brake chopper short-circuited	X	X		
28	Brake check	(X)	(X)		2-15
29	Power board over temp	X	X	X	
30	Motor phase U missing	(X)	(X)	(X)	4-58
31	Motor phase V missing	(X)	(X)	(X)	4-58
32	Motor phase W missing	(X)	(X)	(X)	4-58
33	Inrush fault		X	Χ	
34	Fieldbus communication fault	X	X		
38	Internal fault		X	X	
47	24 V supply low	X	X	X	
48	1.8 V supply low		X	X	
50	AMA calibration failed	6.727.003	X		
51	AMA check Unom and Inom		X		
52		(15) KW 13/2/(8)	X		
53	AMA motor too big		X		
	AMA motor too small	4 2 2 4 5 5 5 T	X	01 <u>- 1884</u> - 10	130 g 4 36 g
	AMA parameter out of range		X		
	AMA interrupted by user		X		
57	AMA timeout	· · · · · · · · · · · · · · · · · · ·	X		<u>, , , , , , , , , , , , , , , , , , , </u>
	AMA internal fault	χ		1. 14.700° 4	
59	Current limit	X			
	Tracking Error		(X)		4-30
62	Output Frequency at Maximum Limit	X	شنوشته فينسست المدار مسسست		
	Voltage Limit			4-27 (S. S. S. J. J. S.	7.00
65	Control Board Over-temperature	X	X	X	
	Heat sinke Temperature Low		- 18 19 1		
67	Option Configuration has Changed	atamatan S. Phatagara S. Para	X		
	Safe Stop Activated	8 12 2 2 2 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5 1 4 2 5	TOTAL X CONTRACT	Control of the Contro	- 46aa - 666
80	Drive Initialised to Default Value		X		
00	Diffe Initialized to Deladic Value				

Table 9.1: Alarm/Warning code list

(X) Dependent on parameter

LED indication	
Warning **	yellow
Alarm	flashing red
Trip_locked	yellow and red

VLT® AQUA Drive Operating Instructions



9. Troubleshooting

6 %	: Hex 😅 🔧 🤏	Dec 🎨 🗅	Alarm Word	Warning Word	Extended Status Word
	00000001	1	Brake Check	Brake Check	Ramping
jang de	00000002	Mayor Report to 2 - 1987	Pwr. Card Temp	Pwr. Card Temp	AMA Running
	00000004	4	Earth Fault	Earth Fault	Start CW/CCW
14.7				Ctrl.Card Temp	Slow Down
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	00000010	16	Ctrl. Word TO	Ctrl. Word TO	Catch Up
rights.	00000020	32		The state of the s	Feedback High
	00000040	64	Torque Limit	Torque Limit	Feedback Low
42.0	00000080				Output Current High
	00000100	256	Motor ETR Over	Motor ETR Over	Output Current Low
	00000200		Inverter Overld		
)	00000400	1024	DC under Volt	DC under Volt	Output Freq Low
	100000800		DC over Volt	DC over Volt	
) LYNKOVITY	00001000	4096	Short Circuit	DC Voltage Low	Braking Max
-		8192		The state of the s	Braking
<u> </u>	00004000	16384	Mains ph. Loss	Mains ph. Loss	Out of Speed Range
14.	The state of the s	//∛ 1233 32768 32768	AMA Not OK		OVE Active (1997)
. 22.0	,00010000	65536	Live Zero Error	Live Zero Error	
	00020000			<u>்</u> 10V tów ு	
}	00040000	262144	Brake Overload	Brake Overload	
	200080000		U phase Loss	Brake Resistor	A CONTRACTOR OF THE PARTY OF TH
) SSE 31	00100000	1048576	V phase Loss	Brake IGBT	
1976	2.00200000		Wiphase Loss	Speed Limit	
100	00400000	4194304	Fieldbus Fault	Fieldbus Fault	
-		8388608 16777216	24 V Supply Low :		NAMES OF THE PROPERTY AND ADDRESS OF THE PROPERTY OF THE PROPE
- 6687u	01000000 02000000			Mains Failure	
	04000000 08000000	67108864	Brake Resistor Brake IGBT	Low Temp	
**********	10000000	416 4-1-1 particular de l'annuelle de l'annuelle de l'annuelle de l'annuelle de l'annuelle de l'annuelle de l'a			
) 125		268435456	Option Change	Unused	
ا	40000000	536870912 1073741824	Drive Initialised		
 	40000000	10/3/41824	Safe Stop	Unused	

Table 9.2: Description of Alarm Word, Warning Word and Extended Status Word

The alarm words, warning words and extended status words can be read out via serial bus or optional fieldbus for diagnosis. See also par. 16-90, 16-92 and 16-94.

9.1.1. Fault messages

WARNING 1, 10 Volts low:

The 10 V voltage from terminal 50 on the control card is below 10 V. Remove some of the load from terminal 50, as the 10 V supply is overloaded. Max. 15 mA or minimum 590 Ω .

WARNING/ALARM 2, Live zero error:

The signal on terminal 53 or 54 is less than 50% of the value set in par. 6-10 *Terminal 53 Low Voltage*, par. 6-12 Terminal *53 Low Current*, par. 6-20 *Terminal 54 Low Voltage*, or par. 6-22 Terminal *54 Low Current* respectively.

WARNING/ALARM 3, No motor:

No motor has been connected to the output of the frequency converter.

WARNING/ALARM 4, Mains phase loss:

A phase is missing on the supply side, or the mains voltage imbalance is too high.

This message also appears in case of a fault in the input rectifier on the frequency converter.

Check the supply voltage and supply currents to the frequency converter.

WARNING 5, DC link voltage high:

The intermediate circuit voltage (DC) is higher than the over-voltage limit of the control system. The frequency converter is still active.

WARNING 6, DC link voltage low:

The intermediate circuit voltage (DC) is below the undervoltage limit of the control system. The frequency converter is still active.

WARNING/ALARM 7, DC over voltage:

If the intermediate circuit voltage exceeds the limit, the frequency converter trips after a time.

Possible corrections:

Select **Q**ver **Y**oltage **C**ontrol function in par. 2-17 Over-voltage *Control*

Connect a brake resistor

Extend the ramp time

Activate functions in par. 2-10 Brake Function

Increase par. 14-26 Trip Delay at Inverter Fault

Selecting OVC function will extend the ramp times.

Voltage Range		3.x 380-500 V A
Undervoltage	185	373
Voltage warning low	205	× 410×
Voltage warning high (w/o brake - w/brake)	390/405	810/840
Overvoltage	410	855
The voltages stated are the in- quency converter with a tolera mains voltage is the intermedi by 1.35	ince of ± 5 %. TI	ne corresponding

VLT® AQUA Drive Operating Instructions

9. Troubleshooting



WARNING/ALARM 8, DC under voltage:

If the intermediate circuit voltage (DC) drops below the "voltage warning low" limit (see table above), the frequency converter checks if 24 V back-up supply is connected.

If no 24 V backup supply is connected, the frequency converter trips after a given time depending on the unit.

To check whether the supply voltage matches the frequency converter, see 3.1 General Specifications.

WARNING/ALARM 9, Inverter overloaded:

The frequency converter is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. You <u>cannot</u> reset the frequency converter until the counter is below 90%.

The fault is that the frequency converter is overloaded by more than nominal current for too long.

WARNING/ALARM 10, Motor ETR over temperature:

According to the electronic thermal protection (ETR), the motor is too hot. You can choose if you want the frequency converter to give a warning or an alarm when the counter reaches 100% in par. 1-90 Motor *Thermal Protection*. The fault is that the motor is overloaded by more than nominal current for too long. Check that the motor par. 1-24 *Motor Current* is set correctly.

WARNING/ALARM 11, Motor thermistor over temp:

The thermistor or the thermistor connection is disconnected. You can choose if you want the frequency converter to give a warning or an alarm in par. 1-90 Motor *Thermal Protection*. Check that the thermistor is connected correctly between terminal 53 or 54 (analog voltage input) and terminal 50 (+ 10 Volts supply), or between terminal 18 or 19 (digital input PNP only) and terminal 50. If a KTY sensor is used, check for correct connection between terminal 54 and 55.

WARNING/ALARM 12, Torque limit:

The torque is higher than the value in par. 4-16 Torque *Limit Motor Mode* (in motor operation) or the torque is higher than the value in par. 4-17 Torque *Limit Generator Mode* (in regenerative operation).

WARNING/ALARM 13, Over Current:

The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning will last approx. 8-12 sec., then the frequency converter trips and issues an alarm. Turn off the frequency converter and check if the motor shaft can be turned and if the motor size matches the frequency converter.

ALARM 14, Earth fault:

There is a discharge from the output phases to earth, either in the cable between the frequency converter and the motor or in the motor itself. Turn off the frequency converter and remove the earth fault.

ALARM 15, In-complete hardware:

A fitted option is not handled by the present control board (hardware or software).

ALARM 16, Short-circuit:

There is short-circuiting in the motor or on the motor terminals.

Turn off the frequency converter and remove the short-circuit.

WARNING/ALARM 17, Control word timeout:

There is no communication to the frequency converter.

The warning will only be active when par. 8-04 Control *Timeout Func*tion is NOT set to *OFF*. If par. 8-04 Control *Timeout Function* is set to *Stop* and *Trip*, a warning appears and the frequency converter ramps down to zero speed, while giving an alarm.

par. 8-03 Control Timeout Time could possibly be increased.

WARNING 22, Hoist Mech. Brake:

Report value will show what kind it is.

- 0 = The torque ref. was not reached before timeout
- 1 = There was no brake feedback before timeout

WARNING 23, Internal fans:

External fans have failed due to defect hardware or fans not mounted.

WARNING 24, External fan fault:

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in par. 14-53 Fan *Monitor*, [0] Disabled.

WARNING 25, Brake resistor short-circuited:

The brake resistor is monitored during operation. If it short-circuits, the brake function is disconnected and the warning appears. The frequency converter still works, but without the brake function. Turn off the frequency converter and replace the brake resistor (see par. 2-15 Brake *Check*).

ALARM/WARNING 26, Brake resistor power limit:

The power transmitted to the brake resistor is calculated as a percentage, as a mean value over the last 120 s, on the basis of the resistance value of the brake resistor (par. 2-11 Brake *Resistor (ohm)*) and the intermediate circuit voltage. The warning is active when the dissipated braking power is higher than 90%. If *Trip* [2] has been selected in par. 2-13 Brake *Power Monitoring*, the frequency converter cuts out and issues this alarm, when the dissipated braking power is higher than 100%.

WARNING/ALARM 27, Brake chopper fault:

The brake transistor is monitored during operation and if it short-circuits, the brake function disconnects and the warning comes up. The frequency converter is still able to run, but since the brake transistor has short-circuited, substantial power is transmitted to the brake resistor, even if it is inactive.

Turn off the frequency converter and remove the brake resistor.



Warning: There is a risk of substantial power being transmitted to the brake resistor if the brake transistor is short-circuited.

ALARM/WARNING 28, Brake check failed:

Brake resistor fault: the brake resistor is not connected/working.

WARNING/ALARM 29, Drive over temperature:

If the enclosure isIP00, IP20/Nema1 or IP21/TYPE 1, the cut-out temperature of the heat-sink is 95 °C \pm 5 °C. The temperature fault cannot be reset, until the temperature of the heatsink is below 70 °C.

The fault could be:

- Ambient temperature too high
- Too long motor cable

ALARM 30, Motor phase U missing:

Motor phase U between the frequency converter and the motor is missing.

Turn off the frequency converter and check motor phase U.

144

MG.20.M5.02 - VLT[™] is a registered Danfoss trademark

Page 149 of 333

ALARM 31, Motor phase V missing:

Motor phase V between the frequency converter and the motor is missing. Turn off the frequency converter and check motor phase V.

ALARM 32, Motor phase W missing:

Motor phase W between the frequency converter and the motor is missing.

Turn off the frequency converter and check motor phase W.

ALARM 33, Inrush fault:

Too many powerups have occured within a short time period. See the chapter *General Specifications* for the allowed number of power-ups within one minute.

WARNING/ALARM 34, Fieldbus communication fault:

The fieldbus on the communication option card is not working.

WARNING/ALARM 36, Mains failure:

This warning/alarm is only active if the supply voltage to the frequency converter is lost and parameter 14-10 is NOT set to OFF. Possible correction: check the fuses to the frequency converter

WARNING/ALARM 37, Phase Imbalance:

There is a current imbalance between the power units.

ALARM 38, Internal fault:

Contact your local Danfoss supplier.

ALARM 39, Heatsink Sensor:

No feedback from the heatsink sensor.

WARNING 40, Overload of Digital Output Terminal 27

Check the load connected to terminal 27 or remove short-circuit connection. Check parameters 5-00 and 5-01.

WARNING 41, Overload of Digital Output Terminal 29:

Check the load connected to terminal 29 or remove short-circuit connection. Check parameters 5-00 and 5-02.

WARNING 42, Overload of Digital Output On X30/6:

Check the load connected to X30/6 or remove short-circuit connection. Check parameter 5-32.

WARNING 42, Overload of Digital Output On X30/7:

Check the load connected to X30/7 or remove short-circuit connection. Check parameter 5-33.

ALARM 46, Pwr. card supply:

The supply on the power card is out of range.

WARNING 47, 24 V supply low:

The external 24 V DC backup power supply may be overloaded, otherwise contact your Danfoss supplier.

ALARM 48, 1.8 V supply low:

Contact your Danfoss supplier.

WARNING 49, Speed limit:

The speed has been limited by range in par. 4-11 Motor Speed Low Limit [RPM] and par. 4-13 Motor Speed High Limit [RPM].

ALARM 50, AMA calibration failed:

Contact your Danfoss supplier.

ALARM 51, AMA check Unom and Inom:

The setting of motor voltage, motor current, and motor power is presumably wrong. Check the settings.

ALARM 52, AMA low Inom:

The motor current is too low. Check the settings.

ALARM 53, AMA motor too big:

The motor is too big for the AMA to be carried out.

ALARM 54, AMA motor too small:

The motor is too small for the AMA to be carried out.

ALARM 55, AMA par. out of range:

The par. values found from the motor are outside acceptable range.

ALARM 56, AMA interrupted by user:

The AMA has been interrupted by the user.

ALARM 57, AMA timeout:

Try to start the AMA again a number of times, until the AMA is carried out. Please note that repeated runs may heat the motor to a level where the resistance Rs and Rr are increased. In most cases, however, this is not critical.

WARNING/ALARM 58, AMA internal fault:

Contact your Danfoss supplier.

WARNING 59, Current limit:

The current is higher than the value in par. 4-18 Current Limit.

WARNING 60, External Interlock:

External Interlock has been activated. To resume normal operation, apply 24 VDC to the terminal programmed for External Interlock and reset the frequency converter (via Bus, Digital I/O or by pressing [Reset]).

WARNING/ALARM 61, Tracking Error:

Tracking error. Contact your supplier.

WARNING 62, Output Frequency at Maximum Limit:

The output frequency is limited by the value set in par. 4-19 Max *Output Frequency*

WARNING 64, Voltage Limit:

The load and speed combination demands a motor voltage higher than the actual DC link voltage.

WARNING/ALARM/TRIP 65, Control Card Over Temperature:

Control card over temperature: The cut-out temperature of the control card is 80° C.

WARNING 66, Heatsink Temperature Low:

The heat sink temperature is measured as 0° C. This could indicate that the temperature sensor is defective and thus the fan speed is increased to the maximum in case the power part or control card is very hot. If the temperature is below 15° C the warning will be present.

ALARM 67, Option Configuration has Changed:

One or more options has either been added or removed since the last power-down.

ALARM 68, Safe Stop:

Safe Stop has been activated. To resume normal operation, apply 24 VDC to terminal 37 then send a Reset signal (via Bus, Digital I/O or by pressing [Reset]).

ALARM 69, Pwr. Card Temp:

Power card over temperature.

ALARM 70, Illegal Frequency Converter Configuration:

Actual combination of control board and power board is illegal.

ALARM 90, Feedback Mon.:

ALARM 91, Analogue Input 54 Wrong Settings:

Switch S202 has to be set in position OFF (voltage input), when a KTY sensor is connected to the analogue input terminal 54.

9. Troubleshooting



VLT® AQUA Drive Operating Instructions

ALARM 92, NoFlow:

A no load situation has been detected for the system. See parameter group 22-2*.

ALARM 93, Dry Pump:

A no flow situation and high speed indicates that the pump has run dry. See parameter group 22-2* $\,$

ALARM 94, End of Curve:

Feed back stays lower than the set point, which may be indicates a leakage in the pipe system. See parameter group 22-5*

ALARM 95, Broken Belt:

Torque is below the torque level set for no load indicating a broken belt. See parameter group 22-6*

ALARM 96, Start Delayed:

Start of the motor has been delayed due to short cycle protection is active. See parameter group 22-7*.

ALARM 250, New Spare Part:

The power or Switch Mode Power Supply has been exchanged. The frequency converter type code must be restored in the EEPROM. Select the correct type code in Par 14-23 according to the label on unit. Remember to select 'Save to EEPROM' to complete.

ALARM 251, New Type Code:

The frequency converter has got a new type code.

VLT® AQUA Drive Operating Instructions



10. Specifications

10. Specifications

10.1. General Specifications

Q-Pulse Id TMS942

10

10.1.1. Mains Supply 1 x 200 - 240 VAC

		-	<u>.</u>		
Mains Supply 1 x 200 - 240 VAC - Normal	overload 110% for 1 minute				
Frequency converter		P5K	Р7К 5	P15K	P22K
Typical Shaft Output [kW]					
Typical Shaft Output [HP] at 240 V		7.5	10	20	30
IP 21 / NEMA 1		B1	B2	C1:	C2
IP 55 / NEMA 12		B1	B2	C1	C2
IP 66		81 ×	B2	C1	C2
Output current					
	Continuous (3'x 200-240'V) [A]	24.2	30.8	59.4	88
7000	Intermittent				
(600)	(3 x 200-240 V) [A]	26.6	33.4	65.3	96.8
0000	Continuous kVA	22.74	6.40		
	(208 V AC) [kVA]	5.00	6.40	12.27	18.30
	Max. cable size:				
	(mains, motor, brake)	10/7	25/2	50/1/0	95/4/0
	[[mm²/_AWG] ²⁾	10//	35/2	30/1/0	99/7/0
Max. input current					
	Continuous		Marie Sanda Marie Carlo	(i)	5
	(1 x 200-240 V.) [A]	46	59	111	172
	Intermittent				
	(1 x 200-240 V) [A]	50.6	64.9	122.1	189.2
(co)	Max. pre-fuses ¹⁾ [A]	80	100	150	200
(©)0	Environment				**************************************
	Estimated power loss		S 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	40 L 10 10 10 10 10 10 10 10 10 10 10 10 10	7 1 3 1
	at rated max. load [W] 4)	110	150	300	440
	Weight enclosure IP 21 [kg]	23	27	45	65
	Weight enclosure IP 55 [kg]	. 23	27		65
	Weight enclosure IP 66 [kg]	23	27	45	65
	Efficiency 3)	0.98	0.98	0.98	0.98



10.1.2.	Mains	Supply	3	X	200	-	240	VAC_

Normal overload 110% for 1 minute										
		2000 MA2 7/10	A2 * * *	/ AZ	F & A20 46	A2	A2	A2:		A3.
IP 21 / NEMA 1		A2	A2	Á2	A2	A2	A2	A2	A3	A3
IP 55 / NEMA 12		A5	A5	A5 🐩			A5	A5 /		A5
IP 66		A5	A5	A5	A5	A5	A5	A5	A5	A5
Mains supply 200 - 240 VAC	如此,这是一种的特殊的一种。	是5年4月4日1日	SASTAS (APPROXIMATE)				parameter 5	i i i i i i i i i i i i i i i i i i i	464年,李俊宗	of Personal State of
Frequency converter		\$ 10 s_PK25	PK37	PKS5	PK75 0.75) # P1K1 # .	P1K5 1.5	P2K2 2.2) P3K0 - 3	P3K7 3.7
Typical Shaft Output [kW]		0.25	0.37 0.37	0.55 0.55	0.75	1.5	2,0	2.9	4.0	4.9
Typical Shaft Output [HP] at 208 V		0.25	0.37			1.J	2.0			5 Table 1 Total
Output current	Cantagona					element of district of a	e compression and a second		-	
∩ 3	Continuous (3 x 200-240 V) [A]	1.8	2.4	3.5	4.6	6.6	7.5	10.6	12.5	16.7
	Intermittent	STATE OF SHIPPING	NAME OF STREET	STRAINING NAIS.	ACC CARRIED AS 225	7 N - 28 22	397.03 T 100	er er statiete i e	(4)(1) (1) (2) (2)(1)	100 100 100
	(3 x 200-240 v) [A]		2.64	3.85	. 5.06	> 7.26	8.3	11.7	13.8	18.4
caco	Continuous	0.65	0.00	1,26	1.66	2.38	2.70	3.82	4.50	6.00
	kVA (208 V AC) [kVA]	Ç0.U	0.86	1.20	1.00	2.30	2.70	3.02	7.20	0.00
	Max. cable size:	1.6.2 (1.6° -)			3/40/2017					
	(mains, motor, brake)				0.2 - 4	4 mm ² / 4 - 10	AWG			
	[mm² /AWG] 2)	Contract to a September of the F	CONTROL MANAGEMENT	\$70.0000 pp	- 12 MIN / 4 3		An an Magazine to the contraction of	Jan. 1997. (1998.) 1979.	. १ स व्यक्तिस	. 7 Master
Max. Input current		STAL STERMAN	60.950	. Market and the	A. 78 - 64-60 5 4	5159 - 145,059°	ATSTYTEPT - SUTTER	6424 J. 1852 J. 1854		
	Continuous (3 x 200-240 V) [A]	1.6	2.2	3.2	4.1	5.9	6.8	9.5	11.3	15.0
	(3 x 200 240 v) (A)	6, 10	Chrane Litera	1 300 1 33 198	and the second		322249	800 3882AA	754 (755)	A. J. W. L. 1. [8]
î 🛁	(3 x 200-240 V) [A]		2.42	3.52	4.51	6.5	7.5	10.5	. 12.4	16.5
	Max. pre-fuses ¹⁾ [A]	10	10	10	10	20	20	20	32	32
(43)	Environment	\$5.50 A. 1624 S. 5	dik e dikto	Agrai y		X X 40 50 5	డు లేడ్ రెక		No.	14 <u>2</u> 25 1 5 2
0000	Estimated power loss	21	29	42	54	63	82	116	155	185
-⇒	at rated max. load [W] 4)									
´ 			T 25 Y 4 9 Y Y 1	4 9	4'9	4.9	4.9	49	6.5	6.6
[]	Weight enclosure IP20 [kg]	4.9			The second secon	C C	F F	C C	2 5	7 5
	Weight enclosure IP21 [kg]	5.5	5.5	5.5	5,5	5.5	5.5	5.5	7.5	7.5
	Weight enclosure IP21 [kg] Weight enclosure IP55 [kg]	5.5 3.535	5.5 ****/13.5	5.5 4. 13.5	5,5 13,5	13.5	13.5	13.5	13.5	13.5
	Weight enclosure IP21 [kg]	5.5	5.5	5.5 13.5 13.5	5.5 13.5 13.5		13.5 13.5	13.5 13.5		13.5 13.5



MG.20.M5.02 - VLT[®] is a registered Danfoss trademark



20 / NEMA Chassis	to IR21 using a conversion kit (Please contact Danfoss)	В3	B 3€	В3	B4	B4	္မင္မ	္က အ ႏ	C4	C4
3:+4:and C3+4:may be:converted 21 / NEMA 1	to IRVITusing a conversion xit (Riease contact Darifoss)	B1	B1	B1	B2	C1	C1	C1	C2	(2
S5 / NEMA 12*		B1 - 2	B1	B1	B2 7	C1;	7 C1		C2	~ ~ ~
66		B1	B1	B1	B2	C1	C1	C1	C2	<u>C2</u>
quency converter		P5K5	P7K5		№ P15K %	P18K	∜P22K		P37K	.: P45
		5.5 😽	7.5	11	15	18.5	#'∗ 22	√ 30	37	45
oical Shaft Output [HP] at 208 V		7.5	10	15	20	25	30	40	50	60
tput current		用品等		- 1884 (A) (A)	18.00	全:子称2000 A	200	(株) - 1 (漢)		1.00
4 D	Continuous	24,2	30.8	46.2	59.4	74.8	88.0	115	143	170
	(3 x 200-240 V) [A]	47.4	30.0	70.2	25.7	77,0		113		17
December 1	Intermittent (3 x 200-240 V) (4)	26.6	33.9	50.8	65.3	82.3	96.8	127	157	- 18
(88)0 (88)0	((3 X 2 0 0 2) 0 1 / (N)	Z 7 3/		17,000						
	Continuous	8.7	11.1	16.6	21.4	26,9	31.7	41.4	51.5	61
	kvA (208 v AC) [kvA] [Max. cable size:	Carrier India	1 (7 0	FAMILY 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	*>	1 147 1 7	1 20 July 2 2 10 15 15 15 15 15 15 15 15 15 15 15 15 15	. ** **	.,.,.,
	(mains, motor, brake)			23						120/
·····	[mm² /AWG] ²)		10/7		35/2		50/1/0		95/4/0	MC
Input current		1946 YS	The speed		(REST. 12) (RES	8 3 3 4 .		198 Maryar		,,,,
• • • • • • • • • • • • • • • • • • • •	Continuous	22.0	20.0	47.0	F4.0				420.0	45.
	(3 x 200-240 V) [A]	22.0	28.0	42.0	54.0	68.0	80.0	104.0	130.0	154
	Intermittent	24.2	30.8	46.2	59.4	74.8	88.0	114.0	143.0	169
	[(3.x·200-240.V),[A]	24.2		21962	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	15.35.		1900		
5000	Max. pre-fuses ¹⁾ [A]	63	63	63	80	125	125	160	200	25
(Ø S 0°	<u>Environment</u>	100 16		188	Name of the state	f 1 / 22 / 1		3	71 77	
	Estimated power loss at rated max, load [W] ⁴⁾	269	310	447	602	737	845	1140	1353	163
→	Weight enclosure IP20 [kg]	28. 12.33	12	. 12 4	23.5	23.5	35	.≅ 35 ⊜	****50	
	Weight enclosure IP21 [kg]	23	23	23	23:3 27	<u> </u>	45	65	65	50 65
	Weight enclosure IP51 [kg]	23		23 23/1	27			65		
	Weight enclosure IP 66 [kg]	23	23	23	27	45	45	65	65	6.
	Efficiency 3)	0.96	- 0.96		0.96	0.96	0.97	0.97		0.9



10.1.3. Mains Supply 1 x 380 - 480 VAC Mains Supply 1x 380 VAC - Normal overload 110% for 1 minute

Frequency converter Typical Shaft Output [kW]

Typical Shaft Output [HP] at 460 V

IP 21 / NEMA 1 IP 55 / NEMA 12:

Max. input current

IP 66 Output current

		رًا را⊥
		erat ® /
P22K	P37K	AQU
30	50	
C1	C2	% D
C1		1 4 3
C1	C2	5 6

Continuous	16	24	44	73
(3 x 380 -440 V) [A]				,
Intermittent	17.6	26.4	48.4	80.3
(3.x.380-440.V) [A]				1 /2 / 1 / 1 / 1 / 1
Continuous	14.5	21	40	65
(3 x 441-480 V) [A]	11.5		10	
Intermittent	15.4	23.1	44	71.5
(3 x 441-480 V) [A]	19.7	23.1		Constitution (Constitution Constitution Constitution Constitution Constitution Constitution Constitution Const
Continuous kVA	11.0	16.6	30.5	50.6
(400 V AC) [kVA]	11.0	10.0	30.3	30.0
Continuous kVA	11.6	16.7	31.9	51.8
(460 V AC) [kVA]	11.0	10.7	31.5	J1.0 ×
Max. cable size:				
(mains, motor, brake)	10/7	′35/2	50/1/0	120/4/0
[[mm²/_AWG] ²⁾	10/7	23/2	30/1/0	120/4/0

P7K5

10

B1

B1

7.5

P11K

15

B2

B2

B2

	Continuous (1 x 380-440 V) [A]	(a.) (33) (c.)	48	.94	151
	Intermittent (1 x 380-440 V) [A]	36	53	103	166
	Continuous (1 x 441-480 V)[A]	30	41	85	135
(c)	Intermittent (1 x 441-480 V) [A]	33	46	93	148
	Max. pre-fuses ¹⁾ [A] Environment	63	× 80	160	250
	Estimated power loss at rated max, load, [W] 4)	300	440	880	1480
	Weight enclosure IP 21 [kg] Weight enclosure IP.55 [kg]	23	27	45 45	65 65
	Weight enclosure IP 66 [kg]	23	27	45	65
	_Efficiency ³⁾	0.96	0.96	0.96	0.96



10.1.4. Mains Supply 3 x 380 - 480 VAC

I Shaft Outnit (kW)				PK55 0.55	PK75 0.75	P1K1 1.1	P1K5 1.5	P2K2 2.2	P3K0 3	P4K0 4	P5K5 5.5	P7K5 7.5
I Shaft Output [HP] at		MARCO 21 C 970000		0.75	1.0	1.5	2.0	2.9	4.0	5.3	7.5	10
/ NEMA Chassis			A2	A2	A2	A2	A2	A2	A2	^A2	A3	A3_
/ NEMA 1												
/ NEMA 12			A5	A5	A <u>5</u>	A5	A5	A5	A5	A5	A5	A5
14 (1931) 1 a (1931)	SAME AND A STATE OF THE STATE O	N	A5	A5	A5	A5	A5	A5	A5	A5	AA	A5
ut current		1335 1388 S. S. S.			Y K.O.	3.45 Sec. 1.5	1, 0 - 1, 30 b ,	. (4) 5/10	- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	i erus võikra		
	Continuous (3 x 380-440 V) [A]		1.3 .	1.8	2.4	3	4.1	5.6	7.2	10	13	16
-	Intermittent (3 x 380-440 v) [A]		1.43	1.98	2.64	3.3	4.5	6.2	7.9	11	14.3	17.6
	Continuous (3 x 441-480 V) [A]		1.2	1.6	2.1	2.7	3.4	4.8	6.3	8.2	11	14.5
00	Intermittent (3 x 441-480 V) [A]		1:32	1.76	2.31	3.0	3.7	5.3	6.9	9.0	12.1	15.4
▶₽	Continuous kVA (400 V AC) [kVA]		0.9	1,3	1.7	2.1	2.8	3.9	5.0	6.9	9.0	11.0
₫	Continuous kVA (460 V AC) [kVA]		0.9	1.3	1.7	2.4	2.7	3.8	5.0	6.5	8.8	11.6
	Max. cable size:		***************************************									
	(mains, motor, brake) [[mm²/ AWG] ²)						4/10					
input current	Julia de Maria de Maria											
	Continuous (3 x 380-440 V) [A]	1.2	1.6	2.2	2.7	3.7	7 5.	D (.5	9.0	11.7	14.4
	Intermittent (3 x 380-440 V) [A]	1.33	2 1.7	6 2.4	2 3.0	4.1	1 5.	5 7	'.2	9.9	12.9	15.8
	Continuous			***************************************							9.9	
n a		1.0	1.4	1.9	2.7	'	l 4.	3	5.7	7.4	9.9	13.0
	(3 x 441-480 V) [A] Intermittent	1.0	1.4 1.5	45.55.7892.38	- C - W 74000	<u> </u>		<u> </u>	5.7 5.3	7.4 8.1	10.9	13.0 14.3
(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	(3 x 441-480 V) [A] Intermittent (3 x 441-480 V) [A] Max. pre-fuses ¹⁾ [A]			4 2.0	- C - W 74000	3.4	1 4.	7 6				
	(3 x 441_480.V).[A] Intermittent (3 x 441_480 V).[A] Max. pre-fuses ¹⁾ [A) Environment Estimated power loss	1.1	1.5	4 2.0	9 3.0	3.4	4.	7 6	5.3	8.1	10.9	14.3
→	(3 x 441-480.V) [A] Intermittent (3 x 441-480 V) [A] Max. pre-fuses ¹⁾ [A] Environment Estimated power loss at rated max. load [W] 1) Weight enclosure IP20 [kg]	1.1 10 35 4.7	1,5° 10 42 4,7	4 2.0 10 46 4.8	9 3.0 10 58 4.8	3.4 10 62	4. 20 88 9 4.	7 6	5.3 20 .16	8.1 20 124 4.9	10.9	14.3
	(3 x 441-480.V) [A] Intermittent (3 x 441-480.V) [A] Max. pre-fuses ¹ [A] Environment Estimated power loss at rated max. load [W]. 1 Weight enclosure IP20 [kg] Weight enclosure IP 21 [kg]	1.1 10 35 4.7	1.5· 10. 42. 4.7	4 2.0 10 46 4.8	9 3.0 10 58 4.8	3.4 10 62 4.5	88 9 4.	7 6	5.3 20 16 5.9	8.1 20 124 4.9	10.9 30 187 6.6	14.3 30 255 6.6
	(3 x 441-480.V) [A] Intermittent (3 x 441-480 V) [A] Max. pre-fuses ¹⁾ [A] Environment Estimated power loss at rated max. load [W] 1) Weight enclosure IP20 [kg]	1.1 10 35 4.7	1.5- 10 42 4.7 5 13.	4 2.0 10 46 4.8 5 13.	9 3.0 10 58 4.8 5 13.	3.4 10 62 4.5	88 9 4.	7 6	5.3 20- 16 5.9	8.1 20 124 4.9	10.9 30 187	14.3 30 255



	80 VAC - Normal overload 110% for 1 minute									Lamas	Sous North Land College
Frequency converter Typical Shaft Output [kW]		P11K 11	P15K 15	P18K 18.5	P22K 22	P30K 30	P37K 37	P45K 45	P55K + 55	P75K 75	P90K 90
Typical Shaft Output [HP] a	t 460 V	15	20	25	30	40	50	60	75	100	125
IP 20 / NEMA Chassis						24	04	67	-	C4	C4
(B3+4 and C3+4 may be cor Danfoss)	nverted to IP21 using a conversion kit (Please contact	B3	B3.	B3	B4	B4	B4	C3	а		
IP 21 / NEMA 1		B1	B1	B1	B2	82	C1	C1	C1	CZ	C2
IP 55 / NEMA 12		B1 B1	B1 B1	81 81	B2 B2	B2 B2	C1 C1	C1 C1	C1 C1	C2 C2	- 200
						UZ]					
	Continuous (3 x 380-440 V) [A]	24	32	37.5	44	61	73	90	106	147	177
	Intermittent (3 x 380-440 V) [A]	26.4	35.2	41.3	48.4	67.1:	80.3	99	117	162	195
2000	Continuous (3 x 441-480 V) [A]	21	27	34	40	52	65	80	105	130	160
(30)	Intermittent (3 x 441-480 V) [A]	23.1	29.7,	37.4	44	61:6	71.5	88	116	143	176
	Continuous kVA (400 V AC) [kVA]	16.6	22.2	26	30.5	42.3	50.6	62.4	73.4	102	123
	Continuous kVA (460 V AC) [kVA]	16.7	21.5	27.1	31.9	41.4	51.8	63.7	83.7	104	128
	Max. cable size:		100 CO 100 C		144007347300		10.000 X 37 - 17 20	1		Land of the Res	5.00 (A) (A) (A) (A)
	(mains, motor, brake) [[mm²/ AWG] ²⁾		10/7		35	5/2		50/1/0		120/4/0	120/4/0
Max. input current											
	Continuous	22	29	34	40	55	66	82	96	133)	161
	(3 x 380-440 V.):[A] Intermittent			180		200 (100 15 100 1			<u> </u>		477
	(3 x 380-440 V) [A]	24.2	31.9	37.4	44	60.5	72.6	90.2	106	146	177
	Continuous (3 x 441-480 V) [A]	19	25	31	36	47	59	73	95	118	145
0000 2880	Intermittent (3 x 441-480 V) [A]	20.9	27.5	34.1	39.6	51.7	64.9	80.3	105	130	160
0000	Max. pre-fuses ¹⁾ [A]	63	63	63	- 63	80	100	125	160	250	250
	Environment Estimated power loss	490 D.N. 16,256	- 15.7383842UVS88	\$8.876.J.M.S.A.	Text and a sector	ovoden visikili	S. KAGE		NOV Salari	Telegraphic Control	A 57*** A 1583
	at rated max load [W] 4)	278	-392	465	525	698	739	843	1083	1384	1474
	Weight enclosure IP20 [kg]	12	12	12	23.5	23.5	23.5	35	35	50	50
	Weight enclosure IP 21 [kg] Weight enclosure IP 55 [kg]	23 23		23	27 27	<u>27</u> 27	45 45	45 45	45 45	65 65	65 65
	Weight enclosure IP 55 [kg]	23	23 23	23 23	27	27	45			65	65
	Efficiency 3)	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.99
											





Normal overload 110% for	1 minute									
Frequency converter		P110	P132	P160	P200	P250	P315	*P355	P400	P450
Typical Shaft Output [kW]		110	132	160	200	250	315		400	450
Typical Shaft Output [HP] at 4	60V	150	200	250	300	350	450	500	550	600
IP 00		D3	D3	D4	. D4	D4	E2	EΣ	E2	EΣ
IP 21 / Nema 1		D1	D1	D2	D2	D2	E1	E1	E1	E1
IP 54 / Nema 12		D1"	D1	D2	D2	D2	E1	E1	E1	E1
Output current										
	Continuous (3 x 380-400 V) [A]	212	260	315	395	480	600	658	745	800
	Intermittent (3 x 380-400 V) [A]	233	286	347	435	528	660	724	820	880
poso	Continuous (3 x 401-480V) [A]	190	240	302	361	443	540	590	678	730
(1800) (1800)	Intermittent (3 x 401-480V) [A]	209	264	332	397	487	594	649	746	803
0000	Continuous kVA (400 VAC) [kVA] >=	147	180	218			416	456	516	554
	Continuous kVA (460 VAC) [kVA]	151	191	241	288	353	430	470	540	582
	Max. cable size:	- Gradien (Signa)		1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	海绵染金	A COLUMBATION	Agran, Santa	Sec. Osto	. 134.0%	
		2x70		2x185	A 38 % \$ 6		4x240			
	Max. cable size: (mains, motor, brake) [mm²/ AWG] ²)	2x2/0		2x350 mcm			4x500 mc			
Max. input current	(mains, motor, brake) [mm²/ AWG] ²)	2x2/0		2x350 mcm			4x500 mc	m	o makalikan	10 mm
Max. Input current	(mains, motor, brake) [mm²/ AWG] ²⁾ Continuous (3 x 380-400 V) [A]	2x2/0 204	251	2x350 mcm 304	381	463	4x500 mc	m 647	733	787
Max. input current	(mains, motor, brake) [mm²/ AWG] ²⁾ Continuous (3 x 380-400 V) [A] [Continuous (3 x 401-480V) [A]	2x2/0 204 183 en	251 231	2x350 mcm 304 291	348	427.	4x500 mc 590 531	m 647 580	733 667	787 718
	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] Continuous (3 x 401-480V) [A] Max. pre-fuses¹[A]	2x2/0 204	251	2x350 mcm 304			4x500 mc	m 647	733	787
Max. Input current	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] Continuous (3 x 401-480V) [A] Max. pre-fuses¹ [A] Environment	2x2/0 204 183 en	251 231	2x350 mcm 304 291	348	427.	4x500 mc 590 531	m 647 580	733 667	787 718
	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] Continuous (3 x 401-480V) [A] Max. pre-fuses¹][A] Environment Estimated power loss	2x2/0 204 183 300	251 	2x350 mcm 304 291 400	348 500	427 600	590 531 700	647 580 900	733 667 900	787 718 900
	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] Continuous (3 x 401-480V) [A] Max. pre-fuses¹¹[A] [Environment. Estimated power loss at rated max. load [W] ⁴)	2x2/0 204 183 300	251 231 350 3782	2x350 mcm 304 291 400 4213	348 500 5119	427 600 5893	590 531 700 7630	647 580 900	733 667 900 8879	787 718 900
	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] [Continuous (3 x 401-480V) [A] Max. pre-fuses¹¹[A] [Environment. Estimated power loss at rated max. load [W] ⁴) [Weight enclosure IP00 [kg]]	2x2/0 204 183 300 3234 81.9	251 A231 350 3782 90.5	2x350 mcm 304 291 400 4213	348 500 5119 122.9	427, 600 5893	590 531 700 7630 221.4	647 580 900 7701	733 667 900 8879 236.4	787 718 900 9428 277.3
	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] Continuous (3 x 401-480V) [A] Max. pre-fuses¹¹[A] Environment Estimated power loss at rated max. load [W] ¹) Weight enclosure IP00 [kg] Weight enclosure IP 21 [kg]	2x2/0 204 183 300 3234 81:9 95.5	251 231 350 3782 90.5 104.1	2x350 mcm 304 291 400 4213 111.8 125.4	348 500 5119 122:9 136.3	427 600 5893 137.7 151.3	590 531 700 7630 221:4 263.2	647 580 900 7701 234.1 270.0	733 667 900 8879 236.4 272.3	787 718 900 9428 277.3 313.2
	(mains, motor, brake) [mm²/ AWG] ²) Continuous (3 x 380-400 V) [A] [Continuous (3 x 401-480V) [A] Max. pre-fuses¹¹[A] [Environment. Estimated power loss at rated max. load [W] ⁴) [Weight enclosure IP00 [kg]]	2x2/0 204 183 300 3234 81.9	251 A231 350 3782 90.5	2x350 mcm 304 291 400 4213	348 500 5119 122.9 136.3	427, 600 5893	590 531 700 7630 221.4	647 580 900 7701	733 667 900 8879 236.4	787 718 900 9428 277.3 313.2

¹⁾ For type of fuse see section Fuses



²⁾ American Wire Gauge 🏖

Measured using 5 m screened motor cables at rated load and rated frequency.

Measured using 5 m screened motor cables at rated load and rated frequency.

The typical power loss is at normal load conditions and expected to be within +/- 15% (tolerance relates to variety in voltage and cable conditions).

Values are based on a typical motor efficiency (eff2/eff3 border line). Lower efficiency motors will also add to the power loss in the frequency converter and vice versa.

If the switching frequency is raised from nominal the power losses may rise significantly.

LCP and typical control card power consumptions are included. Further options and customer load may add up to 30% to the losses. (Though typically only 4W extra for a fully loaded control card, or options for slot A or slot B,

Although measurements are made with state of the art equipment, some measurement inaccuracy must be allowed for $(\pm/\pm5\%)$

10.1.5.	Mains	Supply	3 x	525	- 600	VAC
Normal ov	erioad 11	0% for 1	minut	e		

	d 110% for 1 minute																1 40-1-1-1			
		PK75	P1K1	P1K5%	P2K2	P3K0 -	.P3K7	5P4K0√	P5K5	P7K5	P11K	P15K	P18K	₹P22K	₽ P30K	P37K	P45K	P55K∙	®P75K े	.P90K
Typical Shaft Out	out (kW)	0.75	1.1	1.5	2.2	3	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
IP 20 / NEMA Cha	ssis				- A2			A2		A3	B3	<u>83</u>	B3	B4	B4	B4	:C3		2 C4 2	
IP 21 / NEMA 1		A2	A2	A2	A2	A2	A2	A2	A3	A3	B1	81	B1	B2	B2	B2	C1	C1	C2	C2
			(A. 2.2.20)																	
IP'55 / NEMA 12		A5	`A5 .	A5	A5	A5:	. A5	A5 -	A5	A5	B1	B1	·B1	B2	B2-	B2	C1	C1*	C2 💝	C2 -
							*				74, 345			3.00	(1) (1) (1)				(T)	
IP 66		A5	A5	A5	A5	A5	A5	A5	A 5	A5	B1	B1	B1	B2	B2	82	C1	C1	C2	C2
					SWALL	Z2000	14.500		9.08 S		and the same		WAR THE				1.5/63%/5.Fr		(a) (1.25)	
	Continuous		2.6	2.9	4.1	5.2		<i>C</i> A	9.5	11.5	10	23	28	36	43	54	65	87	105	137
	(3 x 525-550 V) [A]	1.8	2.6	2.9	4.1	5.2	•	6.4	9.5	11.5	19	23	28	20	43	24		-	102	137
	Intermittent		2.9	3.2	4.5	5.7.		7.0	√ 10.5 ·	12,7	21	25	31	40	47	59	72	96	116	151
	(3 x 525-550 V) [A]		, 2.5	5.2		in Zize.		3,7.0	92.10.5	12.73	W. 51.44	2.7	37.50	10	20 X O		25/2	14/20/2	110	
Parameter 1	Continuous	1.7	2.4	2.7	3.9	4.9	_	6.1	9.0	11.0	18	22	27	34	41	52	62	83	100	131
	(3 x 525-600 V) [A]				V. V. 19 V. 7		X 1 3000 - 7 4		77 77 2 7 7 7 7 7		1				7. 74 90 97 90 27		, , , , , , , , , , , , , , , , , , ,			
66	Intermittent (3 x 525-600 V.) [A]		2.6	3.0	4.3	5.4		6.7	9.9	12:1	20	⊬ 24	30	37	45	57	- 68	91	110	144
	Continuous kVA (525 V AC)			A 2000 et 12 (20)			**************************************					2//							327 - DAY 248	
	[kVA]	1.7	2.5	2.8	3.9	5.0	-	6.1	9.0	11.0	18.1	21.9	26.7	34.3	41	51.4	61.9	82.9	100	130.5
	Continuous kVA (575 V AC).	1.01-7 <u>=</u> 0.00		2.7		A 4 2 4 5 5 5		100	1.000	37.00	800 C	72		Z2020	40.8	51.8	7,000	82.7	99.6	
	[kVA]	1./	2.4	2:7.6	3.9	4.9		6.1	9.0	11.0	17.9	21.9	26.9	√33.9 ি	40.8	. 51.8	61.7	. 282.7- «	99.6	130.5
	Max. cable size							n	4 - 10 AW	ıc		<i>c</i>		•	٦			4	2.	···
	(mains, motor, brake)						-	2	0.2 - 4	76		16			35			50	3/ 95	
	[AWG] ²⁾ [mm ²]) U		
Max. input curr	entonia di iliano.	(Temporal)	2 Section 2	And Dear	Carlo San	J. 18 Buch	DAN.	AND.			Section 1	16677.74E	ar mass	16.00	7.589		1880 C	where is	a	(a.
	Continuous	1.7	2.4	2.7	4.1	5.2	_	5.8	8.6	10.4	17.2	20.9	25.4	32.7	39	49	59	78.9	95.3	124.3
	(3 x 525-600 V) [A]		4 - 1200 1100 1100 1100	_,,		-					200.00					_		. 015	90.0	
	Intermittent		2.7	3.0	4.5	5.7		6.4	9.5	11.5	19	23	28	36	43	54	65	87.	105	i37 🎎
0000	(3 x 525-600 V) [A]	10	10	10	20	20		20	32								<u> </u>		<u> </u>	1. 3.0.488
(300	Max. pre-fuses ¹⁾ [A] [Environment:		10	10	20	20	- Nachte			32	30.200.500		200	202386.7	71.37.982.5	7 190 5 19 5	1808 CONTRACT	VI, 38 1 (4) 3	3.60	2 T 875
0000	Estimated power loss		5.7945833	4 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	orenegacii .	380 XX						702-2-30		20.00034			2000		28	لكتنده
	at rated max. load [W] 4)	35	50	65	92	122	-	145	195	261	225	285	329							
	Enclosure IP 20:	83 S	·		ACMINATE.	N	. 127e-15		55 S. 185			6.7.E 3.88		1000000			30.X2	\$7.35 Z. Ps.		S 1.32
	Weight									*****			M					<u> </u>	***************************************	·····
	enclosure IP20 [kg]	6.5	6.5	6.5	6.5	6.5	-	6.5	6.6	6.6	12	12	12	23.5	23.5	23.5	35	35	50	50
	Efficiency 1)	0.97	0.97	×0.97	0.97	0.97		0.97	₹0.97	0.97	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98	0.98
											1									

Table 10.1: 5) Motor and mains cable: 300MCM/150mm²



156

10.1.6. Mains Supply 3 x 525 - 690 VAC

uency conver cal Shaft Out		P45K 45	P55K	P75K *	P90K 90	P110	P132 132	P160 160	P200 200	P250 250	P315 315	P400 400	P450 450	P500 500		P630 630	P710	P800 800	P900 900	P1M0 1000	P1 12
	put [HP] at 575 V	50	60	75	100	125	150	200	250	300	350	400	450	500	600	650	750	950	1050	1150	1.
0		D3	_D3	D3	⊘D3	D3	D3	D3		D4**	D4	D4	E2			E2.			-		100000
1 / Nema 1		D1	D1	D1	D1	D1	D1	D1	D2	D2	D2	D2	E1	E1	E1	E1	F1/ F3 ⁶)	F1/ F3 ⁶⁾	F1/F3 ⁶⁷	F2/ F4 ⁶)	F
4 / Nema 12		D1	D1	D1	D1	D1	D1	D1	D2	D2.	D2	D2	E1	E1	Ē1	E1	F1/ F3 ⁶⁾	F1/ F3 ⁶⁾	F1/F3 ⁶	F47	F
put current		7,000,000	5, 5, 86 a K	CU 5 Nr.		11835,	v	W.2.	122	.x2.39949 # <u>.</u>	<u>v</u>	200	1		83 <u>x</u>	· · · · · · · · · · · · · · · · · · ·	11.5			11.5	
	Continuous (3 x 550 V) [A]	56	76	90	113	137	n 162	201	253	303	360	418	470	523	596	630	763	889	988	1108	* 1
	Intermittent (3 x 550 V) [A]	62	84	99	124	151	178	221	278	333	396	460	517	575	656	693	839	978	1087	1219	1
	Continuous (3 x 690V) [A]	54: ***	73	86	108	131	155	192	242	290 -	344	400	450	500	570	630	730	850	945	1060	1
	Intermittent (3 x 690 V) [A]	59	80	95	119	144	171	211	266	319	378	440	495	550		693	803	935	1040	1166	1
	Continuous kVA (550 VAC) [kVA]	53 ≎	. 72	86	108	131	154	191	241	289	343	398	448	. 498	568	600	727	847	941	1056	1
Si v	Continuous kVA (575 VAC) [kVA]	54	73	86	108	130	154	191	241	289	343	398	448	498	568	627	727	847	941	1056	1
	Continuous kVA (690 VACr) [kVA]	65	87///	103	129	∂ 157∉	- 185	. 229	289	347	411	478	538	< 598	681	753	872	1016	1129	1267	* 1
L	Max. cable size:																				
	(Mains) [mm²/,AWG] 2)				2x70 2x2/0						2x185 350 mcm	1			x240 00 mcm		8x240 8x500)) mcm		8x240 8x500	
	44. 35. 34.0003.33	2x70							2×185)				4	x240		8x150)		12x15	
4.	(Motor) [mm²/ AWG] ²⁾	2x2/0							2x350) mcm				4x50	00 mcm		8x300	mcm (12x30	00 n
- 10 m	(P=1-2) (=-2) (AM(C12))	2x70			74,3		XX 98.7		2x185	500 Kill Co.		- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	000000000	38000000	x185	Market Control of the Control	Water State of the	Score and Carlo			2.582
4 1 3 cm	(Brake) [mm²/, AWG] ²⁾	242/0	. 12 XS 14.			1000	10 mg 20 20 20 20 20 20 20 20 20 20 20 20 20	1924			a Marchie	1.0					4x185			6x185	
. input curr		2x2/0	14,337				43 MB 3474			mcm	a March 8	5.5			50_mcm			mcm_		6x350	
. input curre		2x2/0						. AM													
a input curr		2x2/0						.													
c. input curr	ent	2x2/0	77	89	110	130	158	198			299	355	453				4x350	mcm		6x350	<u>) ma</u>
c. input curre			77	. 89	110	130	158	198	2x350) mcm	299	355	453	2x3!	5 <u>0 mcm</u>	607	4x350		962		
	ent		77	89	110	130	158	198	2x350) mcm	299	355	453	2x3!	5 <u>0 mcm</u>		4x350	mcm		6x350) m
	continuous (3 x 525 V) [A]	60							2x350 299	245				2x3! 504	50 mcm 574	607	4x350 743	866	962	6x350) m
	ent Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A]		77 74 77	89 85 87	106	130 124 128	158 151 151	198 189 189	2x350 299 286	245 234	286	339	434	2x3 ¹ 504 482	50 mcm 574 549	607 607	743 711	866 828	962 920	1079 1032) m 1
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 690 V) [A]	60 58 58	74 77	85 87	106 109	124 128	151 155	189 197	2x35(299 286 296	245 234 240	286 296	339 352	434 434	504 482 482	50 mcm 574 549 549	607 607 607	743 711 711	866 828 828	962 920 920	1079 1032 1032) me
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 690 V) [A] Max. mains pre-fuses [A]	60 58	74 77 160	85 87 200	106	124 128 250	151	189 197 350	299 286 296 350	245 234 234 240 400	286	339	434 434 700	504 482 482 700	50 mcm 574 549 549 900	607 607 607 900	743 711 711 2000	866 828	962 920	1079 1032) mc
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 575 V) [A] Max. mains pre-fuses [A] Environmenti	60 58 58 125	74 77 160	85 87 200	106 109 200	124 128 250	151 155 315	189 197 350	299 286 296 350	245 234 240 400	286 296 500	339 352 550	434 434 700	504 504 482 482 700	574 549 549 900	607 607 607 900	743 711 711 2000	866 828 828 2000	962 920 920	1079 1032 1032	1 1
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 690 V) [A] Max. mains pre-fuses [I][A] Environmenti Estimated power loss	60 58 58 125	74 77 160	85 87 200	106 109 200	124 128 250	151 155 315	189 197 350	299 286 296 350	245 234 234 240 400	286 296 500	339 352 550	434 434 700	504 482 482 700	50 mcm 574 549 549 900	607 607 607 900	743 711 711 2000	866 828 828 2000	962 920 920	1079 1032 1032) me
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 690 V).[A] Max. mains pre-fuses V[A] Environment: Estimated power loss at rated max. load [W] 4)	60 58 58 58 125	74 77 160 1717	85 87 200	106 109 200 2262	124 128 250 2662	151 155 315	189 197 350 3612	299 286 296 350 4292	245 234 234 240 400	286 296 500 5821	339 352 550	434 434 700	2x3: 504. 482. 482. 700.	574 574 549 549 900	607 607 607 900 9673	743 711 711 2000	866 828 828 2000	962 920 920	1079 1032 1032) me
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 690 V) [A] Max. mains pre-fuses 1 [A] Environment Estimated power loss at rated max. load [W] 4) Weight enclosure IP00 [kg]	58 58 58 125 1458	74 77 160 1717 82	85 87 200 1913	106 109 200 2262 82	124 128 250 2662	151 155 315 3114 82	189 197 350 3612 91	286 296 350 4292	245 234 234 240 400 5156	286 296 500 5821	339 352 550 6149 151	434 434 700 6449	2x3: 504. 482. 482. 700. 7249. 221.	574 574 549 549 900 8727 236	607 607 607 900 9673 277	743 743 711 711 2000	866 828 828 2000	962 920 920 2000	1079 1032 1032 2000	1 1 1 2
	Continuous (3 x 525 V) [A] Continuous (3 x 575 V) [A] Continuous (3 x 690 V).[A] Max. mains pre-fuses V[A] Environment: Estimated power loss at rated max. load [W] 4)	58 58 58 125 1458 82 96	74 77 160 1717	85 87 200	106 109 200 2262	124 128 250 2662	151 155 315	189 197 350 3612	299 286 296 350 4292	245 234 234 240 400	286 296 500 5821	339 352 550	434 434 700	2x3: 504. 482. 482. 700.	574 574 549 549 900	607 607 607 900 9673	743 711 711 2000	866 828 828 2000	962 920 920 2000	1079 1032 1032	1 1 1 2 2 1

1) For type of fuse see section Fuses

2) American Wire Gauge

³⁾ Measured using 5 m screened motor cables at rated load and rated frequency

^{1.} The typical power loss is at normal load conditions and expected to be within +/-:15% (tolerance relates to variety in voltage and cable conditions).

Values are based on a typical motor efficiency (eff2/eff3 border line). Lower efficiency motors will also add to the power loss in the frequency converter and vice versa.

If the switching frequency is raised from nominal the power losses may rise significantly.

LCP and typical control card power consumptions are included. Further options and customer load may add up to 30W to the losses. (Though typically only 4W extra for a fully loaded control card, or options for slot A or slot B,

Although measurements are made with state of the art equipment; some measurement inaccuracy must be allowed for (+/- 5%).

²⁾ Adding the F-enclosure option cabinet (resulting in the F3 and F4 enclosure sizes) adds 295 kgto the estimated weight:



Protection and Features:

- Electronic thermal motor protection against overload.
- Temperature monitoring of the heatsink ensures that the frequency converter trips if the temperature reaches 95 °C ± 5°C. An overload temperature cannot be reset until the temperature of the heatsink is below 70 °C ± 5°C (Guideline these temperatures may vary for different power sizes, enclosures etc.). The frequency converter has an auto derating function to avoid it's heatsink reaching 95 deg C.
- The frequency converter is protected against short-circuits on motor terminals U, V, W.
- If a mains phase is missing, the frequency converter trips or issues a warning (depending on the load).
- · Monitoring of the intermediate circuit voltage ensures that the frequency converter trips if the intermediate circuit voltage is too low or too high.
- The frequency converter is protected against earth faults on motor terminals U, V, W.

Mains	supply	(L1,	LZ,	L3)	١
-------	--------	------	-----	-----	---

Supply voltage	380-480 V ±10%
Supply voltage	525-690 V ±10%
Supply frequency	50/60 Hz
Max. imbalance temporary between mains phases	3.0 % of rated supply voltage
True Power Factor (λ)	≥ 0.9 nominal at rated load
Displacement Power Factor (cosφ) near unity	(> 0.98)
Switching on input supply L1, L2, L3 (power-ups) ≤ enclosure type A	maximum 2 times/min.
Switching on input supply L1, L2, L3 (power-ups) ≥ enclosure type B, C	maximum 1 time/min.
Environment according to EN60664-1	overvoltage category III/pollution degree 2

The unit is suitable for use on a circuit capable of delivering not more than 100.000 RMS symmetrical Amperes, 500/600/690 V maximum.

Motor output (U, V, W):

Output voltage	0 - 100% of supply voltage
Output frequency	0 - 1000 Hz
Switching on output	Unlimited
Ramp times	1 - 3600 sec.

Torque characteristics:

Starting torque (Constant torque)	 		maximum 110% for 1 min.*
Starting torque		•	maximum 135% up to 0.5 sec.*
Overload torque (Constant torque)			maximum 110% for 1 min.*

^{*}Percentage relates to VLT AQUA Drive's nominal torque.

Cable lengths and cross sections:

Max. motor cable length, screened/armoured	VLT AQUA Drive: 150 m
Max. motor cable length, unscreened/unarmoured	VLT AQUA Drive: 300 m
Max. cross section to motor, mains, load sharing and brake *	
Maximum cross section to control terminals, rigid wire	1.5 mm²/16 AWG (2 x 0.75 mm²)
Maximum cross section to control terminals, flexible cable	1 mm²/18 AWG
Maximum cross section to control terminals, cable with enclosed core	0.5 mm²/20 AWG
Minimum cross section to control terminals	0.25 mm²

^{*} See Mains Supply tables for more information!

Control card, RS-485 serial communication:

Terminal number	68 (P,TX+, RX+), 69 (N,TX-, RX-)
Terminal number 61	Common for terminals 68 and 69

The RS-485 serial communication circuit is functionally separated from other central circuits and galvanically isolated from the supply voltage (PELV).



Digital inputs:	
Programmable digital inputs	4 (6)
Terminal number	18, 19, 27 ¹⁾ , 29, 32, 33,
Logic	PNP or NPN
Voltage level	0 - 24 V DC
Voltage level, logic'0' PNP	< 5 V DC
Voltage level, logic'1' PNP	> 10 V DC
Voltage level, logic '0' NPN	> 19 V DC
Voltage level, logic '1' NPN	< 14 V DC
Maximum voltage on input	28 V DC
Input resistance, R _i	approx. 4 kΩ

All digital inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

1) Terminals 27 and 29 can also be programmed as output.

· · · · · · · · · · · · · · · · · · ·	
Programmable digital/pulse outputs	2
Terminal number	27, 29 ¹⁾
Voltage level at digital/frequency output	0 - 24 V
Max. output current (sink or source)	40 mA
Max. load at frequency output	1 kΩ
Max. capacitive load at frequency output	10 nF
Minimum output frequency at frequency output	0 Hz
Maximum output frequency at frequency output	32 kHz
Accuracy of frequency output	Max. error: 0.1 % of full scale
Resolution of frequency outputs	12 bit


1) Terminal 27 and 29 can also be programmed as input.

The digital output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

10

Analog inputs:	
Number of analog inputs	2
Terminal number	53, 54
Modes	Voltage or current
Mode select	Switch S201 and switch S202
Voltage mode	Switch S201/switch S202 = OFF (U)
Voltage level	: 0 to + 10 V (scaleable)
Input resistance, R _i	approx. 10 kΩ
Max. voltage	± 20 V
Current mode	Switch S201/switch S202 = ON (I)
Current level	0/4 to 20 mA (scaleable)
Input resistance, R	approx. 200 Ω
Max. current	30 mA
Resolution for analog inputs	10 bit (+ sign)
Accuracy of analog inputs	Max. error 0.5% of full scale
Bandwidth	: 200 Hz

The analog inputs are galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.



Analog output:

Number of programmable analog outputs	1
Terminal number	42
Current range at analog output	0/4 - 20 mA
Max. resistor load to common at analog output	500 Ω
Accuracy on analog output	Max. error: 0.8 % of full scale
Resolution on analog output	8 bit

The analog output is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

Control card, 24 V DC output:

Terminal number	12, 13
Max. load	: 200 mA

The 24 V DC supply is galvanically isolated from the supply voltage (PELV), but has the same potential as the analog and digital inputs and outputs.

Relay outputs:

Programmable relay outputs	2
Relay 01 Terminal number	1-3 (break), 1-2 (make)
Max. terminal load (AC-1) ¹⁾ on 1-3 (NC), 1-2 (NO) (Resistive load)	240 V AC, 2 A
Max. terminal load (AC-15) ¹⁾ (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) ¹⁾ on 1-2 (NO), 1-3 (NC) (Resistive load)	60 V DC, 1A
Max. terminal load (DC-13) ¹⁾ (Inductive load)	24 V DC, 0.1A
Relay 02 Terminal number	4-6 (break), 4-5 (make)
Max. terminal load (AC-1) ¹⁾ on 4-5 (NO) (Resistive load) ²⁾³⁾	400 V AC, 2 A
Max. terminal load (AC-15) ¹⁾ on 4-5 (NO) (Inductive load @ cosφ 0.4)	240 V AC, 0.2 A
Max. terminal load (DC-1) ¹⁾ on 4-5 (NO) (Resistive load)	80 V DC, 2 A
Max. terminal load (DC-13) ¹⁾ on 4-5 (NO) (Inductive load)	24 V DC, 0.1A
Max. terminal load (AC-1) ¹⁾ on 4-6 (NC) (Resistive load)	240 V AC, 2 A
Max. terminal load (AC-15) ¹⁾ on 4-6 (NC) (Inductive load @ cosp 0.4)	240 V AC, 0.2A
Max. terminal load (DC-1) ¹⁾ on 4-6 (NC) (Resistive load)	50 V DC, 2 A
Max. terminal load (DC-13) ¹⁾ on 4-6 (NC) (Inductive load)	24 V DC, 0.1 A
Min. terminal load on 1-3 (NC), 1-2 (NO), 4-6 (NC), 4-5 (NO)	24 V DC 10 mA, 24 V AC 20 mA
Environment according to EN 60664-1	overvoltage category III/pollution degree 2

1) IEC 60947 part 4 and 5

The relay contacts are galvanically isolated from the rest of the circuit by reinforced isolation (PELV).

- 2) Overvoltage Category II
- 3) UL applications 300 V AC 2A

Control card, 10 V DC output:

Terminal number	50
Output voltage	10.5 V ±0.5 V
Max. load	25 mA

The 10 V DC supply is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

= 10

VLT® AQUA Drive Operating Instructions

10. Specifications



Control characteristics:	
Resolution of output frequency at 0 - 1000 Hz	: +/- 0.003 Hz
System response time (terminals 18, 19, 27, 29, 32, 33)	: ≤ 2 ms
Speed control range (open loop)	1:100 of synchronous speed
Speed accuracy (open loop)	30 - 4000 rpm: Maximum error of ±8 rpm

All control characteristics are based on a 4-pole asynchronous motor

Enclosure type A	IP 20/Chassis, IP 21kit/Type 1, IP55/Type12, IP 66
Enclosure type B1/B2	IP 21/Type 1, IP55/Type12, IP 66
Enclosure type B3/B4	IP20/Chassis
Enclosure type C1/C2	IP 21/Type 1, IP55/Type 12, IP66
Enclosure type C3/C4	IP20/Chassis
Enclosure type D1/D2/E1	IP21/Type 1, IP54/Type12
Enclosure type D3/D4/E2	IP00/Chassis
Enclosure kit available ≤ enclosure type A	IP21/TYPE 1/IP 4X top
Vibration test	1.0 લ
Max. relative humidity	5% - 95%(IEC 721-3-3; Class 3K3 (non-condensing) during operation
Aggressive environment (IEC 721-3-3), uncoated	class 3C2
Aggressive environment (IEC 721-3-3), coated	class 3C3
Test method according to IEC 60068-2-43 H2S (10 days)	
Ambient temperature	Max. 50 °C
Derating for high ambient temperature, see section on special conditions	
Minimum ambient temperature during full-scale operation	0 °C
Minimum ambient temperature at reduced performance	- 10 °C
Temperature during storage/transport	-25 - +65/70 °C
Maximum altitude above sea level without derating	1000 m
Maximum altitude above sea level with derating	3000 m

Derating for high altitude, see section on special conditions

EMC standards, Emission EN 61800-3, EN 61000-6-3/4, EN 55011, IEC 61800-3
EN 61800-3, EN 61000-6-1/2,

EMC standards, Immunity EN 61000-4-2, EN 61000-4-3, EN 61000-4-5, EN 61000-4-6

See section on special conditions

Control card performance:

Scan interval : 5 ms

Control card, USB serial communication:

USB standard 1.1 (Full speed)
USB plug USB type B "device" plug



Connection to PC is carried out via a standard host/device USB cable.

The USB connection is galvanically isolated from the supply voltage (PELV) and other high-voltage terminals.

The USB connection is <u>not</u> galvanically isolated from protection earth. Use only isolated laptop/PC as connection to the USB connector on VLT AQUA Drive or an isolated USB cable/converter.

160

MG.20.M5.02 - VLT* is a registered Danfoss trademark

Active 10/12/2014 Page 165 of 333



10.1.7. Efficiency

Efficiency of the frequency converter (nylt)

The load on the frequency converter has little effect on its efficiency. In general, the efficiency is the same at the rated motor frequency f_{M,N}, even if the motor supplies 100% of the rated shaft torque or only 75%, i.e. in case of part loads.

This also means that the efficiency of the frequency converter does not change even if other U/f characteristics are chosen. However, the U/f characteristics influence the efficiency of the motor.

The efficiency declines a little when the switching frequency is set to a value of above 5 kHz. The efficiency will also be slightly reduced if the mains voltage is 480 V, or if the motor cable is longer than 30 m.

Efficiency of the motor (ημοτοκ)

The efficiency of a motor connected to the frequency converter depends on magnetising level. In general, the efficiency is just as good as with mains operation. The efficiency of the motor depends on the type of motor.


In the range of 75-100% of the rated torque, the efficiency of the motor is practically constant, both when it is controlled by the frequency converter and when it runs directly on mains.

In small motors, the influence from the U/f characteristic on efficiency is marginal. However, in motors from 11 kW and up, the advantages are significant.

In general, the switching frequency does not affect the efficiency of small motors. Motors from 11 kW and up have their efficiency improved (1-2%). This is because the sine shape of the motor current is almost perfect at high switching frequency.

Efficiency of the system (ησγετεм)

To calculate the system efficiency, the efficiency of the frequency converter (η_{NLT}) is multiplied by the efficiency of the motor (η_{MOTOR}): η_{SYSTEM}) = $\eta_{VLT} \times \eta_{MOTOR}$



Based on the graph outlined above, it is possible to calculate the system efficiency at different speeds.

The acoustic noise from the frequency converter comes from three sources:

- DC intermediate circuit coils.
- Integral fan.
- RFI filter choke.

The typical values measured at a distance of 1 m from the unit:



		Enc	losure	<u>. </u>			At n	educed	fan sj	eed (5	0%) [dBA] *	**		Full	fan sp	eed [dBA]	
42										51						60)		
۱3 ،	460	1960	V 1	1000	, <u> </u>	1.6			v. 37%	51		F.).	174	625	1	60	1	Sa (5)	ske
۹5										54	•					63			
31		₹,*	20, 20,		2.1			25. 6	3.4.	61		C.			- 3	67	, , .	. 4.9 4	
32										58						70)		
33 📉	48.3	S. 37	, 230-87,	1,000	111	1. 1		, 35 je w	- 45	2 pr	.* ;	259	77.75	332	489	-	. 60		1.3
34										-						-			
1		7.	(1)	901 800 V9				7),550°°°		52	1	1 1000000			738 T	62			
C2										55						65	;		
3	marks H			. 1994.	40000			ar Brit			4.00		1,150	13 10 7912	Mai la	33 A -	(A)		3.79 Sec. 27
C4										-						•			
D1+D3		- 222	· 200			g the So		. (***:	. Suddi	74		: 1X			,×	76	1		
D2+D4										73						74	}		
1/E2 *	1 100		1867	· (4,3%)	40.000	*::		171.00	1 1	73 :⊶∵	3. M. A.		1. No. 1			. 74	. 10	34	1 200
1/E2 **										82						83	}		
315 kW					525-60	O VAC	only!									Ç.			
** Remaii *** For D							20.	Nach in	198	See	r ágar.	GL T	Radiae P			- Q	- W.	. M	

When a transistor in the inverter bridge switches, the voltage across the motor increases by a du/dt ratio depending on:

- the motor cable (type, cross-section, length screened or unscreened)
- inductance

The natural induction causes an overshoot UPEAK in the motor voltage before it stabilises itself at a level depending on the voltage in the intermediate circuit. The rise time and the peak voltage UPEAK affect the service life of the motor. If the peak voltage is too high, especially motors without phase coil insulation are affected. If the motor cable is short (a few metres), the rise time and peak voltage are lower.

If the motor cable is long (100 m), the rise time and peak voltage are higher.

In motors without phase insulation paper or other insulation reinforcement suitable for operation with voltage supply (such as a frequency converter), fit a du/dt filter or a sine-wave filter on the output of the frequency converter.



10.2. Special Conditions

10.2.1. Purpose of derating

Derating must be taken into account when using the frequency converter at low air pressure (heights), at low speeds, with long motor cables, cables with a large cross section or at high ambient temperature. The required action is described in this section.

10.2.2. Derating for Ambient Temperature

The average temperature (TAMB, AVG) measured over 24 hours must be at least 5 °C lower than the maximum allowed ambient temperature (TAMB, MAX).

If the frequency converter is operated at high ambient temperatures, the continuous output current should be decreased.

The derating depends on the switching pattern, which can be set to 60 AVM or SFAVM in parameter 14-00.

A enclosures

60 AVM - Pulse Width Modulation




Illustration 10.1: Derating of I_{out} for different $T_{\text{AMB, MAX}}$ for enclosure A, using 60 AVM

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.2: Derating of I_{Out} for different TAMB, MAX for enclosure A, using SFAVM

10

In enclosure A, the length of the motor cable has a relatively high impact on the recommended derating. Therefore, the recommended derating for an application with max. 10 m motor cable is also shown.




Illustration 10.3: Derating of I_{out} for different $T_{\text{AMB}, \text{ MAX}}$ for enclosure A, using 60 AVM and maximum 10 m motor cable




Illustration 10.4: Derating of I_{Out} for different $T_{\text{AMB}, \text{MAX}}$ for enclosure A, using SFAVM and maximum 10 m motor cable

Danfoss

B enclosures

60 AVM - Pulse Width Modulation




Illustration 10.5: Derating of I_{Out} for different $T_{\text{AMB}, \text{MAX}}$ for enclosure B, using 60 AVM in Normal torque mode (110% over torque)

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.6: Derating of I_{out} for different T_{AMB, MAX} for enclosure B, using SFAVM in Normal torque mode (110% over torque)

C enclosures

Please note: For 90 kW in IP55 and IP66 the max, ambient temperature is 5° C lower.

60 AVM - Pulse Width Modulation




Illustration 10.7: Derating of low for different TAMB, MAX for enclosure C, using 60 AVM in Normal torque mode (110% over torque)

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.8: Denating of I_{out} for different $T_{\text{AMB}, \text{ MAX}}$ for enclosure C, using SFAVM in Normal torque mode (110% over torque)

D enclosures

60 AVM - Pulse Width Modulation, 380 - 480 V




Illustration 10.9: Derating of I_{OM} for different $T_{\text{AMB, MAX}}$ for enclosure D at 480 V, using 60 AVM in Normal torque mode (110% over torque)

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.10: Derating of I_{out} for different T_{AMB, MAX} for enclosure D at 480 V, using SFAVM in Normal torque mode (110% over torque)

VLT® AQUA Drive **Operating Instructions**



10. Specifications

60 AVM - Pulse Width Modulation, 525 - 600 V (except P315)




Illustration 10.11: Derating of I_{out} for different $T_{\text{AMB, MAX}}$ for enclosure D at 600 V, using 60 AVM in Normal torque mode (110% over torque). Note: not valid for P315.




Illustration 10.13: Derating of Iout for different Tamb, max for enclosure D at 600 V, using 60 AVM in Normal torque mode (110% over torque). Note: P315 only.

E enclosures

60 AVM - Pulse Width Modulation, 380 - 480 V




Illustration 10.15: Derating of Iout for different TAMB, MAX for enclosure E at 480 V, using 60 AVM in Normal torque mode (110% over torque)

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.12: Denating of I_{out} for different $T_{\text{AMB, MAX}}$ for enclosure D at 600 V, using SFAVM in Normal torque mode (110% over torque). Note: not valid for P315.

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.14: Derating of I_{out} for different $T_{\text{AMB, MAX}}$ for enclosure D at 600 V, using SFAVM in Normal torque mode (110% over torque). Note: P315 only.




Illustration 10.16: Derating of Iout for different TAMB, MAX for enclosure E at 480 V, using SFAVM in Normal torque mode (110% over torque)

60 AVM - Pulse Width Modulation, 525 - 600 V




Illustration 10.17: Derating of I_{Out} for different $T_{\text{AMB, MAX}}$ for enclosure E at 600 V, using 60 AVM in Normal torque mode (110% over torque).

SFAVM - Stator Frequency Asyncron Vector Modulation




Illustration 10.18: Derating of I_{Out} for different $T_{\text{AMB}, \text{MAX}}$ for enclosure E at 600 V, using SFAVM in Normal torque mode (110% over torque).

10.2.3. Derating for Low Air Pressure

The cooling capability of air is decreased at lower air pressure.

At altitudes higher than 2 km, please contact Danfoss regarding PELV.

Below 1000 m altitude no derating is necessary but above 1000 m the ambient temperature (T_{AMB}) or max. output current (I_{OLE}) should be derated in accordance with the shown diagram.




Illustration 10.19: Derating of output current versus altitude at TAMB, MAX. By altitudes above 2 km, please contact Danfoss regarding PELV.

An alternative is to lower the ambient temperature at high altitudes and thereby ensure 100% output current at high altitudes.



10.2.4. Derating for Running at Low Speed

When a motor is connected to a frequency converter, it is necessary to check that the cooling of the motor is adequate.

The level of heating depends on the load on the motor, as well as the operating speed and time.

Constant torque applications (CT mode)

A problem may occur at low RPM values in constant torque applications. In a constant torque application s a motor may over-heat at low speeds due to less cooling air from the motor integral fan.


Therefore, if the motor is to be run continuously at an RPM value lower than half of the rated value, the motor must be supplied with additional air-cooling (or a motor designed for this type of operation may be used).

An alternative is to reduce the load level of the motor by choosing a larger motor. However, the design of the frequency converter puts a limit to the motor size.

Variable (Quadratic) torque applications (VT)

In VT applications such as centrifugal pumps and fans, where the torque is proportional to the square of the speed and the power is proportional to the cube of the speed, there is no need for additional cooling or de-rating of the motor.

In the graphs shown below, the typical VT curve is below the maximum torque with de-rating and maximum torque with forced cooling at all speeds.



10.2.5. Derating for Installing Long Motor Cables or Cables with Larger Cross-Section

The maximum cable length for this frequency converter is 300 m unscreened and 150 m screened cable.

The frequency converter has been designed to work using a motor cable with a rated cross-section. If a cable with a larger cross-section is used, reduce the output current by 5% for every step the cross-section is increased.

(Increased cable cross-section leads to increased capacity to earth, and thus an increased earth leakage current).



VLT® AQUA Drive Operating Instructions

10.2.6. Automatic adaptations to ensure performance

The frequency converter constantly checks for critical levels of internal temperature, load current, high voltage on the intermediate circuit and low motor speeds. As a response to a critical level, the frequency converter can adjust the switching frequency and / or change the switching pattern in order to ensure the performance of the frequency converter. The capability to automatically reduce the output current extends the acceptable operating conditions even further.

10

168

MG.20.M5.02 - $\text{VLT}^{\text{\tiny{40}}}$ is a registered Danfoss trademark

VLT® AQUA Drive Operating Instructions



Index

Index

Default Settings

6	
50 Avm	163
A	
A	
Abbreviations And Standards	12
Acceleration Time	78
Access To Control Terminals	39
Acoustic Noise	161
Ama	48, 59
Analog I/o Option Mcb 109	135
Analog In/out	116
Analog Inputs	158
Analog Output	159
Application Functions	130
Automatic Adaptations To Ensure Performance	168
Automatic Motor Adaptation (ama)	46
Awg	149
В	
	35
Brake Connection Option	35
Brakes Bypass Option	<u>112</u>
pypas Onton	137
C	
Cable Lengths And Cross Sections	157
Cables General	19
Can Fieldbus	119
Can Motor	48
Cascade Controller	133
Cascade Ctl Option	136
Changing A Group Of Numeric Data Values	58
Changing A Text Value	58
Changing Data	57
Changing Of Data Value	58
Check Valve Ramp End Speed [hz]	79
Check Valve Ramp End Speed [rpm]	79
Check Valve Ramp Time	79
Checklist	13
Coasting	54
Comm. And Options	117
Communication Option	145
Constant Torque Applications (ct Mode)	167
Control Cable Clamp	40
Control Cables	41
Control Cables	41
Control Card Performance	160
Control Card, +10 V Dc Output	159
Control Card, 24 V Dc Output	159
Control Card, Rs-485 Serial Communication:	157
Control Card, Usb Serial Communication	160
Control Characteristics	160
Control Terminals	40
Cooling	167
Cooling Conditions	16
Copyright, Limitation Of Liability And Revision Rights	3
D	
Data Readouts	124
Data Readouts 2	126
Dc Bus Connection	34
A - A - A - A	4.42

VLT® AQUA Drive Operating Instructions



Default Settings	
Derating For Ambient Temperature	16
Derating For Installing Long Motor Cables Or Cables With Larger Cross-section	16
Derating For Low Air Pressure	16
Derating For Running At Low Speed	16
Digital In/out	11
Digital Inputs:	15
Digital Cutput	15
Display Line 1.1 Small, 0-20	71
Display Line 1.2 Small, 0-21	7.
	7
Display Line 1.3 Small, 0-22	7.
Display Line 2 Large, 0-23	
Display Line 3 Large, 0-24	7.
Disposal Instruction	
Drive Closed Loop, 20-**	9
E	
Earthing And It Mains	2
Efficiency	16
Efficient Parameter Set-up For Water Applications	6
Electrical Installation	4
Electrical Wiring	4
Electronic Waste	
Enclosure Knock-outs	1
End Of Curve Delay	10
End Of Curve Function	104
Etr	14
Ext. Closed Loop	12
The state of the s	
F	
Fault Messages	14.
Fc Closed Loop	12
Fc Information	12
	10
Filled Setpoint, 29-05	
Final Ramp Time	7'
Frequency Converter	4
Function Relay, 5-40	8
Fuses	
G	
	_
General Settings, 1-0*	
General Warning	
Glcp	50
Graphical Display	5
и	
Н	
How To Connect A Pc To The Frequency Converter	6
How To Connect Motor - Foreword	2
How To Connect To Mains And Earthing For B1 And B2	2
How To Operate Graphical Lcp (glcp)	5
7	
I	
Indexed Parameters	
Indicator Lights (leds):	5
Initial Ramp Time, 3-84	7.
Initialisation	6
Installation At High Altitudes	
Intermediate Circuit	143, 161, 16
ARCHINGOIGE CHEUR	173, 101, 10
K	
Keypad	5'
Kty Sensor	14

VLT® AQUA Drive Operating Instructions



	1	
п		

-	
Language - Parameter, 0-01	69
Language Package 1	70
Language Package 2	70
Language Package 3	70
Language Package 4	70
Lcp	59
<u>Lcp 102</u>	51
Leakage Current	6
Leds	51
Limits / Warnings	114
Load/motor	111
M	
Main Menu	63
Main Menu Mode	54
Main Menu Mode	68
Main Reactance	0 ,76
Mains Connection For A2 And A3	24
Mains Connection For B1, B2 And B3	27
Mains Connection For B4, C1 And C2	28
Mains Connection For C3 And C4	28
Mains Supply	149, 155
Mains Supply (I1, L2, L3)	157
Mains Supply 1 X 200 - 240 Vac	148
Mains Wiring Overview	23
Maximum Boost Time	100
Mct 10	61
Mechanical Dimensions	15
Mechanical Mounting	16
Motor Connection For C3 And C4	34
Motor Current	76
Motor Name Plate	45
Motor Output	157
Motor Protection	157
Motor Voltage	162
Motor Voltage	75
Motor Wiring Overview	30
· · · · · · · · · · · · · · · · · · ·	
N	
Name Plate Data	45
Name Plate Data.	45
Nicp	56
Non UI Compliance	20
0	
Operation/display	109
Output Performance (u, V, W)	157
Over-current Protection	20
n	
P	
Panel Through Mounting	17
Parameter Options	108
Parameter Selection	68
Parameter Set-up	63
Pc Software Tools	61
Peak Voltage On Motor	162
Pid Normal/inverse Control, 20-81	96
Pipe Fill Enable, 29-00	107
Pipe Fill Rate, 29-04	107
Pipe Fill Speed [hz], 29-02	107
Pipe Fill Speed [rpm], 29-01	107
Pine Fill Time, 29-03	107

VLT® AQUA Drive Operating Instructions



Preset Reference	78
Profibus	118
Profibus Dp-v1	61
Protection	20
Protection And Features	157
Pulse Width Modulation	
TOSE WIGHT POCONCOT	163
0	
Q	
Q1 My Personal Menu	
Q2 Quick Setup	
Q3 Function Setups	65
Q5 Changes Made	67
Q6 Loggings	67
Quick Menu	53, 63
Quick Menu Mode	. 53
Quick Transfer Of Parameter Settings When Using Glcp	59
D	
R	
Reference / Ramps	113
Reference/feedback Unit, 20-12	94
Relay Connection	36
Relay Output	38
Relay Outputs	159
Reset	SS
Residual Current Device	6
Rise Time	162
Rs-485 Bus Connection	60
S	
Safety Note	5
Safety Requirements Of Mechanical Installation	17
Screened/armoured.	41
Serial Communication	160
Set Date And Time, 0-70	74
Sfavm	
	163
Side-by-side Installation	16
Sine-wave Filter	29
Sine-wave Filter	48
Smart Logic	120
Software Version And Approvals	8
Special Functions	121
Start/stop	47
Stator Frequency Asyncron Vector Modulation	163
Stator Leakage Reactance	0 ,76
Status	53
Status Messages	51
Step-by-step	58
Submersible Pump	48
Surroundings	160
Switches S201, S202, And S801	44
_	
Т	
Tightening Of Terminals	19
Timed Actions	132
Timed Actions, 23-0*	104
Torque Characteristics	157
Type Code String	11
Type Code String (t/c).	
U	
Unpacking Table	13
Usb Connection.	40

VLT® AQUA Drive Operating Instructions



,

Variable (quadratic) Torque Applications (vt)	16
Voltage Level	15
w	
Wake-up Ref./fb Difference	10
Warning Against Unintended Start	
Water Application Functions	13
Water Application Functions, 29-**	10
Winno Example And Testing	3




















Technical Information

Waterpilot FMX167

Hydrostatic Level Measurement Reliable and rugged level probe with ceramic measuring cell Compact device for level measurement in fresh water, wastewater and saltwater



Applications

The Waterpilot FMX167 is a pressure sensor for hydrostatic level measurement. Three versions of the FMX167 are available from Endress+Hauser:

- FMX167 with an outer diameter = 0.87 in (22 mm): Version suitable for drinking water applications and for use in standard 1 inch well casings
- FMX167 with an outer diameter = 1.66 in (42 mm): Heavy duty version that is easy to clean due to the flush-mounted diaphragm. Suitable for wastewater, sewage treatment plants, and lift stations
- FMX167 with an outer diameter = 1.15 in (29 mm): Chemical resistant version for use in saltwater

Your benefits

- Ceramic pressure sensor provides high mechanical resistance to overload and aggressive media
- High-precision and long-term stability
- Resistant to climatic changes thanks to potted electronics and dual-filter pressure compensation system
- 4 to 20 mA output signal with integrated overvoltage protection
- Simultaneous level and temperature measurement with optional integrated temperature sensor Pt 100
- Drinking water approval: KTW, NSF, ACS
- Certified to ATEX, FM and CSA
- Complete measuring point solutions through comprehensive accessories

T1351P/24/ae



People for Process Automation

Table of contents

Function and system design
Device selection
Measuring principle
Measuring system
Input
Measured variable
Measuring range
Input signal
Outroot
Output
Output signal
Load
Power supply
Electrical connection
Supply voltage9
Cable specifications9
Power consumption
Current consumption
Residual ripple9
71
Performance characteristics10
Reference operating conditions
Maximum measured error
Long-term stability
Influence of medium temperature on the hydrostatic level
measurement of FMX167
Warm-up period
Rise time
Settling time
Installation11
Installation instructions
Environment
Ambient temperature range12
Storage temperature
Degree of protection
Electromagnetic compatibility (EMC)
Overvoltage protection
0. p
Process12
Medium temperature range
Medium temperature limits
Machanian annahus dis-
Mechanical construction
Dimensions of level probe
Dimensions of suspension clamp
Dimensions of extension cable mounting screws
Dimensions of the terminal box IP 66/IP 67 (NEMA 4X)
with filter
Dimensions of temperature transmitter TMT181
Weight
Material
Extension cable

Terminals
Certificates and approvals
$ \begin{array}{llllllllllllllllllllllllllllllllllll$
Ordering information 18 FMX167 18
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
Documentation20Field of Activities20Technical Information20Operating Instructions20Safety Instructions20Installation/Control Drawings20

Function and system design

Device selection


Waterpilot FMX167			l
	P)-Mili72-16-0-14-1-302	POI-PMX1074x-10-12x-14x-14-003	PO 1-PMX 10 7 to 10-10-10-10-10-10-
Field of application	Hydrostatic level measurement in deep wells e.g. drinking water	Hydrostatic level measurement in wastewater	Hydrostatic level measurement in saltwater
Process connection	Suspension clamp Extension cable mounting screw with	' G1 1/2 A or 1-1/2" NPT thread	<u> </u>
Outer diameter	0.87 in (22 mm)	1.66 in (42 mm)	Max. 1.15 in (29 mm)
Seats	- FKM Viton - EPDM ¹	- FKM Viton	- FKM Viton - EPDM
Measuring ranges	- Nine fixed pressure measuring ranges from 0 to 3 ftH₂0 to 0 to 600 ftH₂0 to 0 to 20 bar / 0 to 1 mH₂0 to 0 to - Customer-specific measuring ranges;	' 0 to 1.5 psi to 0 to 300 psi (0 to 0.1 bar 200 mH ₂ O)	- Seven fixed pressure measuring ranges in ftH ₂ O, psi, bar, and mH ₂ O from 0 to 3 ftH ₂ O to 0 to 150 ftH ₂ O / 0 to 1.5 psi to 0 to 60 psi (0 to 0.1 bar to 0 to 4 bar / 0 to 1 mH ₂ O to 0 to 40 mH ₂ O) - Customer-specific measuring ranges; factory-calibrated
Overload	Up to 580 psi (40 bar)		Up to 362 psi (25 bar)
Process temperature	+14 to +158°F (-10 to +70°C)		+32 to +122°F (0 to +50°C)
Ambient temperature range	+14 to +158°F (-10 to +70°C)		+32 to +122°F (0 to +50°C)
Maximum measured error	±0.2 % of upper range value (URV)		
Supply voltage	i 0 to 30 V DC		
Output	4 to 20 mA		
Options	- Drinking water approval - Integrated Pt 100 temperature sensor - Integrated Pt 100 temperature sensor and temperature transmitter TMT181 (4 to 20 mA)	- Integrated Pt 100 temperature sensor - Integrated Pt 100 temperature sensor and temperature transmitter TMT181 (4 to 20 mA)	Integrated Pt 100 temperature sensor Integrated Pt 100 temperature sensor and temperature transmitter TMT181 (4 to 20 mA)
Specialties	- Integrated overvoltage protection - Large selection of approvals, includin - High-precision, long-term stable and		

i) Recommended for drinking water applications, not suitable for use in hazardous areas

Measuring principle

The ceramic sensor is a dry sensor with the process pressure acting directly on the rugged ceramic diaphragm and deflecting it a maximum of 0.0002" (0.005 mm).

The effects of air pressure on the liquid surface are transferred via a pressure compensation tube through the extension cable to the rear of the ceramic diaphragm and compensated. Pressure-dependent changes in capacitance caused by diaphragm movement are measured at the electrodes of the ceramic carrier. The electronics convert the movement into a pressure-proportional signal which is linear to the medium level.



FMX167 measuring principle

- I Ceramic measuring cell
- 2 Pressure compensation tube
- h Level height
- p Total pressure = hydrostatic pressure + atmospheric pressure
- ρ Medium density
- g Gravitational acceleration

phydr. Hydrostatic pressure patm Atmospheric pressure

Temperature measurement with optional Pt 100

Endress+Hauser offers an optional 4-wire Pt 100 resistance thermometer for Waterpilot FMX167 to measure level and temperature simultaneously. The Pt 100 belongs to Accuracy Class B to DIN EN 60751.


Temperature measurement with optional Pt 100 and temperature transmitter TMT181

To convert the Pt 100 signal to a 4 to 20 mA signal, Endress+Hauser also offers the TMT181 temperature transmitter.

Measuring system

The complete standard measuring system consists of Waterpilot FMX167 and a transmitter power supply unit with supply voltage of 10 to 30 V DC.


Example for other measuring point solutions with transmitter and possible evaluation units from Endress+Hauser:



Application examples with FMX167

OP Overvoltage protection e.g. HAW from Endress+Hauser

- Simple cost-effective measuring point solution: Power supply of Waterpilot in hazardous and non-hazardous areas using RN221N active barrier.
 Power supply and additional control of two consumers, e.g. pumps, via limit switch RTA421 with onsite display.
- 2. Power supply, onsite display, two switch outputs and a signal adaptation (turn down) are integrated in evaluation devices RMA421 (for mounting on hat rails) and RIA250 (for panel mounting). The evaluation unit RMA421 also has a trend recognition function, e.g. optimizing pump control in stormwater overflow basins. This function detects and evaluates changes in a measurable value within a specific time period.
- If several pumps are used, pump life can be prolonged by alternate switching. With alternating pump
 control, the pump which was out of service for the longest period of time is switched on. The evaluation
 units RIA452 (for panel mounting) and RMA422 (for mounting on Top-hat rails) offer this function as
 well as several others.
- State-of-the-art recording technology with monitor recorders from Endress+Hauser, e.g. Ecograph, Memograph or hardcopy recorders such as Alphalog for documenting, monitoring, visualizing and archiving.



Application examples with FMX167 with Pt 100

- OP Overvoltage protection e.g. HAW from Endress+Hauser
- 5. If you want to measure, display and evaluate temperature as well as level, e.g. to monitor temperature in fresh water to detect temperature limits for germ formation, you have the following options:
 The optional temperature transmitter can convert the Pt 100 signal into a 4 to 20 mA signal and transfer it to any customary evaluation unit. Evaluation devices RMA421, RIA250 and RIA452 also offer a direct input for the Pt 100 signal.
- If you want to detect and evaluate level and temperature with one device, choose the evaluation unit RMA422 with two inputs. It even includes the mathematical operation for linking the input signals.

Input

Measured variable FMX167 + Pt 100 (optional) Temperature transmitter (optional) · Hydrostatic pressure of a liquid Temperature ■ Pt 100: Temperature of a liquid Measuring range Nine fixed pressure measuring ranges in bar, mH₂O, psi and ftH₂O; → Page 18, "Ordering information" Section Customer-specific measuring ranges; factory-calibrated ■ Temperature measurement from -10...+70°C (+14...+158°F) (optional with Pt 100) FMX167 + Pt 100 (optional) Input signal Temperature transmitter (optional) ■ Pt 100 resistance signal, 4-wire • Change in capacitance ■ Pt 100: Change in resistance

Output

Output signal	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)
	 FMX167: 4 to 20 mA for hydrostatic pressure measured value, two-wire Pt 100: Temperature-dependent resistance of Pt 100 	 4 to 20 mA for temperature measured value, two- wire
Load	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)

$$R_{lot} \le \frac{U_b - 10 \text{ V}}{0.0225 \text{ A}} - 2 \cdot 0.09 \frac{\Omega}{\text{m}} \cdot \text{I} - R_{add}$$

0.02

 $R_{lot} \le \frac{U_b - 8V}{0.025 A} - R_{add}$


Rtot = Max. load resistance $[\Omega]$

Radd= Additional resistances such as resistance of evaluating device and/or display instrument,


line resistance $[\Omega]$

Ub = Supply voltage [V]

Simple length of extension cable [m] (cable resistance per wire $\leq 0.09 / \Omega m$)



Load chart FMX167 for estimating load resistance. Subtract the additional resistances, e.g. resistance of extension cable, from the calculated value as shown in the equation.



Load chart temperature transmitter for estimating load resistance. Subtract the additional resistances from the calculated value as shown in the equation.

Power supply

Electrical connection

Note!


- When using the measuring device in hazardous areas, national standards and regulations as well as the Safety Instructions (XAs) or Installation or Control Drawings (ZDs) have to be observed. → See also Page 20, "Safety Instructions" and "Installation/Control Drawings" Sections.
- Reverse polarity protection is integrated in the Waterpilot FMX167 and in the temperature transmitter TMT181. Changing the polarities has no impact on operation.
- The cable must end in a dry room or in a proper terminal box. For installation outside, use the terminal box NEMA 4X (IP 66/IP 67) with a GORE-TEX® filter from Endress+Hauser. The terminal box can be ordered using the order code of FMX167 (→ see Page 18, "Ordering information" Section) or an accessory (order number: 52006252).

Waterpilot FMX167, standard

10 to 30 V DC to 20 mA 1 RD FMX167

FMX167 electrical connection, versions "7" or "3" for Feature 70 "Additional options" in the order code (→ see Page 18).


Waterpilot FMX167 with Pt 100



PO(-FMX10711-04-11-11-11-000

FMX167 electrical connection with Pt 100, versions "1" or "4" for Feature 70 "Additional options" in the order code (→ see Page 18).

Waterpilot FMX167 with Pt 100 and TMT181 temperature transmitter (4 to 20 mA)



FMX167 with Pt 100 and TMT181 temperature transmitter (4 to 20 mA), version "5" for Feature 70 in the order code (→ see Page 18).

Not for FMX167 with outer diameter = 1.15 in (29 mm)

Wire colors: RD = red, BK = black, WH = white, YE = yellow, BU = blue, BR = brown

8

Waterpilot


Supply voltage	Note! ■ When using the measuring device in hazardous areas, national standards and regulations as well as the safety instructions (XAs) or Installation or Control Drawings (ZDs) have to be observed. → See also Page 20, "Safety Instructions" and "Installation/Control Drawings" Sections.							
	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)						
	FMX167: 10 to 30 V DCPt 100: 10 to 30 V DC	■ 8 to 35 V DC						
Cable specifications	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)						
	 Commercially available instrument cable Terminals, terminal housing FMX167: 20 to 14 AWG (0.08 to 2.5 mm²) If the Pt 100 signal is directly connected to a display and/or evaluation unit, we recommend the use of a shielded cable. 	 ■ Commercially available instrument cable ■ Terminals, terminal housing FMX167: 20 to 14 AWG (0.08 to 2.5 mm²) ■ Connection, transmitter: Max. 14 AWG (1.75 mm²) 						
Power consumption	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)						
	\leq 0.675 W at 30 V DC	≤ 0.875 W at 35 V DC						
Current consumption	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)						
	 Max. current consumption: ≤ 22.5 mA Min. current consumption: ≥ 3.5 mA Pt 100: ≤ 0.6 mA 	 Max. current consumption: ≤ 25 mA Min. current consumption: ≥ 3.5 mA Pt 100 via temperature transmitter: ≤ 0.6 mA 						
Residual ripple	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)						
	No effect for 4 to 20 mA signal up to ± 5 % residual ripple within permissible range	$U_{ss} \ge 5 \text{ V at } U_B \ge 13 \text{ V, } f_{max.} = 1 \text{ kHz}$						

Performance characteristics

Reference operating	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)					
conditions	DIN EN 60770 T _U = 77°F (25°C)	Calibration temperature 73°F ± 5 K (23°C ± 5 K					
Maximum measured error	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)					
	 Non-linearity including hysteresis and non-repeatability as per DIN EN 60770: ±0.2% of upper range value (URV) Pt 100: Max. ±0.7 K (Class B to DIN EN 60751) 	■ ±0.2 K ■ With Pt 100: Max. ±0.9 K					
Long-term stability	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)					
	±0.1% of upper range value (URV) per year	≤ 0.1 K per year					
Influence of medium temperature on the hydrostatic level	■ Thermal change in zero signal and output span for typical application temperature range +32 to +86°F (0 to +30°C): ±0.4% (±0.5%)* of the upper range limit (URL)						
measurement of FMX 167	■ Thermal change in zero signal and output span for the entire medium temperature range +14 to +158°F (-10 to +70°C): ±1.0% (±1.5%)* of the upper range limit (URL)						
	■ Temperature coefficient (T _K) of zero signal and output span: 0.15%/10 K (0.3%/10 K)* of the upper range limit (URL)						
	* Specifications for sensors 0.1 bar (1 $\mathrm{mH_2O}$, 1.5	psi, 3 ftH $_2$ O) and 0.6 bar (6 mH $_2$ O, 10 psi, 20 ftH $_2$ O)					
Warm-up period	FMX167 + Pt 100 (optional)	Temperature transmitter (optional)					
	20 ms	4 s					
Rise time	FMX167 + Pt 100 (optional)						
	■ FMX167: 80 ms ■ Pt 100: 160 s						
Settling time	FMX167 + Pt 100 (optional)						
	■ FMX167: 150 ms ■ Pt 100: 300 s						

Installation

Installation instructions



Installation examples, here shown with FMX167 with an outer diameter = 0.87 in (22 mm)

- 1 Extension cable mounting screw can be ordered via order code or as an accessory, → see Page 14 and 19
- 2 Terminal housing can be ordered via order code or as an accessory, → see Page 15 and 19
- 3 Extension cable bending radius > 4.72 in (120 mm)
- 4 Suspension clamp can be ordered via order code or as an accessory, → see Page 14 and 19
- 5 Extension cable up to 384 ft (300 m), for max. length \rightarrow see Page 16, "Extension cable" Section
- Guide tube for FMX167 with outer diameter = 0.87 in (22 mm) internal diameter > 0.91 in (23 mm)
- Additional weight can be ordered as an accessory for FMX167 with outer diameter = 0.87 in (22 mm) and 1.15 in (29 mm), \rightarrow see Page 19
- 8 Protection cap

Note!

- A sideways movement of the level probe can lead to measuring errors. Therefore, install the probe at a point free from flow and turbulence, or use a guide tube. The internal diameter of the guide tube should be at least 0.04 in (1 mm) bigger than the outer diameter of the selected FMX167.
- The cable must end in a dry room or in a proper terminal box. The terminal box from Endress+Hauser provides optimum humidity and climatic protection and is suitable for outdoor installation.

Environment

Ambient temperature range

FMX167 + Pt 100 (optional)

- FMX167 with outer diameter = 0.87 in (22 mm) and 1.66 in (42 mm): +14 to +158°F (-10 to +70°C) (= medium temperature)
- FMX167 with outer diameter = 1.15 in (29 mm): +32 to +122°F (0 to +50°C) (= medium temperature)

Temperature transmitter (optional)

-40 to +185°F (-40 to +85°C)

Storage temperature

FMX167 + Pt 100 (optional)

-40 to +176°F (-40 to +80°C)

Temperature transmitter (optional)

-40 to +212°F (-40 to +100°C)

Degree of protection

FMX167 + Pt 100 (optional)

- NEMA 6P (IP 68), permanently hermetically sealed
- Optional terminal box: NEMA 4X (IP 66/IP 67)

Temperature transmitter (optional)

- IP 00, moisture condensation permissible
- When mounted in the optional terminal boxes: NEMA 4X (IP 66/IP67)

Electromagnetic compatibility (EMC)

FMX167 + Pt 100 (optional)

- Interference emission to EN 61326 Class B equipment, interference immunity to EN 61326 Appendix A (Industrial)
- Maximum deviation: < 0.5% of span

Temperature transmitter (optional)

 Interference emission to EN 61326 Class B equipment, interference immunity to EN 61326 Appendix A (Industrial)

Overvoltage protection

FMX167 + Pt 100 (optional)

Integrated overvoltage protection to EN 61000-4-5 $\leq 1.2 \, kV$ Install overvoltage protection $\geq 1.2 \, kV$, external if necessary

Temperature transmitter (optional)

Install overvoltage protection, external if necessary.

Process

Medium temperature range

FMX167 + Pt 100 (optional)

- FMX167 with outer diameter = 0.87 in (22 mm) and 1.66 in (42 mm): +14 to +158°F (-10...+70°C)
- FMX167 with outer diameter
 - = 1.15 in (29 mm): +32 to +122°F (0 to +50°C)

Temperature transmitter (optional)

-40 to $+185^{\circ}$ C (-40 to $+85^{\circ}$ C) (= ambient temperature), install temperature transmitter outside medium.

Medium temperature limits


FMX167 + Pt 100 (optional)

- FMX167 with outer diameter
 - = 0.87 in (22 mm) and 1.66 in (42 mm):
 - $-4 \text{ to } +158^{\circ}\text{F} (-20 \text{ to } +70^{\circ}\text{C})$
- FMX167 with outer diameter
 - = 1.15 in (29 mm): +32 to +122°F (0 to +50°C)

(You may operate the FMX167 in this temperature range. The specification can then be exceeded, e.g. measuring accuracy).

Mechanical construction


Dimensions of level probe



Versions of FMX167, dimensions in inches (mm)


- 1 FMX167, version "A" or "D" for Feature 30 "Probe tube" in the order code (→ see Page 18)
- 2 FMX167, version "B" for Feature 30 "Probe tube" in the order code (→ see Page 18)
- 3 FMX167, version "C" for Feature 30 "Probe tube" in the order code (→ see Page 18)
- 4 Pressure compensation tube
- 5 Extension cable
- 6 Protection cap

Dimensions of suspension clamp



Suspension clamp, version 2 for Feature 20 "Connection" in the order code (\rightarrow see Page 18), dimensions in inches (mm) Order number: 52006151

Dimensions of extension cable mounting screws




Extension cable mounting screws, dimensions in inches (mm) Order number: 52009311

- Extension cable mounting screw G 1 1/2 A, version "3" for Feature 20 "Connection" in the order code (→ see Page 18)
- 2 Extension cable mounting screw 1 1/2 NPT, version "4" for Feature 20 "Connection" in the order code (→ see Page 18)

Q-Pulse Id TMS942

Dimensions of the terminal box NEMA 4X (IP 66/IP 67) with filter




Terminal box, dimensions in inches (mm)

Order number: 52006152

Version "3", "4" or "5" for Feature 70 "Additional options" in the order code (→ see Page 18)

- 1 Dummy plug M 20 x 1.5
- 2 GORE-TEX® filter
- 3 Terminals for 20 to 14 AWG (0.08 to 2.5 mm²)

Dimensions of temperature transmitter TMT181



Temperature transmitter TMT181 (4 to 20 mA), dimensions in inches (mm)

Version "5" for Feature 70 "Additional options" in the order code (\rightarrow see Page 18). The temperature transmitter can be used in non-hazardous areas and for EEx nA.

Weight

- Level probe, outer diameter = 0.87 in (22 mm): 0.6 lb (290 g)
- Level probe, outer diameter = 1.66 in (42 mm): 2.5 lb (1150 g)
- Level probe, outer diameter = 1.15 in (29 mm): 0.7 lb (340 g)
- Extension cable LDPE: 0.6 oz/ft (52 g/m)
- Extension cable FEP: 1.3 oz/ft (108 g/m)
- Suspension clamp: 0.4 lb (170 g)
- Extension cable mounting screw G 1 1/2 A: 770 g
- Extension cable mounting screw 1-1/2" NPT: 724 g
- Terminal box: 0.5 lb (235 g)
- Temperature transmitter: 0.1 lb (40 g)
- Additional weight: 0.7 lb (300 g)

Endress+Hauser

15

Material

Level probe

- Level probe, outer diameter = 0.87 in (22 mm): AISI 316L SS (1.4435)
- Level probe, outer diameter = 1.66 in (42 mm): AISI 316L SS (1.4435)
- Level probe, outer diameter = 1.15 in (29 mm):
 - Level probe: AISI 316L SS (1.4435)
 - Sensor sleeve: PPS (polyphenylene sulfide)
 - Heat-shrink sleeve/cover: Polyolefin

Metal does not come into contact with the medium.

- Process ceramic: Al₂O₃ aluminum oxide ceramic
- Seal (internal): EPDM or Viton
- Protective cap: PE-HD (high-density polyethylene)
- Extension cable insulation: Either LDPE (low density polyethylene) or FEP (fluorinated ethylene propylene). For more information, see the next Section "Extension cable"
- Suspension clamp: AISI 316L SS (1.4435) and glass fiber reinforced PA (polyamide)
- Extension cable mounting screw G 1 1/2 A: AISI 304 SS (1.4301)
- Extension cable mounting screw 1-1/2" NPT: AISI 304 SS (1.4301)
- Terminal box: PC (polycarbonate)
- Temperature transmitter: Housing PC (polycarbonate)

Extension cable

Structure of LDPE extension cable

- Slip-resistant extension cable with strain-relief members made of Dynemo; shielded using aluminum-coated film; insulated with low density polyethylene (LDPE), black; copper wires, twisted
- Pressure compensation tube with Teflon filter

Structure of FEP extension cable

- Slip-resistant extension cable; shielded using galvanized steel wire netting; insulated with fluorinated ethylene propylene (FEP), black; copper wires, twisted
- Pressure compensation tube with Teflon filter

Cross-section of LDPE and FEP extension cable

- Total outer diameter: 0.315 inch ± 0.0098 inch (8.0 mm ± 0.25 mm)
- FMX167: 3 x 0.0004 in² (0.227 mm²) + pressure compensation tube with Teflon filter
- FMX167 with Pt 100 (optional): 7 x 0.0004 in² (0.227 mm²) + pressure compensation tube with Teflon filter
- Pressure compensation tube with Teflon filter:
 Outer diameter = 0.098 inch (2.5 mm), internal diameter = 0.059 inch (1.5 mm)

Cable resistance of LDPE and FEP extension cable

■ Cable resistance per wire: $\leq 0.09 \Omega/m$

Cable length of LDPE and FEP extension cable

- Max. free suspended length (mechanical stability under load): 3120 ft (950 m)
- Please also refer to Page 7, "Load" Section.
- When using the measuring device in hazardous areas, national standards and regulations as well as the safety instructions (XAs) or Installation or Control Drawings (ZDs) have to be observed. → See also Page 20, "Safety Instructions" and "Installation/Control Drawings" Sections.

Further technical data of LDPE and FEP extension cable

- Minimum bending radius: 4.72 inch (120 mm)
- Tensile strength: Min. 214 lbf (950 N)
- Cable extraction force: ≥ 100 lbf (450 N)
 - (The extension cable could be extracted from the level probe at a tensile force of $\geq 100 \text{ lbf} / 450 \text{ N.}$)
- Resistance to UV light
- LDPE: Approved for use with drinking water

Terminals

- 3 standard terminals in terminal box
- 4-terminal strip can be ordered as accessory, Order No. 52008938
 Wire cross-section 20 to 14 AWG (0.08 to 2.5 mm²)

Certificates and approvals

	· · ·
CE approval	By attaching the CE symbol, Endress+Hauser confirms that the instrument fulfills all the requirements of the relevant EC directives.
Ex approval,	■ ATEX II 2 G EEx ia IIC T6 ¹
type of protection	■ ATEX II 3 G EEx nA II Tó
-	■ FM: IS, Class I, Division 1, Groups A–D ¹
	■ CSA: IS, Class I, Division I, Groups A–D ¹
	l Only for Waterpilot FMX167 without Pt 100
	Waterpilot FMX167 with outer diameter = 0.87 in (22 mm) is only suitable for use in hazardous areas with the FKM Viton seal.
	All explosion protection data are contained in separate explosion protection documentation which you can also request. Explosion protection documents are supplied as standard for all devices approved for use in explosion hazardous areas. → See also Page 20, "Safety Instructions" and "Installation/Control Drawings" Sections.
Drinking water approval	■ KTW certificate
(for FMX167	■ NSF 61 approval
with $d_0 = 0.87 \text{ in } / 22 \text{ mm}$)	 ACS approval
Marine approval	■ GL approval
	 ABS approval
External standards and	DIN EN 60770 (IEC 60770):
guidelines	Transmitters for use in industrial-control systems
	Part 1: Methods for performance evaluation
	DIN 16086:
	Electrical pressure measuring instruments,
	pressure sensors, pressure transmitters,
	pressure measuring instruments, concepts, specifications on data sheets
	EN 61326 (IEC 61326-1):
	Electrical equipment for measurement, control and laboratory use – EMC requirements
Registered	GORE-TEX®
trademarks	Registered trademark of W.L. Gore & Associates, Inc., USA

Ordering information

FMX167

10	Ap	bto	/al		3,27-31	A Section of the second section of	interior services	A CONTRACTOR OF THE SECOND					
	Α	Ver	sion for no	n-hazardous area									
	В	ATE	EX II 2 G EEx ia HC T6										
	С	ATE	EX II 3 G EEx nA II T6										
	D	FM	IS, Class I, Division I, Groups A – D										
	Ε	CSA	,	s I, Division 1, Groups A	- D								
	F	CSA	A General	Ригроѕе									
20	Co	nne	ction					. Silver and the silv					
		1	Probe cab	le									
		2	Suspensio	n clamp, AISI 316L SS									
		3		unting screw G 1 1/2, Al									
		4	Cable mo	unting screw NPT 1-1/2"	, AISI C	304 SS							
30	Pro	be	tube:										
				r diameter $d = 0.87$ in $\{27$									
				•		flush mount, AISI 316L							
					9 mm),	AISI 316L SS with heat-	shrink steeve PPS/potyo	lefin for saltwater					
			1 1	cations r diameter d = 0.87 in 12°	2 mm1	AISI 316L SS + drinking	water approval VTW/N	SE/ACS					
						with EPDM seal and LDP		31/AW					
40	<u> </u>	·	Mea	suring range:	1275								
1 10 1 10 10 10 10 10 10 10 10 10 10 10	نونان		***************************************	suring range	Meas	suring range	Max. overload	Vacuum					
				1		1		resistance					
			BA	0 to 0.1 bar	MA	0 to 1 mH ₂ O	5 bar	O psia (O bar _{abs})					
			BB	0 to 0.2 bar	MB	0 to 2 mH ₂ O	5 bar	O psia (O bar _{abs})					
			BC	0 to 0.4 bar	MC	0 to 4 mH ₂ O	7 bar	O psia (O bar _{abs})					
			BD	0 to 0.6 bar	MD	0 to 6 mH ₂ O	10 bar	O psia (O bar _{abs})					
			BE	0 to 1.0 bar	ME	0 to 10 mH ₂ O	10 bar	O psia (O bar _{abs})					
			BF	0 to 2.0 bar	MF	0 to 20 mH ₂ O	18 bar	O psia (O bar _{abs})					
			BG	0 to 4.0 bar	MG	0 to 40 mH ₂ O	25 bar	O psia (O bar _{abs})					
			BH	0 to 10.0 bar	MH	0 to 100 mH ₂ O	40 bar	O psia (O bar _{abs})					
			BK	0 to 20.0 bar	MK	0 to 200 mH ₂ O	40 bar	O psia (O bar _{abs})					
ł			PA	0 to 1.5 psi	FA	0 to 3 ftH ₂ O	73 psi	O psia (O bar _{abs})					
ĺ			PB	0 to 3 psi	FB	0 to 6 ftH ₂ O	73 psi	O psia (O bar _{abs})					
			PC	0 to 6 psi	FC	0 to 15 ftH ₂ O	101 psi	O psia (O bar _{abs})					
			PD	0 to 10 psi	FD	0 to 20 ftH ₂ O	145 psi	O psia (O bar _{abs})					
			PE	0 to 15 psi	FΕ	0 to 30 ftH ₂ O	145 psi	O psia (O bar _{abs})					
			PF	0 to 30 psi	FF	0 to 60 ftH ₂ O	261 psi	O psia (O bar _{abs})					
			PG	0 to 60 psi	FG	0 to 150 ftH ₂ O	362 psi	O psia (O bar _{abs})					
			PH	0 to 150 psi	FH	0 to 300 ftH ₂ O	580 psi	O psia (O bar _{abs})					
			PK	0 to 300 psi	FK	0 to 600 ftH ₂ O	580 psi	O psia (O bar _{abs})					
			vv			tions from 0 to (uppe							
				upper range value: 1.5	psi (3 f	tH_2O , 0.1 bar, 1 mH_2O) to	300 psi (600 ft ₂ HO,20	bar, 200 m ₂ HO)					
50		3 5		Sensor seal:									

50	3	<i>i</i> .	1.52	Ser	isor seal:
				1	FKM Viton
			:	2	EPDM

60 ,		3.0	Pr	obe cable (can be shortened):
			A	m, LDPE
			В	10 m, LDPE
	1		c	20 m, LDPE
ļ			Ε .	30 ft, LDPE
			F	60 ft, LDPE
	1		G	ft, LDPE
				m, FEP
			K	10 m, FEP
			l L	20 m, FEP
			М	30 ft, FEP
			N	60 ft, FEP
			P	ft, FEP
<u>-</u>		Т		
FMX167	+	 		Complete order code

 $[\]rightarrow$ Ordering information for FMX167 continued on next page.

Page 196 of 333

FMX167 (continued)

70				F. 1. 18	3 22	. 3%	Αď	Iditional option:
	7	1				\Box	7	Basic version
							S	GL/ABS marine certificate
							1	Pt 100, 4-wire
							3	Terminal box NEMA 4X (IP66/67)
							4	Terminal box NEMA 4X (1P66/67) + Pt 100, 4-wire
							5	Pt 100 + temperature transmitter TMT181, 2-wire, 4 to 20 mA = -4 to +176°F (-20 to +80°C)
	Т	l		l	Т	1	Γ.	
FMX167	\top		_	<u> </u>	<u> </u>			Complete order code

Accessories


Suspension clamp

- Endress+Hauser offers a suspension clamp for simple FMX167 mounting. → See also Page 14.
- Material: AISI 316L SS (1.4404) and glass fiber reinforced PA (polyamide)
- Order number: 52006151

Terminal box

- Terminal box NEMA 4X (IP 66/IP 67) with GORE-TEX® filter incl. 3 mounted terminals.
 The terminal box is also suitable for installing a temperature transmitter (Order No. 52008794) or for four additional terminals (Order No. 52008938). → See also Page 15.
- Order number: 52006152

Additional weight (for FMX167 with $d_O = 0.87$ in / 22 mm and $d_O = 1.15$ in / 29 mm)



 To prevent sideways movement leading to measuring errors or to ensure that the device lowers into a guide tube, Endress+Hauser provides additional weights.

You can thread several weights together. The weights are then attached directly to the FMX167. For FMX167 with outer diameter = 1.15 in (29 mm), a maximum of 5 weights may be threaded on to the FMX167.

- Material: AISI 316L SS (1.4435)
- Weight: 0.7 lb (300 g)
- Order number: 52006153

Temperature transmitter

- Temperature transmitter, 2-wire, preset for measuring range from -4 to +176°F (-20 to +80°C). This setting offers an easily displayable temperature range of 100 K. Note that the Pt 100 resistance thermometer is designed for a temperature range of +14 to +158°F (-10 to +70°C). → See also Page 15.
- Order number: 52008794


Extension cable mounting assembly

- Endress+Hauser offers extension cable mounting assembly to simplify the installation of the FMX167. The threaded assembly caps the measuring pipe opening. → See also Page 14.
- Material: AISI 304 SS (1.4301)
- Order number for extension cable mounting assembly with G 1 1/2 A thread: 52008264
- Order number for extension cable mounting assembly with 1-1/2" NPT thread: 52009311

Terminals

- Four terminal strip for FMX167 terminal box, suitable for wire cross-section of 20 to 14 AWG (0.08 to 2.5 mm²)
- Order number: 52008939

Test adapter (for FMX167 with $d_0 = 0.87 \text{ in } / 22 \text{ mm and}$ $d_0 = 1.15 \text{ in } / 29 \text{ mm}$



- Test adapter
- Connection suitable for level probe FMX167
- В Connection compressed air hose, internal diameter, quick disconnect 0.157 in (4 mm)

- Endress+Hauser offers a test adapter to simplify the function test of level probes.
- Note the maximum pressure for the compressed air hose and the maximum level probe overload. \rightarrow See also Page 18.
- The maximum pressure for the supplied quick hose gland is 145 psi (10 bar).
- Adapter material: AISI 304 SS (1.4301)
- Quick hose gland material: Anodized aluminum
- Adapter weight: 0.1 lb (39 g)
- Order number: 52011868

Documentation

Field of Activities	 Pressure Measurement: FA004P/00/en Recording Technology: FA014R/09/de System Components: FA016K/09/en 	
Technical Information	■ Temperature Head Transmitter iTEMP PCP TMT181: TI070R/24/ae	
Operating Instructions	■ Waterpilot FMX167: BA231P/00/en	
Safety Instructions	■ ATEX II 2 G EEx ia IIC T6: XA131P/00/a3 ■ ATEX II 3 G EEx nA II T6: XA132P/00/a3	
Installation/ Control Drawings	■ FM IS Class I, Div. 1, Groups A – D: ZD063P/00/en ■ CSA IS Class I, Div. 1, Groups A – D: ZD064P/00/en	
Drinking water approval	■ SD126P/00/a3	

United States

Canada

Mexico


Endress+Hauser, Inc. 2350 Endress Place Greenwood, IN 46143 Tel. 317-535-7138 Sales 888-ENDRESS Service 800-642-8737 fax 317-535-8498 inquiry@us.endress.com www.us.endress.com

Endress+Hauser Canada 1075 Sutton Drive Burlington, ON L7L 5Z8 Tel. 905-681-9292 800-668-3199 Fax 905-681-9444 info@ca.endress.com www.ca.endress.com

Endress+Hauser, México, S.A. de C.V. Fernando Montes de Oca 21 Edificio A Piso 3 Fracc. Industrial San Nicolás 54030. Tlalnepantla de Baz Estado de México México Tel: +52 55 5321 2080 Fax +52 55 5321 2099 eh.mexico@mx.endress.com


www.mx.endress.com


T1351P/24/ae/06.07 © 2007 Endress+Hauser, Inc.



People for Process Automation

MTR Level Relay





The MTR level relay has proven itself to be simple and extremely reliable in pump stations everywhere. The MTR controls one pump or one alarm. The MTRA controls one pump and one alarm.

Safe

The extra low sensing voltage ensures maintenance staff and operators are protected at all times.

Four sensitivities

Allows the relay to operate effectively in a wide range of conductive liquids.

Activation delays

Each output can have a different time delay to overcome wave action and turbulence.

LED indication

High intensity LED indicators ensure clear signals. Power On (green). Alarm On (red). Pump On (yellow).

Dipswitch programmable

All settings are easily selectable from the front panel.

Proven reliability

The proven design and performance of the relay ensures long-term reliability of the MultiTrode system.

I.S application

Perfect for I.S application when used with an MTISB.

Unique two-sensor operation (MTRA only) Pump and alarm can be controlled using two or three sensors. Two-sensor operation is ideal for budget applications or where space is limited.

DIN rail or screw mounting

Low installed cost

Specifications

Mode of operation:

MTR Mode MTRA Mode Charge/Discharge (Fill or Empty)

Discharge ONLY

Probe Inputs:

Sensor inputs Sensor voltage Sensor current MTR: 2 / MTRA: 3 10/12VAC Nominal 0.8mA max. (per sensor)

1k, 4k, 20k, 80k

Sensitivity **Relay Outputs:**

> MTR relay output MTR Output delay

2 contact sets: 1 N/O & 1 C/O 0, 2.5, 5, 10, 20, 40, 80, 160 sec

MTRA relay output 2 relays: both N/O

MTRA Output delay Pump: 0.5, 10; Alarm: 0.5, 15 sec

Relay contact rating 250 VAC

Relay contact life Terminal size

5A Resistive, 2A Inductive 105 Operations

2 x 13 AWG / 2.5mm²

Display

LEDs: MTR MTRA Power On Green

Green

Pump Alarm Red

Yellow Red

Physical Product:

Dimensions

2.7/8H x 1.3/4W x 4.1/2D (Inches) 72Hx45Wx114D (mm)

Mounting DIN Rail or 2 x #6 Screws / 2 x M4 Screws Makrolon (self-extinguishing) Enclosure





Power Supply:

Supply Voltage AC **Power Consumption** Supply Voltage DC

24, 110, 240, 415VAC* - 50/60Hz *(MTR only) 3.5 Watts max

12 or 24VDC, **Power Consumption** 3 Watts max

Environmental Range:

- 10º to +60°C Centigrade +14º to +140ºF Fahrenheit





Available Models & Ordering Information

415VAC	MTR-1	n/a
240VAC	MTR-2	MTRA-2
110VAC	MTR-3	MTRA-3
24VAC	MTR-4	MTRA-4
24VDC	MTR-5	MTRA-5
12VDC	MTR-6	MTRA-6

www.multitrode.com

MultiTrode Pty Ltd: Australia

Brisbane Technology Park 18 Brandl Street PO Box 4633 Eight Mile Plains Qld 4113 Tel: +61 7 3340 7000 Fax: +61 7 3340 7077 sales@inultitrode.com.au

MultiTrode Inc. USA

6560 East Rogers Circle Boca Raton Florida 33487.

Tel: +1 561 994 8090 Fax: +1 561 994 6282


sales@multitrode.net

PB251 Series

220-330 WATTS DC UPS

Features

- Ultra-low noise output
- Independent battery charging output
- DC output OK & battery OK alarms & LEDs
- Battery-LVD and alarm
- Over-temperature protection
- Battery fuse fail LED



Specifications	
INPUT	
Voltage:	190 to 264 vac, or 190 to 400VDC
Line regulation:	0.2%typical
Current:	1.4A maximum
Inrush current:	10A maximum
Frequency:	45 to 65 Hz
OUTPUT	
Voltage	See table
Current	See table
Load regulation	0.5%typical
Current limit type - load cct	Constant current
Current limit type - batt. cct	Constant current
Short circuit protection	Indefi nite, auto-resetting
Over-voltage protection	17.5 to 20V latching (13.8Vdc output) 31.5 to 39V latching (27.6Vdc output)
Ripple & noise 100 MHz bandwidth	28mVp-p (13.8Vdc output) 55mVp-p (27.6Vdc output)
ENVIRONMENTAL	
Operating temperature	0 to 70°C ambient with derating, 590% relative humidity (non-condensing)
Over-temperature protection	Automatic & auto-resetting
Cooling requirement	Natural convection
Efficiency	80% minimum

Safety	Complies with AS/NZS 60950, class 1, NSW Office of Fair Trading Approval N20602
EMC	Emissions comply with AS/NZS CISPR11, Group 1, Class B. Complies with ACA EMC Scheme, Safety & EMC Regulatory Compliance Marked
Isolation i/p-o/p i/p-ground o/p-ground	4242VDC for 1 minute 2121VDC for 1 minute 707VDC for 1 minute
ALARMS & BATTERY F	UNCTIONS
Converter ON/OK alarm	Indicated by voltage-free changeover relay contacts &
green LED	ON=PSU OK
Battery low (& fuse) alarm	10.2 to 12.6V for 12V battery, adjustable 20.4 to 25.2V for 24V battery, adjustable Indicated by voltage-free changeover relay contacts & green LED: ON=BATT OK
Low voltage disconnect	9.6 to 12V for 12V battery, adjustable 19.2 to 24V2 for 4V battery, adjustable
Charger over-load protection	Auto-resetting electronic circuit breaker
Reverse polarity protection	Internal battery fuse
Battery to load voltage drop	0.2 to. 0.25V typical
MECHANICAL	
Case size	264 L x 172 W x 67 H mm
Case size with heatsink	264 L x 186 W x 67 H mm
Rack size	232 D x 19" W x 2RU H
Weight	1.9 kg
Weight with heatsink	2.1 kg
Weight (rack mounted version)	5.5 kg

Selection Table

MODEL		OUTPUT			
NUMBER	VDC	I _{LOAD}	IBATT	POWER	
PB251-12CM	13.8V	16A	2A	220W	
PB251-12CM-H	13.8V	20A	2A	275W	
PB251-24CM	27.6V	11A	2A	300W	
PB251-24CM-H	27.6V	12A	2A	330W	
PB251-12RML	13.8V	20A	4A	275W	
PB251-12B	13.8V	20A	4A	275W	
P8251-24RML	27.6V	12A	2A	330W	


Note: Non standard battery charging current available on request. ie PB251-12CM-H-10 for 10A.


powerbox.


PB251 Series

275-330 WATTS DC UPS


Technical Illustrations








FRONT VIEW



REAR VIEW (PB251-**RML)




PB251-**RML & -12B MECHANICAL OUTLINE

- 1. 2RU x 19° rack enclosure per IEC 297
- 2. Mounting slots are suitable for M6 hardware.
 3. Input connector is a 10A Class 1 IEC60320 inlet.

- 3. Input connector is a 10A Class Tiel Cod2/ inlet.
 4. 2 metre IEC mains cord with Australian plug is supplied with unit.
 5. PB251-12B alarm terminal is DB25 female.
 6. PB251-12B output and battery connector is Hirose pn. H528R-4A.
 Mating connector is Hirose pn. H528R-4A (not supplied).
 7. PB251-**RML alarm and output terminals are M3.5 screws suitable for ring or fork lugs up to 8 mm wide.

PB251-**RML ALARM AND OUTPUT TERMINALS



FB251-126 OUTPUT & BATTERY CONNECTOR



PINT: - OUTPUT PIN2: - OUTPUT PINS: + BATTERY PIN4: - BATTERY

P8251-128 ALARM CONNECTOR



PIN 1: COMMON PIN 6: DC OK (NC)


PIN 15: BATTERY OK (NO)

Your dependable power partner - www.powerbox.com.au



DC/DC SWITCHING POWER SUPPLY
DC INPUT 12,24,48, 110
SINGLE OUTPUT
25WATTS

VTA-SCx/VTA-SD SERIES



Dimension: 85W × 135L × 31H

Compact and High Efficiency

DC INPUT: 12V

Input Characteristics Unit	VTA05SC12	VTA12SC12	VTA15SC15	VTA24SC12	VTA48SC12
Input Voltage Vdc			DC 12V		
Input Voltage Range Vdc			DC 9.2V-16V		
Input Current(typ) . A	2.9	2.92	2.87	3.0	2.63
Inrush Current ,*1 A	*		Not Specified		
Efficiency (typical) *2	72	72	74	73	76
MTBF	9		880'000	•	
Switching Frequency	60 Fix.	60 Fix.	60 Fix.	60 Fix.	60 Fix.

DC INPUT: 24V

DO 111101. LIV						
Input Gharacteristics	Unit	VTA05SC24	VTA12SC24	VTA15SC24	VTA24SC24	VTA48SC24
Input Voltage	Vdc			DC 24V	_	
Input Voltage Range	∵Vdc.			DC 19-32V		
[Input Current(typ)	A	1.34	1.33	1.36	1.34	1.28
Inrush Current *1	A-			Not Specified		
Efficiency (typical). *2	. 8	75	78	79	78	82
MTBF	H			880'000		
Switching Frequency	kHz	60 Fix.	60 Fix.	60 Fix.	60 Fix.	60 Fix.

DC INPUT: 48V

Input Characteristics	Unit	VTA05SC48	VTA12SC48	VTA15SC48	- VTA24SC48	VTA48SC48
Input Voltage	Vdc		•	DC 48V		
Input Voltage Range	Vdc	·		DC 38-63V		
Input Current(typ)	. A.	0.68	0.66	0.65	0.67	0.6
Inrush Current *1	A			Not Specified		
Efficiency (typical) *2	· `\$	78	80	82	82	84
MTBF	Н			860'000		
Switching Frequency	kHz	60 Fix.	60 Fix.	60 Fix.	60 Fix.	60 Fix.

DC INPUT: 110V

Input Characteristics	Unit	VTA05SD	VTA12SD	VTA15SD	VTA24SD	VTA48SD
Input Voltage	Vdc .			DC 110V		- ·-
Input Voltage Range	Vdc			DC 85-140V		
Input Current(typ)	A	0.30	0.29	0.30	0.31	0.28
Inrush Current *1	A			Not Specified		
Efficiency (typical) *2	. 8	76	78	78	78	78
	Н		•	790'000	·	
Switching Frequency	kHz	80 Fix.	80 Fix.	80 Fix.	80 Fix.	80 Fix.



ETA USA 16170 Vineyard Blvd. Suite 180, Morgan Hill, CA 95037 Phone: 1-800-ETA-POWER, (408) 778-2793 Fax: (408) 779-2753

Visit us at: www.eta-usa.com email at: sales@eta-usa.com

Q-Pulse Id TMS942 Active 10/12/2014 Page 202 of 333



VTA-SC / VTA-SD

VII/ 307 VII/ 30								
Output				Models				
Characteristic	Unit	VTA05SCx/SD	VTA12SCx/SD	VTA15SCx/SD	VTA24SCx/SD	VTA48SCx / SD		
Output Voltage	V. V.	5	12	15	24	48		
Output Current	A.	5.0	2.1	1.7	1.1	0.5		
Voltage Adjust Range	V	+/-10% o	f Rated Output	Voltage(at no l	oad within inpu	it range)		
Ripple Noise(max) *3	mVpp	100	170	200	290	530		
Rise up time	mS		100mS(maximum) at 25°C and rated input/output					
Hold up time	> mS⊹i			10mS				
Regulation								
a. Line Regulation (max)	mV	40	96	120	192	384		
b. Load Regulation (max)	Viπ	45	108	135	216	432		
c. Temperature Coefficient *4	°C.		0.03%/°C					
d. Drift(maximum) *5	mV .	40	75	90	135	255		
e Dynamic Load Regulation (typ.) *6	mV	150	360	450	720	1440		
f. Recovery Time **6				0.5mS				

Conditions:

- *1 at cold start
- *2 at rated input/output
- ${}^{\star}3$ measured by a bayonet probe at the output connector at a 0 to 100MHz bandwidth
- *4 at 0 to +50℃
- *5 for 7hour period after 1hour warm-up at 25° C and rated input/output *6 when output current changed between 25% and 75% of rated output current rapidly at rated input

Environmental Specification	The state of the s
Operating Temperature	0 to +50°C
Operating Humidity	85%RH(non-condensing)
Storage Temperature	-20 to +85°C
Storage Humidity	-
Withstanding Voltage	Primary-Secondary AC1,500Vfor 1minute (Vin=110 2000) Primary-Frame Ground AC1,500V for 1minute (Vin=110 2000) Secondary-Frame Ground AC500V for 1minute
Isolation Resistance	Primary-Secondary-Frame Ground $50M\Omega$ (minimum) by DC500V insulation tester
Vibration	5-10Hz:10mm double amplitude, 10-55Hz:19.6m/s2, 20minutes' period for 60minutes each along X,Y,Z axes (non-operating)
Shock	294m/s2
Cooling	Convection
Functions	
Over current Protection	Current Limiting with automatic recovery
Over voltage Protection	Output shutdown
Remote Sense	not available
Remote On/Off	not available
Reverse Voltage Protection	by internal fuse
Line Conductión Noise	Not specified
Weight [g](typical)	380 G
Dimension [mm]	85W×135L×31H




16170 Vineyard Blvd. Suite 180, Morgan Hill, CA 95037 Phone: 1-800-ETA-POWER, (408) 778-2793 Fax: (408) 779-2753


Visit us at: www.eta-usa.com email at: sales@eta-usa.com




BLOCK DIAGRAM




DIMENSION DIAGRAM (mm)



EFFICIENCY CURVE




OCP CURVE







ETA USA 16170 Vincyard Blvd. Suite 180, Morgan Hill, CA 95037 Phone: 1-800-ETA-POWER, (408) 778-2793 Fax: (408) 779-2753

Visit us at: www.eta-usa.com email at: sales@eta-usa.com



Operating Instructions VEGABAR 74 4 ... 20 mA/HART







Contents

1	Abo	ut this document							
	1.1 1.2 1.3	Function	5 5 5						
2	For your safety								
	2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 2.9	Authorised personnel. Appropriate use. Warning about misuse. General safety instructions. Safety approval markings and safety tips. CE conformity. Fulfilling NAMUR recommendations. Safety instructions for Ex areas. Environmental instructions.	6 6 6 7 7 8 8						
3	Proc	duct description							
	3.1 3.2 3.3 3.4	Operation	9 10 10 11						
4	Mounting								
	4.1 4.2	General instructions	12 13						
5	Con	necting to power supply							
	5.1 5.2 5.3	Connection procedure	14 16 17						
6	Set	up							
	6.1 6.2	Setup steps without VEGADIS 12 Setup steps with VEGADIS 12	19 19						
7	Setu	ıp with PACTware™							
	7.1 7.2 7.3 7.4 7.5		23 24 24						

N-070718

8	Main	Maintenance and fault rectification												
	8.1	Maintenance	25											
	8.2	Fault clearance	25											
	8.3	Instrument repair	26											
9	Dism	nounting												
	9.1	Dismounting steps	27											
	9.2	Disposal												
10	Supp	olement												
	10.1	Technical data	28											
		Dimensions												
	10.3	Industrial property rights	41											
	10 4	Trademark	41											

Supplementary documentation

Information:

Depending on the ordered version, supplementary documentation belongs to the scope of delivery. You find this documentation in chapter "*Product description*".

Instructions manuals for accessories and replacement parts

Tip:

To ensure reliable setup and operation of your VEGABAR 74, we offer accessories and replacement parts. The associated documents are:

- Supplementary instructions manual 32036 "Welded socket and seals"
- Operating instructions manual 32798 "Breather housing VEGABOX 02"
- Operating instructions manual 20591 "External indicating and adjustment unit VEGADIS 12"



1 About this document

1.1 Function

This operating instructions manual provides all the information you need for mounting, connection and setup as well as important instructions for maintenance and fault rectification. Please read this information before putting the instrument into operation and keep this manual accessible in the immediate vicinity of the device.

1.2 Target group

This operating instructions manual is directed to trained personnel. The contents of this manual should be made available to these personnel and put into practice by them.

1.3 Symbolism used



Information, tip, note

This symbol indicates helpful additional information.



Caution: If this warning is ignored, faults or malfunctions can result.

Warning: If this warning is ignored, injury to persons and/or serious damage to the instrument can result.

Danger: If this warning is ignored, serious injury to persons and/or destruction of the instrument can result.



Ex applications

This symbol indicates special instructions for Ex applications.

List

The dot set in front indicates a list with no implied sequence.

→ Action

This arrow indicates a single action.

1 Sequence

Numbers set in front indicate successive steps in a procedure.

01 /0 / 0-N1

Page 208 of 333

2 For your safety

2.1 Authorised personnel

All operations described in this operating instructions manual must be carried out only by trained specialist personnel authorised by the operator.

During work on and with the device the required personal protection equipment must always be worn.

2.2 Appropriate use

VEGABAR 74 is a pressure transmitter for measurement of gauge pressure, absolute pressure and vacuum.

You can find detailed information on the application range in chapter "Product description".

Operational reliability is ensured only if the instrument is properly used according to the specifications in the operating instructions manual as well as possible supplementary instructions.

Due to safety and warranty reasons, any invasive work on the device beyond that described in the operating instructions manual may be carried out only by personnel authorised by the manufacturer. Arbitrary conversions or modifications are explicitly forbidden.

2.3 Warning about misuse

Inappropriate or incorrect use of the instrument can give rise to application-specific hazards, e.g. vessel overfill or damage to system components through incorrect mounting or adjustment.

2.4 General safety instructions

This is a high-tech instrument requiring the strict observance of standard regulations and guidelines. The user must take note of the safety instructions in this operating instructions manual, the country-specific installation standards as well as all prevailing safety regulations and accident prevention rules.

The instrument must only be operated in a technically flawless and reliable condition. The operator is responsible for troublefree operation of the instrument.

Page 209 of 333



During the entire duration of use, the user is obliged to determine the compliance of the required occupational safety measures with the current valid rules and regulations and also take note of new regulations.

2.5 Safety approval markings and safety tips

The safety approval markings and safety tips on the device must be observed.

2.6 CE conformity

VEGABAR 74 is in CE conformity with EMC (89/336/EWG), fulfils NAMUR recommendation NE 21 and is in CE conformity with LVD (73/23/EWG).

Conformity has been judged according to the following standards:

- EMC:
 - Emission EN 61326: 2004 (class B)
 - Susceptibility EN 61326: 2004 including supplement A
- LVD: EN 61010-1: 2001

VEGABAR 74 is not subject to the pressure device guideline.¹⁾

2.7 Fulfilling NAMUR recommendations

VEGABAR 74 fulfills the following NAMUR recommendations:

- NE 21 (interference resistane and emitted interference)
- NE 43 (signal level for failure information)
- NE 53 (compatibility sensor and indicating/adjustment components)

VEGA instruments are generally upward and downward compatible:

- Sensor software to DTM VEGABAR 74 HART
- DTM VEGABAR 74 for adjustment software PACTware™

The parameter adjustment of the basic sensor functions is independent of the software version. The range of available functions depends on the respective software version of the individual components.

The software version of VEGABAR 74 HART can be read out % via PACTware™.

Due to the flush diaphragm, no own pressure compartment is formed.

:N-070718

You can view all software histories on our website www.vega.com. Make use of this advantage and get registered for update information via e-mail.

2.8 Safety instructions for Ex areas

Please note the Ex-specific safety information for installation and operation in Ex areas. These safety instructions are part of the operating instructions manual and come with the Exapproved instruments.

2.9 Environmental instructions

Protection of the environment is one of our most important duties. That is why we have introduced an environment management system with the goal of continuously improving company environmental protection. The environment management system is certified according to DIN EN ISO 14001.

Please help us fulfil this obligation by observing the environmental instructions in this manual:

- Chapter "Packaging, transport and storage"
- Chapter "Disposal"

Page 211 of 333



3 Product description

3.1 Configuration

Scope of delivery

The scope of delivery encompasses:

- VEGABAR 74 pressure transmitter
- Documentation
 - this operating instructions manual
 - Test certificate for pressure transmitters
 - Ex-specific "Safety instructions" (with Ex-versions)
 - if necessary, further certificates

Components

VEGABAR 74 consists of the following components:

- Process fitting with measuring cell
- Housing with electronics
- Connection cable (direct cable outlet)

The components are available in different versions.




Fig. 1: Example of a VEGABAR 74 with process fitting G11/2 A

- 1 Connection cable
- 2 Housing with electronics
- 3 Process fitting with measuring cell

:N-0/0/18

3.2 Principle of operation

Area of application

VEGABAR 74 is a pressure transmitter for use in the paper, food processing and pharmaceutical industry. Thanks to the high protection class IP 68/IP 69K it is particularly suitable for use in humid environment. Depending on the version, it is used for level, gauge pressure, absolute pressure or vacuum measurements. Measured products are gases, vapours and liquids, also with abrasive contents.

Functional principle

The sensor element is the CERTEC® measuring cell with flush, abrasion resistant ceramic diaphragm. The hydrostatic pressure of the medium or the process pressure causes a capacitance change in the measuring cell via the diaphragm. This change is converted into an appropriate output signal and outputted as measured value.

The CERTEC® measuring cell is also equipped with a temperature sensor. The temperature value can be processed via the signal output.

Supply

Two-wire electronics 4 ... 20 mA/HART for power supply and measured value transmission over the same cable.

The supply voltage range can differ depending on the instrument version.

The data for power supply are stated in chapter "Technical data" in the "Supplement".

3.3 Operation

VEGABAR 74 4 ... 20 mA/HART can be adjusted with different adjustment media:

- with external adjustment/indication VEGADIS 12
- an adjustment software according to FDT/DTM standard,
 e.g. PACTware[™] and PC
- with a HART handheld

The kind of adjustment and the adjustment options depend on the selected adjustment component. The entered parameters are generally saved in the respecitive sensor, when adjusting with PACTware™ and PC optionally also in the PC.

Page 213 of 333

Product description



3.4 Packaging, transport and storage

Packaging

Your instrument was protected by packaging during transport. Its capacity to handle normal loads during transport is assured by a test according to DIN EN 24180.

The packaging of standard instruments consists of environment-friendly, recyclable cardboard. For special versions, PE foam or PE foil is also used. Dispose of the packaging material via specialised recycling companies.

Transport

Transport must be carried out under consideration of the notes on the transport packaging. Nonobservance of these instructions can cause damage to the device.

Transport inspection

The delivery must be checked for completeness and possible transit damage immediately at receipt. Ascertained transit damage or concealed defects must be appropriately dealt with.

Storage

Up to the time of installation, the packages must be left closed and stored according to the orientation and storage markings on the outside.

Unless otherwise indicated, the packages must be stored only under the following conditions:

- Not in the open
- Dry and dust free
- Not exposed to corrosive media
- Protected against solar radiation
- Avoiding mechanical shock and vibration

Storage and transport temperature

- Storage and transport temperature see "Supplement -Technical data - Ambient conditions"
- Relative humidity 20 ... 85 %

Page 214 of 333

4 Mounting

4.1 General instructions

Materials, wetted parts

Make sure that the wetted parts of VEGABAR 74, especially the seal and process fitting, are suitable for the existing process conditions such as pressure, temperature etc. as well as the chemical properties of the medium.

You can find the specifications in chapter "Technical data" in the "Supplement".

Temperature limits

Higher process temperatures often mean also higher ambient temperatures. Make sure that the upper temperature limits stated in chapter "*Technical data*" for the environment of the electronics housing and connection cable are not exceeded.




Fig. 2: Temperature ranges

- 1 Process temperature
- 2 Ambient temperature

Connection

- The connection cable has a capillary for atmospheric pressure compensation
- → Lead the cable end into a dry space or into a suitable terminal housing.

ĭ

Information:

VEGA recommends the breather housing VEGABOX 02 or the indication/adjustment VEGADIS 12. Both contain terminals and a ventilation filter for pressure compensation. For mounting outdoors, a suitable protective cover is available.

Page 215 of 333



4.2 Mounting steps

Sealing/Screwing in threaded versions

Seal the thread with teflon, hemp or a similar resistant seal material on the process fitting thread 1½ NPT.

→ Screw VEGABAR 74 into the welded socket. Tighten the hexagon on the process fitting with a suitable wrench. Wrench size, see chapter "Dimensions".

Sealing/Screwing in flange versions

Seal the flange connections according to DIN/ANSI with a suitable, resistant seal and mount VEGABAR 74 with suitable screws.

Sealing/Screwing in hygienic fittings

Use the seal suitable for the respective process fitting. You can find the components in the line of VEGA accessories in the supplementary instructions manual "Welded socket and seals".



Connecting to power supply

Preparing the connection

Note safety instructions

Always keep in mind the following safety instructions:

- Connect only in the complete absence of line voltage
- If overvoltage surges are expected, versions with integrated overvoltage arresters should be used or external overvoltage arresters should be installed



Tip:

We recommend the version of VEGABAR 74 with integrated overvoltage arrester or VEGA type ÜSB62-36G.X as external overvoltage arreaster.

Take note of safety instructions for Ex applications



In hazardous areas you should take note of the appropriate regulations, conformity and type approval certificates of the sensors and power supply units.

Select power supply

Power supply and current signal are carried on the same twowire cable. The voltage supply range can differ depending on the instrument version.

The data for power supply are stated in chapter "Technical data" in the "Supplement".

Provide a reliable separation of the supply circuit from the mains circuits according to DIN VDE 0106 part 101.

VEGA power supply units VEGATRENN 149AEx, VEGASTAB 690, VEGADIS 371 as well as all VEGAMETs meet this requirement. When using one of these instruments, protection class III is ensured for VEGABAR 74.

Bear in mind the following factors regarding supply voltage:

- Output voltage of the power supply unit can be lower under nominal load (with a sensor current of 20.5 mA or 22 mA in case of fault message)
- Influence of additional instruments in the circuit (see load values in chapter "Technical data")

Selecting connection cable

VEGABAR 74 is connected with standard two-wire cable without screen. An outer cable diameter of 5 ... 9 mm ensures the seal effect of the cable gland when connecting via VEGABOX 02 or VEGADIS 12. If electromagnetic interference is expected which is above the test values of EN 61326 for

28432-EN

Page 217 of 333



industrial areas, screened cable should be used. For HART multidrop operation we recommend as standard practice the use of screened cable.




Fig. 3: Connection of VEGABAR 74

- 1 Direct connection
- 2 Connection via VEGABOX 02 or VEGADIS 12

Cable screening and grounding

If screened cable is necessary, connect the cable screen on both ends to ground potential. In the VEGABOX 02 or VEGADIS 12, the screen must be connected directly to the internal ground terminal. The ground terminal on the outside of the housing must be connected to the potential equalisation (low impedance).

If potential equalisation currents are expected, the connection on the processing side must be made via a ceramic capacitor (e.g. 1 nF, 1500 V). The low frequency potential equalisation currents are thus suppressed, but the protective effect against high frequency interference signals remains.

Select connection cable for Ex applications



Take note of the corresponding installation regulations for Ex applications. In particular, make sure that no potential equalisation currents flow over the cable screen. In case of grounding on both sides this can be achieved by the use of a capacitor or a separate potential equalisation.

:N-0/0/

5.2 Connection procedure

Direct connection

Proceed as follows:

- 1 Wire the connection cable up to the connection compartment. The bending radius must be at least 25 mm.²⁾
- 2 Connect the wire ends to the screw terminals according to the wiring plan

Via VEGABOX 01 or VEGADIS 12

Proceed as follows:

- 1 Snap connection housing onto the carrier rail or screw it to the mounting plate
- 2 Loosen the cover screws and remove the cover
- 3 Insert the cable through the cable entry into the connection housing housing
- 4 Loosen the screws with a screwdriver
- 5 Insert the wire ends into the open terminals according to the wiring plan
- 6 Tighten the screws with a screwdriver
- 7 Check the hold of the wires in the terminals by lightly pulling on them
- 8 Tighten the compression nut of the cable entry. The seal ring must completely encircle the cable
- 9 Connect the supply cable according to steps 3 to 8
- 10 Screw the housing cover back on

The electrical connection is finished.

Page 219 of 333

The connection cable is already preconfectioned. After shortening the cable, fasten the type plate with support again to the cable.



5.3 Wiring plan

Direct connection




Fig. 4: Wire assignment, connection cable

- 1 brown (+): to power supply or to the processing system
- 2 blue (-): to power supply or to the processing system
- 3 yellow: is only required with VEGADIS 12, otherwise connect to minus or with VEGABOX 01 to terminal 3³⁾
- 4 Screen
- 5 Breather capillaries with filter element

Connection via VEGABOX 02




Fig. 5: Terminal assignment VEGABAR 74

- To power supply or the processing system
- 2 Screen⁴⁾

Wire number	Wire colour/Polarity	VEGABAR 74 terminal
1	brown (+)	1
2	blue (-)	2
3	Yellow	2
	Screen	Ground

- For customer-specific versions already connected with blue (-) when being shipped.
- 4) Connect screen to ground terminal. Connect ground terminal on the outside of the housing as prescribed. The two terminals are galvanically connected.

284

N-070718

Connection via VEGADIS 12




Fig. 6: Terminal assignment, VEGADIS 12

- 1 To power supply or the processing system
- 2 Control instrument (4 ... 20 mA measurement)
- 3 Screen⁵⁾

)

- 4 Breather capillaries
- 5 Suspension cable

Wire number	Wire colour/Polarity	Terminal VEGADIS 12
1	brown (+)	1
2	blue (-)	2
3	Yellow	3

7

8432-EN

5) Connect screen to ground terminal. Connect ground terminal on the outside of the housing as prescribed. The two terminals are galvanically connected.



6 Set up

6.1 Setup steps without VEGADIS 12

After mounting and electrical connection, VEGABAR 74 is ready for operation.

→ Switch on voltage

The electronics now carries out a self-check for approx. 2 seconds. Then VEGABAR 74 delivers a current of 4 ... 20 mA according to the actual level.

6.2 Setup steps with VEGADIS 12

Adjustment volume

- zero measuring range begin
- span measuring range end
- ti Integration time

Adjustment system




Fig. 7: Adjustment elements of VEGADIS 12

- 1 Rotary switch: choose the requested function
- 2 [+] key, change value (rising)
- 3 [-] key, change value (falling)
- With the rotary switch the requested function is selected
- With the [+] and [-] keys, the signal current or the integration time are adjusted
- Finally the rotary switch is set to position "OPERATE"

The set values are transmitted to the EEPROM memory and remain there even in case of voltage loss.

Adjustment steps, adjustment

Proceed as follows for adjustment with VEGADIS 12:

- 1 Open housing cover
- 2 Connect hand multimeter to terminals 10 and 12
- 3 Meas. range begin: Set rotary switch to "zero"

N-0707

- 4 Empty the vessel or reduce process pressure
- 5 Set a current of 4 mA with the [+] and [-] keys
- 6 Meas. range end: Set rotary switch to "span"
- 7 Fill the vessel or increase process pressure
- 8 Set a current of 20 mA with the [+] and [-] keys
- 9 Operation: Set rotary switch to "OPERATE"
- 10 Close housing cover

The adjustment data are effective, the output current 4 ... 20 mA corresponds to the actual level.

Adjustment steps, integration time

Proceed as follows for the adjustment of the integration time with VEGADIS 12:

- 1 Open housing cover
- 2 Set rotary switch to "ti"
- 3 By pushing the [-] key 10-times, make sure that the integration time is set to 0 sec.
- 4 For every 1 sec. requested integration time, push the [+] key once.
- 5 The integration time is the time required by the output current signal to reach 90 % of the actual height after a sudden level change.
- 6 Set rotary switch to "OPERATE"
- 7 Close housing cover

Adjustment steps, scaling

The display outputs the current 4 ... 20 mA as bar graph and digital value.

With 4 mA no segment of the bar graph appears, with 20 mA all segments appear. This assignment is fix.

You can scale the digital value to any value between -9999 ... +9999 via the adjustment module.

Proceed as follows for scaling the indication of VEGADIS 12:

- 1 Open housing cover
- 2 Initial value: Set rotary switch to "zero"
- 3 Set the requested value, e.g. 0 with the [+] and [-] keys
- 4 Final value: Set the rotary switch to "span"
- 5 Set the requested value, e.g. 1000 with the [+] and [-] keys
- 6 Decimal point: Set the rotary switch to "point"
- 7 With the [+] and [-] keys you can adjust the requested value, e.g. 8888 (no decimal point)

Page 223 of 333



- 8 Set rotary switch to "OPERATE"
- 9 Close housing cover

The adjustment data are effective, the output current 4 ... 20 mA corresponds to the actual level.

4 :N-070



7 Setup with PACTware™

7.1 Connect the PC with VEGACONNECT 3

Connecting the PC to the signal cable




Fig. 8: Connecting the PC to the signal cable

- 1 RS232 connection (with VEGACONNECT 3) or USB connection (with VEGACONNECT 4)
- 2 VEGABAR 74
- 3 HART adapter cable
- 4 HART resistance 250 Ohm (optional depending on the processing)

Necessary components:

- VEGABAR 74
- PC with PACTware™ and suitable VEGA DTM
- VEGACONNECT 3 or 4 with HART adapter cable (art. no. 2.25397)
- HART resistance approx. 250 Ohm
- Power supply unit

Note:

With power supply units with integrated HART resistance (internal resistance approx. 250 Ohm), an additional external resistance is not necessary (e.g. VEGATRENN 149A, VEGADIS 371, VEGAMET 381/624/625, VEGASCAN 693). In such cases, VEGACONNECT 3 can be connected parallel to the 4 ... 20 mA cable.

Page 225 of 333



7.2 Connect the PC with VEGACONNECT 4

Connection via HART




Fig. 9: Connecting the PC via HART to the signal cable

- VEGABAR 74
- HART resistance 250 Ohm (optional depending on the processing)
- Connection cable with 2 mm pins and terminals
- Processing system/PLC/Voltage supply

Necessary components:

- **VEGABAR 74**
- PC with PACTware™ and suitable VEGA DTM
- **VEGACONNECT 4**
- HART resistance 250 Ohm (optional depending on the processing)
- Power supply unit or processing system

Note:

With power supply units with integrated HART resistance (internal resistance approx. 250 Ohm), an additional external resistance is not necessary. This applies, e.g. to the VEGA instruments VEGATRENN 149A, VEGADIS 371, VEGAMET 381). Also usual Ex separators are most of the time equipped with a sufficient current limitation resistor. In such cases, VEGACONNECT 4 can be connected parallel to the 4 ... 20 mA cable.



7.3 Parameter adjustment with PACTware™

Further setup steps are described in the operating instructions manual "DTM Collection/PACTwareTM" attached to each CD and which can also be downloaded from our homepage. A detailed description is available in the online help of PACTwareTM and the VEGA DTMs.

i

Note:

Keep in mind that for setup of VEGABAR 74, DTM-Collection in the actual version must be used.

All currently available VEGA DTMs are provided in the DTM Collection on CD and can be obtained from the responsible VEGA agency for a token fee. This CD includes also the up-to-date PACTwareTM version. The basic version of this DTM Collection incl. PACTwareTM is also available as a free-of-charge download from the Internet.

Go via www.vega.com and "Downloads" to the item "Software".

7.4 Parameter adjustment with AMS™ and PDM

For VEGA sensors, instrument descriptions for the adjustment programs AMS[™] and PDM are available as DD or EDD. The instrument descriptions are already implemented in the current versions of AMS[™] and PDM. For older versions of AMS[™] and PDM, a free-of-charge download is available via Internet.

Go via www.vega.com and "Downloads" to the item "Software".

7.5 Saving the parameter adjustment data

It is recommended to document or save the parameter adjustment data. They are hence available for multiple use or service purposes.

The VEGA DTM Collection and PACTware™ in the licensed, professional version provide suitable tools for systematic project documentation and storage.



8 Maintenance and fault rectification

8.1 Maintenance

When used as directed in normal operation, VEGABAR 74 is completely maintenance free.

8.2 Fault clearance

Reaction in case of failures

The operator of the system is responsible for taken suitable measures to remove interferences.

Causes of malfunction

VEGABAR 74 offers maximum reliability. Nevertheless faults can occur during operation. These may be caused by the following, e.g.:

- Sensor
- Process
- Supply
- Signal processing

Fault rectification

The first measures to be taken are to check the output signals as well as to evaluate the error messages via the indicating and adjustment module. The procedure is described below. Further comprehensive diagnostics can be carried out on a PC with the software PACTware™ and the suitable DTM. In many cases, the causes can be determined in this way and faults can be rectified.

24 hour service hotline

However, if these measures are not successful, call the VEGA service hotline in urgent cases under the phone no. +49 1805 858550.

The hotline is available to you 7 days a week round-the-clock. Since we offer this service world-wide, the support is only available in the English language. The service is free of charge, only the standard telephone costs will be charged.

Checking the 4 ... 20 mA signal

Connect a handheld multimeter in the suitable measuring range according to the wiring plan.

- ? 4 ... 20 mA signal not stable
 - Level fluctuations
 - → Adjust integration time via PACTware™
 - no atmospheric pressure compensation
 - → Check the capillaries and cut them clean

4 :N-07

- → Check the pressure compensation in the housing and clean the filter element, if necessary
- ? 4 ... 20 mA signal missing
 - Wrong connection to power supply
 - → Check connection according to chapter "Connection steps" and if necessary, correct according to chapter "Wiring plan"
 - No voltage supply
 - → Check cables for breaks; repair if necessary
 - supply voltage too low or load resistance too high
 - → Check, adapt if necessary
- ? Current signal 3.6 mA; 22 mA
 - electronics module or measuring cell defective
 - → Exchange instrument or return instrument for repair



In Ex applications, the regulations for the wiring of intrinsically safe circuits must be observed.

Reaction after fault rectification

Depending on the failure reason and measures taken, the steps described in chapter "Set up" must be carried out again, if necessary.

8.3 Instrument repair

If a repair is necessary, please proceed as follows:

You can download a return form (23 KB) from the Internet on our homepage www.vega.com under: "Downloads - Forms and certificates - Repair form".

By doing this you help us carry out the repair quickly and without having to call back for needed information.

- Print and fill out one form per instrument
- Clean the instrument and pack it damage-proof
- Attach the completed form and, if need be, also a safety data sheet outside on the packaging
- Please ask the agency serving you for the address of your return shipment. You can find the respective agency on our website www.vega.com under: "Company - VEGA worldwide"

Page 229 of 333



9 Dismounting

9.1 Dismounting steps



Warning:

Before dismounting, be aware of dangerous process conditions such as e.g. pressure in the vessel, high temperatures, corrosive or toxic products etc.

Take note of chapters "Mounting" and "Connecting to power supply" and carry out the listed steps in reverse order.

9.2 Disposal

The instrument consists of materials which can be recycled by specialised recycling companies. We use recyclable materials and have designed the electronics to be easily separable.

WEEE directive 2002/96/EG

This instrument is not subject to the WEEE directive 2002/96/ EG and the respective national laws (in Germany, e.g. ElektroG). Pass the instrument directly on to a specialised recycling company and do not use the municipal collecting points. These may be used only for privately used products according to the WEEE directive.

Correct disposal avoids negative effects to persons and environment and ensures recycling of useful raw materials.

Materials: see chapter "Technical data"

If you cannot dispose of the instrument properly, please contact us about disposal methods or return.

Page 230 of 333



10 Supplement

10.1 Technical data

General data

Manufacturer VEGA Grieshaber KG, D-77761 Schiltach

Type name VEGABAR 74

Parameter, pressure Gauge pressure, absolute pressure, vacuum

Measuring principle Ceramic-capacitive, dry measuring cell

Communication interface None

Materials and weights

Material 316L corresponds to 1.4404 or 1.4435

Materials, wetted parts

Process fitting316L

Diaphragm
 sapphire ceramic[®] (99.9 % oxide ceramic)

Seal
 FKM (e.g. Viton), Kalrez 6375, EPDM, Chem-

raz 535

Seal process fitting thread G½ A,

G11/2 A

Klingersil C-4400

Materials, non-wetted parts

Housing316L

Ground terminalConnection cablePUR, FEP, PE

type label support on cable
 PE-HART

Weight 0.8 ... 8 kg (1.8 ... 17.6 lbs), depending on

process fitting

Output variable

Output signal 4 ... 20 mA/HART

Failure signal 22 mA (3.6 mA), adjustable

Max. output current 22.5 mA

Damping (63 % of the input variable) 0 ... 10 s, adjustable

Step response or adjustment time 70 ms (ti: 0 s, 0 ... 63 %)

Fulfilled NAMUR recommendations NE 43

Additional output parameter - temperature

Processing is made via HART-Multidrop

VEGABAR 74 - 4 ... 20 mA/HART

27

28432-EN

Range

-50 ... +150 °C (-58 ... +302 °F)

Resolution

1 °C (1.8 °F)

Accuracy

in the range of 0 ... +100°C (+32 ... +212 °F)

±3 K

in the range of -50 ... 0 °C (-58 ... +32 °F) and +100 ... +150 °C

(+212 ... +302 °F)

typ. ±4 K

Input variable

Adjustment

Zero adjustable

-20 ... +95 % of the nominal measuring range

Span adjustable

3.3 ... +120 % of the nominal measuring range

Recommended max. turn down

Nominal measuring ranges and overload resistance

Nominal range	Overload, max. pressure6)	Overload, min. pressure
Gauge pressure		
0 0.1 bar/0 10 kPa	15 bar/1500 kPa	-0.2 bar/-20 kPa
0 0.2 bar/0 20 kPa	20 bar/2000 kPa	-0.4 bar/-40 kPa
0 0.4 bar/0 40 kPa	30 bar/3000 kPa	-0.8 bar/-80 kPa
0 1 bar/0 100 kPa	35 bar/3500 kPa	-1 bar/-100 kPa
0 2.5 bar/0 250 kPa	50 bar/5000 kPa	-1 bar/-100 kPa
0 5 bar/0 500 kPa	65 bar/6500 kPa	-1 bar/-100 kPa
0 10 bar/0 1000 kPa	90 bar/9000 kPa	-1 bar/-100 kPa
0 25 bar/0 2500 kPa	130 bar/13000 kPa	-1 bar/-100 kPa
0 60 bar/0 6000 kPa	200 bar/20000 kPa	-1 bar/-100 kPa
-1 0 bar/-100 0 kPa	35 bar/3500 kPa	-1 bar/-100 kPa
-1 1.5 bar/-100 150 kPa	50 bar/5000 kPa	-1 bar/-100 kPa
-1 5 bar/-100 500 kPa	65 bar/6500 kPa	-1 bar/-100 kPa
-1 10 bar/-100 1000 kPa	90 bar/9000 kPa	-1 bar/-100 kPa
-1 25 bar/-100 2500 kPa	130 bar/13000 kPa	-1 bar/-100 kPa
-1 60 bar/-100 6000 kPa	300 bar/30000 kPa	-1 bar/-100 kPa
-0.05 0.05 bar/-5 5 kPa	15 bar/1500 kPa	-0.2 bar/-20 kPa
-0.1 0.1 bar/-10 10 kPa	20 bar/2000 kPa	-0.4 bar/-40 kPa

Limited to 200 bar according to the pressure device directive.

28



Nominal range	Overload, max. pressure6)	Overload, min. pressure
-0.2 0.2 bar/-20 20 kPa	30 bar/3000 kPa	-0.8 bar/-80 kPa
-0.5 0.5 bar/-50 50 kPa	35 bar/3500 kPa	-1 bar/-100 kPa
Absolute pressure		
0 0.1 bar/0 10 kPa	15 bar/1500 kPa	
0 1 bar/0 100 kPa	35 bar/3500 kPa	
0 2.5 bar/0 250 kPa	50 bar/5000 kPa	
0 5 bar/0 500 kPa	65 bar/6500 kPa	
0 10 bar/0 1000 kPa	90 bar/9000 kPa	
0 25 bar/0 2500 kPa	130 bar/13000 kPa	
0 60 bar/0 6000 kPa	200 bar/20000 kPa	

Reference conditions and influencing variables (similar to DIN EN 60770-1)

Reference conditions according to DIN EN 61298-1

- Temperature +15 ... +25 °C (+59 ... +77 °F)

Relative humidity45 ... 75 %

Air pressure
 860 ... 1060 mbar/86 ... 106 kPa

(12.5 ... 15.4 psi)

Determination of characteristics Limit point adjustment according to

IEC 61298-2

Characteristics linear

Reference installation position upright, diaphragm points downward

Influence of the installation position <0.2 mbar/20 Pa (0.003 psi)

Deviation determined according to the limit point method according to IEC 607707)

Applies to **digital** HART interface as well as to **analogue** current output 4 ... 20 mA. Specifications refer to the set span. Turn down (TD) = nominal measuring range/set span.

Deviation

Turn down 1:1 up to 5:1
 <0.075 %

Turn down up to 10:1
 <0.015 % x TD

Deviation with absolutely flush process fittings EV, FT

- Turn down 1:1 up to 5:1
<0.05 %</p>

_ Turn down up to 10:1 <0.01 % x TD

⁷⁾ Incl. non-linearity, hysteresis and non-repeatability.



Deviation with absolute pressure measuring range 0.1 bar

Turn down 1:1 up to 5:1

<0.25 % x TD

- Turn down up to 10:1

<0.05 % x TD

Influence of the product or ambient temperature

Applies to **digital** HART interface as well as to **analogue** current output 4 ... 20 mA. Specifications refer to the set span. Turn down (TD) = nominal measuring range/set span.

Average temperature coefficient of the zero signal

In the compensated temperature range of 0 ... +100 °C (+212 °F), reference temperature 20 °C (68 °F):

Average temperature coefficient of the zero signal

Turn down 1:1

<0.05 %/10 K

Turn down 1:1 up to 5:1

<0.1 %/10 K

- Turn down up to 10:1

<0.15 %/10 K

Outside the compensated temperature range:

Average temperature coefficient of the zero signal

Turn down 1:1

typ. <0.05 %/10 K

Thermal change of the current output

Applies also to the analogue 4 ... 20 mA current output and refers to the set span.

- Thermal change, current output
- <0.15 % at -40 ... +80 °C (-40 ... +176 °F)

Long-term stability (similar to DIN 16086, DINV 19259-1 and IEC 60770-1)

Applies to **digital** HART interface as well as to **analogue** current output 4 ... 20 mA. Specifications refer to the set span. Turn down (TD) = nominal measuring range/set span.

- Long-term drift of the zero signal
- <(0.1 % x TD)/1 year

Total deviation (similar to DIN 16086)

The total deviation (max. practical deviation) is the sum of basic accuracy and long-term stability:

$$F_{perf} = \sqrt{((F_T)^2 + (F_{KI})^2)}$$

With

- F_{total}: Total deviation
- Fperf: Basic accuracy
- F_{stab}: Long-term drift

- F_T: Temperature coefficient (influence of medium or ambient temperature)
- F_{KI}: Deviation

Ambient conditions

Ambient, storage and transport temperature

- Connection cable PE
- Connection cable PUR, FEP
- -40 ... +60 °C (-40 ... +140 °F)
- -40 ... +85 °C (-40 ... +185 °F)

Process conditions

The specifications of the pressure stage are used as an overview. The specifications on the type plate are applicable.

Pressure stage, process fitting

Thread 316L

PN 60

- Thread Alu

PN 25

Hygienic fittings 316L

- PN 10, PN 16, PN 25, PN 40
- Flange 316L, flange with extension
- PN 40 or 150 lbs, 300 lbs

316L

Product temperature depending on the measuring cell seal

FKM (e.g. Viton)

-20 ... +100 °C (-4 ... +212 °F)

EPDM

- -40 ... +100 °C (-40 ... +212 °F), 1 h: 140 °C/
- 284 °F cleaning temperature

Kalrez 6375 (FFKM)

-10 ... +100 °C (+14 ... +212 °F)

Chemraz 535

-30 ... +100 °C (-22 ... +212 °F)

Vibration resistance

mechanical vibrations with 4 g and 5 ... 100 Hz⁸

Shock resistance

Acceleration 100 g/6 ms⁹⁾

Electromechanical data

Connection cable

Configuration

- four wires, one suspension cable, one breather
 - capillary, screen braiding, metal foil, mantle

Wire cross-section

0.5 mm² (AWG no. 20)

wire resistance

<0.036 Ohm/m (0.011 Ohm/ft)

Standard length

- 6 m (19.685 ft)
- max. length with VEGADIS 12
- 200 m (656.168 ft)

- 8) Tested according to the regulations of German Lloyd, GL directive 2.
- 9) Tested according to EN 60068-2-27.

Page 235 of 333



Min. bending radius at 25 °C/77 °F

- Diameter

- Colour - standard PE

- Colour - standard PUR

- Colour - Ex-version

25 mm (0.985 in)

approx. 8 mm (0.315 in)

Black

Blue

Blue

Voltage supply

Supply voltage

Non-Ex instrument

12 ... 36 V DC

EEx ia instrument

12 ... 29 V DC

Permissible residual ripple

- <100 Hz

U_{ss} <1 V

- 100 Hz ... 10 kHz

 U_{ss} <10 mV

Load

see diagram




Fig. 10: Voltage diagram VEGABAR 74

- 1 HART load
- 2 Voltage limit Ex instrument
- 3 Voltage limit non-Ex instrument
- 4 Voltage supply

Load in conjunction with VEGADIS 12

see diagram

4 :N-070718




Fig. 11: Voltage diagram VEGABAR 74 with VEGADIS 12

- 1 HART load
- 2 Voltage limit Ex instrument
- 3 Voltage limit non-Ex instrument
- 4 Voltage supply

Integrated overvoltage protection	
Nominal leakage current (8/20 μs)	10 kA
Min. response time	<25 ns
Electrical protective measures	
Protection	IP 68 (25 bar)/IP 69K
Overvoltage category	III
Protection class	III
Approvals ¹⁰⁾	
ATEX ia	ATEX II 1G EEx ia IIC T6; ATEX II 2G EEx ia IIC T6
Ship approvals	GL, LRS, ABS, CCS, RINA, DNV
Others	WHG

Deviating data in Ex applications: see separate safety instructions.



10.2 Dimensions

VEGABAR 74 - threaded fitting




Fig. 12: VEGABAR 74 threaded fitting: GV = G% A manometer connection EN 837, GI = G% A inner G% A, GG = G1% A, GN = 1% NPT, GM = G1% A 70 mm, GR = % NPT inner % NPT

:N-070718

284

VEGABAR 74 - hygienic fitting 1




Fig. 13: VEGABAR 74 hygienic fitting: $CC = Tri-Clamp \ 1\frac{1}{2}$ ", $CA = Tri-Clamp \ 2$ ", $LA = hygienic fitting with compression nut F40, <math>TA = Tuchenhagen \ Varivent \ DN \ 25$, $RA/RB = bolting \ DN \ 40/DN \ 50$ according to DIN \ 11851



VEGABAR 74 - hygienic fitting 2




Fig. 14: VEGABAR 74 KA/KH = cone DN 40, AA = DRD, SD/SE = Anderson 3" long/short fitting

VEGABAR 74 - flange connection




Fig. 15: VEGABAR 74 - flange connection

- 1 Flange connection according to DIN 2501
- 2 Flange fitting according to ANSI B16.5
- 3 Flange with extension
- 4 Order-specific

Page 241 of 333



VEGABAR 74 - threaded fitting for paper industry




Fig. 16: VEGABAR 74 - connection for paper industry: BA/BB = M44x1.25

Page 242 of 333

VEGABAR 74 - extension fitting for paper industry




Fig. 17: VEGABAR 74 - extension fitting for paper industry: EV/FT = absolutely flush for pulper (EV 2-times flattened), EG = extension for ball valve fitting (L = order-specific)



10.3 Industrial property rights

VEGA product lines are global protected by industrial property rights. Further information see http://www.vega.com.

Only in U.S.A.: Further information see patent label at the sensor housing.

VEGA Produktfamilien sind weltweit geschützt durch gewerbliche Schutzrechte. Nähere Informationen unter http://www.vega.com

Les lignes de produits VEGA sont globalement protégées par des droits de propriété intellectuelle.

Pour plus d'informations, on pourra se référer au site http://www.vega.com

VEGA lineas de productos están protegidas por los derechos en el campo de la propiedad industrial.

Para mayor información revise la pagina web http://www.vega.com.

Линии продукции фирмы ВЕГА защищаются по всему миру правами на интеллектуальную собственность.

Дальнейшую информацию смотрите на сайте http://www.vega.com

VEGA系列产品在全球享有知识产权保护。 进一步信息请参见网站<http://www.vega.com>。

10.4 Trademark

All brands used as well as trade and company names are property of their lawful proprietor/originator.



28432-EN 718

VEGABAR 74 - 4 ... 20 mA/HART

41

N-0/0

28432-EN 718

VEGABAR 74 - 4 ... 20 mA/HART

43



VEGA Grieshaber KG Am Hohenstein 113 77761 Schiltach Germany Phone +49 7836 50-0 Fax +49 7836 50-201 E-mail: info@de.vega.com www.vega.com








All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.


© VEGA Grieshaber KG, Schiltach/Germany 2007

Subject to change without prior notice

28432-EN-070718



Operating Instructions VEGADIS 12







Safety information, Note Ex area

Safety information

Please read this manual carefully, and also take note of country-specific installation standards (e.g. the VDE regulations in Germany) as well as all prevailing safety regulations and accident prevention rules.

For safety and warranty reasons, any internal work on the instruments, apart from that involved in normal installation and electrical connection, must be carried out by qualified VEGA personnel.

Note Ex area

Please note the approval documents (yellow binder), and especially the included safety data sheet.

20 591-EN-030728

Page 250 of 333

Contents



Contents

	Safe	ety information	. 2
	Note	Ex area	. 2
1	Pro	duct description	
	1.1	Function and configuration	. 4
	1.2	Types and versions	. 4
	1.3	Technical data	. 5
	1.4	Approvals	. 7
	1.5	Dimensions	. 8
2	Моц	unting	. 8
3 Electrical connection		ctrical connection	
	3.1	Connection instructions	9
	3.2	Wiring plan	10
4	Set	up	
	4.1	Adjustment elements	12
	4.2	Adjustment and indicating elements (version with display)	12
	4.3	Adjustment of the transmitter	13
	4.4	Scaling of the indication	13
5	Dia	gnostics	
	5.1	Maintenance	14
	5.2	Failure rectification	14



Product description

1 Product description

1.1 Function and configuration

VEGADIS 12 is an external connection housing with integrated adjustment elements. It is connected via the VEGA special cable with breather capillaries or a three-wire standard cable to the hydrostatic pressure transmitter VEGAWELL 72 - 4 ... 20 mA/HART®, VEGABAR 74 or VEGABAR 75. VEGADIS 12 is connected to the supply and signal circuit of the pressure transmitter and does not require a separate external energy source.


VEGADIS 12 has the following functions:

- adjustment of zero, span and ti
- atmospheric pressure compensation for the pressure transmitter
- measured value display (optional).

As a standard feature, VEGADIS 12 is equipped with an adjustment module for the pressure transmitter. The optional display is located in the housing cover and is equipped with a bar graph and a digital display indication. In this version, additional adjustment elements for indication scaling are integrated.


1.2 Types and versions

VEGADIS 12 without display





VEGADIS 12 with display





20 591-EN-030728

Q-Pulse Id TMS942

Product description



1.3 Technical data

Standard data

Materials	and	weig	ıht
------------------	-----	------	-----

Housing high-resistance plastic PBT (Polyester)

Ground terminal stainless steel 1.4305

Display window Lexan

Breather facility PTFE filter element ¹⁾
Weight approx. 0.5 kg

Adjustment and indicating elements

Adjustment elements 2 keys, 1 rotary switch

Adjustment elements with display 2 x 2 keys, 2 x 1 rotary switch Display (option) LC multifunctional display with

bar graph (20 segments)digital value (4 digits)

- tendency indicator for rising or falling values

Connection

Cable entry M20 x 1.5 (for cable Ø 5 ... 9 mm)
Screw terminals for wire cross-section up to 2.5 mm²

Adjustment circuit

Connection to VEGAWELL 72 - 4 ... 20 mA/HART®,

VEGABAR 74 or VEGABAR 75

connection cable VEGA special cable with breather capillaries

or 3-wire standard cable

Cable length max. 200 m

1) air permeable and humidity blocking

Q-Pulse Id TMS942

5



Product description

Supply and signal circuit (analogue transmission, 4 ... 20 mA)

Supply voltage via pressure transmitter in conjunction with VEGADIS 12

- without display

- with display

Max. input current

Range of the current signal

Max. permissible load

12 ... 36 V DC 17 ... 36 V DC


150 mA

3.5 ... 22 mA

depending on the supply voltage


(see load diagrams)

Load diagram without display



Voltage of the external energy U_H in Volt

Load diagram with display



Voltage of the external energy U_u in Volt

Protective measures

Housing	IP 65 ¹⁾
Protection class	111
Overvoltage category	111

Ambient conditions

Ambient temperature

- VEGADIS 12 -40°C ... +85°C - VEGADIS 12 with display -20°C ... +70°C -40°C ... +85°C Storage and transport temperature

¹⁾ Maintaining the housing protection IP 65 requires the use of a seal in the cable entry fitting to the cable. If the supplied seal does not fit, the customer has to provide a suitable one.

VEGADIS 12

6

Product description



1.4 Approvals

If a pressure transmitter or the external housing is used in hazardous areas, approved versions should be used.

The respective official documents (test reports, test certificates and conformity certificates) must be noted for these applications. These are supplied with the respective instrument.

General approvals

VEGADIS 12

CENELEC EEx ia IIC

CE conformity (€

The external housings VEGADIS 12 or VEGADIS 12 Ex meet the protective regulations of EMC (89/336/EWG) and NSR (73/23/EWG). The conformity has been judged acc. to the following standards:

EMC

Emission

EN 50 081

Susceptibility

EN 50 082

NSR

EN 61 010

NAMUR regulations


Full compliance with NAMUR regulations NE21, May 1993.

20 591-EN-030728


Page 255 of 333

1.5 Dimensions

without display



with display



2 Mounting

VEGADIS 12 can be mounted in the following ways:

- on carrier rail 35 x 7.5 acc. to EN 50 022
- on mounting sheet or to the wall.

In case of vertical wall mounting, the cable entry must point downwards to avoid moisture ingress.

If VEGADIS 12 is additionally used for atmospheric pressure compensation for the pressure transmitter, the following must be noted:

- there must be the same atmospheric pressure on the breather facility as on the vessel
- the breather facility must not be clogged or dirty.

20 591-EN-030728




3 Electrical connection

3.1 Connection instructions

VEGADIS 12 is connected to the supply and signal circuit of the pressure transmitter and does not require a separate external energy source.

Block diagram



The electronics in the pressure transmitter is designed in two-wire technology and requires a supply voltage of 12 ... 36 V DC, with display 17 ... 36 V DC. Supply voltage and current signal are led via the same two-wire connection cable to the connection terminals. The third cable between pressure transmitter and VEGADIS 12 is used for transmission of the adjustment data.

The external energy is provided via a separate power supply unit:

- power supply unit, e.g. VEGASTAB 690
- processing unit with integrated DC current source (e.g. active DCS input)

Make sure that the external energy source is reliably separated from the mains circuits acc. to DIN VDE 0106, part 101. The above mentioned VEGA instruments meet this requirement and protection class III is therefore ensured.

The external energy source must deliver a terminal voltage of at least 12 V or 17 V to the transmitter. The actual terminal voltage on the transmitter depends on the following factors:

- output voltage U_H of the external energy source under nominal load.
- load resistances of the instruments in the current circuit.

For electrical connection in general, the following points should be given attention:

- The connection must be made according to the national installation standards (e.g. in Germany acc. to the VDE regulations).
- To avoid damage of the electronics, the terminal voltage must not exceed 36 V.
- The connection elements have built-in protection against polarity reversal.
- The wiring between pressure transmitter and VEGADIS 12 or between VEGADIS 12 and the power supply can be made with standard three or two-wire cable.
- If strong electromagnetic interferences are expected, screened cable is recommended. The screening must be made on both ends. For use in Ex areas, the installation regulations must be noted.
- If overvoltages are expected, we recommend the installation of VEGA overvoltage arresters.
- A seal fitting the cable must be used in the cable entry.




Electrical connection

3.2 Wiring plan

VEGADIS 12 without display


VEGADIS 12



Page 258 of 333



VEGADIS 12 with display



20 591-EN-030728


VEGADIS 12

11



4 Setup


4.1 Adjustment elements



Adjustment system (transmitter)

- Choose the requested function with the rotary switch.
- With the "+" and "-" keys you modify the signal current to the requested values or set the suitable integration time.
- Set the rotary switch to position "OPERATE". The set values are transferred to the EEPROM memory and remain there even in case of voltage loss.

4.2 Adjustment and indicating elements (version with display)




Adjustment system (transmitter)

(see section 4.1)

Adjustment system (display)

- With the rotary switch you choose the requested function
- With the "+" and "-" keys you change the display indication to the requested values or set the suitable decimal point.
- Then set the rotary switch to position "OPERATE". The set values are transferred to the EEPROM memory and remain there even in case of voltage loss.



VEGADIS 12



4.3 Adjustment of the transmitter

Adjustment

To adjust the beginning of the measuring range and end value of the measuring range, connect an ammeter to terminals 10 and 12. The measured value is identical to the output current.

1 Adjust zero

(vessel empty)

- Set the rotary switch to zero.
- Set a current of 4 mA by pushing the "+" and "-" key.

2 Adjust span

(max. vessel level)

- Set the rotary switch to span.
- Set a current of 20 mA by pushing the "+" and "-" key.

Adjustment range of the measuring range final value:

3.3 % ... 120 % of nominal range

Adjustment instructions:

- A modification of the beginning of the measuring range does not influence the adjusted span.
- It is also possible to adjust currents for partial fillings, e.g. 8 mA for 25 % and 16 mA for 75 %. The electronics then calculates automatically the current values for 0 % and 100 % (only possible with a delta ≥ 3 %).
- The current value first changes in steps of 6 μA steps, then after approx. 10 sec. of pressing, in steps of about 300 μA.
- If the current values react to the key pressing with a time delay, this can have two reasons:
 - the last adjustment was carried out with a level considerably deviating from the actual level.

Integration time

An integration time t_i of 0 ... 10 sec can be set for damping level fluctuations.

Procedure:

- Set rotary switch to t...
- By pushing the "-" key 10 times, make sure that the integration time is set to 0 sec.
- For every 1 sec requested integration time, push the "+" key once.

The integration time is the time required by the current output signal to reach 90 % of the actual level after a sudden level change.

4.4 Scaling of the indication

The display provides the current values 4 ... 20 mA as bar graph and as digital value.

Bar graph

At 4 mA no segment of the bar graph appears, at 20 mA all segments appear. This assignment is fixed.

Digital value

The digital value can be scaled individually between -9999 ... +9999 via the adjustment module.

1 Adjust zero

- Set the rotary switch to zero.
- Set the requested value, e.g. 0 by pushing the "+" and "-" key.

2 Adjust end

- · Set the rotary switch to end.
- Set the requested value, e.g. 1000 by pushing the "+" and "-" key.

3 Adjust the decimal point (point)

- Set the rotary switch to point.
- Set the requested values, e.g. 8888 (no decimal point) by pushing the "+" and "-" key.

Page 261 of 333

5 Diagnostics

5.1 Maintenance

VEGADIS 12 is maintenance-free.

5.2 Failure rectification

In case of an instrument failure, please check the following:

- the atmospheric pressure compensation
- the electrical connections and components.

Check atmospheric pressure compensation


First of all open the housing cover. The indicated measured value must not change. However, if the indicated value changes nevertheless, the compensation of the atmospheric pressure is not ensured. Please therefore check:

- the breather facility on the housing
- the capillaries in the special cable.

Note:

There must be always the same atmospheric pressure on the breather facility as on the open vessel.

Check electrical components



Instruction for Ex applications

Deviating from the previous assignment, the terminals 10 and 12 are here used for brief connection to a certified, active, floating (max. value: 470 mW) or to an individual passive, floating measuring instrument. For connection, the regulations for wiring of intrinsically safe circuits (measuring instrument, supply and signal circuit) must be noted.

Voltage

 Check the terminal voltage on VEGADIS 12 (must be at least 12 V DC or 17 V DC with display).

Current

Current value	Condition
3.8 20.5 mA	standard range for output current
0 mA	signal cable interrupted
< 3.6 mA	electronics or pressure sensor element defective
22 mA	electronics or pressure sensor element defective

20 591-EN-030728

20 591-EN-030728

VEGADIS 12

15

Q-Pulse Id TMS942



VEGA Grieshaber KG Am Hohenstein 113 77761 Schiltach Germany Phone (0 78 36) 50 - 0 Fax (0 78 36) 50 - 201 E-mail info@de.vega.com www.vega.com







All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the latest information at the time of printing.

Technical data subject to alterations

20 591-EN-030728

SP126 Road Hemmant SPS Electrical Switchboard OM

2. Test Results

J & P Richardson Industries Pty Ltd

2.0 TEST RESULTS

File: //Jpr_Server/docs/!sched/Masters.doc Revision 0 Date: 25 May 2001



SSM089

FIXED SPEED SEWAGE PUMP STATION

SWITCHBOARD CHANGEOVER **COMMISSIONING PLAN**

Site ID and Name	Younks Ro. SP126	. ,
Commissioning Date	6-9-08	

In Attendance

Name	Role During Commissioning	Company	
MARK DE NOUTER	ELECT SUPERVISE	71	TPR
GLEN LERUETTO	ELECTION		4
CADE MOWAND	ETECTAICAL	_	4
PALL FRAMPON	MEH / TRUCK IN	1462	4
	•		

Doc Id: 006142

Active Date: 2 November 2007

Brisbane Water Confidential

Printed:

12/08/2008

Owner: Alex Witthoft

Version 1.00

Printed copies of this document should be verified for currency against the published electronic copy.

1 INTRODUCTION

This document is the standard testing procedure for a switchboard change over at a sewage pumping station. The procedure ensures that for a two pump sewage pump station, at least one pump will be operational at all times. The basic cut-over procedure is as follows:

- 1. Install temporary pumping system (pump controller and generator).
- 2. Disconnect sewage Pump #2 from existing switchboard and connect to temporary pumping system.

PUMP #1 IS NOW RUNNING THE STATION FROM EXISTING SWITCHBOARD

3. Fully commission Pump #2 on the temporary pumping system.

PUMP #2 IS NOW RUNNING THE STATION FROM TEMPORARY PUMPING SYSTEM

- 4. Disconnect Pump #1, consumer mains, on site generator and all field instrumentation from the existing switchboard.
- 5. Install new switchboard and connect to consumer mains.
- 6. Connect Pump #1 to the new switchboard and test in "emergency pumping" mode (via the "Emergency Start" switch).

PUMP #2 IS STILL RUNNING THE STATION FROM THE TEMPORARY PUMPING SYSTEM AND PUMP #1 CAN BE RUN UNDER "EMERGENCY PUMPING" MODE FROM NEW SWITCHBOARD.

- 7. Connect all field instrumentation.
- 8. Fully commission Pump #1 on the new switchboard to operate in "Local" and "Remote" modes.

PUMP #1 IS NOW RUNNING THE STATION FROM NEW SWITCHBOARD

- 9. Connect Pump #2 to the new switchboard and fully commission on the new switchboard to operate in all modes.
- 10. Complete the Site Acceptance Test (SAT) including all pump, RTU and SCADA testing.

NOTE: This testing procedure will only be acceptable on sites that do NOT need two pumps to run during the cut over procedure.

(Confirm the current running conditions of the existing switchboard before commencing).

For sites that require two pumps to run simultaneously under dry weather conditions during the proposed cut over period, a site-specific cut over procedure must be developed to incorporate adequate flow control measures (ie tankers or temporary pumps).

Doc Id:

006142

Active Date: 2 November 2007

Brisbane Water Confidential

Printed:

12/08/2008

Owner: Alex Witthoft

Note: Printed copies of this document should be verified for currency against the published electronic copy.

2 PRE - CHANGE OVER WORKS CHECKLIST

The following checklist is to be completed and signed by the electrical contractor.

2.1 SWITCHBOARD FACTORY ACCEPTANCE TEST

Contractor Task	Completed
FAT has been completed as per BW FAT Document and all defects that were identified have been rectified.	11/

2.2 CONCRETE SLAB EXTENSION

Contractor Task	Result
Confirm the concrete slab extension is complete including all necessary conduits.	OK □

2.3 SUPPLY AUTHORITY

Contractor Task	Outcome
The relevant supply authority has been organised to install the metering into the New Switchboard.	Company Booked for / / @(rime) Ref #

2.4 NEW RADIO ANTENNA MAST LOCATION

Contractor Task	Result
Check the location of the antenna mast and ensure that the new position will not	Location OK
be directly below electrical transmission lines.	Antenna dir.

2.5 DISCHARGE MAINS PRESSURE TRANSDUCER

Contractor Task	Completed
Install delivery pressure transducer on the discharge rising main.	Installed OK
Transducer is calibrated to the specified range (as per spec). Calibration sheet to be supplied with AS BUILT drawings. 0kPA tokPA	Range(m) to(m)

2.6 TEMPORARY GENERATOR SIZE

Contractor Task	Completed
Note the kW of each pump.	Pump #1kW
	Pump #2 kW
Determine the type of generator and size of pump starter required	Genset Size kVA
	Date Booked / /
	Delivery Date / /
	Delivery Time

Brisbane Water Confidential

Electrical Contactor's Supervisor

Name: Date: Signature:

Doe Id: 006142 Active Date: 2 November 2007

Printed: 12/08/2008 Owner: Alex Witthoft

Note: Printed copies of this document should be verified for currency against the published electronic copy.

Q-Pulse Id TMS942 Active 10/12/2014 Page 270 of 333

3 CHANGE OVER WORKS

The following sequence of works that must be carried out in order. One pump must be operational at all times. After each phase has been completed, the commissioning manager will record the results and instruct the commissioning team to commence work on the next phase.

3.1 STEP 1 - INSTALL TEMPORARY PUMPING SYSTEM

3.1.1 Register with Control Room

Contractor Task	Outcome
Call the Brisbane Water Control Room Operator (CRO) and inform him that you are on site. Record the CRO's Name and Officer Code and record the time of the call.	Name: M. PERUZ
Advise CRO that you are performing a switchboard changeover and that you will initially be taking one pump off line. Give the operator a contact name and number and ask that he contact you if any level alarm is activated on site.	CRO:

3.1.2 Existing Switchboard Parameters

Contractor Task		Outcome
Ensure that the station is fully functional (pump can run)		OK 🗹
Record the direction of the installed antenna for later reference.	Poron Ton	AAAtenha dir. von Lor Poo
Record the kWhr meter serial numbers.		#
Record 3 phase motor currents	Pump #1	80.8 v. 16 W. 16.8
	Pump #2	V6 8V. 16 8V. 16 8
Record pump rotation Mains Supply		C'wise (RWB) Anti C'wise
	Pump #1	
	Pump #2	

3.1.3 Prepare and Install Temporary Pump Controller and Generator

Contractor Task	Outcome
Position generator in an appropriate location. Locate away from the work site to reduce noise.	OK 🗹
Position fire extinguisher and oil spill bund as per risk analysis.	OK D
Connect the temporary pump controller to the generator and test connection (ie point to point to confirm correct connection)	ок 🗔
Install Multitrode level sensors and set the Start and Stop levels to be equivalent to the current Start and Stop levels of the existing switchboard parameters.	ОК 🖫
Install the backup audible and visual alarm system (powered by separate battery). Test electrodes back to temporary pump controller to confirm operation.	OK 🗖
Ensure that the generator fuel will be sufficient to enable the generator to run loaded for 12 hours. (This may require extra fuel – arrange if required).	OK 🗔
Start the generator and measure the 3 phase volts and record the phase	C'wise (RWB) Anti C'wise
rotation.	

	al Contactor's Su	•	BW Commi	ssioning Manager
Name:.	M. RE My	Date: 6-908	Name:	Date:
Signatu	ıre:		Signature:	· · · · · · · · · · · · · · · · · · ·
Doc Id:	006142//	Active Date: 2 Novem	ber 2007	Brisbane Water Confidential
Printed:	12/08/2008	Owner: Alex Wit	thoft	
Note:	Printed copies of th	is document should be verified for currency	against the publish	ed electronic copy.

3.2 STEP 2 - CONNECT PUMP #2 TO TEMPORARY PUMPING SYSTEM

Contractor Task	Outcome
On the existing switchboard, Isolate sewage pump (Pump #2) as per BW Isolation Tag and Lock Out procedure. (Unplug from Decontactor).	ок Б
Disconnect Pump #2 from the existing switchboard and remove the power and control cables from the switchboard.	OK 🗹
Connect Pump #2 power and control cables to the temporary pump controller.	OKE
Electrically test Pump #2 to temporary pump controller connections.	OK.Z
Switch the existing switchboard to "Local" and stop Pump #1.	OK 🗷
Manual Test of Temporary Pumping System: (Confirm Pump Direction) Manually start the submersible pump and closely monitor wet well level to confirm that the level is dropping. When confirmed, stop pump.	OK 🗷
Auto Test of Temporary Pumping System: (Confirm Pump Cycle) Allow the temporary pumping system to complete one full start and stop cycle automatically to confirm complete system is functioning correctly.	OK Ø
This is a HOLD point. Do not proceed until the temporary pump is confirmed to be controlling the wet well level.	TIME:

3.3 STEP 3 - DISCONNECT EXISTING SWITCHBOARD AND REMOVE

3.3.1 Contact Control Room

Contractor Task	Outcome
Call the Control Room Operator (CRO) and advise that you are going to remove power to the switchboard and that he will lose communication with the site.	Name:
Record the CRO's office code and the time of the call.	CRO:
	Time:

3.3.2 Disconnect Pump #1 and Remove Existing Switchboard

Contractor Task	Outcome
On the existing switchboard, Isolate sewage pump (Pump #1) as per BW Isolation Tag and Lock Out procedure. (Unplug from Decontactor).	OK 🗹
Disconnect Pump #1 from the existing switchboard and remove the power and control cables from the switchboard and place near the temporary system so as to enable a quick changeover for Pump #2 if required.	OK E
Isolate main incomer at the switchboard. Ensure all secondary sources of power (ie on site Generator) are also isolated. Confirm there is no load.	OK 🗹
Remove primary 3-phase fuses from power pole. Lock fuses in lockout box as per BW Isolation and Lock Out procedure.	OK 🗷
Disconnect mains cable from the switchboard.	OK 🗷
Disconnect all other control and communication cables and remove	OK D
Remove the existing switchboard away from job site.	OK 🗗

Electrical Contactor's Supervisor		BW Commissioning Manager		
Name:.	Date:	6-9-8	Name:	Date:
	ire:		Signature:	
Doc Id:	006142	Active Date: 2 Novem	ber 2007	Brisbane Water Confidential
Printed:	12/08/2008	Owner: Alex Wit	thoft	
Note:	Printed copies of this document shou	ld be verified for currency	against the published electron	ic conv.

Q-Pulse Id TMS942 Active 10/12/2014 Page 272 of 333

3.4 STEP 4 - INSTALL NEW SWITCHBOARD

3.4.1 Install new switchboard (For Sites with Option F Only)

Contractor Task	Outcome
Install and connect the required (new or existing) mains and earth as per the contract.	New 🖳
Contract.	Existing
Record the cable insulation resistance of the 3 phases	A 200 + Megohm
	B <u>200 r</u> Megohm.
	C 700 1 Megohm
Record earth resistance	0.02 ohms
Point to point phase continuity	R to L1 OKD
	W to L2 OK₽
	B to L3 OK⊠

3.4.2 Install Supply Authority Metering

Task		Outcome
Install the direct connected kWhr	Meter METERING.	ОК 🖸

3.4.3 Energise New Switchboard

Contractor Task	Outcome
Retrieve mains 3-phase pole fuses from lock out box as per BW Isolation and Lock Out procedure.	OK 🗗
Ensure new switchboard main incomer is turned "Off".	OK 🗗
Install the 3-phase pole Tuses.	OK 🖫
Turn on mains switch	ok □
Check 3 phase voltages	ABV
	BCV
	CAV
Check phase rotation and ensure it is the same as determined earlier.	ок□
Check MEN connection.	ok □

Electrical Contactor's Supervisor	BW Commissioning N	Manager
Name: Date:	-9-03 Name:	Date:
Signature:	Signature:	
Doc Id: 006142// Acti	ive Date: 2 November 2007	Brisbane Water Confidential
Printed: 12/08/2008	Owner: Alex Witthoft	

Note: Printed copies of this document should be verified for currency against the published electronic copy.

3.5 STEP 5 - CONNECT PUMP #1 TO NEW SWITCHBOARD

Contractor Task	Outcome
At the beginning of this procedure, Pump #2 is operating under the control of the temporary switchboard running from the Generator.	OK D
Isolate submersible Pump #1 and Pump #2 at the new switchboard , as per BW Isolation and Lock Out procedure.	OKE
Via the MERACHAL plug in sockets provided on the switchboard reconnect the power and control cables for Pump #1 (the pump that is not connected to the generator set) If VFD connection is direct connect.	ок б
Before beginning the next step ensure that the well level is between 'Start' and 'Stop' level and Pump #2 is not running.	ок 🗹
Isolate Pump #2 to prevent it from running during the next test	
De-isolate this now connected Pump #1. Check the rotation by bumping the pump On / Off via the local "Emergency Start" switch.	ок 🗇
Check the 3 phase motor current and compare with original readings.	A /6 8 Amps
PUMP #1 Can now be run in an emergency under the control of the new switchboard.	B 16.8 Amps
When checking is complete - Isolate Pump #1	C <u>/6 .</u> Amps
De-isolate Pump #2 so that the station is again under the control of the temporary switchboard.	ок 🗓

3.6 STEP 6 - CONNECT FIELD INSTRUMENTATION TO NEW SWITCHBOARD

3.6.1 Field Devices

Contractor Task	Outcome
Install and connect the hydrostatic level probe to the transmitter	OK 🗹 👂 toMtrs
Connect the delivery pressure probe to the transmitter	OK 🗹 /0 toMtrs
Install and connect the Multitrode LR3 wet well high level relay Probe	OK 1 At 4.4 Mtrs
Install and connect the Multitrode SIR surcharge imminent level relay Probe	OK at 2.55 Mtrs
Connect the moisture in oil sensor for each pump (sites with option A only)	OK□ N/A □
Connect the moisture in stator for each pump (sites with option B1 only) ムス	OK□ N/A □
Connect the motor bearing temperature for each pump (sites with option B2 only) PA	OK N/A
Connect the reflux valve micro switch for each pump (sites with option C only)	OK 🗆 N/A 🗹
Connect the upstream manhole surcharge imminent probe (sites with option D only) /	100K □ N/A □
Connect the Multitrode LR2 sump pump start/ stop probes (sites with option E only)	OK 🗆 / N/A 🗅
Connect the Multitrode LR4 sump pump high/trip probes (sites with option E only)	OK 🛭 N/A 🗆
Connect the sump pump (sites with option E only)	OK 🗆 N/A 🖼
Connect the generator IO cables (sites with option F only)	OK 🗆 N/A 🗹
Connect the thermistors for each pump (sites with option I only)	OK □ N/A 🗷

Electrical Contactor's Supervisor BW Commissioning Manager		anager		
Name:.			Name:	Date:
Signati	are: M.J		Signature:	
Doc Id:	006142	Active Date: 2 Novemb	рет 2007	Brisbane Water Confidential
Printed:	12/08/2008	Owner: Alex Witt	hoft	
Note:	Printed copies of this	document should be verified for currency a	gainst the published electronic c	opy.

3.6.2 Install Generator Mains (For Sites with Permanent Generators)

Contractor Task	Outcome
Record insulation resistance of the 3-phases	AMegohm B Megohm. C Megohm
Record earth resistance	ohms
Point to point phase continuity	R to L1 OK□ W to L2 OK□ B to L3 OK□

3.6.3 Radio Antenna Installation

BW Programmer Task	Outcome
Install new mast with Antenna, orientate antenna to the position determined in section 3.1.2 connect coaxial cable plugs.	OK D
O.C.A. Televestore and O.C.A.D.A. Or constructions Observe	BRIS WATE

3.6.4 Telemetry and SCADA Communications Checks

BW Programmer Task	Outcome
Brisbane Water programmer must complete the following procedures	
From the SSM086 Standard Fixed Speed Sewage Pumping Station (S.A.T.)	ок□
Section 1: Setup and Pre-Commissioning Checks	

3.7 STEP 7 - COMMISSIONING PUMP #1

BW Programmer & Contractor Task	Outcome
Before doing the next step ensure that the well level is between 'Start' and 'Stop' level and Pump #2 is not running.	OK 🗗
Isolate Pump #2 to prevent it from running during the next test.	
At this stage the Brisbane Water Programmer must complete the following procedures	01/2
From the SSM086 Standard Fixed Speed Sewage Pumping Station (S.A.T.)	UK-2
Section2: On Site Commissioning Procedure (Pump #1 Only)	
Once Pump #1 has been commissioned, leave the new switchboard in control of the site operating under "Remote" control.	OK ₽

Electric	al Contactor's Supervisor		BW Commi	ssioning Manager
Name:.	D	ate: 6 - 7 - 8	Name:	Date:
Signati	ure: //		Signature:	
Doc Id:	006142	Active Date: 2 Nove	mber 2007	Brisbane Water Confidential
Printed:	12/08/2008	Owner: Alex W	/itthoft	

Note: Printed copies of this document should be verified for currency against the published electronic copy.

3.8 STEP 8 - CONNECT PUMP #2 AND COMMISSION

3.8.1 Connect Pump #2 to New Switchboard

Contractor Task	Outcome
At the beginning of this procedure, Pump #1 is operating under the control of the new switchboard running from the supply authority.	ОК 🗗
Shut down the generator and disconnect Pump #2 from the temporary switchboard	OK 🗹
Ensure Pump #2 circuit breaker at the new switchboard is still isolated and locked out as per BW Isolation and Lock Out procedure.	ок 🗹
Via the MERACHAL plug in sockets provided on the switchboard, connect the power and control cables for Pump #2.	OK 🗹
De-isolate this now connected submersible pump. Check the rotation of this submersible pump by bumping the pump On / Off via the local "Emergency Start" switch.	ок 🗹
Check the 3-phase motor current and compare with original results.	A /6 % Amps B/6 % Amps
PUMP #2 Can now be run in an emergency under the control of the new switchboard.	B/6.8 Amps
	C/6.8 Amps

3.8.2 Commissioning of Pump #2

BW Programmer & Contractor Task	Outcome
Before beginning the next step ensure that the well level is between "Start and Stop" level and Pump #1 is not running. (Station under the control of the new board)	ок 🗹
Isolate Pump #1 to prevent it from running during the next test.	
Brisbane Water Programmer must complete the following procedures	
From the SSM086 Standard Fixed Speed Sewage Pumping Station (S.A.T.)	OK EV
Section2: On Site Commissioning Procedure – (Pump #2 Only)	
Once Pump #2 has been commissioned, de-isolate Pump #1 and leave that	
new switchboard in control of the site operating under remote control with both pumps able to run	OK 🗹

3.9 SUGGESTIONS FOR IMPROVEMENT

Suggestion	Recommended By

Electrical Contactor's Supervisor		BW Commissioning Manager		
Name:.	Lo 1	Date:	Name:	Date:
Signati			Signature:	
Doc Id:	006142	Active Date: 2 Novem	nber 2007	Brisbane Water Confidential
Printed:	12/08/2008	Owner: Alex Wi	itthoft	
Note:	Printed copies of this do	cument should be verified for currency	against the nublishe	d electronic conv

3.10 STEP 9 - COMPLETE TESTING

3.10.1 Site Acceptance Testing (S.A.T) – Remaining Tests

BW Programmer & Contractor Task	Outcome
Once pump 2 has been commissioned Complete any remaining procedures in Section 2 from the SSM086 Standard Fixed Speed Sewage Pumping Station (S.A.T.)	ок 🗆
Check operation of SIR for 20 sec. with probe to prove probe operation and operation of 2 pumps	ок 🗆
Check operation LR3 with probe to prove RTU and probe	OK 🗆
Seal conduits with denso and grout under switchboard.	OK 🗗
Check Energex Phase Fail Input.	OK ₽
Confirm automatic control of pumps.	OK 🗆
Check Parameter 203 of Soft Starter is a positive value	OK 🗆 🗸
Confirm correct operation of all door locks	OK 🖾
Confirm Operation & Maintenance Manual left on site.	ОК □

3.10.2 SCADA Testing

BW Programmer & Contractor Task	Outcome
The Brisbane Water Programmer must complete the following procedures with the assistance from the Commissioning Engineer and SCADA Commissioning Engineer in the Control Room.	ок 🗆
From the SSM086 Standard Fixed Speed Sewage Pumping Station (S.A.T.) Section3: SCADA Commissioning Procedure	

3.10.3 Preliminary Work Completion by Electrical Contractors

Contractor Task	Outcome
Leave the site clean and tidy and hazard free.	OK D
Confirm with BW that the job is complete and their staff can leave.	OK D
Confirm with BW that BW staff will lock up the site on completion of the switchboard change over work.	ок 🖬
Note: If there is a problem with finishing the work due to unforeseen circumstance refer to the Risk Analysis attached.	ок 🗆

3.10.4 Register Control Room

BW Programmer & Contractor Task	Outcome
Commissioning Engineer to call the Control Room Operator (CRO) and inform him that the site works is complete and that the site is now fully in "Remote" control and	Name
that all alarms are to be acted on as per the alarm instructions. C.R.O. to confirm that the site is healthy and that there are no alarms active.	CRO
Record the C.R.O.'s name and Officer Code and record the time of the call.	TIME:
Sund (o A Learn BW Commissioning Manager	

			ł ·
Jana	10	CALLOOM	BW Commissioning Manager
	اكبه	not "	Name: Date:
	C.		Signature:

Doc Id: 006142 Active Date: 09/Aug/2007 Brisbane Water Confidential

Printed: 12/08/2008 Owner: Alex Witthoft

Note: Printed copies of this document should be verified for currency against the published electronic copy.

4 Post Change Over Checklist

4.1 DELIVERABLES FROM RTU PROGRAMMER

BW Programmer	Date Completed
Within 7 days of the change over the following must be completed and signed off by the BW Programmer0	, ,
Complete Section 4: Post Commissioning	' '
from the SSM086 Standard Fixed Speed Sewage Pumping Station (S.A.T.)	
The BW Programmer will ensure that the Control Room Acceptance (CRA) form is signed by the Manager of the Control Room Officers. The form is to be handed to the Contracts Manager (CM).	1 1

4.2 DELIVERABLES FROM ELECTRICAL CONTRACTOR

Contractor Task	Date Completed
All documentation required under the contract is to be provided with the time specified (AS BUILT's, Electrical Certificates etc).	1 1

4.3 DELIVERABLES FROM COMMISSIONING MANAGER

Commissioning Manager	Date Completed
All documentation is handed to the Project Manager to that the new switchboard asset can be capitalised and handed over to the customer.	
Factory Acceptance Test Sheet – Completed & signed off.	OK 🗆
Electrical Inspection Sheet – Completed & signed off.	OK 🗆
Site Acceptance Test Sheet - Completed & signed off.	OK 🗆
Commissioning Plan – Completed & signed off.	OK 🗆
Control Room Acceptance Form - Completed & signed off	OK 🗆
As built Drawings have been updated, drafted and taken to site along with the Site Specific Functional Specification,	1 1

BW Commi	ssioning Manager
Name:	Date:
Signature:	

Doc Id: 006142 Active Date: 09/Aug/2007 Brisbane Water Confidential

Printed: 12/08/2008 Owner: Alex Witthoft

Note: Printed copies of this document should be verified for currency against the published electronic copy.

Q-Pulse Id TMS942 Active 10/12/2014 Page 278 of 333

J. & P. RICHARDSON INDUSTRIES PTY. LTD.

A.B.N. 23 001 952 325 Lic. No. 756
ELECTRICAL CONTRACTORS and ENGINEERS DOCKET No. TELEPHONE: 3271 2911 (All hours) 114 CAMPBELL AVENUE - WACOL, BRISBANE Q 4076 JOB NUMBER DAY: C Ν Н 0 М S F DATE: OS ADDRE WORK START TIME EMP. No. NORMAL RISK MANAGEMENT HAS BEEN CARRIED OUT IN ACCORDANCE WITH: RISK ASSESS I have carried out the work listed & I confirm it complies with Good Work Practices, Our Quality Goals & to Customer's Satisfaction. m REPORT PROMPTLY ANY CONDITION LIABLE TO CAUSE AN ACCIDENT REMEMBER YOU ARE RESPONSIBLE FOR YOUR SAFETY TIME CLOCK 6m 48m 12n O UNITS PER HR. 42m 18n 24m Customer's Authorisation 30m for live work: ENT BY: Customer's Signature HBS. MIN. **UNITS** 0600 TO 1900 WORK T095 To 3*Q* To TRAVEL To To **SERVICE CALL-**APP BY ~ **ENDORSEE -**SERVICE CALL OUT -COST SECTION -SS **FOLLOW UP**

DRIVER FATIGUE MANAGEMENT						
UNIT No.		Ove	12 Tonne G	SVM		
Driving Time		Drivin	Total			
Start	Finish	Start	Finish	Hours		

Form No. F1024/4 May 08

Copyright 2006

CERTIFICATE OF TESTING & SAFETY

I certify that the electrical work listed has been tested in accordance with the prescribed procedure and that such work complies in every respect with the requirements of the Electrical Safety Regulation 2002. The electrical equipment listed to the extent that it is affected by the above electrical work, is electrically safe.

Certificate of Competency No:

Signature of Electrical Worker:



J. & P. RICHARDSON INDUSTRIES PTY. LTD.

114 CAMPBELL AVENUE, WACOL, BRISBANE, QLD. 4076

Telephone: (07) 3271 2911 - All Hours Facsimile: (07) 3271 3623

ELECTRICAL CONTRACTORS & ENGINEERS INDUSTRIAL - COMMERCIAL - MINING

ELECTRICAL INSTALLATION AND MAINTENANCE

CERTIFICATE OF COMPLIANCE

CONTRACT NUMBER BW.70103-06/07 ORDER No: 70103-001

JPR JOB No: C25200 **CONTROL PANEL FOR SP126**

DRAWINGS 486/5/7-0039-000,-001,-002,-003,-006,-007,-008,-009,-010,-011,-012,-014,-015,-016,-017,-018,-019,-020,-022,-023,-024 AMEND. B

POWER RETICULATION

SWITCHBOARD DESIGN AND MANUFACTURE

24 HOUR

SERVICE

BREAKDOWN

ELECTRICAL ENGINEERING, **PROCESS** SOFTWARE AND **DESIGN SERVICES**

SHEETMETAL **FABRICATION**

PUMPING INSTALLATIONS

MUNICIPAL

J&P Richardson Industries Pty. Ltd. certify that the above listed control panel has been tested in accordance with the job specification and the as built drawings on the date recorded on the quality assurance documentation for this control panel.

Yours faithfully,

J & P RICHARDSON INDUSTRIES PTY LTD

D.WEDLEY

ASSISTANT'SWITCHBOARD MANAGER

HIGH VOLTAGE **INSTALLATIONS** GOLD COAST PH: (07) 5591 6340 SUNSHINE COAST PH: (07) 5476 5133 TOOWOOMBA PH: (07) 4659 9900 Electrical Services Family owned company providing

EADM E 1005

since

1958."

CA!

© 2008 J & P RICHARDSON INDUSTRIES [TS]

Form No. F1017/3



J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: jpr@jpr.com.au

SWITCHBOARD & SHEETMETAL INSPECTION REPORT

Customer Name: Beis	BANE WA	TER.	Job No:	C 25	200	
Item:			Drawing No:			
SEWASE P/S SB S	P126		Ect-Ci	25200/A	10, A1, A2, A3	
TASK	PRODUCT DETAIL	INSPECTED BY	DATE	PASS/ FAIL	CORRECTIVE ACTION REQUEST OR COMMENTS	
Design	Documents	DW	15/2	P		
Drafting	Documents	DW	15/2	P		
Sheetmetal	Switchboard	2806	3/3	P		
(Refer F1018 for details)	Doors	Thet	4/3	P		
	Cell/Panels	The	29-2	P		
Painting		7/4				
Process	Powder / Wet.				•	
Min DFT (40 STD)						
Cure Test		1				
Colour Exterior	MIST SALE	A 4	11	916-		
Colour Internal	1	THU W	25/03/08	TASS		
Colour Panels	MIST SAEKA WHITE	A Joh	7.	_		
Cubicle Erection	WHITE	16	7 5 -0	PAS		
Electrical Fitout	M. LAWEY	Marine Co	7-3~08	70 7750		
(In accordance with drawings)	1. 6110263	Mr. Havely	-			
Inspection & Test		Etnor	21/4/08	Poss		
(Refer to F1019)						
Packing					moto	
Comments:	J	<u></u>		1		
PATEURA - 109	RAGUIZ	in on	5104	NACL		
1 + %	TIONION	BACK	LEFT	(eng)		
all keg an	Son. Aga	and Way	n 05/	03/88		
						
					•	
			er man de proposition de la compa	and the first days of	Service and the control of the contr	
NOTE: Manufact	ure is not to proceed	to the next pro	cess unit the	iteni lias pas	sea inspection	
Affix Status Here: -	Augitina Inggating					
Yellow Green	Awaiting Inspection Inspection & Test Page					
Red	Inspection & Test Fa		Rectification			
					Y A CONTRACT	

Form No. F1018/2



J. & P. RICHARDSON INDUSTRIES PTY. LTD.

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: jpr@jpr.com.au

SWITCHBOARD / SHEETMETAL INSPECTION CHECKLIST

					· -=	
CLIENT: BRISBANE	WATER				J(OB NO: 525260
PRODUCT DESCRIPTION: SELVAGE P/5 5B 5P/26			I .		EDULE NUMBERS	
SEWAGE P/5 51	R 5P126			EOT C	2520	0 AO-A3
CONSTRUCTION	,	QUA	LITY	COMPI	LIANCE RAWINGS	REMARKS OR
	[ЮОО	POOR	YES	NO	ACTION
1. Folds				1		
2. Welds				/		
3. Edges / File				/	+	
4. Gauge				/	 	
5. Material				V	·· ·····	
6. Ventilation Openings / Filter	Bracket			/		
7. Equipment Mounting Arran	gement	 		v		
8. Doors Stiffened				/		
9. Escutcheons and Lexan Cove	ers	 		/		
10. Cable Saddles						
11. Grinding					· W ·	
12. Door Stays Fitted				/		
13. Earth Studs				/		
14. Rubber Retainer			1	N/A		
15. Drawing Holder		- 	k			!
16. Hat Sections			¥			
17. Locking Bars Fitted				<u>/</u>		
18. External Crevice Welded and	Ground					
19. Legend Cards				/		
20. General Conditions Satisfacto	iry	·		<u> </u>		
21. Cabinet Clean		· · · · · · · · · · · · · · · · · · ·	/	<u> </u>		
22. Job Name and Number Mark	A /		/			
INSPECTED BY:				DATE: ム	- 25-0	.7

AFFIX STATUS HERE

Yellow Green Red

Awaiting Inspection Inspected/Tested Passed

Inspected/Tested Awaiting Rectification





.....

J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: jpr@jpr.com.au

<u>SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT</u> <u>INDIVIDUAL DRIVES</u>

Customer Name: B	risbane	e Wa	ter				
Project: Young's Road Sewage Pump Station							
	<u>C 2 52</u>		Item: RTU section				
Constructed by:	VI Lac	vley	Tested by:	EE	nsor	Date: 21/4/08	
Item check list:	<u> </u>	4 do comp		wings, Docui			
Main Functional Unit/s:	Qty		Size	ļ	Fuses/O/L	·	
Fuse Fittings	Qty		Size		Fuse Size		
Circuit Breakers	Qty	ļ	Size		O/L		
Neutral	Reqd		Size	ļ	ID	<u> </u>	
Earthing	Checked		Size				
C.T.s	Qty		Rating	<u> </u>	Function	<u> </u>	
Тоггоід	Qty	<u> </u>	Rating		Function		
Meters	Qty		Rating		Function		
Contactors	Qty	<u> </u>	Rating	İ.,	Voltage		
Overloads	Qty		Rating		Function		
Relays	Qty		Rating	<u> </u>	Voltage		
Timers	Qty	<u> </u>	Rating		Voltage		
Control Switches	Qty		Rating		Function		
Push Buttons	Qty		Rating		Function		
Pilot Lights	Qty		Rating		Voltage	<u> </u>	
Transformer/DC Supply	Qty		Rating		Voltage		
ATT	Qty		Rating		Function		
VFD	Qty		Rating		Function		
Soft Starter	Qty		Rating		Function		
Terminals	Qty		Size		ID		
Engraving	Qty		Size		ID	/	
Cabling	Туре		Size		ID		
Busbars	Туре		Size	<u> </u>	ID		
Escutcheons / Shrouds	Туре		Material		IP rating		
Earth Leakage Unit	Qty		Size		Function		
Remote I/O Unit	Qty		Size		Function		
General/Check List:	50. T						
IP Sealing	Rating						
Door Latches	Qty		Type		Operation		
Ventilation	Required		Туре		Operation		
Circuit Schedule	Required		Fitted		Checked		
Terminal Tightness	Power		Control		Result		
Polarity Check	R-R		W - W		B - B		
Continuity Check	R-R		W - W		B-B	N-N	
Partially Checked Circuits	- Point to P	oint					
Comments:		<i></i>					
							
			 .				
		 			_		
							
				<u> </u>			
							

Form No. F1019/8 Page 2 of 6



J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: Jpr@Jpr.com.au

SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT INDIVIDUAL DRIVES

Customer Name: R	rishana	11/10	or				 -	
	unces P	much	Source	p Pinn	o stat	iden	SP 12	6
	2520	0	Item:	and the	Contro	. [<u> </u>	<u> </u>
	baul	0/4	Tested by:	= F.	0.C.C.C.C	Date:	2//15	108
Tienricheck list a 22		To com	lowith Dea	vinessDoca	1507 ments & Spe	citicali	70 2 3	
Main Functional Unit/s:	Qty	Commission of the Commission o	Size		Fuses/O/L		ACTION OF SER	
Fuse Fittings	Qty		Size		Fuse Size			
Circuit Breakers	Qty		Size		O/L			
Neutral	Reqd		Size		ID	 -		
Earthing	Checked		Size			 		
C.T.s	Qty		Rating		Function	 		
Тоггоід	Qty		Rating		Function	 		
Meters	Qty		Rating		Function			
Contactors	Qty		Rating		Voltage	 		
Overloads	Qty		Rating		Function			
Relays	Qty		Rating		Voltage			
Timers	_ Qty		Rating		Voltage			
Control Switches	Qty	/	Rating		Function			
Push Buttons	Qty		Rating		Function			
Pilot Lights	Qty	\	Rating		Voltage			
Transformer/DC Supply	Qty		Rating		Voltage			
ATT	Qty		Rating		Function			
VFD	Qty		Rating		Function			
Soft Starter	Qty		Rating		Function			
Terminals	Qty		Size		ID	1		
Engraving	Qty		Size		ID			
Cabling	Type		Size		ĺD	\		
Busbars	Туре		Size		ID			
Escutcheons / Shrouds	Туре		Material	_	IP rating	/		
Earth Leakage Unit	Qty		Size		Function			
Remote I/O Unit	Qty		Size		Function			
General Check List					3.67.72			
IP Sealing	Rating							
Door Latches	Qty		Туре		Operation	/		
Ventilation	Required		Туре		Operation			
Circuit Schedule	Required		Fitted		Checked			
Terminal Tightness	Power		Control		Result	/		
Polarity Check	R-R		W - W		B-B			
Continuity Check	R-R		W - W		B-B		N-N	
artially Checked Circuits	- Point to P	oint						
omments:		800444	41666	ti labara		<i>177</i> 69	3 19-10-2	4
								
	··							
			•	-				
								

Form No. F1019/8 Page 2 of 6



J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: jpr@jpr.com.au

SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT INDIVIDUAL DRIVES

Customer Name: [-	3 ris bai	re W	atec			
Project: You	ngs R	gad Se	wage	PUMI	2 Stuti	ion 89126
JPR Job No: C 2	25200	<u> </u>	Item:	Pump	Nol	
Constructed by:	Low	ey	Tested by:	EF	1COC	Date: 21/4/08-
Item check list:	#14.00 (A)	Lo comp		vings, Docu	ments & Spe	
Main Functional Unit/s:	Qty	<u> </u>	Size		Fuses/O/L	
Fuse Fittings	Qty		Size		Fuse Size	
Circuit Breakers	Qty		Size		O/L	
Neutral	Reqd		Size		ID	/
Earthing	Checked		Size			
C.T.s	Qty		Rating		Function	
Torroid	Qty		Rating		Function	
Meters	Qty		Rating		Function	
Contactors	Qty		Rating		Voltage	
Overloads	Qty		Rating		Function	
Relays	Qty		Rating		Voltage	/
Timers	Qty		Rating		Voltage	
Control Switches	Qty		Rating		Function	
Push Buttons	Qty		Rating		Function	
Pilot Lights	Qty		Rating		Voltage	
Transformer/DC Supply	Qty		Rating		Voltage	
ATT	Qty		Rating		Function	
VFD	Qty		Rating		Function	
Soft Starter	Qty		Rating		Function	· · · · · · · · · · · · · · · · · · ·
Terminals	Qty		Size		ID	/
Engraving	Qty		Size		ID	/
Cabling	Туре		Size		ID	
Busbars	Туре		Size		ID	
Escutcheons / Shrouds	Type		Material		IP rating	
Earth Leakage Unit	Qty		Size		Function	
Remote I/O Unit	Qty		Size		Function	
General Check List:						***
IP Sealing	Rating			T	I	
Door Latches	Qty		Type		Operation	
Ventilation	Required		Туре		Operation	
Circuit Schedule	Required		Fitted		Checked	
Terminal Tightness	Power		Control	_	Result	
Polarity Check	R-R		W - W		B-B	
Continuity Check	R-R		W-W		B-B	N-N
Partially Checked Circuits		oint				
	T					
Comments:				<u>_</u>	l	
		•				
						
	-					
						
					··,	
						
						
			-			
	·					

Form No. F1019/8
Page 2 of 6



J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076
Ph: (07) 3271 2911 - Fax: (07) 3271 3623
E-mail: jpr@jpr.com.au

<u>SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT</u> <u>INDIVIDUAL DRIVES</u>

Customer Name:	eris ban	e Wo	ter			·	
Project: You	ngs R	oad 9	ewage	e Pumi	a Stotr	00	
	57.00	<u> </u>	Item:	Punn			
Constructed by:	Laul	ey_	Tested by:		1501	Date: 214	108
Itemichecklistie		- Lo com	lly with Drai	vings; Docu	nichts,&Spe	cification.	10
Main Functional Unit/s:	Qty		Size		Fuses/O/L]	
Fuse Fittings	Qty		Size		Fuse Size		
Circuit Breakers	Qty		Size		O/L		
Neutral	Reqd		Size		ID	-	
Earthing	Checked		Size				
C.T.s	Qty		Rating		Function		
Топоid	Qty		Rating		Function		
Meters	Qty		Rating		Function		
Contactors	Qty	•	Rating		Voltage		
Overloads	Qty		Rating		Function		
Relays	Qty	١	Rating	/	Voltage		
Timers	Qty		Rating		Voltage		
Control Switches	Qty	· · · · · · · · · · · · · · · · · · ·	Rating		Function		
Push Buttons	Qty		Rating		Function]	
Pilot Lights	Qty		Rating		Voltage		
Transformer/DC Supply	Qty		Rating		Voltage		
ATT	Qty		Rating		Function		
VFD	Qty		Rating		Function		
Soft Starter	_Qty		Rating	Ţ	Function		
Terminals_	Qty		Size		ID_	/	
Engraving	Qty		Size		Œ	/	
Cabling	Туре		Size		ID		
Busbars	Туре		Size		ID		
Escutcheons / Shrouds	Туре		Material		IP rating		
Earth Leakage Unit	Qty		Size		Function		
Remote I/O Unit	Qty		Size		Function		
General Check List:						2.00	
IP Sealing	Rating						
Door Latches	Qty		Туре		Operation		
Ventilation	Required		Туре		Operation		
Circuit Schedule	Required		Fitted		Checked		
Terminal Tightness	Power		Control		Result		
Polarity Check	R-R		W - W		B - B	/	
Continuity Check	R-R		W - W		B - B	N - N	
Partially Checked Circuits	- Point to Po	oint					
Complents: : : :: :: :: :: ::					5 Establis		
					· · · · · · · · · · · · · · · · · · ·		
						<u> </u>	

Form No. F1019/8 Page 1 of 6

源

J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076
Ph: (07) 3271 2911 - Fax: (07) 3271 3623
E-mail: jpr@jpr.com.au

SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT

Customer Name:	Brisbone			SPECIA	UN & TEST	KEFUK	ī	
				^	011			
Project: V_{α}	ungs R	<u> </u>	ew age	- PUMP	Station			
JPR Job No:	C 252	<u>00 </u>	Item:	5/1	126	D. (7 -
Constructed by:	V Law	<u>ea</u>	Tested t	y: EE	nso/	Date: 2	4/4	08-
Hemichees (ISI)		1 1000		(avangs, 4)				4.0 21
Main Functional Unit			Size		Fuses/O		_	
Fuse Fittings	Qty		Size		- Fuse Siz	e		
Circuit Breakers	Qty		Size		O/L			
Neutral	Reqd		Size		ID			
Earthing	Checked	1	Size			1		
C.T.s	Qty		Rating					
Meters	Qty		Rating					
Contactors	Qty		- Rating		Voltage			
Overloads	Qty		Rating		Function			
Relays	Qty		Rating		 Voltage 			
Timers	Qty		Rating		Voltage			
Control Switches	Qty		Rating		Function			
Push Buttons	Qty		Rating		Function			
Pilot Lights	Qty		Rating	-	Voltage	1		_
Transformers	Qty		Rating	 	Voltage			_
ATT/VFD/Soft Starter	Qty	 	Rating	 	Function	/	_	
DC Supply	Qty		Rating	 	Voltage	1/		
Terminals	Qty		Size		ID	 	_	
Engraving	Qty		Size	 	ID ID	 		
Cabling	Type		Size	 	1D	 		
Busbars	Type		Size		ID	-		
Scutcheons / Shrouds			Material	 _	IP rating	-	-	
	Type	 -	_+	<u> </u>	1F latting	 		
A. Metering CTs	Qty	<u></u>	Rating			 		
A Metering Links	Туре	 	01:	 	-	 	-}	
A. Meters	Туре	 	Size	 	0.5.00	 		
PR Label	Fitted -	ļ <u> </u>	Stamped	 	Safety Stkr	<u> </u>		
egend Card	Qty	<u> </u>	Соггест		<u> </u>	ļ		
LC/Telemetry	Qty		Size			ļ		
ower Monitor Relay	Qty		Rating		Function	COLOR DE CONTRACTOR	Transition 18	ERROR THROOF
eneral Greck Wister				Sale South		S# 8 50	17 %	
Sealing	Rating		<u> </u>					
oor Latches/Hinges	Qty		Туре		Operation	_		
entilation	Required		Туре		Operation		<u> </u>	
ircuit Schedule	Required		Fitted		Checked			
erminal Tightness	Power		Control		Result			
ısbar System	Clearances		Joints		ID		1	
rth Continuity	Body to E		Doors to E	_	Panels to E			
ibicle Cleaned								
int Finish Intact		_		7. 2		-		
larity Check	R-R		W-W		B-B			
nction	Power		Control		PLC/Telem		•	
ntinuity Check	R-R		W-W		B-B	- N	- N	
minents is a second				7 W 7 Y 7 Y				
AND THE PARTY OF T	anguna at Sangara ay Capa (ang Sangara ang Anda)	The second second second second	The second secon			-Andrews and	- Search of Color	A Bur Gran
			· · · · · · · · · · · · · · · · · · ·					
	·							

Form No. F1019/9 Page 6 of 6



J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076
Ph: (07) 3271 2911 - Fax: (07) 3271 3623
E-mail: jpr@jpr.com.au

SWITCHBOARD CONTINUITY & INSULATION TEST REPORT

	Road ;	sewage 1	comp Sto	ztion	·	
JPR Job No: C 2 52	00	Switchboard:	SP 126	·	· · · · · · · · · · · · · · · · · · ·	
Constructed by: M Lo	wley	Tested by:	Ensor		Date: 9/	4/08
		CONTINUITY TE	Care Nancy and Company of the Compan			175
From		То	Red	White	Blue	Neutra
					_	
	 		- 		- 	ļ
			-{			
			 		 	
			- 		 	
					 	
			 	·	 	
					 	
					 	
					 	
					 	
			 	····	 	
			- 		 	
			 		 	
	 				 	
		······································	- 		 	
	 				 	
						
						
cetch:						
Designation	1000	ESTSTO SEGTION V Test (ΜΩ)	2.5 kV Test		1000 V Te	
Designation ed to Earth	1000 V	V Test (MΩ)			1000 V Te	
Designation Ed to Earth hite to Earth	1000 Y 500 500	V Test (ΜΩ)			1000 V Te	
Designation Ed to Earth hite to Earth ue to Earth	1000 V	V Test (ΜΩ)			1000 V Te	
Designation d to Earth hite to Earth ue to Earth uutral to Earth	1000 500 500 500	V Test (MΩ)			1000 V Te	
Designation Ed to Earth hite to Earth eu to Earth eutral to Earth d to White	1000 500 500 500	V Test (MΩ)			1000 V Te	st (MΩ)
Designation d to Earth hite to Earth ue to Earth uutral to Earth	1000 500 500 500	V Test (ΜΩ)			1000 V Te	





J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: jpr@jpr.com.au

<u>SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT</u> <u>INDIVIDUAL DRIVES</u>

Customer Name:	Brisba	ne W	ater			
	ings f		Sewoo	e Pum	a Str	Tirin
JPR Job No: C 2	5200)	Item:	remor	DA S	ections
Constructed by: Mic	en len		Tested by:	EEn	or	Date: 2/4/08
Hem check list:	7	To com	ly with Dra	wings; Docui	nents & Spe	cification /
Main Functional Unit/s:	Qty		Size	_	Fuses/O/L	
Fuse Fittings	Qty		Size		Fuse Size	· · · · · · · · · · · · · · · · · · ·
Circuit Breakers	Qty		Size		O/L	
Neutral	Reqd		Size		ID	_
Earthing	Checked		Size			
C.T.s	Qty		Rating		Function	
Топоid	Qty		Rating		Function	
Meters	Qty		Rating		Function	
Contactors	Qty		Rating		Voltage	
Overloads	Qty		Rating		Function	
Relays	Qty	1	Rating		Voltage	
Timers	Qty		Rating		Voltage	
Control Switches	Qty		Rating		Function	
Push Buttons	Qty		Rating		Function	
Pilot Lights	Qty_		Rating		Voltage	
Transformer/DC Supply	Qty		Rating		Voltage	
ATT	Qty		Rating		Function	. <u>.</u>
VFD	Qty		Rating		Function	
Soft Starter	Qty		Rating		Function	
Terminals	Qty_		Size		ID	
Engraving	Qty		Size		ID	
Cabling	Туре		Size		ID	
Busbars	Туре		Size		ID	
Escutcheons / Shrouds	Туре		Material		IP rating	
Earth Leakage Unit	Qty		Size		Function	
Remote I/O Unit	Qty	A POP HONOLOGY	Size	1	Function	
General Check List:						
IP Sealing	Rating					
Door Latches	Qty		Туре		Operation	
Ventilation	Required		Туре		Operation	
Circuit Schedule	Required		Fitted		Checked	
Terminal Tightness	Power		Control		Result	
Polarity Check	R - R		W - W		B - B	
Continuity Check	R - R		W - W		B-B	N-N
Partially Checked Circuits	- Point to Po	oint				
	<u> </u>					
Comments:						
						

Form No. F1019/8 Page 5 of 6



J. & P. RICHARDSON INDUSTRIES PTY LTD

114 Campbell Avenue, WACOL QLD 4076 Ph: (07) 3271 2911 - Fax: (07) 3271 3623 E-mail: jpr@jpr.com.au

SWITCHBOARD ELECTRICAL INSPECTION & TEST REPORT EARTH LEAKAGE TEST

<u> </u>	7	1 1 1 1					
Customer Name: JPR Job No: Constructed by:	RUIS	bane Wi	rec	. 8-1		<u> </u>	,
JPR Job No:	<u> </u>	<u>oo</u>	Ittem: Y	oungs Rd	•	SP 126 Date: 17/4	1.6
Constructed by: Test Unit	N La	wiey	1 ested by	- b Enco	<u>'</u> ——	Date: 17/4	108
Test Unit	Megger K	CD 1330	<u> </u>	Other	<u> </u>		
	 			·			·
							,
Gircuil Breaker,	DL	Rated Current		Trip Gurrent (ma)		Trip Time	Comments
Circuitibreakers	1,000	(mA) 22.23		L (mA)		(mS)	Comments
	R	30		21		53.1	
Q11	W	30		2/		51.4	
	B	30		21		51·4 50·2	
@12		30		23		28.7	
Q13		30		25		29.7	
							
@19		30		23		27.7	
221		30		25		29.6	
500				-6-1		<u>~// </u>	
							
			 -		·		
					-	·	
							
							
			<u>-</u>		~ -		
							
							
					1_	<u>_</u> <u>_</u>	
Comments:-				·			
				· · · · · · · · · · · · · · · · · · ·			

FILE: EMC0381/BL

03/01/03

PAGE 1 OF 1

JOB SAFETY ANALYSIS

LIVE LOW VOLTAGE WORK

TESTING SWITCHBOARDS AND CONTROL PANELS WITHIN OUR MANUFACTURING PREMISES

APPROVED BY:

Eric McCulloch (WHSO)

LOCATION:

WACOL WORKSHOP

DATE: 18141.28

AUTHORISAT	IONS	PERSO	NAL PROTECTIV	VE EQUIPMENT
Authorisation from person in charge (Signature)	n Ø YES	Insulating Insulating	otton clothing ng work gloves in te ng mats / covers in t oard rescue kit in te	est C YES
TASK	Work area c	nts identified a	ions	O YES
LIVE LOW VOLTAGE WORK		•	ited to work area	YES YES
TESTING SWITCHBOARDS AND CONTROL PANELS WITHIN OUR MANUFACTURING PREMISES	Written author a person in cl JPR authorisa	ent is fit for pur prity to proceed narge ation to conduc	pose I has been obtained t live work is curre supply only used fo	nt 🗹 YES
OPTION OPTION	(A) RCD protects > RCD protects > Safety Obs (B) Non RCD protects > Supervisor	ed outputs used ection checked server je7 is no	used at power supp r to use	Ø YES Ø YES
understand and am fully aware of				
Signatures: 1. El Cura 2.	3.		4.	5.

FILE: EMC0381/BL

03/01/03

PAGE I OF :

JOB SAFETY ANALYSIS

LIVE LOW VOLTAGE WORK

TESTING SWITCHBOARDS AND CONTROL PANELS WITHIN OUR MANUFACTURING PREMISES

APPROVED BY: Eric McCulloch (WHSO)

LOCATION:

WACOL WORKSHOP

DATE: 17.14.10.8

AUTHORISAT	IONS	PERSONAL PROTECTIVE EQ	UIPMENT
Authorisation from person in charge (Vignature)	n N YES	 Long cotton clothing Insulating work gloves in test Insulating mats / covers in test Switchboard rescue kit in test 	8 YES 8 YES 8 YES 7 YES
TASK	7	nts identified and accessible ear of obstructions	Ø YES
LIVE LOW VOLTAGE WORK	Unauthorised	access prevented to work area	BY YES
	• P.P.E. is fit fo	or purpose	DY YES
	Test equipment	nt is fit for purpose	Ø YES
TESTING SWITCHBOARDS	a person in ch	rity to proceed has been obtained from arge ion to conduct live work is current	2 YES
AND CONTROL PANELS WITHIN OUR MANUFACTURING	Approved ded testing.	icated power supply only used for	D YES
PREMISES	Approved dedi	cated power supply in current test	Ø YES
OPTION	1	d outputs used at power supply	2 YES
	> RCD protect	ction checked daily prior to use	YES
	> Safety Obse	erver is is not required	2 YES
OPTION	- · · -	ected outputs used at power supply consulted prior to use	□ YES □ YES
	> Safety Obse	rver is in attendance	□ YES
understand and am fully aware of	the requirements of	this job safety analysis.	
gnatures: 1. Eugense 2.	3.	4. 5.	

FILE: EMC0381/BL

03/01/03

PAGE 1 O

JOB SAFETY ANALYSIS

LIVE LOW VOLTAGE WORK

TESTING SWITCHBOARDS AND CONTROL PANELS WITHIN OUR MANUFACTURING PREMISES

APPROVED BY: Eric McCulloch (WHSO)

LOCATION:

WACOL WORKSHOP

DATE: 21.1.41.0.8

AUTHORISAT	TIONS	PERSONAL PROTECTIVE	EQUIPMENT
Authorisation from person charge (Signature)	in V YES	 Long cotton clothing Insulating work gloves in test Insulating mats / covers in test Switchboard rescue kit in test 	O YES O YES O YES
TASK	<u>-</u>	nts identified and accessible ear of obstructions	O YES O YES
LIVE LOW VOLTAGE WORK	• Unauthorised	access prevented to work area	O YES
	• P.P.E. is fit fo	r purpose	BY YES
	Test equipmer	nt is fit for purpose	Q YES
TESTING SWITCHBOARDS	a person in cha	rity to proceed has been obtained fro arge ion to conduct live work is current	m O YES
AND CONTROL PANELS WITHIN OUR MANUFACTURING PREMISES	Approved deditesting.	cated power supply only used for	e yes
·	1	cated power supply in current test	Ø YES
OPTION	(A) RCD protected	doutputs used at power supply	D YES
	> RCD protec	tion checked daily prior to use	₽ YES
	1	rver is is not required	D YES
OPTION	,	ected outputs used at power supply onsulted prior to use	O YES
	> Safety Obser	ver is in attendance	U YES
understand and am fully aware of	the requirements of the	his job safety analysis.	
gnatures: 1. Ellane 2.	3.	4. 5.	

SP126 SP126

0

Q-Pulse Id TMS942 Active 10/12/2014

J & P Richardson Industries Pty Ltd

3.0 ELECTRICAL DRAWINGS

File: //Jpr_Server/docs/!sched/Masters.doc

Revision 0

Date: 25 May 2001



SP126 YOUNGS ROAD SEWAGE PUMPING STATION

SITE COVER SHEET

DWG N°.	TITLE	SHEET	F	REV	ISI	SNC	3
486/5/7-0039-000	SITE COVER SHEET	00	P1	0	Α	В	1
486/5/7-0039-001	POWER DISTRIBUTION SCHEMATIC DIAGRAM	01	P1	0	Α	В	1
486/5/7-0039-002	PUMP 01 SCHEMATIC DIAGRAM	02	P1.	0	Α	В	Ī
486/5/7-0039-003	PUMP 02 SCHEMATIC DIAGRAM	03	P1	0	Α	В	Γ
486/5/7-0039-004	RESERVED (SUMP PUMP)	04					Γ
486/5/7-0039-005	RESERVED (GENERATOR CONTROL)	05					Γ
+86/5/7-0039-006	COMMON CONTROLS SCHEMATIC DIAGRAM	06	P1	0	Α	В	
+86/5/7-0039-007	COMMON RTU I/O SCHEMATIC DIAGRAM	07	P1:	0 ·	Α	В	Γ
486/5/7-0039-008	RTU POWER DISTRIBUTION SCHEMATIC DIAGRAM	08	P1	0	Α	В	Τ
486/5/7-0039-009	RTU DIGITAL INPUTS TERMINATION DIAGRAM	09	P1	0	·A	В	Ι
486/5/7-0039-010	RTU DIGITAL INPUTS TERMINATION DIAGRAM	10	P1	0	Α	В	Τ
86/5/7-0039-011	RTU DIGITAL OUTPUTS TERMINATION DIAGRAM	11	P1	0	Α	В	Ī
486/5/7-0039-012	RTU ANALOGS & MISCELLANEOUS TERMINATION DIAGRAM	12	P1	0	Α	В	Τ
486/5/7-0039-013	RESERVED (COMMON CONTROLS TERMINATION DIAGRAM).	13					Γ
86/5/7-0039-014	EQUIPMENT LIST	14	P1	0	Α	В	Γ
86/5/7-0039-015	CABLE SCHEDULE	15	P1	0	Α	В	T
+86/5/7-0039-016	SWITCHBOARD LABEL SCHEDULE	16	P1	0	Α	В٠	T
+86/5/7-0039-017	SWITCHBOARD CONSTRUCTION DETAILS	. 17	P1	0	Α	В	T
86/5/7-0039-018	SWITCHBOARD CONSTRUCTION DETAILS	18	P1	0	Α	В	Ť
86/5/7-0039-019	LEVEL PROBES AND PRESSURE TRANSMITTER INSTALLATION DETAILS	19	P1	0	Α	В	T
86/5/7-0039-020	CATHODIC PROTECTION UNIT – CONSTRUCTION AND WIRING DETAILS	20	P1	0	Α	В	Ť
+86/5/7-0039-021	RESERVED (FIELD DISCONNECTION BOX)	21	\Box				Ī
86/5/7-0039-022	SWITCHBOARD GENERAL ARRANGEMENT - ELEVATIONS - SINGLE SIDED	22	P1	0	Α	В	Ť
86/5/7-0039-023	SWITCHBOARD GENERAL ARRANGEMENT - SECTIONS - SINGLE SIDED	23	P1	0	Α	В	T
86/5/7-0039-024	SLAB & CONDUIT DETAILS	24	P1	0	Α	В	Ť
			\Box				t

STANDARD VARIABLES	
DESCRIPTION .	VALUES
CT METERING ISOLATOR	250A SLB 250 3P
NORMAL SUPPLY MAIN SWITCH	160A X54005E/750
GENERATOR SUPPLY MAIN SWITCH	160A XS400SE/250
PUMP1 CIRCUIT BREAKER	100A \$125GJ/100
PUMP2 CIRCUIT BREAKER	100A \$125GJ/100
DRY WELL SUMP PUMP CIRCUIT BREAKER	NOT APPLICABLE
PUMP VSD SIZE	FC202P30X
PUMP RATING	22kW 40A
PUMP LINE CONTACTOR	CA7-85
SUMP PUMP RATING	NOT APPLICABLE
SUMP PUMP CONTACTOR & TOL	NOT APPLICABLE
WET WELL LEVEL TRANSMITTER	FM167-A28MD1A3 6m
EMERGENCY STORAGE WELL LEVEL TRANSMITTER	NOT APPLICABLE
DELIVERY PRESSURE TRANSMITTER	BR74XXGG1FHA2X S0m
WET WELL ULTRASONIC LEVEL SENSOR	NOT APPLICABLE
FLDWMETER RANGE	100L/s
RADIO :	DR900-06A02-D0
EMERGENCY PUMPING TIME	360sec .
No of SINGLE POINT PROBES	3
INCOMING MAINS SUPPLY CABLE	50mm²
MAIN EARTHING CABLE	16mm²
INCOMING GENERATOR SUPPLY CABLE	NOT APPLICABLE
PUMP MOTOR SUPPLY CABLE	16mm²
	-
	······································

	STANDARD DESIGN OPTIONS		1
OPTION	DESCRIPTION	FITTED]
-	INDIVIDUAL PUMP MOISTURE IN OIL (MIO) SENSOR AND FAULT RELAY	DES NO]
-B	INDIVIDUAL PUMP MOTOR AUX PROTECTION SENSORS AND FAULT RELAYS	DES NO]
 C	INDIVIDUAL PUMP REFLUX VALVE MICROSWITCH	ß⊠ NO]
-D	STATION MANHOLE SURCHARGE IMMINENT	®ESSIN0]
-E	STATION DRY WELL SUMP PUMP AND LEVEL INDICATION SENSORS AND RELAYS	ØESSIN0]
F	STATION PERMANENT GENERATOR - ATS AND CONTROL CONNECTIONS	DESSI NO]
6	STATION EMERGENCY STORAGE LEVEL SENSOR	Ø23 N0]
Н	STATION DELIVERY FLOWMETER	YES DAKE	ij
-+	BACKUP COMMUNICATION OPTIONS	BESS NO]
j	PUMP CONNECTION (Via Intergrated Disconnect Cubicle)	YES DE	ij
K	CATHODIC PROTECTION	YES DEED	ī
L	MOTDR THERMISTORS (Via Intergrated Disconnect Cubicle)	YES DEK	ij
- M	ODOUR CONTROL	DES NO	1
N	CURRENT TRANSFORMER (CT) METERING	YES DAKE	1
-0	PUMPS ELECTRICAL INTERLOCK	MESSI NO	1
• Р	WET WELL WASHER (Solenoid not Installed)	YES DE	ij
Q	FLOWMETER PIT SUMP PUMP AND LEVEL PROBE	YES DEKE	וֹנ
R	TELEMETRY RADIO	YES DERE	ij
<u>-Ş</u>	WET WELL ULTRASONIC LEVEL SENSOR	DESS NO	1
Т	SINGLE SIDED SWITCHBOARD	YES DE	ĵĮ.
U	DELIVERY PRESSURE TRANSMITTER	YES DEN	1
_v	CHEMICAL DOSING	MESS NO	J

STANDARD DESIGN OPTIONS

ELECTRICAL AS BUILT CERTIFICATION

REV COMPANY J&PRICHARDSON
C CONTRACTOR LICENCE No. 756

C CONTRACTOR LICENCE No. 756

A 11.07 RE-ISSUED FOR TENDER
C 12.08 AS BUILT
B 01.08 ISSUED FOR CONSTRUCTION

P.H. A.W. THIS DRAWING OF PART THEREOF IS RESTECTED BY THE LAW. DRAFTED P.H.A. LAWS OF CONTINENT AND ANY NOT BE COMED OR REPRODUCED WITHOUT THE DOPRESS PERMISSION OF DRAFTING CHECK A.W.I. P.H. A.W. © 2006 CAD FILE 57-0 DRN. APD. Reference Drawings B.C.C. FILE No.

Original Signed by A.WITTHOFT
DESIGN
Original signed by R.JANFADA

07 Original Signed by P.SHERRIFF 28.08.


SP126 YOUNGS ROAD SEWAGE PUMP STATION SITE COVER SHEET


AS BUILT


486/5/7-0039-000

Sheet 00

age 297 of 333










M QT	Y DESCRIPTION	MANUFACTURER	CATALOGUE No	190	REMARKS	ITEM	QTY	DESCRIPTION	MANUFACTURER	CATALOGUE No	OPT	REMARKS	ITEM	YTO	DESCRIPTION		MANUFACTURER	CATALOGUE No	ОРТ	REMARKS
1 1	01 HETERING ISOLATOR	SOCOMEC	SLB 250 3P	N		65	2	VSD RUNNING RELAY - K3	DEC	RH48-UL-240VAC	·		129	1	CATHOOIC PROTE	TICH UNIT	DRAVING No	SHEET 20	K	
2 1	02 NORMAL SUPPLY MAIN SWITCH	TERASAKI	XS400SE/750	1-1	Set @ 160A + N/O AUX	66					\sqcup		80		ANODE - FREE IS	UE			K	Installed by BW
3 1	03 GENERATOR SUPPLY MAIN SWITCH	TERASAKI	XS4005E/250	-	Set (9 160A	67	ļ	NOT USED			\sqcup		81		NOT USED	· · · - ·				DANCE AND
<u> </u>	Q4 PUMP1 CRCUIT BREAKER	TERASAKI	\$125GJ/100	<u> • </u>	Set @ 100A	68	ļ				E		137	1	FLOWMETER - F		ENDRES-HAUSER	PROHATIC 19	Н	RANGE = 100L/s
5 1	QS PUMP2 CIRCUIT BREAKER	TERASAKI	S125GJ/100	<u> </u>	Set @ 100A	69	_				A		133	1	VET VELL LEVE		EMDRUSS + HAUSER	PHI67-A2BHD1A3		RANGE = 6a
5				£		70					В		84	_!	MEL AETT TEAST	TRANSMITTER TERMINAL HOUSING	ENDRUSS + HAUSER	(Part of Item 133)		
7 1	Q7 ENERGEX PHASE FAILURE CIRCUIT BREAKER	TERASAKI	DT(815306C	ļ -		71	<u> </u>				В.		135						6	
8				F		72		NOT USED					B6						6	
9 1	Q9 SUB-DISTRIBUTION BOARD CIRCUIT BREAKER	TERASAKI	S125NU/63	<u> - </u>		73	↓	NOT USED			L		87		DELIVERY PRESS	····	VEGA VEGABAR74	BR74XXGG1FHA2X	U	RANGE = 50m
19 1	Q 19 STATION MAINS PHASE FAILURE CIRCUIT BREAKER	TERASAKI	DTCB6306C	-		74	2	PUMP RUN COMMAND RELAY - K20	IDEC	RHZB-UL-24VDC	<u> </u>		88	1	DELIVERY PRESS	RE ADJUSTMENT UNIT	VEGA VEGA 01\$12	VEGADIS1ZXBAX	U	
n 1	Q 11 3 PHASE OUTLET CIRCUIT BREAKER	TERAŞAKI	DTCB6332C	-	PLUS DSRON-32-38-3PN	75	2	PUMP FAULT RESET RELAY - K21	IDEC ·	RHZB-UL-24VDC	-		139	1	RTU POWER SUP	LY 24VDC	POWERBOX .	PB251-2401-CC-T		
2 1	0.12 15A GPO CIRCUIT BREAKER	TERASAKI	DSRCBH-16-30A	-		76	2	PUMP EMERGENCY MODE INTERRUPT RELAY - 1622	IDEC	RH2B-UL-24VDC	-		14.0	1	RADIO 24V/13.8V	OC CONVERTER	POWERBOX	VTA12SC24	R	·
3 1	Q13 RTU LAPTOP GPO CIRCUIT BREAKER	TERASAKI	DSRCBH-19-30A	-		η	2	PUMP 'RUN AT MAX' RELAY ~ K23	DEC	RH2B-UL-24VDC	- [141						1	
4 1	Q14 SPARE	TERASAKI	DTCB&196C 1	E		78	2	PUMP START PUSHBUTTON - 51	SPRECHER & SCHUH	07P-F3-PX10	-		14.2	2	BATTERIES		YUASA	UXH50-12	-	
5 1	QIS SPARE	TERASAKI	DTCB6119C	E	1	79	2	PUMP STOP PUSHBUTTON - S2	SPRECHER & SCHUH	DTP-F4-PX10	-		14.3	1	RADIO		TRIO	0R908-06A02-D0	R	
6 1	Q16 SW/80 INTERNAL LIGHTING CIRCUIT BREAKER	TERASAKI	DTCB6196C			80	2	PUMP EN/STOP PUSHBUTTON - \$3	SPRECHER & SCHUH	D7P-HT34-PX02S	- 1	c/w 60mma E/Stop Ring - Label	14.4	1	ANTENNA		TREO	LABTHA DAY	R	S ELEMENT 1848
7 1	0.17 SURGE FILTER CIRCUIT BREAKER	TERASAKI	DTCB6119C	1 - 1		81	2	PUMP RESET PUSHBUTTON - SA	SPRECHER & SCHOOL	DTP-F6-PX10	- 1		14.5	1	RADIO CDAX SUF	E PROTECTION UNIT	POLYPHASER CORPORATION	IS-50NX-C2	R	
8 1	Q IS EM PUMP ONTRL & SURCHARGE IMPRIENT CB	TERAŠAKI	DTCB6195C	1 -		82		PUMP HOUR RUN METER	NATIONAL	PEAHT	- 1	· · · · · · · · · · · · · · · · · · ·	14.6	1	TELEMETRY UNIT		LOGICA CMG	MD3311EAL/271D-0-7	- +	
9 1	Q19 GENERATOR AUXILLARY SUPPLY CIRCUIT BREAKER	TERASAKI	DSR(BH-10-30A	╅		13	-	NOT USED					147						 	
9 1	Q20 CATHODIC PROTECTION POWER SUPPLY	TERASAKI	DTCB6196C	ĸ			+		 		E		14.8						+	
	Q21 FLOWMETER PTT SUMP PUMP POWER SUPPLY	TERASAKI	DSRCBH-19-30A	Q Q		84	1		 		E		149		DISCONNECT PLU	· · · · · · · · · · · · · · · · · · ·	PHOENDX CONTACT	HSTB 2,5/20-ST-5.08	+	
1 1	421 (LOWERLEACH) SOUR FORE PUBER SUFFLT	, DASAN	USINCON- IN-SUA	+		85	\vdash		 		+ -		-	6	DISCONNECT TER		PHOENIX CONTACT	UNSTBVK2,5/20-G-5.08	+	•
2				H		86	+		 		+ -		51	$\overline{}$		MANUEL DE DECENO	PHOENIX CONTACT .	K6S-MSTB2.5/20	-+	·
23		ļ		\ \ \		87	1	-	 		E			6	CABLE HOUSING		FOUCHA CUITACT	NG3-1310 <i>L3/ L</i> 8	-	
4	NOT USED	· · · · · · · · · · · · · · · · · · ·		1		88	-	-	1		E		152	\vdash	NOT USED	A LANG IMPORTATION OF THE PARTY	MOONE AMERICA	EFT/1 94-1/1 44-1	\longrightarrow	
5	NOT USED			1		89	ऻ	ļ	 		E		53	7		S - 2 WIRE IMPUT LOOP POWERED	MOORE INDUSTRIES	ECT/4-20mA/4-20mA		
26 1	Q30 RTU POWER SUPPLY CIRCUIT BREAKER	TERASAKI	DTCB6104C	1:1		99	<u> </u>				E		54		NOT USED			·		
7 1	031 SURGE DIVERTERS RELAY CIRCUIT BREAKER	TERASAKI	DTCB6104C			91	1	LR3- WET WELL HIGH LEVEL RELAY	MULTITRODE	MTR-S	-	24VDC	155		CODING PINS		PHOENIX CONTACT	CP-HSTB + CR-HSTB	-	•
19 1	Q32 FLOWHETER CIRCUIT BREAKER	TÉRASAKI	DTCB6104C	Н		92	1	LR4- FLOWNETER PIT HIGH LÉVEL RELAY	MULTITRODE	MTR-5	a	24VDC	154	1	ANTENNA MAST		SWBO BUILDER	SHEET 22	R	LENGTH = GHTRS
9 1	Q33 SPARE	TERASAKI	- DTCB6104C	-		93					D	•	167	1	COAX CABLE IN	ERHAL)	r.f. Industries	RGI	R	
10	NOT USED					94	1	SIR - SURCHARGE PHONENT LEVEL RELAY	MULTITRODE	MTR-2	-	240VAC	158	1	(OAX CABLE (E)	(ERHAL)	r.f. noustries	RG213	R	
1 1	Q.4-1 PUMP1 CONTROL CIRCUIT BREAKER	TERASAKI	DTCB6186C			95	3	SINGLE POINT PROBES	MULTITRODE	. 0.2/2-'x' (2 core)	-	'x' = CABLE LENGTH TO SUIT	159	1	COAX PLUG		R.F. INDUSTRIES	SMA	R -	
12 1	QS-1 PUMP2 CONTROL CIRCLIT BREAKER	TERASAKI	DTCB6106C	1 -		%	1	EMERGENCY PUMPONS MODE RELAY PUMP1 - EMS1	IDEC	RH2B-UL-24VDC			150	1	COAX PLUG		R.F. INDUSTRIES	NSS (MALE)	R	
13				E	-	97	1	SURCHARGE INNIXENT DELAY TIMER - SIDT	SPRECHER & SCHUH	RZ7-FSA 3E - U23	- 1	ON DELAY 0.05-60sec	161	1	(OAX PLUS		R.F. INDUSTRIES	NO7 DIALE)	R	
4	NOT USED					98	1	EMERGENCY PUMPING HODE TIMER - EMGOT	SPRECHER & SCHUH	RZ7-F58 4U - UZ3	-	OFF DELAY 0.05-60hr	16.2	1	U CLAMPS		R.F. PIDUSTRIES	LINY	R	
15				F	•	99	1	EMERGENCY PUMPINS HODE TIMER PUMP2- EMG2	SPRECHER & SCHUH	RZ7-FSA 4U - U23	-	ON DELAY 0.05-601s	163		NOT USED					
16 1	DISTRIBUTION BOARD CHASSIS	TERASAKI	CD-2-24/18-3U	1.		100	2	EHERGENCY PUHPING HODE SWITCH - SS	SPRECHER & SCHUH	07P-LSH25-PX20	1 - 1	ENGRAVE 'OFF ON'	164		SWITO	BOARD TERMINALS				
7 3	F1 - SURGE DIVERTER CIRCUIT FUSES	KHP	ZME6 PMAE6	1.1	FUSES & HOLDERS	101					F		164.1	Lot	FUSED TERMINA	S with LED 24V INDICATION	PHOENIX CONTACT	UT 4-HESI LED24 (5x20)	-	
8 3	SURGE DIVERTER	CRITEC	TDS-150-25-277	1 -		192	1				F		164.2	Lat	FUSE CARTRIDG	S	PHOENIX CONTACT	M205	-	ATINGS AS REQU
9 1		CRITEC	DAR-275V	1.		193	1				F		164.3	Lat	DISCONNECT TE	THALS	PHOENIX CONTACT	UT4-HT P/P	-	
0 1		CRITEC	TDF-10A-240V	١.		104					F		164.4	4	EARTH TERMINA	<u>s</u>	PHOENIX CONTACT	UT4-MTD-PE/S	- 1	
1 1		CROMPTON INSTRUMENTS	252-PSGW	┪.		195	+	-			F		164.5	8	GROUP MARKER	ARRER	PHOENIX CONTACT	UBE	-	
2	NOT USED	CKOTF TON INSTRUMENTS	224-30#	1		106	1		 		F		164.5	2	TEST PLUG ADA	TOR	PHOENEX CONTACT	PS-6	- 1	
3 1		CROMPTON DISTRUMENTS	2S2-PSGW	1.		197	+-		 		F		164.7	_	SCREW DRIVER		PHOENIX CONTACT	SZS 0.6 x 3.5	- 1	
* .		CKOULE ION IN 2 I KOULEN 12	ZZ-PSQW	╁╌┤		198	┼		 		F		164.0		PLUG-IN BRIDGE		PHOENDX CONTACT	FBS	 	AS REQUIRED
4	NOT USED .					<u> </u>	-						164.9	LOI	PUUG-M OKIDGE		FINGERA CONTACT	100	- +	- ALEGED
5 1	MAIN NEUTRAL LINK	D&L ELEC	DLAH12	1	ansulated .	109	+				F		P -3	<u> </u>					\vdash	
6 1	MAIN EARTH LINK	DAT ETEC	DLAHE12	1-		110	ļ			<u>.</u>	F		\perp						 	
7 1	DIST. BD NEUTRAL LINK	D&L ELEC	2DLA24	1-1	INSULATED .	m	-		ļ		F		165		CORROSION INHO		CORTEC	VPCI-119 OR 111		ROH AP CONTRO
8 1	DIST. BD EARTH LINK	DAY ETEC.	2DLAE24	1:1		112	+		<u> </u>		F		166	Lot		AT SEALING BUNGS	RUBBER	TO SUIT CONDUITS		Detal W
9				$oldsymbol{ol}}}}}}}}}}}}}}}}}}$: 18	<u> </u>				F		167	ļ	NOT USED			ļ	Щ	
0 1.	_ INSTRUMENT_EARTH LINK	D&L ELEC	OLBE12	. •	INSULATED	114.		NOT USED			1		168	_ 1	ENERGEX PADLO	X - 45mm brass pin humbler	H.A. REED LOCKSHITHS	KEY No 325	_ :_	c/w 2 KEYS
1 1	RTU FILTERED SUPPLY NEUTRAL LINK	CLIPSAL	L7	[-	RISULATED	15	1	GRAPHIC DISPLAY	REDLION	E306C000	<u>L-</u>]		169		NOT USED					•
2 1	3 PHASE SWITCHED OUTLET	CLIPSAL	560532	-	USE ENCLOSURE AS SHROUD	11.6		NOT USED					170	Lot	S/STEEL FITTIN	S AS DETAILED FOR PRESSURE TX	FITTINGS	STAMLESS STEEL	U	Sheet 19
3 1	1 PHASE OUTLET ISA	CLIPSAL	15/15+908 (SHROUD)	1.1		117	1	SW/80 LIGHTING CONTROL RELAY - SLCR	IDEC	RH28-UL-24 VDC	-		171	1	EARTH ROD CON	ECTION BOX	NESCO	ERB1	[-]	
4 1	RTU LAPTOP GPD	CLIPSAL	15+449A+449AP	 		118	1	STATION LOCAL/REMOTE SWITCH - S%	KRAUS & NAIMER	CAD11	-	ENGRAVE 'LOCAL REMOTE'	172	1	LINE TAP - BON	ING TO EARTHING ROD	CLIPSAL	BP26	-	
5 1	1 PHASE OUTLET - GENERATOR AUX POWER	CLIPSAL	5650310	M	P56	119	1	ELECTRODES TEST RELAY - ETR	IDEC	RH48-UL-24VDC	-		173	1	EARTHING ROD		COPPER ROD	Ban Okneter	- 1	
5 1	3 PHASE NEE APPLIANCE BLET - GENERATOR POWER	MENONEKES	ME)G68	H	C/W PROTECTIVE CAP 40788	120	+	WETWELL WASHER AUX RELAY - WWR	IDEC	RH28-UL-24 VDC	P		174	1	P67 JUNCTION E	DX - FOR F/HETER SUMP PUMP		To Suit Installation	a	
7 1	3 PHASE N&E CONNECTOR - GENERATOR POWER	MENNEKES	MEN1454	н		121	+	WET WELL LEVEL INDICATOR		244-01KG-H6-IP-SR 4-20mA	(<u>. </u>	8-199% ADJ RED PORTER	175	 	NOT USED					
8 13		CAMSCO	SH202	+:-	13 OFF N/D	122	-	NOT USED		:	+-		176		NOT USED				П	
9 7	SW/BD 8W INTERNAL FLURO LIGHTS	THORN	B80108	+		123	+	VSD CUBICLE VENT FAN	RITTEL	3326.607	1	360H3/Hr	لت					L		· · · · · · · · · · · · · · · · · · ·
				E299-77	-CA-80'	121		CUBICLE FAN THERMOSTAT	18HP	5326.607 FZK01100	+-	360F3/Hr 10 - +60°C								
0 Z	PUMP VARIABLE SPEED DRIVES	DANFOSS	Model No: FC202P30KT4	K / MIXIGU	IX-DEDIXAXBY CETEROX	125		NOT USED	NAP .	LTVAIMA	+-	10 - 700 L						06-	_ 1	A A
2	REMOTE KEYPAD HOUNTING KIT	DANFOSS	3081107	╁╧					 		₩					ELECTRICAL AS BUI	IT CERTIFICATION	Shee	Jŧ	14
2 2	SPEED POTENTIONETERS 1κΩ TW1 Turn	XI-P	DTP-POT3	\vdash	c/⊌ lkΩ fW1 Tum POT.	126	+	HOT USED	 		╁	<u></u>					CHARDSON			
3 2		SPRECHER & SCHUH	CA7-85	1	-	127			 		S	· · · · · · · · · · · · · · · · · · ·				C CONTRACTOR LICENCE	• •	AS BUIL	Т	
4 2	PUMP CONTROL (CT POWER ON RELAY - K2	DEC	RHZB-UL-240VAC	<u> </u>		128	<u>Щ</u>		<u></u>		S						UYTER OATE: 6/9/2008	70 001		
		211 4 141			ORAFTED P.H	AGUE		Original Signed by A.WITTHOFT	21.06.07 Orig Signed b	y F.FORNASIER 27.08.07	· ~ —	1 Verre			-:-	YTITLE	——————————————————————————————————————	SHEET No. 14		
	-ISSUED FOR TENDER	P.H. A.W. THIS DRAY	WHICH OR PART THEREOF IS PROTECTE	D BY THE	P.H	7002		· · · · · · · · · · · · · · · · · · ·	21.08.07	y F.FURNASIER 27.06.07	1	65426				EOUDDARS 1	ST 1	SHEET NO. 14	_	
7 RE		P.H. A.W. REPRODUC	COPYRIGHT AND HAY NOT BE COPYED ED VITHOUT THE EXPRESS PERMESS	D BY THE COR COR COF		/ITTHOP	т	DESIGN R.P.E.Q. No.		DESIGN MANAGER DATE	- 1	SP126	ROAL)		EQUIPMENT LIS	ST	BRISBANE WATER DRAWIN	G No.	014


CABLE No.	STATUS (Note 2)	SIZE	CORES	TYPE	LENGTH (m)	FROM	ТО	CABLE FUNCTION	NOTES	
P01	EXISTING	50mm²	4C+E	PVC/CU/PVC		ENERGEX Supply Pillar	Switchboard	Incoming Mains Supply		•
P02	EXISTING	16mm²	10	Building Wire		Switchboard	Earth stake	Main Earth		
P03	 	-							Reserved - Generator Supply	
P04		-			1				Reserved 240VAC gen supply	
P05		-							Reserved Pump 1	
P06		-							Reserved Pump 1	
P07	EXISTING	16mm²	3C+E+2plots	Screened Flexible (Submersible)		Switchboard	Pump No1	Pump 1 Mator Feed +Thermistors		
		-				_				
P08		-							Reserved Pump 2	
P09		-							Reserved Pump 2	•
P10	EXISTING	16mm²	3C+E+2plots	Screened Flexible (Submersible)		Switchboard	Ритор №2	Pump 2 Motor Feed +Theraistors		
							·			
P11		-							Reserved Dry Well Sump Pump	
P11A		-							Reserved Dry Well Sump Pump	
P12		-							Reserved Pump Well Lighting	·
PB		-							Reserved Pump Well Vent Fan	
. P14	NEW	2.5mm²	2C+E	PVC/CU/PVC		Switchboard	F/Meter Pit Sump Pump Junction Box (IP67)	F/Meter Pit Sump Pump Motor		
P14A	NEW	2.5mm²	2C+E	Vendor		F/Meter Pit Sump Pump Junction Box (IP67)	F/Meter Pit Sump Pump	F/Heter Pit Sump Pump Motor		NOTE:
P15		-							Reserved Odour Control Unit	
P16		-							Reserved Chemical Dosing Unit	1. THE CONTRACTOR IS RESPONSIBLE IN DETERMINING THE ACTUAL CABLE LENGTHS REQUIRED ON SITE.
CO1		-							Reserved Pump 1 MIO probe	2. USE EXISTING CABLES IF SIZE & CONDITION IS ADEQUATE
CO2	T	-							Reserved Pump 1 MIS probe	2. USE EXISTING CABLES IF SIZE & CONDITION IS ADEQUATE FOR NEW LOADS & FUNCTIONS. OTHERWISE SUPPLY & Install New Cables. Type & Size as per this schedule
C03		-							Reserved Pump 1 B.Temp RTD	
C04		-		······································					Reserved Pump 1 relux I/s	
COS		-							Reserved Pump 2 MIO probe	
(06		-						· ·	Reserved Pump 2 MIS probe	
C07		-							Reserved Pump 2 B.Temp RTD	
(08	1	-							Reserved Pump 2 relux L/s	
CO9	NEW		20	Vendor- 0.20130FSP	25ntrs	Switchboard	Wet Well High Level Probe	Wet Well Level Signal (LR3)		· ·
		-				···· ·· · · · · · · · · · · · · · ·			Reserved Remote LR3 Terminals	
C10	NEW		20	Vendor- 0.20 B0FSP	25ntrs	Switchboard	Surcharge Imminent Probe	Surcharge Imminent Signal (SIR)		_
		-							Reserved Remote SIR Terminals	
. (11		-							Reserved Dry Well Trip Level	•
C12		-							Reserved Dry Well Alarm Level	
C13A		-		,				·-	Reserved Sump Pump level	
C13B		-							Reserved Sump Pump Level	·
C14										<i>,</i>
C15	1	-							Reserved Generator controls	
C16	NEW	15mm²	20	PVC/PVC		Switchboard .	Cathodic Protection Anode	Anode		
C17	NEW		20	Vendor- 0.20130FSP	30ntrs	Switchboard	Flowmeter Pit High Level Probe	Flowmeter Pit High Level Signal [LR4]		
C18		-		,					Reserved Pump 1 Lockout	
C19		-							Reserved Pump 2 Lockout	
C20		-			<u> </u>				Reserved Dry Well Alarm Strobe	1
(21	1	-	1.						Reserved Odour Control Unit	1
C22		-			†				Reserved Manhole Surcharge	1
101	- NEW		· .	Vendor	25mtrs	- Switchboard	Wet Well Hydroscopic Level Sensor	Primary Wet Well Level		
	<u> </u>	•		*					Reserved Remote Mount TX	· ·
102	NEW		l	Vendor	25ntrs	Switchboard .	Delivery Pressure Transmitter	Delivery Pressure		
103			-			· · · · · · · · · · · · · · · · · · ·			Reserved Emstorage level	
104	NEW		<u> </u>	Vendor	Sontrs	Switchboard	Delivery Flowmeter	Flowmeter Sensor Power Supply		1
104A	NEW			Vendor	50ntrs	Switchboard	Delivery Howmeter	Flowmeter Signals		<u> </u>
								<u> </u>	Reserved Ultrasonic Level	1
									Reserved Ultrasonic Level	1
106	NEW	0.75mm²	1Pr	Dekaron	 	Switchboard - RTU	Switchboard - Pump 1 Soft Starter	RS485 Contras	Overall Screened Twisted Pair	·
107	NEW	0.75mm²	1Pr	Dekaran		Switchboard - Pump 1 Soft Starter	Switchboard - Pump 2 Soft Starter	RS485 Corums	Overall Screened Twisted Pair	
108	NEW	0.75mm	1Pr	Dekoran		Switchboard - Pump 2 Soft Starter	Switchboard - Graphic Display	RS485 Corams	Overall Screened Twisted Pair	Sheet 15
109	1	-	<u> </u>		† . †				Reserved Chemical Dosing Unit	ELECTRICAL AS BUILT CERTIFICATION STIECE 13
X01	NEW		 	Vendor		Switchboard - Radio	Aerial Coax Surge Protector	Radio Communications		REV COMPANY J&P RICHARDSON
X02	NEW			Vendor	1	Aerial Coax Surge Protector	Aerial	Radio Communications		C CONTRACTOR LICENCE No. 756
RE-ISSUED F		FR	P.H. AW		Y 700					CERTIFIED BY M. DEROTTER DATE: 6/9/2008
AS BUILT	UN TEND	L-P	P.H. AW	I AND OF CORVENSAT AND MAY NOT BE CO	PED OR DR	AFTING CHECK AWITTHOFT DESIGN	•	∰ _ SP1	26	TITLE CABLE SCHEDULE SHEET NO. 15 BRISBANE WATER DRAWING NO.
SSUED FO	R CONST	RUCTION	P.H. A.W	ERISBAIE VATER C 2006	CA			ned by P.SHERRIFF 26.06.07	JNGS ROAD VAGE PUMP STATION	486/5/7-0039-015
			DRN, APO.			C.C. FILE No. DESIGN CHEC		BRISBANE		(争のロ/ン// *いいつぎり 1つ


H # OP	T. DESCRIPTION	LABEL 1	LABELS 2 & 3 (F NECESSARY)	TEXT HEIGHT	MATERIAL / COLOUR	ITEH 0	OPT. DESCRIPTION	LABEL 1	LABELS 2 & 3 (F NECESSARY)	TEXT HEIGHT	HATERIAL / COLOUR	ITEM # OI	T. DESCRIPTION .	LABEL 1	LABELS 2 & 3 (IF NECESSAR	Y) TEXT HEIGHT	
, N	KETERING ISOLATOR	CT HETERIKS ISOLATOR ONLY		10aa	ABS PLASTIC							149	RTU DISCONNECT PLUG	PLUS No??		Les	ABS PLASTIC
2	DIERGEX SUPPLY	NORMAL SUPPLY MAIN SWITCH		ion Van	ABS PLASTYC				· 			54	RTU DISCONNECT TERMONAL BLOCKS	PLUS No??		ien	ABS PLASTIC
		160A GENERATOR SUPPLY HAIN SWITCH		¥an Waa	ABS PLASTIC	-	NO. 2011 CHARLES 47 1			 	ABS PLASTIC				-		W/8
3	GENERATOR SUPPLY	160A	DINO N. 3	ina .	B/W	74	PUMP RUN COMMAND RELA	9020	21/25	- tem	ABS PLASTIC			 			ABS PLASTIC
4/05	PUMP CIRCUIT BREAKER	PUMP No1 130A	PUMP No.2 100A	ione ion	ABS PLASTIC W/B	75	PUMP FAULT RESET RELAY	R21	2K21	400	W/B	53	SIGNAL ISOLATOR	10	ZI.	i i i i i i i i i i i i i i i i i i i	W/B
						76	PUMP EMERGENCY MODE ON	RRUPT RELAY 18722	20022	i-em	ABS PLASTIC W/B	1 1					
,	PHASE FAILURE CIRCUIT BREAKER	ENERGEX PHASE FAILURE CB	FED FROM LINE SIDE OF MAIN SWITCH	i en	ABS PLASTIC W/8 - R/W	77	PUMP 'RUN AT HAX' RELA	1623	2023	i.nn	ABS PLASTIC		TERHINAL HEADER	RTU POWER Supplies		4en	ABS PLASTIC
8		07	OF HAM SWITCH	4723	W/8 - R/W	78	PUMP START PUSHBUTTO	START	START	i,em	ABS PLASTIC		TERMINAL HEADER	DIGITAL INPUTS	DIGITAL INPUTS	4en 4en	ABS PLASTIC
-+		SUB-DISTRIBUTION BOARD		400	ABS PLASTIC	<u> </u>				 	ABS PLASTIC	-		DIGITAL NAPUTS	012		ABS PLASTIC
,	SUB-DISTRIBUTION BOARD CB	63A · `]		éan Lea	W/8	79	PURP STOP PUSHBUTTON	STOP	. STOP	ies	W/B		TERMINAL HEADER	DB DIGITAL OUTPUTS	DIGITAL OUTPUTS	4m 4m	ABS PLASTIC
•	PHASE FAILURE CIRCUIT BREAKER	STATION PHASE FAILURE CB Q10		im.	ABS PLASTIC W/8	80	TTUBHRUP POTATE PHUP	EMERGENCY STOP	EMERGENCY STOP	4600	ABS PLASTIC Y/B		TERHINAL HEADER	001	DO2	- 480 480	W/8
	3 PHASE OUTLET CIRCUIT BREAKER	39 OUTLET		· ima	ABS PLASTIC	B	PUMP RESET PUSHBUTTON	FAULT RESET	FAULT RESET	i,em	ABS PLASTIC W/B		TERMINAL HEADER	ANALOG NPUTS All	·	4en 4en	ABS PLASTIC
-	1 PHASE DUTLET CIRCLIT BREAKER	19 GPO	<u></u>	i inn	ABS PLASTIC	12				+	1 */0	 	· · · · · · · · · · · · · · · · · · ·	 	 		 ""
		Q12 RTU LAPTOP 6P0	· · · · · · · · · · · · · · · · · · ·	inn inn	ABS PLASTIC	"			_	 	+			NON FILTERED		60a .	ABS PLASTIC
3	RTU LAPTOP CROUIT BREAKER	013		im	W/B							ļĻ	HEADER LABEL (Above Graft Breakers)	SUPPLY FILTERED	<u> </u>	6ma	W/8
				<u> </u>	i l				1		1 1		HEADER LABEL (Above Circuit Breakers)	SUPPLY		- 6nm	ABS PLASTIC W/B
													HEADER LABEL (Incorner Section)	HEN BEI WO		600	ABS PLASTIC
+	SWITCHBOARD LIGHTING CIRCUIT BREAKER	SWITCHBOARD LIGHTING		400	ABS PLASTIC		- 		- 	†	 						 ""
-		Q16 RTU SURGE FALTER		im im	W/B ABS PLASTIC	\vdash			 	+	+		+	+	-		+
<u>'</u>	RTU SURGE FILTER CIRCUIT BREAKER	017		im.	W/B		1						<u> </u>		 		
•	EM PUMP CONTROL & SIR CIRCUIT BREAKER	EN PUNPING CCT & SIR OIS		ien	ABS PLASTIC W/B						<u>i </u>		<u> 1</u>		<u></u>		
,	GENERATOR ANGLLARY SUPPLY CB	GENERATOR ANGLLARY SUPPLY		i an	ABS PLASTIC								GENERATOR INTERFACE TERMINALS	GENERATOR Interface	1	4en 4en	ABS PLASTIC
	,	CATHODIC PROTECTION	<u> </u>	Len	ABS PLASTIC	91	LET UPLI DELL'ORI CO	, WET WELL		480	ABS PLASTIC	 	PUMP CONNECTIONS	PURP No1	PUNSP Nes2	5ca	ABS PLASTIC
0 K	CATHOOIC PROTECTION POWER SUPPLY CB	020 F/HETER PIT SUMP PUMP		- tem	W/B	\vdash	WET WELL HIGH LEVEL RE	HIGH LEVEL - LES		4en	W/B ABS PLASTIC			BUSBAR LIVE WHEN SWITCHBOARD	I SIN PAGE	460	ABS PLASTIC
1 0	PLOWHETER PIT SUMP PUMP POWER SUPPLY CO	021		ian ian	ABS PLASTIC W/B	92	Q PLOWMETER PIT LEVEL RE	Y HIGH LEVEL - LR4		580 580	AND PLASTIC		Z GENERATOR BOLITED CONNECTIONS	ENERGISED FROM GENERATOR		400	R/W
.											1			1			
\neg	1	·		<u> </u>		94	SROWRGE INDICENT LEVE	RELAY WET WELL SURCHARGE		460	ABS PLASTIC		GLAND PLATE LABEL (TTTTT Section)	SPARE CONDUITS BELOW FOR FUTURE INSTALLS		623 603	ABS PLASTN
	 			 	 	<u> </u>		Interest - SR		400	ABS PLASTIE		PUMP INFORMATION LABEL	SP126 YOUNGS ROAD	 	(en	ABS PLASTI
\dashv	-			1		. %	EMERGENCY PUMPING HOD		<u> </u>	i i i i i i i i i i i i i i i i i i i	ABSPLASTIC		Label size to be approximately	PUMPS ZONE 77 DIPPELLER 777		-	₩/B
	<u></u>		•	ļ <u>.</u>	<u> </u>	97	SURCHARGE IMMENT ON	AY TIMER SØT		l,ess	W/B:		150:250	DPELLER TT			_L
6	RTU POWER SUPPLY CIRCUIT BREAKER	RTU POWER SUPPLY 030		ien ien	ABS PLASTIC W/B	98	EMERGENCY PUMPING MOD	FF CELAY THER EMGDT		i em	ABS PLASTIC W/B			·			
,	SURGE DIVERTER RELAY ORCUIT BREAKER	SURSE DIVERTER RELAY		ien	ABS PLASTIC	99	EMERGENICY PUMPING HOD	UMP 2 TIMER EH62		i,em	ABS PLASTIC		•			*.	
9 H	PLOWNETER CIRCUIT BREAKER	FLOWHETER		100	ABS PLASTIC	100	EMERGENCY PUMPING HOD	TART SUTTON EMERGENCY	EMERGENCY	4ma	ABS PLASTIC						
		Q32 SPARE	1	ion ion	ABS PLASTIC		CERCENCI POPPED ROO	PUMPING HODE	PUMPING HODE	- 4em	W/B						
,	SPARE CIRCUIT BREAKER	. 033	Calhab N. 3	4em	W/B					+	1			EXTERNAL LABEL L	.I <u>ST</u>		
1/32	PUMP CONTROL CIRCUIT SREAKER	PUMP No1 QL-1	PUMP No2 05-1	Len Len	ABS PLASTIC W/B											-	
			,								,		LABEL	TEXT	TEXT PANT RLL	SEZE QTY OF	PT
		 			†								541		TEXT PAINT FILL HEIGHT LETTERING	-	<u>`</u>
	+									+	 		A SP126		20mm Black	10 ft 35 1	
		CIDELUMENTED CIRCL	EEU COVM I HRE CLVE	<u> </u>	ABS PLASTIC		· ·			+			B RTU		10ma Black	58x29 1	7
'	SURGE DIVERTER FUSES	SURGE DIVERTER FUSES 63A	FED FROM LINE SIDE OF MADN SWITCH	ien ien	W/B - R/W					ļ			C PUMP CONTROL		10mm Stack	1201/20 2	
.	SURGE DIVERTERS	LIGHTHONG ARRESTORS	FED FROM LINE SIDE OF MAIN SWITCH	ion ion	ABS PLASTIC W/B - R/W				1		1				 		⊣
,	SURGE DIVERTER ALARM RELAY	SDAR	INVITABILMI	ica	ABS PLASTIC						•		D WARNING . THIS SITE IS HONTORED BY METW	YORK CONTROL	Steps Stack	254x100 2	
		RTU SURGE		ien.	ABS PLASTIC					+	+		PLEASE INFORM THE OPERATOR B	REFORE ISOLATING PUMPS OR STATION	+		_
•	RTU SURGE REDUCTION FALTER	REDUCTION FILTER ENERGEX HAIRS	FED FROM LINE SIDE	i eza	W/B ABS PLASTIC			`		+	+		E PLEASE CHECK THAT THE STATIO BEFORE LEAVING SITE	IN IS IN REHOTE MODE	Stean Stack	2190:54 1	
<u>' </u>	PHASE FAILURE RELAY	POWER FAIL - PERE	OF MAIN SWITCH	ien.	W/B - R/W	-				 			E COMMON CONTROL		19am Black	120x24 1	\dashv
1															 		
3	PHASE FAILURE RELAY	STATION HAIRS POWER FAIL - PERS		ian ian	ABS PLASTIC W/B	117	SWITTHBOARD LIGHTING C	TROL RELAY SLOR		les	ABS PLASTIC W/B		G METERDAG ISOLATUR		10esa (Stack	120x20 1 1	" —
5	MAIN NEUTRAL LINK	HAR NEUTRAL		4400	ABS PLASTIC	118	STATION LOCAL/RENOTE S	ECTOR SWITCH STATION CONTROL MODE	1	i (con	ABS PLASTIC		H METERING CT's		10mm (Nack	1001/20 1 1	N_
			<u> </u>		W/B ABS PLASTIC	179				+	ABS PLASTIC		I HAIN SWITCHES		10ma Black	120:20 1	7
•	HAIN EARTH LINK	MAIN EARTH		4400	W/B		ELECTRODES TEST RELAY	ETR	<u> </u>	i i i i i i i i i i i i i i i i i i i	ABS PLASTIC		J DISTRIBUTION BOARD		then Black	158x24 1	\neg
7	SUB-BOARD NEUTRAL LINK	MEUTRAL		4400	ABS PLASTIC W/B	128	P WETWELL WASHER AUX R	AY WWR		i i i	W/B		- SISTEMATION GONED		+		
•	SUB-BOARD EARTH LINK	EARTH		4em	ABS PLASTIC W/B	121	WET WELL LEVEL MOICAT	. WET WELL LEVEL		ien	ABS PLASTIC W/B				 		\dashv
,	SURCE DIVERTER EARTH LINK	EARTH		i i i i i i i i i i i i i i i i i i i	ABS PLASTIC						T :::*		L GENERATOR CONNECTIONS	·	(Pera Black	1881:26 1 F	F
	 			+	ABS PLASTIC	\vdash		- 		+	+		N PUMP ? VSD		10zza Black	80x20 2	
•	INSTRUMENT EARTH LINK	INSTRUMENT EARTH		4en	W/B						_		N GENERATOR DILET		10mm Black	.120×20 1 F	F
1	RTU FILTERED SUPPLY NEUTRAL LINK	FILTERED SUPPLY NEUTRAL		i en	ABS PLASTIC W/B				<u> </u>						 		
-	LAPTOP GPO	LAPTOP GPO		4an	ABS PLASTIC W/B								O BATTERES		10 eca (Stack	B0x20 1	
5 H.	GENERATOR 248VAC CONNECTION SOCKET-	GENERATOR		- im	ABS PLASTIC				:				P SUPPLY AUTHORITY METERING		10ma Black	2007.20 1	
		AUX SUPPLY GENERATOR		(ma	ABS PLASTIC		-			_	ABS PLASTIC		Q. DANGER 415V		19mm Black	199×29 4	
6 H	GENERATOR POWER CONNECTION SOCIET	CONNECTION		6mm	W/B	129		CATHODIC PROTECTION UNIT		Hess	W/B ABS PLASTIC		R DANGER - 2 SOURSES OF SUPPLY	 	19aca Red	720x20 1	\neg
		<u> </u>		<u>L</u>	<u> * </u>	132	H DELIVERY FLOWNETER TR	SMITTER DELIVERY FLOWNETER		4400	I ₩/B I		·	<u></u>	 		
	PUMP VARIABLE SPEED DRIVE	PUNP No1	PUMP No2	(con)	ABS PLASTIC	133	WET WELL LEYEL ADJ. UN	PRIMARY WET WELL LEVEL	PRIMARY WET WELL LEVEL	ien	ABS PLASTIC W/B		S PUMP CONNECTIONS .		19sta Black	150x20 1	_
\top	PUMP VSD KEYPAD	PUNP No1	PUMP No2	680	ABS PLASTIC								EXTERNAL LABELS 1000 THUCK 31 FIXED WITH HB 314 STAINLESS ST	IS GRADE STAINLESS STEEL Tet netal threads			
	<u> </u>				ABS PLASTIC	97	II NE APPRO PROPERTY			iae	ABS PLASTIC				·		
·	PUMP MANUAL SPEED CONTROL	A20 25EED	A20 25EED	6ea	W/8		U DELIVERY PRESSURE AD A	070140/000			ABS PLASTIC :			<u>Detail Q</u>			
1	E/STOP CONTACTOR	1K1	, 2 K1	ion.	ABS PLASTIC W/B	139	RTU 248YAC/Z4VDC POW	SUPPLY POWER SUPPLY		4en 4en	W/B						
,	PUMP CONTROL CCT POWER ON RELAY	162	202	ien.	ABS PLASTIC W/B	14.0	R RADIO 244/13LBVDC CONV			4en	ABS PLASTIC W/B						
; -	VSD RUNORDIG RELAY	163	21/3	ian.	ABS PLASTIC			PRINTING - HUMB			<u> </u>			•			
		<u> </u>		+	W/B ABS PLASTIC	11.7	R RADIO	RADIO		469	ABS PLASTIC			•			
	PUMP INTERLOCKING RELAY	TK4	2%4	ian .	W/B				-+		ABS PLASTIC						4 0
<u>' </u>		<u> </u>				14.5	R RADIO COAX SURGE PROTI	TIGN RADIO SURSE PROTECTION		i,es	W/8				Sh	eet 1	1ら 1
- 1				1		144	TÉLÉHETRY UNIT	RTU		in.	ABS PLASTIC W/B		FIECTOR	CAL AS BUILT CERTIFICA	ATION LINOITA		10
			_		 								REV COMPA				
+	•			+	\vdash					+	1			ACTOR LICENCE No. 756	1 40	BUILT	
	•	. 1				1	 	1	I	1	ı 1			LED BY M. DERUYTER DATE	: 6/9/2008 J	DUILI	<u> </u>
		L		<u> </u>									€ I CERTIF	TED BY M. DC. CO			
7 85	ISSUED FOR TENDER		DANIMA NO PART TERROR IS RECOGNIS	V DE YORA	FTED D	IAGUE	Original Stoned by 4	/TTHOFT 21.08.07 Y Odo	Signed by F.FORNASIER 27.09.07	ΥÄ	SITE		TITLE				
	ISSUED FOR TENDER	P.H. A.W. REPRO	RANGIS OR PART THEREOF IS PROTECTED IS OF COPYRIGHT AND HAY NOT BE COPIED OR DUCED WITHOUT THE COPIESS PERMISSION			AGUE VITTHOFT	Original Signed by A	• ·	Signed by F.FORNASIER 27.06.07	I ≝	SITE SP126		TITLE SWITCH	-BOARD	SHEET No. 18	TER ORAWING No.	
8 AS	ISSUED FOR TENDER BUILT	P.H. A.W. REPRO	OF COPYRIGHT AND MAY NOT BE COPIED OR DUCED WITHOUT THE EXPRESS PERMISSION (ANE WATER	OF DRA	UFTING CHECK ALV	AGUE VITTHOFT	DESIGN	R.P.E.Q. No. DATE PRIN	Signed by F.FORNASIER 27.06.07 ICIPAL DESIGN MANAGER DATE and Signed by P.SHERRIFF 28.06.07		YOUNGS		TITLE SWITCH		SHEET No. 18 BRISBANE WA	TER DRAWING No.	016














Q-Pulse Id TMS942