| | | | |
|---|---|---|---|
| **DESCRIPTION:** | Mechanical – Beaudesert Raw Sludge Thickening Mixer lube | **FREQUENCY:** | |
| **LOCATION:** | Various Locations | **STANDARD JOB No.:** | |

| | |
|---|---|
| | |
| | **Reference Material** |
| | |
| | |
| | |
| | |
| | |
| | **Procedural Steps** |
| | **Before isolating any equipment where possible observe in running condition. Check for correct operation.** |
| | |
| | |
| | **Minor Service** |
| | Visually inspect Sludge Balance Tank Mixer gear unit. Check the oil level. |
| | Check the oil level. |
| | Apply single shot of grease to Sludge Balance Tank Mixer |
| | |
| | |
| | **Intermediate Service** |
| | Change the Sludge Balance/Floccuation Tank Mixer gear unit oil. |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |