DESCRIPTION:	6 Monthly Zone 2 Lubrication Maintenance	**FREQUENCY:**	6 Monthly
LOCATION:	ST18 Luggage Point WRP	**STD JOB ID:**	LTS025

	Grease and Oils Required	**Maintenance Group**
	Castrol AP3 Grease	Ethanol Dosing Facility
	Castrol Mollub Alloy 936SF Open Gear Grease	WAS Pumps
	Castrol EPX 80W-90 (Spirax 80W 90)	
	Castrol Optileb WOM 14	
	Procedural Steps	
	Ethanol Dosing Facility	
	Apply 2 shots of AP3 to each grease nipple on Unloading pump	
	Check Dosing Pumps oil level. Top up with EPX 80W-90 if required.	
	WAS Pump 1	
	Check pump oil level. Top up with Optileb WOM 14 if required.	
	Grease manual knife gate valve spindles with Mollub Alloy Open Gear Grease	
	Remove coupling guard and check condition of couplings and rubbers.	
	WAS Pump 2	
	Check pump oil level. Top up with Optileb WOM 14 if required.	
	Grease manual knife gate valve spindles with Mollub Alloy Open Gear Grease	
	Remove coupling guard and check condition of couplings and rubbers.	
	WAS Pump 3	
	Check pump oil level. Top up with Optileb WOM 14 if required.	
	Grease manual knife gate valve spindles with Mollub Alloy Open Gear Grease	
	Remove coupling guard and check condition of couplings and rubbers.	
	WAS Pump 4	
	Check pump oil level. Top up with Optileb WOM 14 if required.	
	Grease manual knife gate valve spindles with Mollub Alloy Open Gear Grease	
	Remove coupling guard and check condition of couplings and rubbers.	

DESCRIPTION:	6 Monthly Zone 2 Lubrication Maintenance	**FREQUENCY:**	6 Monthly
LOCATION:	ST18 Luggage Point WRP	**STD JOB ID:**	LTS025

	WAS Pump 5
	Check pump oil level. Top up with Optileb WOM 14 if required.
	Grease manual knife gate valve spindles with Mollub Alloy Open Gear Grease
	Remove coupling guard and check condition of couplings and rubbers.
	WAS Pump 6
	Check pump oil level. Top up with Optileb WOM 14 if required.
	Grease manual knife gate valve spindles with Mollub Alloy Open Gear Grease
	Remove coupling guard and check condition of couplings and rubbers.