

 DESCRIPTION:
 Zone 2. Monthly Lubrication Maintenance
 FREQUENCY:
 Monthly

 LOCATION:
 ST33 Wacol STP
 STD JOB ID:
 LTS095

Grease and Oil required:	Maintenance Group
Mobil SHC624 synthetic oil	Aeration Blowers
Mobil SHC 624 Oil (oil type cannot be changed, Mob	oil is the only manufacturer of this type of oil)
Parts / Materials	
Inlet filter mesh AES Environmental (WMK10 cut media pads 1880mm x 630mm)	
References	
Procedural Steps	
Aeration Blowers No.1 to 3	
Replace inlet air filter.	
Check the oil level of each blower unit. If necessary top up with Mobil SHC 624	
Note:- Oil Level To Be In Line With Max - Level Mark On The Sight Glass	
Note:- The Marked Oil Levels On The Sight Glass Apply For Oil During Operation	

Doc Id:FOR492Active Date:15/3/2017Urban Utilities ConfidentialOwnerMatthew DellawayRevision:3Page 1 of 1

Note: Printed copies of this document should be verified for currency against the published electronic copy.