

 DESCRIPTION:
 3 Monthly Zone 3 Lubrication Maintenance
 FREQUENCY:
 3 Monthly

 LOCATION:
 ST032 Gibson Island STP
 STD JOB ID:
 LTS061

Grease and Oils Required	Maintenance Group
Castrol AP3 Grease	Thickener Tanks
Castrol EPL2 Grease	Bioreactor Mixers
Castrol ALPHA SP220	Scum Harvesters
Reference	•
Thickener Tank No's 1 & 2	
Grease each bridge wheel bearing2 with 4 sh	nots of EPL2 grease.
Grease centre column bearings with 4 shots	of EPL2 grease to each nipple.
Greasing block located on the floor directly in	front of switchboard in the centre of the bridge.
Landox Mixers No's 1- 6	
Check gearbox oil levels. Dip stick located or	n the non drive end of gear box.
Top up as required with ALPHA SP220.	
Grease motor bearings with 2 pumps of AP3	grease
	PL2 grease
Scum Harvesters Grease Conveyor drive end bearings with EF	PL2 grease
	PL2 grease
	PL2 grease

Doc Id:FOR704Active Date:14/3/2017Urban Utilities ConfidentialOwnerMatthew DellawayRevision:4Page 1 of 1

Note: Printed copies of this document should be verified for currency against the published electronic copy.