



DESCRIPTION:	Mechanical – ST018 Effluent Pump – Inspection and Service	FREQUENCY:	
LOCATION:		STANDARD JOB No.:	

SCOPE
Complete inspection and service of ST018 Effluent Pump
REQUIREMENTS
Complete inspection and service as per relevant task list below.
Where possible observe equipment in running condition before isolating. Check for unusual noise, vibration, leaks.
*Equivalents can be used but must be documented for future use. This is to avoid the use of multiple lubricants in application.
MINOR SERVICE
Inspect pump while running for coupling and bearing noise.
Ensure correct amount of water is coming from gland packing, if not adjust gland packing.
Grease pump bearings and motor. Use 6 – 8 shots of AP3 grease each
Remove coupling guard and visually check condition of coupling.
Check coupling is secure on pump and motor shafts.
Check tightness of fasteners.

Active Date: 27/06/2023 Doc Id: FOR1213 Revision 1 Tyson Craig Printed: **Printed copies of this document should be verified for currency against the published electronic copy.** Page 1 of 1 Owner

Note: