

DESCRIPTION:	Mechanical – OCU Recirculation Pumps – Inspection and Service	FREQUENCY:	
LOCATION:		STANDARD JOB No.:	

	SCOPE
	Complete inspection and service of recirculation pump.
	REQUIREMENTS
	**Equivalents may be used but must be documented for future use. This is to avoid the use of multiple lubricants in application.
	Before isolating any equipment, listen for unusual noise or vibration
	MINOR SERVICE
	Check oil level. Visually check quality of oil.
	Remove cover and visually check condition of couplings and alignment.
	Check condition of mechanical seals for leaks.
	INTERMEDIATE SERVICE
	Drain and replace oil. Use manufacturer recommended or equivalent.
	Remove cover and visually check condition of couplings and alignment.
	Check condition of mechanical seals for leaks.