

DESCRIPTION:	Clean Pump Screw Feeder Housing	FREQUENCY:	3 Months
LOCATION:	Oxley Creek DWAS Pulper Pumps	STD JOB ID:	MTS046

Instructions		
Isolate Pulper Pump.		
Remove cover from feeder box on top of pump intake.		
Clean housing and reinstate pump.		
Use CHE168 to submit any relevant information regarding the cleaning.		
Use CHE168 to submit completion of work.		

Doc Id:FOR957Active Date:22/3/2017Urban Utilities ConfidentialOwnerMatthew DellawayRevision:1Page 1 of 1

Note: Printed copies of this document should be verified for currency against the published electronic copy.